


BOCA RESEARCH, INC.

BOCA 112K DYNAMICDUO

Card Type	Modem, Fax
Chip Set	Unidentified
Maximum Modem Rate	56Kbps
Maximum Fax Rate	14.4Kbps
Data Modulation Protocol	Bell 103A/212A ITU-T V.21, V.22, V.22bis, V.22A/B, V.23, V.32, V.32bis, V.34
Fax Modulation Protocol	ITU-T V.17, V.21CH2, V.27ter, V.29, V.33
Error Correction/Compression	MNP10-EC, MNP5, V.42, V.42bis
Fax Class	Class I
Data Bus	32-bit PCI
Card Size	Three-quarter length, full-height card



CONNECTIONS			
Function	Label	Function	Label
Line in	CN1	Line out	CN2

SUPPORTED COMMAND SET
Basic AT Commands
AT, '+***', A/
A, E, H, M, O, Q, V, W, X, Y, Z
&C, &P, &T, &V, &W, &Y
Extended AT Commands
\K, \N
%C, %E, %L, %Q
S Registers
S0, S1, S2, S3, S4, S5, S6, S7, S8, S9, S10, S11, S12, S14, S16, S18, S21, S22, S23, S24, S25, S26, S27, S28, S29, S30, S31, S32, S33, S36, S37, S38, S39, S40, S41, S82, S91, S92, S95
Special Commands
+MS
Note: See MHI Help File for full command documentation.

Continued on next page . . .

Proprietary AT Command Set

AUTO-MODE DETECTION	
Type:	Configuration
Format:	AT [cmds] Nn [cmds]
Description:	Selects various options for the automatic detection and negotiation of protocols during the handshake process if the modem is communicating with a remote modem of dissimilar speed.
Command	Function
N0	Auto-mode detection disabled
í N1	Auto-mode detection enabled

COMMUNICATIONS MODE	
Type:	Configuration
Format:	AT [cmds] &Qn [cmds]
Description:	Selects communications mode options
Command	Mode
í &Q0	Asynchronous mode, serial port speed follows connect speed.
&Q5	Error correction mode
&Q6	Buffered asynchronous mode

DATA SET READY (DSR)	
Type:	Configuration
Format:	AT [cmds] &Sn [cmds]
Description:	Selects DSR options
Command	Function
&S0	DSR forced high
í &S1	DSR high only while modem is handshaking or connected

DATA TERMINAL READY (DTR)				
Type:	Configuration			
Format:	AT [cmds] &Dn [cmds]			
Description:	Selects modem response to DTR			
Note:	The action each variant of &D causes depends on the setting of &Q			
	&Q Setting	&D0	&D1	&D2
í	&Q0, &Q5, &Q6	NONE	Command 2	Command 3
	&Q1, &Q4	Command 1	Command 2	Command 3
	&Q2, &Q4	Command 3	Command 3	Command 3
	Command	Function		
í	Command 0	Modem does not respond to DTR		
	Command 1	Modem goes to command mode after DTR goes is off		
	Command 2	Modem goes to command mode and disconnects (hangs up) after DTR goes off; Auto-Answer is disabled.		
	Command 3	Modem is initialized after DTR goes off		

BOCA RESEARCH, INC.
BOCA 112K DYNAMICDUO

. . . continued from previous page

DIAL	
Type:	Immediate
Format:	AT [cmds] D<#> [cmds]
Description:	Dials telephone number according to any modifiers included in the string
Note:	Any combination of modifiers can be used to produce the desired dial functions in sequence.
Command	Function
DL	Re-dial last number
DP	Pulse dialing enabled
DS=n	Dial stored telephone number <i>n</i>
DT	Tone dialing enabled/Pulse dialing disabled
DW	Dialing resumed following dial tone detection
D,	Dialing paused for amount of time specified in S8 register
D!	Flash function initiated. Modem commanded to go off-hook for specified time before returning on-hook.
D@	Wait for Quiet Answer function enabled. Modem waits until a "quiet answer," a ring-back signal followed by silence up to the time specified in S7, is received prior to executing the rest of the dial string.
D^	Disable calling tone
D;	Modem returned to idle state after dialing. The semicolon can only be placed at the end of the dial command.

FACTORY DEFAULT PROFILE	
Type:	Configuration
Format:	AT [cmds] &F [cmds]
Description:	Sets values in active profile to values found in the default profile
Command	Function
i &F0	Restore factory configuration 0
&F1	Restore factory configuration 1

FLOW CONTROL	
Type:	Configuration
Format:	AT [cmds] &Kn [cmds]
Description:	Enables flow control options
Command	Function
&K0	Flow control disabled
i &K3	RTS/CTS flow control enabled
&K4	XON/XOFF flow control enabled
&K5	Transparent XON/XOFF flow control enabled
&K6	Both RTS/CTS and XON/XOFF flow control enabled

Continued on next page . . .

BOCA RESEARCH, INC.
BOCA 112K DYNAMICDUO

. . . continued from previous page

REPORT INFORMATION	
Type:	Immediate
Format:	AT [cmds] In [cmds]
Description:	Displays information requested
Command	Function
I0	Reports the product identification code
I1	Reports ROM checksum
I2	Tests and reports ROM checksum
I3	Reports the firmware revision level
I4	Reports OEM defined identifier string
I5	Reports country code
I6	Reports modem data pump model
I7	Reports DAA code

RTS/CTS	
Type:	Configuration
Format:	AT [cmds] &Rn [cmds]
Description:	Selects RTS/CTS options
Command	Function
í &R0	Function not supported
&R1	CTS forced high, RTS is ignored.

SPEAKER VOLUME	
Type:	Configuration
Format:	AT [cmds] Ln [cmds]
Description:	Controls speaker volume
Command	Function
L0	Low volume setting
L1	Low volume setting
í L2	Medium volume setting
L3	Highest volume setting

STORE TELEPHONE NUMBER	
Type:	Configuration
Format:	AT [cmds] &Zn=(phone # & modifiers)
Description:	Writes selected telephone numbers into the non-volatile memory at location <i>n</i>
Note:	The characters described in the D command are valid for use in the &Z command; telephone numbers and modifiers can include up to 36 characters.
Command	Function
&Z0	Stores a 34 digit dial string
&Z1	Stores a 34 digit dial string
&Z2	Stores a 34 digit dial string
&Z3	Stores a 34 digit dial string

Continued on next page . . .

Extended AT Commands

SINGLE LINE CONNECT MESSAGE	
Type:	Configuration
Format:	AT [cmds] \Vn [cmds]
Description:	Selects the operating mode the modem uses while connected
Command	Function
\V0	Connect messages are controlled by the command settings X, W, and S95
\V1	Connect messages are displayed in single line format

S(status) -REGISTERS

AUTOSYNC OPTIONS	
Type:	Register
Format	AT [cmds] S19= <i>n</i> [cmds]
Default:	0
Range:	0-255
Unit:	1 second
Description:	Sets the AutoSync options

CONNECTION FAILURE CODES	
Type:	Register
Format	AT [cmds] S86? [cmds]
Description:	Reports codes which correspond to the possible causes of a connection failure
Value	Meaning
0	Normal hang up
4	Carrier signal lost
5	No error-control detected for remote modem during feature negotiation
9	No common protocol found
12	No failure - remote modem disconnected normally
13	Remote modem failed to respond after 10 re-transmissions same message
14	Violation of negotiated protocol caused failure

DATA COMPRESSION CONTROL	
Type:	Register
Format	AT [cmds] S46 [cmds]
Default:	128
Range:	128
Description:	Controls data compression

HDLC ADDRESS	
Type:	Register
Format	AT [cmds] S20= <i>n</i> [cmds]
Default:	0
Range:	0-255
Unit:	1 second
Description:	Sets the AutoSync HDLC address

BOCA RESEARCH, INC.
BOCA 112K DYNAMICDUO

. . . continued from previous page

V.42 NEGOTIATION	
Type:	Register
Format	AT [cmds] S48 [cmds]
Default:	7
Range:	0, 7, 128
Description:	Controls V.42 negotiation