

AR-B1476  
INDUSTRIAL GRADE  
486DX/DX2/DX4 CPU CARD  
User' s Guide

Edition: 1.52  
Book Number: AR-B1476-05.0525



# Table of Contents

<b>0.</b>	<b>PREFACE</b> .....	<b>0-3</b>
0.1	COPYRIGHT NOTICE AND DISCLAIMER .....	0-3
0.2	WELCOME TO THE AR-B1476 CPU BOARD.....	0-3
0.3	BEFORE YOU USE THIS GUIDE.....	0-3
0.4	RETURNING YOUR BOARD FOR SERVICE .....	0-3
0.5	TECHNICAL SUPPORT AND USER COMMENTS .....	0-3
0.6	ORGANIZATION.....	0-4
0.7	STATIC ELECTRICITY PRECAUTIONS .....	0-4
<b>1.</b>	<b>OVERVIEW</b> .....	<b>1-1</b>
1.1	INTRODUCTION.....	1-1
1.2	PACKING LIST.....	1-2
1.3	FEATURES .....	1-2
<b>2.</b>	<b>SYSTEM CONTROLLER</b> .....	<b>2-1</b>
2.1	DMA CONTROLLER.....	2-1
2.2	KEYBOARD CONTROLLER.....	2-1
2.3	INTERRUPT CONTROLLER .....	2-2
2.3.1	I/O Port Address Map.....	2-3
2.3.2	I/O Channel Pin Assignment (Bus1) .....	2-3
2.4	REAL-TIME CLOCK AND NON-VOLATILE RAM.....	2-5
2.5	TIMER .....	2-5
2.6	SERIAL PORT.....	2-6
2.7	PARALLEL PORT .....	2-8
<b>3.</b>	<b>SETTING UP THE SYSTEM</b> .....	<b>3-1</b>
3.1	OVERVIEW .....	3-1
3.2	SYSTEM SETTING .....	3-2
3.2.1	Hard Disk (IDE) Connector (CN1).....	3-2
3.2.2	FDD Port Connector (CN2) .....	3-3
3.2.3	Parallel Port Connector (CN4) .....	3-3
3.2.4	PC/104 Connector.....	3-4
3.2.5	LED Header.....	3-6
3.2.6	Serial Port.....	3-7
3.2.7	Keyboard Connector (CN9 & J9) .....	3-9
3.2.8	External Speaker Header (J2).....	3-9
3.2.9	Power Connector (J10) .....	3-9
3.2.10	Reset Header (J8).....	3-10
3.2.11	PS/2 Mouse Connector .....	3-10
3.2.12	CPU Setting .....	3-11
3.2.13	Memory Setting .....	3-12
3.2.14	DiskOnChip Installation (SW1).....	3-13
<b>4.</b>	<b>CRT/LCD FLAT PANEL DISPLAY</b> .....	<b>4-1</b>
4.1	CRT CONNECTOR (DB1) .....	4-1
4.2	LCD FLAT PANEL DISPLAY .....	4-1
4.2.1	Inverter Board Description .....	4-2
4.2.2	LCD Connector.....	4-2
<b>5.</b>	<b>INSTALLATION</b> .....	<b>5-1</b>
5.1	OVERVIEW .....	5-1
5.2	UTILITY DISKETTE .....	5-1
5.2.1	VGA Driver .....	5-2
5.2.2	BIOS FLASH Utility .....	5-4
5.3	WATCHDOG TIMER.....	5-5
5.3.1	Watchdog Timer Setting.....	5-5
5.3.2	Watchdog Timer Enabled.....	5-6
5.3.3	Watchdog Timer Trigger.....	5-6
5.3.4	Watchdog Timer Disabled.....	5-6
<b>6.</b>	<b>BIOS CONSOLE</b> .....	<b>6-1</b>
6.1	BIOS SETUP OVERVIEW .....	6-1
6.2	STANDARD CMOS SETUP .....	6-2
6.3	ADVANCED CMOS SETUP.....	6-3
6.4	ADVANCED CHIPSET SETUP.....	6-6
6.5	PERIPHERAL SETUP.....	6-7
6.6	AUTO-DETECT HARD DISKS .....	6-7
6.7	PASSWORD SETTING.....	6-8
6.7.1	Setting Password .....	6-8
6.7.2	Password Checking.....	6-8

6.8	LOAD DEFAULT SETTING.....	6-8
6.8.1	Auto Configuration with Optimal Setting .....	6-8
6.8.2	Auto Configuration with Fail Safe Setting.....	6-8
6.9	BIOS EXIT.....	6-9
6.9.1	Save Settings and Exit .....	6-9
6.9.2	Exit Without Saving .....	6-9
6.10	BIOS UPDATE .....	6-9
<b>7.</b>	<b>SPECIFICATIONS .....</b>	<b>7-1</b>
<b>8.</b>	<b>PLACEMENT &amp; DIMENSIONS.....</b>	<b>8-1</b>
8.1	PLACEMENT .....	8-1
8.2	DIMENSIONS.....	8-2
<b>9.</b>	<b>PROGRAMMING RS-485 &amp; INDEX.....</b>	<b>9-1</b>
9.1	PROGRAMMING RS-485 .....	9-1
9.2	INDEX .....	9-3

## 0.PREFACE

### 0.1 COPYRIGHT NOTICE AND DISCLAIMER

**June 1998**

This document is copyrighted, 1998, by Acrosser Technology Co., Ltd. All rights are reserved. No part of this manual may be reproduced, copied, transcribed, stored in a retrieval system, or translated into any language or computer language in any form or by any means, such as electronic, mechanical, magnetic, optical, chemical, manual or other means without the prior written permission of original manufacturer.

Acrosser Technology assumes no responsibility or warranty with respect to the contents in this manual and specifically disclaims any implied warranty of merchantability or fitness for any particular purpose. Furthermore, Acrosser Technology reserves the right to make improvements to the products described in this manual at any times without notice. Such revision will be posted on the Internet ([WWW.ACROSSER.COM](http://WWW.ACROSSER.COM)) as soon as possible. Possession, use, or copying of the software described in this publication is authorized only pursuant to a valid written license from Acrosser or an authorized sub licensor.

### ACKNOWLEDGEMENTS

Acrosser, ALI, AMI, HMC, IBM PC/AT, Windows 3.1, Windows 95, Windows NT, AMD, Cyrix, Intel...are registered trademarks.

All other trademarks and registered trademarks are the property of their respective holders.

This document was produced with Adobe Acrobat 3.01.

### 0.2 WELCOME TO THE AR-B1476 CPU BOARD

This guide introduces the Acrosser AR-B1476 CPU board.

The information provided in this manual describes this card's functions and features. It also helps you start, set up and operate your AR-B1476. General system information can also be found in this publication.

### 0.3 BEFORE YOU USE THIS GUIDE

Please refer to the Chapter 3, "Setting Up the System" in this guide, if you have not already installed this AR-B1476. Check the packing list before you install and make sure the accessories are completely included.

The AR-B1476 diskette provides the newest information regarding the CPU card. **Please refer to the README.DOC file of the enclosed utility diskette.** It contains the modification and hardware & software information, and it has updated to products functions that may not be mentioned here.

### 0.4 RETURNING YOUR BOARD FOR SERVICE

If your board requires any services, contact the distributor or sales representative from whom you purchased the product for service information. If you need to ship your board to us for service, be sure it is packed in a protective carton. We recommend that you keep the original shipping container for this purpose.

You can help assure efficient servicing for your product by following these guidelines:

1. Include your name, address, telephone, facsimile number and E-mail.
2. A description of the system configuration and/or software at the time is malfunction.
3. A brief description of the problem occurred.

### 0.5 TECHNICAL SUPPORT AND USER COMMENTS

User's comments are always welcome as they assist us in improving the quality of our products and the readability of our publications. They create a very important part of input used for product enhancement and revision.

We may use and distribute any of the information you provide in any way appropriate without incurring any obligation. You may, of course, continue to use the information you provide.

If you have any suggestions for improving particular sections or if you find any errors on it, please send your comments to Acrosser Technology Co., Ltd. or your local sales representative and indicate the manual title and book number.

Internet electronic mail to: [webmaster@acrosser.com](mailto:webmaster@acrosser.com)

## 0.6 ORGANIZATION

This information for users covers the following topics (see the Table of Contents for a detailed listing):

- Chapter 1, "Overview", provides an overview of the system features and packing list.
- Chapter 2, "System Controller" describes the major structure.
- Chapter 3, "Setting Up the System", describes how to adjust the jumper, and the connectors setting.
- Chapter 4, "CRT/LCD Flat Panel Display", describes the configuration and installation procedure using the LCD and CRT display.
- Chapter 5, "Installation", describes setup procedures including information on the utility diskette.
- Chapter 6, "BIOS Console", providing the BIOS options setting.
- Chapter 7, Specifications
- Chapter 8, Placement & Dimensions
- Chapter 9, Programming RS-485 & Index

## 0.7 STATIC ELECTRICITY PRECAUTIONS

Before removing the board from its anti-static bag, read this section about static electricity precautions.

Static electricity is a constant danger to computer systems. The charge that can build up in your body may be more than sufficient to damage integrated circuits on any PC board. It is, therefore, important to observe basic precautions whenever you use or handle computer components. Although areas with humid climates are much less prone to static build-up, it is always best to safeguard against accidents may result in expensive repairs. The following measures should generally be sufficient to protect your equipment from static discharge:

- Touch a grounded metal object to discharge the static electricity in your body (or ideally, wear a grounded wrist strap).
- When unpacking and handling the board or other system component, place all materials on an antic static surface.
- Be careful not to touch the components on the board, especially the "golden finger" connectors on the bottom of every board.

# 1. OVERVIEW

This chapter provides an overview of your system features and capabilities. The following topics are covered:

- Introduction
- Packing List
- Features

## 1.1 INTRODUCTION

The AR-B1476 is a half size industrial grade CPU card that has been designed to withstand continuous operation in harsh environments. The AR-B1476 supports on-board memory 8MB, and extends to 72MB DRAM for using one 72-pin SIMM.

The 8 layers PCB CPU card is equipped with an IDE HDD interface, a floppy disk drive adapter, 1 parallel port, 2 serial ports and a watchdog timer. Its dimensions are as compact as 122mmX185mm. Its highly condensed features make it an ideal cost/performance solution for high-end commercial and industrial applications where CPU speed and mean time between failure is critical.

The AR-B1476 provides 2 bus interfaces, ISA bus and PC/104 compatible expansion bus. Based on the PC/104 expansion bus, you could easily install thousands of PC/104 modules from hundreds of vendors around the world. You could also directly connect the power supply to the AR-B1476 on-board power connector in standalone applications.

A watchdog timer has a software programmable time-out interval, is also provided on this CPU card. It ensures that the system does not hang-up if a program cannot execute normally.

The AR-B1476 is implemented with M1487 and M1489 chipsets incorporate a memory controller, parity generation and checking, two 8237 DMA controllers, two 8259 interrupt controllers, one 8254 timer/counter, an address buffer and a data buffer.

A super I/O chip (SMC37C669) is embedded in the AR-B1476 card. It combines functions of a floppy disk drive adapter, a hard disk drive (IDE) adapter, two serial (with 16C550 UART) adapters and 1 parallel adapter. The I/O port configurations can be done by setting the BIOS setup program.

As an UART, the chip supports serial to parallel conversion on data characters received from a peripheral device or a MODEM, and parallel to serial conversion on data characters received from the CPU. The UART includes a programmable baud rate generator, complete MODEM control capability and a processor interrupt system. As a parallel port, the SMC37C669 provides the user with a fully bi-directional parallel centronics-type printer interface.

## 1.2 PACKING LIST

The accessories are included with the system. Before you begin installing your AR-B1476 board, take a moment to make sure that the following items have been included inside the AR-B1476 package.

- This user's guide
- 1 AR-B1476 CPU card
- 1 Hard disk drive interface cable
- 1 Floppy disk drive interface cable
- 1 Parallel port interface cable & 1 RS-232C interface cable mounted on one bracket
- 1 Software utility CD.

## 1.3 FEATURES

The system provides a number of special features that enhance its reliability, ensure its availability, and improve its expansion capabilities, as well as its hardware structure.

- All In One designed 486DX/DX2/DX4 CPU card.
- Supports 3.45V/5V CPU with voltage regulator.
- Supports ISA bus and PC/104 bus.
- Supports 512KB cache on board.
- Supports on-board 8MB and extends one 72-pin DRAM SIMM up to 72MB DRAM on board.
- Supports shadow memory and EMS.
- Supports D.O.C. up to 72MB.
- Legal AMI BIOS.
- IDE hard disk drive interface.
- Floppy disk drive interface.
- Bi-direction parallel interface.
- 2 serial ports with 16C550 UART.
- Programmable watchdog timer.
- On-board built-in buzzer.
- 8 layers PCB.



## 2. SYSTEM CONTROLLER

This chapter describes the major structure of the AR-B1476 CPU board. The following topics are covered:

- DMA Controller
- Keyboard Controller
- Interrupt Controller
- Real-Time Clock and Non-Volatile RAM
- Timer
- Serial Port
- Parallel Port

### 2.1 DMA CONTROLLER

The equivalent of two 8237A DMA controllers are implemented in the AR-B1476 board. Each controller is a four-channel DMA device that will generate the memory addresses and control signals necessary to transfer information directly between a peripheral device and memory. This allows high speed information transfer with less CPU intervention. The two DMA controllers are internally cascaded to provide four DMA channels for transfers to 8-bit peripherals (DMA1) and three channels for transfers to 16-bit peripherals (DMA2). DMA2 channel 0 provides the cascade interconnection between the two DMA devices, thereby maintaining IBM PC/AT compatibility.

Following is the system information of DMA channels:

DMA Controller 1	DMA Controller 2
Channel 0: Spare	Channel 4: Cascade for controller 1
Channel 1: IBM SDLC	Channel 5: Spare
Channel 2: Diskette adapter	Channel 6: Spare
Channel 3: Spare	Channel 7: Spare

**Table 2-1 DMA Channel Controller**

### 2.2 KEYBOARD CONTROLLER

The 8042 processor is programmed to support the keyboard serial interface. The keyboard controller receives serial data from the keyboard, checks its parity, translates scan codes, and presents it to the system as a byte data in its output buffer. The controller can interrupt the system when data is placed in its output buffer, or wait for the system to poll its status register to determine when data is available.

Data can be written to the keyboard by writing data to the output buffer of the keyboard controller.

Each byte of data is sent to the keyboard controller in series with an odd parity bit automatically inserted. The keyboard controller is required to acknowledge all data transmissions. Therefore, another byte of data will not be sent to keyboard controller until acknowledgment is received for the previous byte sent. The "output buffer full" interruption may be used for both send and receive routines.

## 2.3 INTERRUPT CONTROLLER

The equivalent of two 8259 Programmable Interrupt Controllers (PIC) are included on the AR-B1476 board. They accept requests from peripherals, resolve priorities on pending interrupts in service, issue interrupt requests to the CPU, and provide vectors which are used as acceptance indices by the CPU to determine which interrupt service routine to execute.

Following is the system information of interrupt levels:

Interrupt Level	Description
NMI	Parity check
CTRL1	CTRL2
IRQ 0	System timer interrupt from timer 8254
IRQ 1	Keyboard output buffer full
IRQ 2	
	IRQ8 : Real time clock
	IRQ9 : Rerouting to INT 0Ah from hardware IRQ2
	IRQ10 : spare
	IRQ11 : spare
	IRQ12 : spare (PS/2 mouse)
	IRQ13 : Math. coprocessor
	IRQ14 : Hard disk adapter
	IRQ15 : spare (Watchdog Timer)
IRQ 3	Serial port 2
IRQ 4	Serial port 1
IRQ 5	Parallel port 2
IRQ 6	Floppy disk adapter
IRQ 7	Parallel port 1

Figure 2-1 Interrupt Controller

### 2.3.1 I/O Port Address Map

Hex Range	Device
000-01F	DMA controller 1
020-021	Interrupt controller 1
022-023	ALI M1489/M1487
040-04F	Timer 1
050-05F	Timer 2
060-06F	8042 keyboard/controller
070-071	Real-time clock (RTC), non-maskable interrupt (NMI)
080-09F	DMA page registers
0A0-0A1	Interrupt controller 2
0C0-0DF	DMA controller 2
0F0	Clear Math Co-processor
0F1	Reset Math Co-processor
0F8-0FF	Math Co-processor
170-178	Fixed disk 1
1F0-1F8	Fixed disk 0
201	Game port
208-20A	EMS register 0
218-21A	EMS register 1
278-27F	Parallel printer port 2 (LPT 2)
2E8-2EF	Serial port 4 (COM 4)
2F8-2FF	Serial port 2 (COM 2)
300-31F	Prototype card/streaming type adapter
320-33F	LAN adapter
378-37F	Parallel printer port 1 (LPT 1)
380-38F	SDLC, bisynchronous
3A0-3AF	Bisynchronous
3B0-3BF	Monochrome display and printer port 3 (LPT 3)
3C0-3CF	EGA/VGA adapter
3D0-3DF	Color/graphics monitor adapter
3E8-3EF	Serial port 3 (COM 3)
3F0-3F7	Diskette controller
3F8-3FF	Serial port 1 (COM 1)

Table 2-2 I/O Port Address Map

### 2.3.2 I/O Channel Pin Assignment (Bus1)

I/O Pin	Signal Name	Input/Output	I/O Pin	Signal Name	Input/Output
A1	-IOCHCK	Input	B1	GND	Ground
A2	SD7	Input/Output	B2	RSTDRV	Output
A3	SD6	Input/Output	B3	+5V	Power
A4	SD5	Input/Output	B4	IRQ9	Input
A5	SD4	Input/Output	B5	-5V	Power
A6	SD3	Input/Output	B6	DRQ2	Input
A7	SD2	Input/Output	B7	-12V	Power
A8	SD1	Input/Output	B8	-ZWS	Input
A9	SD0	Input/Output	B9	+12V	Power
A10	-IOCHRDY	Input	B10	GND	Ground
A11	AEN	Output	B11	-SMEMW	Output
A12	SA19	Input/Output	B12	-SMEMR	Output
A13	SA18	Input/Output	B13	-IOW	Input/Output
A14	SA17	Input/Output	B14	-IOR	Input/Output
A15	SA16	Input/Output	B15	-DACK3	Output
A16	SA15	Input/Output	B16	DRQ3	Input

I/O Pin	Signal Name	Input/Output	I/O Pin	Signal Name	Input/Output
A17	SA14	Input/Output	B17	-DACK1	Output
A18	SA13	Input/Output	B18	DRQ1	Input
A19	SA12	Input/Output	B19	-REFRESH	Input/Output
A20	SA11	Input/Output	B20	BUSCLK	Output
A21	SA10	Input/Output	B21	IRQ7	Input
A22	SA9	Input/Output	B22	IRQ6	Input
A23	SA8	Input/Output	B23	IRQ5	Input
A24	SA7	Input/Output	B24	IRQ4	Input
A25	SA6	Input/Output	B25	IRQ3	Input
A26	SA5	Input/Output	B26	-DACK2	Output
A27	SA4	Input/Output	B27	TC	Output
A28	SA3	Input/Output	B28	BALE	Output
A29	SA2	Input/Output	B29	+5V	Power
A30	SA1	Input/Output	B30	OSC	Output
A31	SA0	Input/Output	B31	GND	Ground

Table 2-3 I/O Channel Pin Assignments

I/O Pin	Signal Name	Input/Output	I/O Pin	Signal Name	Input/Output
C1	-SBHE	Input/Output	D1	-MEMCS16	Input
C2	LA23	Input/Output	D2	-IOCS16	Input
C3	LA22	Input/Output	D3	IRQ10	Input
C4	LA21	Input/Output	D4	IRQ11	Input
C5	LA20	Input/Output	D5	IRQ12	Input
C6	LA19	Input/Output	D6	IRQ15	Input
C7	LA18	Input/Output	D7	IRQ14	Input
C8	LA17	Input/Output	D8	-DACK0	Output
C9	-MRD16	Input/Output	D9	DRQ0	Input
C10	-MWR16	Input/Output	D10	-DACK5	Output
C11	SD8	Input/Output	D11	DRQ5	Input
C12	SD9	Input/Output	D12	-DACK6	Output
C13	SD10	Input/Output	D13	DRQ6	Input
C14	SD11	Input/Output	D14	-DACK7	Output
C15	SD12	Input/Output	D15	DRQ7	Input
C16	SD13	Input/Output	D16	+5V	Power
C17	SD14	Input/Output	D17	-MASTER	Input
C18	SD15	Input/Output	D18	GND	Ground

Table 2-4 I/O Channel Pin Assignments

## 2.4 REAL-TIME CLOCK AND NON-VOLATILE RAM

The AR-B1476 contains a real-time clock compartment that maintains the date and time in addition to storing configuration information about the computer system. It contains 14 bytes of clock and control registers and 114 bytes of general purpose RAM. Because of the use of CMOS technology, it consumes very little power and can be maintained for long period of time using an internal Lithium battery. The contents of each byte in the CMOS RAM are listed as follows:

Address	Description
00	Seconds
01	Second alarm
02	Minutes
03	Minute alarm
04	Hours
05	Hour alarm
06	Day of week
07	Date of month
08	Month
09	Year
0A	Status register A
0B	Status register B
0C	Status register C
0D	Status register D
0E	Diagnostic status byte
0F	Shutdown status byte
10	Diskette drive type byte, drive A and B
11	Fixed disk type byte, drive C
12	Fixed disk type byte, drive D
13	Reserved
14	Equipment byte
15	Low base memory byte
16	High base memory byte
17	Low expansion memory byte
18	High expansion memory byte
19-2D	Reserved
2E-2F	2-byte CMOS checksum
30	Low actual expansion memory byte
31	High actual expansion memory byte
32	Date century byte
33	Information flags (set during power on)
34-7F	Reserved for system BIOS

Table 2-5 Real-Time Clock & Non-Volatile RAM

## 2.5 TIMER

The AR-B1476 provides three programmable timers, each with a timing frequency of 1.19 MHz.

Timer 0 The output of this timer is tied to interrupt request 0. (IRQ 0)

Timer 1 This timer is used to trigger memory refresh cycles.

Timer 2 This timer provides the speaker tone.  
Application programs can load different counts into this timer to generate various sound frequencies.

## 2.6 SERIAL PORT

The ACEs (Asynchronous Communication Elements ACE1 to ACE4) are used to convert parallel data to a serial format on the transmit side and convert serial data to parallel on the receiver side. The serial format, in order of transmission and reception, is a start bit, followed by five to eight data bits, a parity bit (if programmed) and one, one and half (five-bit format only) or two stop bits. The ACEs are capable of handling divisors of 1 to 65535, and produce a 16x clock for driving the internal transmitter logic.

Provisions are also included to use this 16x clock to drive the receiver logic. Also included in the ACE is a completed MODEM control capability, and a processor interrupt system that may be software tailored to the computing time required to handle the communications link.

The following table is a summary of each ACE accessible register

DLAB	Port Address	Register
0	base + 0	Receiver buffer (read)
		Transmitter holding register (write)
0	base + 1	Interrupt enable
X	base + 2	Interrupt identification (read only)
X	base + 3	Line control
X	base + 4	MODEM control
X	base + 5	Line status
X	base + 6	MODEM status
X	base + 7	Scratched register
1	base + 0	Divisor latch (least significant byte)
1	base + 1	Divisor latch (most significant byte)

Table 2-6 ACE Accessible Registers

### (1) Receiver Buffer Register (RBR)

Bit 0-7: Received data byte (Read Only)

### (2) Transmitter Holding Register (THR)

Bit 0-7: Transmitter holding data byte (Write Only)

### (3) Interrupt Enable Register (IER)

Bit 0: Enable Received Data Available Interrupt (ERBFI)

Bit 1: Enable Transmitter Holding Empty Interrupt (ETBEI)

Bit 2: Enable Receiver Line Status Interrupt (ELSI)

Bit 3: Enable MODEM Status Interrupt (EDSSI)

Bit 4: Must be 0

Bit 5: Must be 0

Bit 6: Must be 0

Bit 7: Must be 0

### (4) Interrupt Identification Register (IIR)

Bit 0: "0" if Interrupt Pending

Bit 1: Interrupt ID Bit 0

Bit 2: Interrupt ID Bit 1

Bit 3: Must be 0

Bit 4: Must be 0

Bit 5: Must be 0

Bit 6: Must be 0

Bit 7: Must be 0

**(5) Line Control Register (LCR)**

Bit 0: Word Length Select Bit 0 (WLS0)

Bit 1: Word Length Select Bit 1 (WLS1)

WLS1	WLS0	Word Length
0	0	5 Bits
0	1	6 Bits
1	0	7 Bits
1	1	8 Bits

Bit 2: Number of Stop Bit (STB)

Bit 3: Parity Enable (PEN)

Bit 4: Even Parity Select (EPS)

Bit 5: Stick Parity

Bit 6: Set Break

Bit 7: Divisor Latch Access Bit (DLAB)

**(6) MODEM Control Register (MCR)**

Bit 0: Data Terminal Ready (DTR)

Bit 1: Request to Send (RTS)

Bit 2: Out 1 (OUT 1)

Bit 3: Out 2 (OUT 2)

Bit 4: Loop

Bit 5: Must be 0

Bit 6: Must be 0

Bit 7: Must be 0

**(7) Line Status Register (LSR)**

Bit 0: Data Ready (DR)

Bit 1: Overrun Error (OR)

Bit 2: Parity Error (PE)

Bit 3: Framing Error (FE)

Bit 4: Break Interrupt (BI)

Bit 5: Transmitter Holding Register Empty (THRE)

Bit 6: Transmitter Shift Register Empty (TSRE)

Bit 7: Must be 0

**(8) MODEM Status Register (MSR)**

Bit 0: Delta Clear to Send (DCTS)

Bit 1: Delta Data Set Ready (DDSR)

Bit 2: Training Edge Ring Indicator (TERI)

Bit 3: Delta Receive Line Signal Detect (DSLSD)

Bit 4: Clear to Send (CTS)

Bit 5: Data Set Ready (DSR)

Bit 6: Ring Indicator (RI)

Bit 7: Received Line Signal Detect (RSLD)

**(9) Divisor Latch (LS, MS)**

	<b>LS</b>	<b>MS</b>
Bit 0:	Bit 0	Bit 8
Bit 1:	Bit 1	Bit 9
Bit 2:	Bit 2	Bit 10
Bit 3:	Bit 3	Bit 11
Bit 4:	Bit 4	Bit 12
Bit 5:	Bit 5	Bit 13
Bit 6:	Bit 6	Bit 14
Bit 7:	Bit 7	Bit 15

<b>Desired Baud Rate</b>	<b>Divisor Used to Generate 16x Clock</b>
300	384
600	192
1200	96
1800	64
2400	48
3600	32
4800	24
9600	12
14400	8
19200	6
28800	4
38400	3
57600	2
115200	1

Table 2-7 Serial Port Divisor Latch

**2.7 PARALLEL PORT****(1) Register Address**

<b>Port Address</b>	<b>Read/Write</b>	<b>Register</b>
base + 0	Write	Output data
base + 0	Read	Input data
base + 1	Read	Printer status buffer
base + 2	Write	Printer control latch

Table 2-8 Registers' Address

**(2) Printer Interface Logic**

The parallel portion of the SMC37C669 makes the attachment of various devices that accept eight bits of parallel data at standard TTL level.


**(3) Data Swapper**

The system microprocessor can read the contents of the printer's Data Latch through the Data Swapper by reading the Data Swapper address.



**(4) Printer Status Buffer**

The system microprocessor can read the printer status by reading the address of the Printer Status Buffer. The bit definitions are described as follows:



**Figure 2-2 Printer Status Buffer**

**NOTE:** X presents not used.

Bit 7: This signal may become active during data entry, when the printer is off-line during printing, or when the print head is changing position or in an error state. When Bit 7 is active, the printer is busy and cannot accept data.

Bit 6: This bit represents the current state of the printer's ACK signal. A0 means the printer has received the character and is ready to accept another. Normally, this signal will be active for approximately 5 microseconds before receiving a BUSY message stops.

Bit 5: A1 means the printer has detected the end of the paper.

Bit 4: A1 means the printer is selected.

Bit 3: A0 means the printer has encountered an error condition.

### (5) Printer Control Latch & Printer Control Swapper

The system microprocessor can read the contents of the printer control latch by reading the address of printer control swapper. Bit definitions are as follows:




Figure 2-3 Bit's Definition

**NOTE:** X presents not used.

Bit 5: Direction control bit. When logic 1, the output buffers in the parallel port are disabled allowing data driven from external sources to be read; when logic 0, they work as a printer port. This bit is writing only.

Bit 4: A1 in this position allows an interrupt to occur when ACK changes from low state to high state.

Bit 3: A1 in this bit position selects the printer.

Bit 2: A0 starts the printer (50 microseconds pulse, minimum).

Bit 1: A1 causes the printer to line-feed after a line is printed.

Bit 0: A0.5 microsecond minimum highly active pulse clocks data into the printer. Valid data must be present for a minimum of 0.5 microseconds before and after the strobe pulse.

### 3. SETTING UP THE SYSTEM

This section describes pin assignments for system's external connectors and the jumpers setting.

- Overview
- System Setting

#### 3.1 OVERVIEW

The AR-B1476 is a half size industrial grade CPU card that has been designed to withstand continuous operation in harsh environments. This section provides hardware's jumpers setting, the connectors' locations, and the pin assignment.




Figure 3-1 External System Location

### 3.2 SYSTEM SETTING

Jumper pins allow you to set specific system parameters. Set them by changing the pin location of jumper blocks. (A jumper block is a small plastic-encased conductor [shorting plug] that slips over the pins.) To change a jumper setting, remove the jumper from its current location with your fingers or small needle-nosed pliers. Place the jumper over the two pins designated for the desired setting. Press the jumper evenly onto the pins. Be careful not to bend the pins.

We will show the locations of the AR-B1476 jumper pins, and the factory-default setting.

**CAUTION:** Do not touch any electronic component unless you are safely grounded. Wear a grounded wrist strap or touch an exposed metal part of the system unit chassis. The static discharges from your fingers can permanently damage electronic components.

#### 3.2.1 Hard Disk (IDE) Connector (CN1)

A 40-pin header type connector (CN1) is provided to interface with up to two embedded hard disk drives (IDE AT bus). This interface, through a 40-pin cable, allows the user to connect up to two drives in a "daisy chain" fashion. To enable or disable the hard disk controller, please use the BIOS Setup program. The following table illustrates the pin assignments of the hard disk drive's 40-pin connector.




Figure 3-2 CN1: Hard Disk (IDE) Connector

Pin	Signal	Pin	Signal
1	-RESET	2	GROUND
3	DATA 7	4	DATA 8
5	DATA 6	6	DATA 9
7	DATA 5	8	DATA 10
9	DATA 4	10	DATA 11
11	DATA 3	12	DATA 12
13	DATA 2	14	DATA 13
15	DATA 1	16	DATA 14
17	DATA 0	18	DATA 15
19	GROUND	20	NOT USED
21	NC	22	GROUND
23	-IOW A	24	GROUND
25	-IOR A	26	GROUND
27	-CHRDY A	28	NOT USED
29	NC	30	GROUND
31	-IRQ A	32	-IO16
33	SA 1	34	NOT USED
35	SA 0	36	SA 2
37	CS 0	38	CS 1
39	HD LED A	40	GROUND

Table 3-1 HDD Pin Assignment

### 3.2.2 FDD Port Connector (CN2)

The AR-B1476 provides a 34-pin header type connector for supporting up to two floppy disk drives.

To enable or disable the floppy disk controller, please use the BIOS Setup program.



Figure 3-3 CN2: FDD Port connector

Pin	Signal	Pin	Signal
1-33(odd)	GROUND	18	-DIRECTION
2	DRVEN 0	20	-STEP OUTPUT PULSE
4	NOT USED	22	-WRITE DATA
6	DRVEN 1	24	-WRITE GATE
8	-INDEX	26	-TRACK 0
10	-MOTOR ENABLE 0	28	-WRITE PROTECT
12	-DRIVE SELECT 1	30	-READ DATA
14	-DRIVE SELECT 0	32	-SIDE 1 SELECT
16	-MOTOR ENABLE 1	34	DISK CHANGE

Table 3-2 FDD Pin Assignment

### 3.2.3 Parallel Port Connector (CN4)

To use the parallel port, an adapter cable has to be connected to the CN4 (26-pin header type) connector. This adapter cable is mounted on a bracket and is included in your AR-B1476 package. The connector for the parallel port is a 25 pin D-type female connector.




Figure 3-4 CN4: Parallel Port Connector

CN4	DB-25	Signal	CN4	DB-25	Signal
1	1	-Strobe	2	14	-Auto Form Feed
3	2	Data 0	4	15	-Error
5	3	Data 1	6	16	-Initialize
7	4	Data 2	8	17	-Printer Select In
9	5	Data 3	10	18	Ground
11	6	Data 4	12	19	Ground
13	7	Data 5	14	20	Ground
15	8	Data 6	16	21	Ground
17	9	Data 7	18	22	Ground
19	10	-Acknowledge	20	23	Ground
21	11	Busy	22	24	Ground
23	12	Paper	24	25	Ground
25	13	Printer Select	26	--	No Used

Table 3-3 Parallel Port Pin Assignment

### 3.2.4 PC/104 Connector

#### (1) 64 Pin PC/104 Connector Bus A & B (CN7)




Figure 3-5 CN7: 64 Pin PC/104 Connector Bus A & B




Figure 3-6 CN7: 64-Pin PC/104 Connector Bus A & B

#### (2) 40 Pin PC/104 Connector Bus C & D (CN8)




Figure 3-7 CN8: 40 Pin PC/104 Connector Bus C & D




Figure 3-8 CN8: 40-Pin PC/104 Connector Bus C & D

**(3) I/O Channel Signal Description**

<b>Name</b>	<b>Description</b>
<b>BUSCLK</b> [Output]	The BUSCLK signal of the I/O channel is asynchronous to the CPU clock.
<b>RSTDRV</b> [Output]	This signal goes high during power-up, low line-voltage or hardware reset
<b>SA0 - SA19</b> [Input / Output]	The System Address lines run from bit 0 to 19. They are latched onto the falling edge of "BALE"
<b>LA17 - LA23</b> [Input/Output]	The Unlatched Address line run from bit 17 to 23
<b>SD0 - SD15</b> [Input/Output]	System Data bit 0 to 15
<b>BALE</b> [Output]	The Buffered Address Latch Enable is used to latch SA0 - SA19 onto the falling edge. This signal is forced high during DMA cycles
<b>-IOCHCK</b> [Input]	The I/O Channel Check is an active low signal which indicates that a parity error exist on the I/O board
<b>IOCHRDY</b> [Input, Open collector]	This signal lengthens the I/O, or memory read/write cycle, and should be held low with a valid address
<b>IRQ 3-7, 9-12, 14, 15</b> [Input]	The Interrupt Request signal indicates I/O service request attention. They are prioritized in the following sequence : (Highest) IRQ 9, 10, 11, 12, 13, 15, 3, 4, 5, 6, 7 (Lowest)
<b>-IOR</b> [Input/Output]	The I/O Read signal is an active low signal which instructs the I/O device to drive its data onto the data bus
<b>-IOW</b> [Input/Output]	The I/O write signal is an active low signal which instructs the I/O device to read data from the data bus
<b>-SMEMR</b> [Output]	The System Memory Read is low while any of the low 1 mega bytes of memory are being used
<b>-MEMR</b> [Input/Output]	The Memory Read signal is low while any memory location is being read
<b>-SMEMW</b> [Output]	The System Memory Write is low while any of the low 1 mega bytes of memory is being written
<b>-MEMW</b> [Input/Output]	The Memory Write signal is low while any memory location is being written
<b>DRQ 0-3, 5-7</b> [Input]	DMA Request channels 0 to 3 are for 8-bit data transfers. DMA Request channels 5 to 7 are for 16-bit data transfers. DMA request should be held high until the corresponding DMA has been completed. DMA request priority is in the following sequence:(Highest) DRQ 0, 1, 2, 3, 5, 6, 7 (Lowest)
<b>-DAACK 0-3, 5-7</b> [Output]	The DMA Acknowledges 0 to 3, 5 to 7 are the corresponding acknowledge signals for DRQ 0 to 3 and 5 to 7
<b>AEN</b> [output]	The DMA Address Enable is high when the DMA controller is driving the address bus. It is low when the CPU is driving the address bus
<b>-REFRESH</b> [Input/Output]	This signal is used to indicate a memory refresh cycle and can be driven by the microprocessor on the I/O channel
<b>TC</b> [Output]	Terminal Count provides a pulse when the terminal count for any DMA channel is reached
<b>SBHE</b> [Input/Output]	The System Bus High Enable indicates the high byte SD8 - SD15 on the data bus

Name	Description
<b>-MASTER</b> [Input]	The MASTER is the signal from the I/O processor which gains control as the master and should be held low for a maximum of 15 microseconds or system memory may be lost due to the lack of refresh
<b>-MEMCS16</b> [Input, Open collector]	The Memory Chip Select 16 indicates that the present data transfer is a 1-wait state, 16-bit data memory operation
<b>-IOCS16</b> [Input, Open collector]	The I/O Chip Select 16 indicates that the present data transfer is a 1-wait state, 16-bit data I/O operation
<b>OSC</b> [Output]	The Oscillator is a 14.31818 MHz signal used for the color graphic card
<b>-ZWS</b> [Input, Open collector]	The Zero Wait State indicates to the microprocessor that the present bus cycle can be completed without inserting additional wait cycle

Table 3-4 I/O Channel Signal's Description

### 3.2.5 LED Header

#### (1) External Power LED & Keyboard Lock Header (J6)




Figure 3-9 J6: Power LED &amp; Keyboard Lock Header

#### (2) HDD LED Header (J3)




Figure 3-10 J3: HDD LED Header

#### (3) Watchdog LED Header (J1)




Figure 3-11 J1: Watchdog LED Header



### 3.2.6 Serial Port

#### (1) RS-232/RS-485 Select (SW1, JP4 & JP9)

JP4 selects COM B port, and adjusts the CN5 connector is RS-485 or RS-232C. JP9 selects COM A port for using DB2 for RS-232C or connects External RS-485. SW1 adjusts the onboard RS-485.

##### (A) COM-A RS-485 Adapter Select (JP9)




Figure 3-12 JP9: COM-A RS-485 Adapter Select

##### (B) COM-B RS-485 Adapter Select (JP4)




Figure 3-13 JP4: COM-B RS-485 Adapter Select

##### (C) COM-B RS-232/RS-485 Select (SW1)




Figure 3-14 SW1: COM-B RS-232/RS-485 Select

#### (2) RS-485 Terminator Select (JP2)





Figure 3-15 JP2: RS-485 Terminator Select

**(3) RS-485 Connector (J4)**

J4 is onboard RS-485 header, J4 pin assignments are as follows:



J4 (COM B)

Figure 3-16 J4: RS-485 Connector

**(4) RS-232 Connector (CN5 & DB2)**

There are two serial ports with EIA RS-232C interface on the AR-B1476. COM A uses one onboard D-type 9 pin male connector (DB2) and COM B uses one 10 pin header (CN5) which are located at the right side of the card. To configure these two serial ports, use the BIOS Setup program, and adjust the jumpers on JP4 and JP9.

The pin assignments of the DB2 and CN5 for serial port A & B are as follows:




Figure 3-17 DB2 & CN5: RS-232 Connector

CN5	DB2	Signal	CN5	DB2	Signal
1	1	-DCD	2	6	-DSR
3	2	RXD	4	7	-RTS
5	3	TXD	6	8	-CTS
7	4	-DTR	8	9	-RI
9	5	GND	10	--	Not Used

Table 3-5 RS-232 Connector Pin Assignment

### 3.2.7 Keyboard Connector (CN9 & J9)

CN9 is a Mini-DIN 6-pin connector. This keyboard connector is a PS/2 type keyboard connector. This connector is also for a standard IBM-compatible keyboard with the keyboard adapter cable. J9 provides another way of connecting a keyboard to the AR-B1476.




Figure 3-18 CN9: Keyboard Connector




Figure 3-19 J9: AUX. Keyboard Connector

### 3.2.8 External Speaker Header (J2)

Besides the onboard buzzer, you can use an external speaker by connecting to the J2 header.




Figure 3-20 J2: Speaker Header

### 3.2.9 Power Connector (J10)

J10 is an 8-pin power connector. You can directly connect the power supply to the onboard power connector for stand-alone applications.




Figure 3-21 J10: Power Connector

### 3.2.10 Reset Header (J8)

J8 is used to connect to an external reset switch. Shorting these two pins will reset the system.




Figure 3-22 J8: Reset Header

### 3.2.11 PS/2 Mouse Connector

#### (1) PS/2 Mouse IRQ12 Setting (JP8)

The default of <Enabled> allows the system detecting a PS/2 mouse on boot. If detected, IRQ12 will be used for the PS/2 mouse. IRQ12 will be reserved for expansion cards and therefore the PS/2 mouse will not function.




Figure 3-23 JP8: PS/2 Mouse IRQ12 Setting

**CAUTION:** After adjusting the JP8 correctly, the user must set the <PS/2 Mouse Support> option to Enabled in the BIOS <Advanced CMOS Setup> Menu. Then the PS/2 mouse can be used.

#### (2) PS/2 Mouse Connector (CN6 & J7)

To use the PS/2 interface, an adapter cable has to be connected to the CN6 and J7 (6-pin header type) connector. This adapter cable is mounted on a bracket and is included in your AR-B1476 package. The connector for the PS/2 mouse is a Mini-DIN 6-pin connector. Pin assignments for the PS/2 port connector are as follows:




Figure 3-24 CN6 & J7: PS/2 Mouse Connector

### 3.2.12 CPU Setting

The AR-B1476 accepts many types of microprocessors such as Intel/AMD/Cyrix 486DX/DX2/DX4. All of these CPUs include an integer processing unit, floating-point processing unit, memory-management unit, and cache. They can give a two to ten-fold performance improvement in speed over the 386 processor, which is depending on the clock speeds used and specific application. Like the 386 processor, the 486 processor includes both segment-based and page-based memory protection schemes. The instruction of processing time is reduced by on-chip instruction pipelining. By performing fast, on-chip memory management and caching, the 486 processor relaxes requirements for memory response for a given level of system performance.

#### (1) CPU Logic Core Voltage Select (P1 & P2)




Figure 3-25 P1 & P2: CPU Logic Core Voltage

#### (2) AMD 3X/4X CPU Select (JP5)




Figure 3-26 JP5: AMD 3X/4X CPU Select

#### (3) PCI Clock Select (JP7)




Figure 3-27 JP7: PCI Clock Select

#### (4) CPU Clock Multiplier Select (JP6)

A	B	Base Clock	Note	
Close	Close	50MHz		
Open	Close	40MHz		
Close	Open	33.3MHz	Factory Preset	
Open	Open	25MHz		

Table 3-6 JP6: CPU Clock Multiplier Select

### 3.2.13 Memory Setting

#### (1) DRAM Configuration

There are two 32-bit memory banks on the AR-B1476 board. It can be one-side or double-side SIMM (Single-Line Memory Modules) which is designed to accommodate 256KX36 bit to 16MX36-bit SIMMs. This provides the user with up to 64MB of main memory. The 32-bit SIMM (without parity bit) also can be used on AR-B1476 board. There are listing on-board memory configurations available. Please refer to the following table for details:

SIMM1	Total Memory
256KX32(X36)	1MB
512KX32(X36)	2MB
1MX32(X36)	4MB
2MX32(X36)	8MB
4MX32(X36)	16MB
8MX32(X36)	32MB
16MX32(X36)	64MB

Table 3-7 DRAMs' Configuration

#### (2) Cache RAM (JP1)

The AR-B1476 can be configured to provide a write-back or write-through cache scheme and support 512KB cache systems. A write-back cache system may provide better performance than a write-through cache system. The BIOS Setup program allows you to set the cache scheme either write-back or write-through, either the internal cache selection.




Figure 3-28 JP1: Write-Through/Write-Back CPU Select

#### (3) Cache Size Select (CP1)

The CP1 is located on the back of CPU card. The factory setting is fixed is 512K Byte, this function can't be supplied for user adjusting. The type of setting's table is in following.

CP1	Data RAM	TAG RAM	SIZE
OPEN	four 64K x 8	32K x 8	256KB
CLOSE	four 128K x 8	32K x 8	512KB

Table 3-8 Cache Size Selected

### 3.2.14 DiskOnChip Installation (SW1)

The DiskOnChip is a new generation of high performance single-chip Flash Disk. It provides a Flash Disk in a standard 32-pin DIP package.

This unique data storage solution offers a better, faster, and more cost-effective Flash Disk for Single Board embedded systems. The DiskOnChip provides a Flash Disk that does not require any bus, slot or connector. Simply insert the DiskOnChip into 32-pin socket U16 position on the CPU board. It is the optimal solution for single board computers, it is a small, fully functional, easy to integrate, plug-and-play Flash Disk with a very low power consumption.

The DiskOnChip is fully tested and formatted before the product is shipped.

#### (1) DiskOnChip Hardware Installation

**Step 1:** Make sure the target platform is powered OFF

**Step 2:** Plug the DiskOnChip device into the U16 socket. Verify the direction is correct (pin 1 of the DiskOnChip is aligned with pin 1 of the U16 socket)

**Step 3:** Power up the system

**Step 4:** During power up you may observe the messages displayed by the DiskOnChip when its drivers are automatically loaded into system's memory

**Step 5:** At this stage the DiskOnChip can be accessed as any disk in the system

**Step 6:** If the DiskOnChip is the only disk in the system, it will appear as the first disk (drive C: in DOS)

**Step 7:** If there are more disks besides the DiskOnChip, it will appear by default as the last drive, unless it was programmed as first drive.

**Step 8:** If you want the DiskOnChip to be bootable, copy the operating system files into the DiskOnChip by using the standard DOS command.

#### (2) DiskOnChip Memory Address Setting (SW1)




Figure 3-29 SW1: DiskOnChip Memory Address Setting

#### (3) Configuring the DiskOnChip as a Bootable Disk

The DiskOnChip fully supports the BOOT capability. In order for the DiskOnChip to be bootable, it should be DOS formatted as bootable, like any floppy or hard disk that required to be booted.

SYS D:

Change the disk into bootable (assuming the DiskOnChip is disk D)





## 4. CRT/LCD FLAT PANEL DISPLAY

This section describes the configuration and installation procedure using LCD and CRT display.

- CRT Connector
- LCD Flat Panel Display
- Supported LCD Panel

### 4.1 CRT CONNECTOR (DB1)

The AR-B1476 supports CRT color monitors. AR-B1476 used onboard VGA chipset and supported 1MB on-board VRAM. For different VGA display modes, your monitor must possess certain characteristics to display the mode you want.

To connect to a CRT monitor, an adapter cable has to be connected to the DB1 connector. DB1 is used to connect with a VGA monitor when you are using the on-board VGA controller as a display adapter. Pin assignments for the DB1 connector are as follows:




Figure 4-1 DB1: CRT Connector

### 4.2 LCD FLAT PANEL DISPLAY

This section describes the configuration and installation procedure for a LCD display. Skip this section if you are using a CRT monitor only.

Use the Flash memory Writer utility to download the new BIOS file into the ROM chip to configure the BIOS default settings for different types of LCD panels. Next, set your system properly and configure the AR-B1476 VGA module for the right type of LCD panel you are using.

The following shows the block diagram of the system when using the AR-B1476 with a LCD display.




Figure 4-2 LCD Panel Block Diagram

The block diagram shows that the AR-B1476 still needs components to use with a LCD panel. The inverter board provides the control for the brightness and the contrast of the LCD panel. The inverter is also the components that supply the high voltage to drive the LCD panel. Each item will be explained further in the section.




Figure 4-3 LCD Panel Cable Installation Diagram

**NOTE:** Be careful with the pin orientation when installing connectors and the cables. A wrong connection can easily destroy your LCD panel. Pin 1 of the cable connector is indicated with a sticker and pin1 of the ribbon cable is usually has a different color.

### 4.2.1 Inverter Board Description

The inverter board supplies high voltage signals to drive the LCD panel by converting the 12 volt signal from the AR-B1476 into a high voltage AC signal for LCD panel. It can be installed freely on the space provided over the VR board. If the VR board is installed on the bracket, you have to provide a place to install the inverter board into your system.

### 4.2.2 LCD Connector

#### (1) DE/E Signal from M or LP Select (JP3)




Figure 4-4 JP3: DE/E Signal from M or LP

#### (2) LCD Control Connector (J5)

J5 is a 5-pin connector that attaches to the Contrast and Backlight board. Its pin assignment is shown below:




Figure 4-5 J5: LCD Control Connector

#### (3) Touch Screen Connector (J11)





Figure 4-6 J11: Touch Screen Connector

**(4) LCD Panel Display Connector (CN3)**

Attach a display panel connector to this 44-pin connector with pin assignments as shown below:



**Figure 4-7 CN3: LCD Display Connector**

Pin	Signal	Pin	Signal
1	GND	2	SHFCLK
3	GND	4	LP
5	FLM	6	GND
7	P0(B0)	8	P1(B1)
9	P2(B2)	10	P3(B3)
11	P4(B4)	12	P5(B5)
13	GND	14	P6(B6)
15	P7(B7)	16	P8(G0)
17	P9(G1)	18	P10(G2)
19	P11(G3)	20	GND
21	P12(G4)	22	P13(G5)
23	P14(G6)	24	P15(G7)
25	P16(R0)	26	P17(R1)
27	GND	28	P18(R2)
29	P19(R3)	30	P20(R4)
31	P21(R5)	32	P22(R6)
33	P23(R7)	34	GND
35	VCC	36	VCC
37	+12V	38	+12V
39	GND	40	GND
41	DE	42	ENABLK
43	GND	44	VEE

**Table 4-1 LCD Display Assignment**

<http://www.acrosser.com>



## 5. INSTALLATION

This chapter describes the procedure of the utility diskette installation. The following topics are covered:

- Overview
- Utility Diskette
- Watchdog Timer

### 5.1 OVERVIEW

This chapter provides information for you to set up a working system based on the AR-B1476 CPU board. Please read the details of the CPU board's hardware descriptions before installation carefully, especially jumpers' setting, switch settings and cable connections.

Follow steps listed below for proper installation:

- Step 1 :** Read the CPU card's hardware description in this manual.
- Step 2 :** Install any DRAM SIMM onto the CPU card. (or user can skip this step because that the AR-B1476 embedded on-board DRAM)
- Step 3 :** Set jumpers.
- Step 4 :** Make sure that the power supply connected to your passive CPU board backplane is turned off.
- Step 5 :** Plug the CPU card into a free AT-bus slot or PICMG slot on the backplane and secure it in place with a screw to the system chassis.
- Step 6 :** Connect all necessary cables. Make sure that the FDC, HDC, serial and parallel cables are connected to pin 1 of the related connector.
- Step 7 :** Connect the hard disk/floppy disk flat cables from the CPU card to the drives. Connect a power source to each drive.
- Step 8 :** Plug the keyboard into the keyboard connector.
- Step 9 :** Turn on the power.
- Step 10:** Configure your system with the BIOS Setup program then re-boot your system.
- Step 11:** If the CPU card does not work, turn off the power and read the hardware description carefully again.
- Step 12:** If the CPU card still does not perform properly, return the card to your dealer for immediate service.

### 5.2 UTILITY DISKETTE

AR-B1476 provides two VGA driver diskettes. It supports WIN31, WIN95, WINNT 4.0 and OS/2. If your operating system is the other operating system, please attach Acrosser that will provide the technical supporting for the VGA resolution.

There are two diskettes: disk 1 is for WIN31, WIN95 & WINNT4.0 VGA resolution; disk 2 is for OS/2 VGA resolution. While user extracted the compressed files there is the README.\* file in each sub-directories. Please refer to the file of README for any troubleshooting before install the driver.

## 5.2.1 VGA Driver

### (1) WIN 3.1 Driver

For the WIN31 operating system, user must in the DOS mode decompress the compress file. And then as to the steps:

- Step 1:** Make the new created directory to put the VGA drivers.  
C: \>MD VGAW31
- Step 2:** Insert the Utility Disk #1 in the floppy disk drive, and then copy the compress file—D54XW31P.ZIP, and the extract program—PKUNZIP.EXE, in the new created directory.  
C: \>COPY A: \ D54XW31P.ZIP C: \VGAW31  
C: \>COPY A: \PKUNZI P. EXE C: \VGAW31
- Step 3:** Change directory to the new created directory, and extract the compress file.  
C: \>CD VGAW31  
C: \VGAW31>PKUNZI P -d D54XW31P.ZIP
- Step 4:** And then re-name the SET545P.SCP file as SETUP5XX.SCP. Acrosser recommends the method as:  
C:\VGAW31>COPY SET545P.SCP SETUP5XX.SCP
- Step 5:** In the DOS mode execute the SETUP.EXE file.  
C:\VGAW31>SETUP
- Step 6:** The screen shows the chip type, and presses any key enter the main menu.  
CHIPS 655XX - PCI Display Drivers  
Preliminary Version 3.3.0
- Step 7:** There are some items for choice to setup. Please choose the <Windows Version 3.1> item, notice the function key defined. Press [ENTER] selected the <All Resolutions>, when this line appears [\*] symbol, that means this item is selected. Press [End] starts to install.
- Step 8:** The screen will show the dialog box to demand user typing the WIN31's path. The default is C:\WINDOWS.
- Step 9:** Follow the setup steps' messages execute. As completed the setup procedure will generate the message as follow.  
  
Installation is done!  
  
Change to your Windows directory and type SETUP to run the Windows Setup program. Choose one of the new drivers marked by an \*. Please refer to the User's Guide to complete the installation.
- Step 10:** Presses [Esc] return the main menu, and re-press [Esc] return to the DOS mode.
- Step 11:** In the WIN31, you can find the <Chips CPL> icon located in the {CONTROL PANEL} group.
- Step 12:** Adjust the <Refresh Rate>, <Cursor Animation>, <Font size>, <Resolution>, and <Big Cursor>.

**(2) WIN 95 Driver**

For the WIN95 operating system, user must in the DOS mode decompress the compress file. And then as to the steps:

- Step 1:** Make the new created directory to put the VGA drivers.  
C:\>MD VGAW95
- Step 2:** Insert the Utility Disk #1 in the floppy disk drive, and then copy the compress file—D55XW95.ZIP, and the extract program—PKUNZIP.EXE, in the new created directory.  
C:\>COPY A:\D55XW95.ZIP C:\VGAW95  
C:\>COPY A:\PKUNZIP.EXE C:\VGAW95
- Step 3:** Change directory to the new created directory, and extract the compress file.  
C:\>CD VGAW95  
C:\VGAW95>PKUNZIP -d D55XW95.ZIP
- Step 4:** Enter the WIN95 operation system and please choose the <SETTING> item of the <DISPLAY> icon in the {CONTROL PANEL}. Please select the <From Disk Install> item, and type the factory source files' path.  
C:\VGAW95
- Step 5:** And then you can find the <Chips and Tech 65545 PCI (new)> item, select it and click the <OK> button.
- Step 6:** Finally, user can find the <DISPLAY> icon adds the <Chips> item. You can select this item, and adjust the <Screen Resolution>, <Refresh Rate>, <Font Size>...and other functions. Please refer to the messages during installation.

**(3) WINNT 4.0 Driver**

For the WINNT4.0 operating system, user must in the DOS mode decompress the compress file. And then as to the steps:

- Step 1:** Make the new created directory to put the VGA drivers.  
C:\>MD VGANT40
- Step 2:** Insert the Utility Disk #1 in the floppy disk drive, and then copy the compress file—D5XXNT4.ZIP, and the PKUNZIP.EXE program—, in the new created directory.  
C:\>COPY A:\D5XXNT4.ZIP C:\VGANT40  
C:\>COPY A:\PKUNZIP.EXE C:\VGANT40
- Step 3:** Change directory to the new created directory, and extract the compress file.  
C:\>CD VGANT40  
C:\ VGANT40>PKUNZIP -d D5XXNT4.ZIP
- Step 4:** Enter the WINNT4.0 operation system and please choose the <SETTING> item of the <DISPLAY> icon in the {CONTROL PANEL}. Please select the <From Disk Install> item, and type the factory source files' path.  
C:\VGANT40
- Step 5:** And then you can find the <Chips and Tech 65545 PCI (new)> item, select it and click the <OK> button.
- Step 6:** Finally, user can find the <DISPLAY> icon adds the <Chips> item. You can select this item, and adjust the <Screen Resolution>, <Refresh Rate>, <Font Size>...and other function. Please refer to the messages during installation.

#### (4) OS/2 Warp Driver

The following steps must be performed before you install the 65545/65548 display's driver:

---

**CAUTION:**

1. OS/2 DOS Support must be installed.
2. If you previously installed SVGA support, you must do the following:
  - a) Close all DOS Full Screen and WIN-OS2 sessions.
  - b) Reset the system to VGA mode. VGA is the default video mode enabled when OS/2 is installed. To restore VGA mode, use Selective Install and select VGA for Primary Display. For more information on this procedure, see the section on Changing Display Adapter Support in the OS/2 Users Guide.

To install this driver, do the following steps:

- Step 1:** Open an OS/2 full screen or windowed session.
- Step 2:** Place the 65545/65548 PCI Display Driver Diskette in drive A. (DISK #2)
- Step 3:** Because the diskette enclosed the compress file, to extract file had to as the steps.
- Step 4:** In the OS/2-DOS mode, make the VGA directory for decompress the driver.  
C:\>MD VGAOS2  
C:\>CD VGAOS2  
C:\VGAOS2>COPY A:\\*. \*  
C:\VGAOS2>PKUNZIP -d D54XOS2P.ZIP
- Step 5:** At the OS/2 command prompt, type the following commands to copy the files to the OS/2 drive:  
C:\VGAOS2> SETUP C:\VGAOS2 C: <ENTER>
- Step 6:** When the Setup Program is completed, you will need to perform a shutdown and then restart the system in order for changes to take effect.
- Step 7:** Please refer to the README.TXT file, there is detail description, user had to according to the installation step by step. When install completed, user can adjust the VGA resolution in the SYSTEM icon <SCREEN> item of the <SYSTEM SETUP>.

#### 5.2.2 BIOS FLASH Utility

The main function of AMIFLASH.COM supports BIOS update. The AR-B1476 can provide FLASH BIOS update function for you to easily upgrade newer BIOS version. Please contact Acrosser engineer to support the modification of the BIOS.

1. Use the AMIFLASH.COM program to update the BIOS setting function.
2. And then refer to the section "BIOS Console", as the steps to modify BIOS.
3. Now the CPU board's BIOS is the newest, user can use this program to modify BIOS function in the future, when the BIOS adding some function.



## 5.3 WATCHDOG TIMER

This section describes how to use the Watchdog Timer, disabled, enabled, and trigger.

The AR-B1476 is equipped with a programmable time-out period watchdog timer. User can use the program to enable the watchdog timer. Once you have enabled the watchdog timer, the program should trigger it every time before it times out. If your program fails to trigger or disable this timer before it times out because of system hang-up, it will generate a reset signal to reset the system. The time-out period can be programmed to be 3 to 42 seconds.




Figure 5-1 Watchdog Block Diagram

### 5.3.1 Watchdog Timer Setting

The watchdog timer is a circuit that may be used from your program software to detect crashes or hang-ups. Whenever the watchdog timer is enabled, the LED will blink to indicate that the timer is counting. The watchdog timer is automatically disabled after reset.

Once you have enabled the watchdog timer, your program must trigger the watchdog timer every time before it times-out. After you trigger the watchdog timer, it will be set to zero and start to count again. If your program fails to trigger the watchdog timer before time-out, it will generate a reset pulse to reset the system or trigger the IRQ15 signal to tell your program that the watchdog is times out.

The factor of the watchdog timer time-out constant is approximately 6 seconds. The period for the watchdog timer time-out period is between 1 to 7 timer factors.

If you want to reset your system when watchdog times out, the following table listed the relation of timer factors between time-out periods.

Time Factor	Time-Out Period (Seconds)
80H	3
81H	6
82H	12
83H	18
84H	24
85H	30
86H	36
87H	42

Table 5-1 Time-Out Setting

If you want to generate IRQ15 signal to warn your program when watchdog times out, the following table listed the relation of timer factors between time-out period. And if you use the IRQ15 signal to warn your program when watchdog timer out, please enter the BIOS Setup the <Peripheral Setup> menu, the <OnBoard PCI IDE> and <IDE Prefetch> these two items must set to **Primary**.

Time Factor	Time-Out Period (Seconds)
0C0H	3
0C1H	6
0C2H	12
0C3H	18
0C4H	24
0C5H	30
0C6H	36
0C7H	42

Table 5-2 Time-Out Setting

- NOTE:** 1. If you program the watchdog to generate IRQ15 signal when it times out, you should initial IRQ15 interrupt vector and enable the second interrupt controller (8259 PIC) in order to enable CPU to process this interrupt. An interrupt service routine is required too.
2. Before you initial the interrupt vector of IRQ15 and enable the PIC, please enable the watchdog timer previously, otherwise the watchdog timer will generate an interrupt at the time watchdog timer is enabled.




Figure 5-1 SW1: Watchdog I/O Port Address Select

### 5.3.2 Watchdog Timer Enabled

To enable the watchdog timer, you have to output a byte of timer factor to the watchdog register whose address is 214H or Base Port. The following is a BASICA program, which demonstrates how to enable the watchdog timer and set the time-out period at 24 seconds.

```

1000     REM Points to command register
1010     WD_REG% = 214H
1020     REM Timer factor = 84H (or 0C4H)
1030     TIMER_FACTOR% = %H84
1040     REM Output factor to watchdog register
1050     OUT WD_REG%, TIMER_FACTOR%
      .,etc.

```

### 5.3.3 Watchdog Timer Trigger

After you enable the watchdog timer, your program must write the same factor as enabling to the watchdog register at least once every time-out period to its previous setting. You can change the time-out period by writing another timer factor to the watchdog register at any time, and you must trigger the watchdog before the new time-out period in next trigger. Below is a BASICA program, which demonstrates how to trigger the watchdog timer:

```

2000     REM Points to command register
2010     WD_REG% = 214H
2020     REM Timer factor = 84H (or 0C4H)
2030     TIMER_FACTOR% = &H84
2040     REM Output factor to watchdog register
2050     OUT WD_REG%, TIMER_FACTOR%
      .,etc.

```

### 5.3.4 Watchdog Timer Disabled

To disable the watchdog timer, simply write a 00H to the watchdog register.

```

3000     REM Points to command register
3010     WD_REG% = BASE_PORT%
3020     REM Timer factor = 0
3030     TIMER_FACTOR% = 0
3040     REM Output factor to watchdog register
3050     OUT WD_REG%, TIMER_FACTOR%
      ., etc.

```

## 6. BIOS CONSOLE

This chapter describes the AR-B1476 BIOS menu displays and explains how to perform common tasks needed to get up and running, and presents detailed explanations of the elements found in each of the BIOS menus. The following topics are covered:

- BIOS Setup Overview
- Standard CMOS Setup
- Advanced CMOS Setup
- Advanced Chipset Setup
- Peripheral Setup
- Auto-Detect Hard Disks
- Password Setting
- Load Default Setting
- BIOS Exit
- BIOS Update

### 6.1 BIOS SETUP OVERVIEW


BIOS is a program used to initialize and set up the I/O system of the computer, which includes the ISA bus and connected devices such as the video display, diskette drive, and the keyboard.

The BIOS provides a menu-based interface to the console subsystem. The console subsystem contains special software, called firmware that interacts directly with the hardware components and facilitates interaction between the system hardware and the operating system.

The BIOS Default Values ensure that the system will function at its normal capability. In the worst situation the user may have corrupted the original settings set by the manufacturer.

After the computer turned on, the BIOS will perform a diagnostics of the system and will display the size of the memory that is being tested. Press the [Del] key to enter the BIOS Setup program, and then the main menu will show on the screen.

The BIOS Setup main menu includes some options. Use the [Up/Down] arrow key to highlight the option that you wish to modify, and then press the [Enter] key to assure the option and configure the functions.



**Figure 6-1 BIOS: Setup Main Menu**

- CAUTION:**
1. AR-B1476 BIOS the factory-default setting is used to the <Auto Configuration with Optimal Settings> Acrosser recommends using the BIOS default setting, unless you are very familiar with the setting function, or you can contact the technical support engineer.
  2. If the BIOS loss setting, the CMOS will detect the <Auto Configuration with Fail Safe Settings> to boot the operation system, this option will reduce the performance of the system. Acrosser recommends choosing the <Auto Configuration with Optimal Setting> in the main menu. The option is best-case values that should optimize system performance.
  3. The BIOS settings are described in detail in this section.

## 6.2 STANDARD CMOS SETUP

The <Standard CMOS Setup> option allows you to record some basic system hardware configuration and set the system clock and error handling. If the CPU board is already installed in a working system, you will not need to select this option anymore.

AMIBIOS SETUP - STANDARD CMOS SETUP									
(C) 1996 American Megatrends, Inc. All Rights Reserved									
Date (mm/dd/yyyy): Sat Dec 05, 1998					640K				
Time (hh/mm/ss): 13:13:00					39MB				
Floppy Drive A: Not Installed									
Floppy Drive B: Not Installed									
	Type	Size	Cyln	Head	Wpcom	Sec	LBA Mode	Blk Mode	PIO 32Bit Mode
Pri Master	: Auto						Off	Off	Auto Off
Pri Slave	: Auto						Off	Off	Auto Off
Boot Sector Virus Protection					Disabled				
Month: Jan - Dec					ESC:Exit :Sel				
Day: 01 - 31					PgUp/PgDn:Modify				
Year: 1901 - 2099					F2/F3:Color				

Figure 6-2 BIOS: Standard CMOS Setup

### Date & Time Setup

Highlight the <Date> field and then press the [Page Up] / [Page Down] or [+]/[-] keys to set the current date. Follow the month, day and year format.

Highlight the <Time> field and then press the [Page Up] / [Page Down] or [+]/[-] keys to set the current date. Follow the hour, minute and second format.

The user can bypass the date and time prompts by creating an AUTOEXEC.BAT file. For information on how to create this file, please refer to the MS-DOS manual.

### Floppy Setup

The <Standard CMOS Setup> option records the types of floppy disk drives installed in the system.

To enter the configuration value for a particular drive, highlight its corresponding field and then select the drive type using the left-or right-arrow key.

### Hard Disk Setup

The BIOS supports various types for user settings, The BIOS supports <Pri Master> and <Pri Slave> so the user can install up to two hard disks. For the master and slave jumpers, please refer to the hard disk's installation descriptions and the hard disk jumper settings.

You can select <AUTO> under the <TYPE> and <MODE> fields. This will enable auto detection of your IDE drives during bootup. This will allow you to change your hard drives (with the power off) and then power on without having to reconfigure your hard drive type. If you use older hard disk drives, which do not support this feature, then you must configure the hard disk drive in the standard method as described above by the <USER> option.

### Boot Sector Virus Protection

This option protects the boot sector and partition table of your hard disk against accidental modifications. Any attempt to write to them will cause the system to halt and display a warning message. If this occurs, you can either allow the operation to continue or use a bootable virus-free floppy disk to reboot and investigate your system. The default setting is <Disabled>. This setting is recommended because it conflicts with new operating systems. Installation of new operating system requires that you disable this to prevent write errors.

## 6.3 ADVANCED CMOS SETUP

The <Advanced CMOS SETUP> option consists of configuration entries that allow you to improve your system performance, or let you set up some system features according to your preference. Some entries here are required by the CPU board 's design to remain in their default settings.

AMIBIOS SETUP - ADVANCED CMOS SETUP (C) 1996 American Megatrends, Inc. All Rights Reserved		
BootUp Sequence	C:,A:,CDROM	Available Options: C:, A:, CDROM A:, C:, CDROM CDROM, A:, C:
BootUp Num-Lock	On	
Floppy Drive Swap	Disabled	
Floppy Drive Seek	Disabled	
Mouse Support	Enabled	
Typematic Rate	Fast	
System Keyboard	Present	
Primary Display	VGA/EGA	
Password Check	Setup	
Wait For 'F1' If Error	Enabled	
Hit 'DEL' Message Display	Enabled	
Internal Cache	WriteBack	
External Cache	WriteThru	
System BIOS Cacheable	Enabled	
Hard disk Delay	3 Sec	
C000, 16k Shadow	Enabled	
C400, 16k Shadow	Enabled	
C800, 16k Shadow	Disabled	
CC00, 16k Shadow	Disabled	
D000, 16k Shadow	Disabled	
D400, 16k Shadow	Disabled	
D800, 16k Shadow	Disabled	
DC00, 16k Shadow	Disabled	
		ESC:Exit :Sel PgUp/PgDn:Modify F2/F3:Color

Figure 6-3 BIOS: Advanced CMOS Setup

### BootUp Sequence

The option determines where the system looks first for an operating system.

### BootUp Num-Lock

This item is used to activate the Num-Lock function upon system boot. If the setting is on, after a boot, the Num-Lock light is lit, and user can use the number key.

### Floppy Drive Swap

The option reverses the drive letter assignments of your floppy disk drives in the Swap A, B setting, otherwise leave on the default setting of **Disabled** (No Swap). This works separately from the BIOS Features floppy disk swap feature. It is functionally the same as physically interchanging the connectors of the floppy disk drives. When the setting is <**Enabled**>, the BIOS will be swapped floppy drive assignments so that Drive A becomes Drive B, and Drive B becomes Drive A under DOS.

### Floppy Drive Seek

If the <Floppy Drive Seek> item is setting **Enabled**, the BIOS will seek the floppy <A> drive one time upon boot up.

### Mouse Support

The setting of **Enabled** allows the system to detect a PS/2 mouse on boot up. If detected, IRQ12 will be used for the PS/2 mouse. IRQ 12 will be reserved for expansion cards if a PS/2 mouse is not detected. **Disabled** will reserve IRQ12 for expansion cards and therefore the PS/2 mouse will not function.

### Typematic Rate

This item specifies the speed at which a keyboard keystroke is repeated.

### System Keyboard

This function specifies that a keyboard would be attached to the computer.

### Primary Display

The option is used to set the type of video display card installed in the system.

### Password Check

This option enables password checking every time the computer is powered on or every time the BIOS Setup is executed. If **Always** is chosen, a user password prompt appears every time the computer is turned on. If **Setup** is chosen, the password prompt appears if the BIOS executed.

### Wait for 'F1' If Error

AMIBIOS POST error messages are followed by:

Press <F1> to continue

If this option is set to **Disabled**, the AMIBIOS does not wait for you to press the <F1> key after an error message.

### Hit 'DEL' Message Display

Set this option to **Disabled** to prevent the message as follows:

Hit 'DEL' if you want to run setup

It will prevent the message from appearing on the first BIOS screen when the computer boots.

### Internal Cache

This option specifies the caching algorithm used for L1 internal cache memory. The settings are:

Setting	Description
Disabled	Neither L1 internal cache memory on the CPU or L2 secondary cache memory is enabled.
WriteBack	Use the write-back caching algorithm.
WriteThru	Use the write-through caching algorithm.

Table 6-1 Internal Cache Setting

### External Cache

This option specifies the caching algorithm used for L2 secondary (external) cache memory. The settings are:

Setting	Description
Disabled	Neither L1 internal cache memory on the CPU or L2 secondary cache memory is enabled.
WriteBack	Use the write-back caching algorithm.
WriteThru	Use the write-through caching algorithm.

Table 6-2 External Cache Setting

### System BIOS Cacheable

When this option is set to **Enabled**, the contents of the F0000h system memory segment can be read from or written to L2 secondary cache memory. The contents of the F0000h memory segment are always copied from the BIOS ROM to system RAM for faster execution.

The settings are **Enabled** or **Disabled**. The Optimal default setting is **Enabled**. The Fail-Safe default setting is **Disabled**.

**Shadow**

These options control the location of the contents of the 32KB of ROM beginning at the specified memory location. If no adapter ROM is using the named ROM area, this area is made available to the local bus. The settings are:

<b>SETTING</b>	<b>DESCRIPTION</b>
Disabled	The video ROM is not copied to RAM. The contents of the video ROM cannot be read from or written to cache memory.
Enabled	The contents of C000h - C7FFFh are written to the same address in system memory (RAM) for faster execution.
Cached	The contents of the named ROM area are written to the same address in system memory (RAM) for faster execution, if an adapter ROM will be using the named ROM area. Also, the contents of the RAM area can be read from and written to cache memory.

**Table 6-3 Shadow Setting**

## 6.4 ADVANCED CHIPSET SETUP

This option controls the configuration of the board's chipset. Control keys for this screen are the same as for the previous screen.

AMIBIOS SETUP - ADVANCED CHIPSET SETUP (C) 1996 American Megatrends, Inc. All Rights Reserved		
Auto Config Function	Enabled	Available Options : Disabled Enabled
AT Bus Clock	CLK/4	
DRAM Read Timing	Normal	
DRAM Write Timing	Normal	
Memory Parity Check	Disabled	
DRAM Hidden Refresh	Enabled	
DRAM Refresh Period Setting	60us	
Memory Hole At 15-16M	Disabled	
ISA I/O Recovery	Disabled	ESC:Exit :Sel
ISA I/O Recovery time	1.5us	PgUp/PgDn:Modify F2/F3:Color

Figure 6-4 BIOS: Advanced Chipset Setup

### Automatic Configuration

If selecting a certain setting for one BIOS Setup option determines the settings for one or more other BIOS Setup options, the BIOS automatically assigns the dependent settings and does not permit the end user to modify these settings unless the setting for the parent option is changed. Invalid options are grayed and cannot be selected.

### AT Bus Clock

This option sets the polling clock speed of ISA Bus (PC/104).

**NOTE:** 1. PCLK means the CPU inputs clock.  
2. Acrosser recommends user setting at the range of 8MHz to 10MHz.

### Memory Parity Check

This option **Enables** or **Disables** parity is error checking for all system RAM. This option must be **Disabled** if the used DRAM SIMMs are 32-bit but not 36-bit devices.

### Memory Hole at 15-16 M

This option specifies the range 15MB to 16MB in memory that cannot be addressed on the ISA bus.

### ISA I/O Recovery

#### ISA I/O Recovery Time

These options specify the length of the delay (in BUSCLK) inserted between consecutive 8-bit/16-bit I/O operations.



## 6.5 PERIPHERAL SETUP

This section is used to configure peripheral features.

AMIBIOS SETUP - PERIPHERAL SETUP (C) 1996 American Megatrends, Inc. All Rights Reserved		
OnBoard FDC	Enabled	Available Options : Auto Disabled Enabled
OnBoard Serial Port1	3F8	
OnBoard Serial Port1 IRQ	4	
OnBoard Serial Port2	2F8	ESC:Exit :Sel PgUp/PgDn:Modify F2/F3:Color
OnBoard Serial Port2 IRQ	3	
OnBoard Parallel Port	378	
Parallel Port Mode	Normal	
EPP Version	N/A	
Parallel Port IRQ	7	
Parallel Port DMA Channel	N/A	
OnBoard PCI IDE	Both	

**Figure 6-5 BIOS: Peripheral Setup**

### OnBoard FDC

This option enables the floppy drive controller on the AR-B1476.

### OnBoard Serial Port

This option enables the serial port on the AR-B1476.

### OnBoard Parallel Port

This option enables the parallel port on the AR-B1476.

### Parallel Port Mode

This option specifies the parallel port mode. ECP and EPP are both bi-directional data transfer schemes that adhere to the IEEE P1284 specifications.

### Parallel Port DMA Channel

This option is only available if the setting for the parallel Port Mode option is ECP.

### OnBoard PCI IDE/IDE Prefetch

This option specifies the onboard IDE controller channels that will be used.

## 6.6 AUTO-DETECT HARD DISKS

This option detects the parameters of an IDE hard disk drive, and automatically enters them into the Standard CMOS Setup screen.

## 6.7 PASSWORD SETTING

This BIOS Setup has an optional password feature. The system can be configured so that all users must enter a password every time the system boots or when BIOS Setup is executed. User can set either a Supervisor password or a User password.

### 6.7.1 Setting Password

Select the appropriate password icon (Supervisor or User) from the Security section of the BIOS Setup main menu. Enter the password and press [Enter]. The screen does not display the characters entered. After the new password is entered, retype the new password as prompted and press [Enter].

If the password confirmation is incorrect, an error message appears. If the new password is entered without error, press [Esc] to return to the BIOS Main Menu. The password is stored in CMOS RAM after BIOS completes. The next time the system boots, you are prompted for the password function is present and is enabled.

Enter new supervisor password:

### 6.7.2 Password Checking

The password check option is enabled in Advanced Setup by choosing either **Always** (the password prompt appears every time the system is powered on) or **Setup** (the password prompt appears only when BIOS is run). The password is stored in CMOS RAM. User can enter a password by typing on the keyboard. As user select Supervisor or User. The BIOS prompts for a password, user must set the Supervisor password before user can set the User password. Enter 1-6 character as password. The password does not appear on the screen when typed. Make sure you write it down.

## 6.8 LOAD DEFAULT SETTING

In this section permit user to select a group of setting for all BIOS Setup options. Not only can you use these items to quickly set system configuration parameters, you can choose a group of settings that have a better chance of working when the system is having configuration related problems.

### 6.8.1 Auto Configuration with Optimal Setting

User can load the optimal default settings for the BIOS. The Optimal default settings are best-case values that should optimize system performance. If CMOS RAM is corrupted, the optimal settings are loaded automatically.

Load high performance settings (Y/N) ?

### 6.8.2 Auto Configuration with Fail Safe Setting

User can load the Fail-Safe BIOS Setup option settings by selecting the Fail-Safe item from the Default section of the BIOS Setup main menu.

The Fail-Safe settings provide far from optimal system performance, but are the most stable settings. Use this option as a diagnostic aid if the system is behaving erratically.

Load fail safe settings (Y/N) ?

## 6.9 BIOS EXIT

This section is used to exit the BIOS main menu in two types situation. After making your changes, you can either save them or exit the BIOS menu and without saving the new values.

### 6.9.1 Save Settings and Exit

This item set in the <Standard CMOS Setup>, <Advanced CMOS Setup>, <Advanced Chipset Setup> and the new password (if it has been changed) will be stored in the CMOS. The CMOS checksum is calculated and written into the CMOS.

As you select this function, the following message will appear at the center of the screen to assist you to save data to CMOS and Exit the Setup.

Save current settings and exit (Y/N) ?

### 6.9.2 Exit Without Saving

When you select this option, the following message will appear at the center of the screen to help to Abandon all Data and Exit Setup.

Quit without saving (Y/N) ?

## 6.10 BIOS UPDATE

The BIOS program instructions are contained within computer chips called FLASH ROMs that are located on your system board. The chips can be electronically reprogrammed, allowing you to upgrade your BIOS firmware without removing and installing chips.

The AR-B1476 provides FLASH BIOS update function for you to easily upgrade newer BIOS version. Please follow the operating steps for updating new BIOS:

**Step 1:** Turn on your system and don't detect the CONFIG.SYS and AUTOEXEC.BAT files. Keep your system in the real mode.

**Step 2:** Insert the FLASH BIOS diskette into the floppy disk drive.

**Step 3:** In the MS-DOS mode, you can type the AMIFLASH program.

```
A:\>AMIFLASH
```

**Step 4:** The screen will show the message as follow:

Enter the BIOS File name from which Flash EPROM will be programmed. The File name must and with a <ENTER> or press <ESC> to exit.

**Step 5:** And then please enter the file name to the box of <Enter File Name>. And the box of <Message> will show the notice as follow. In the bottom of this window always show the gray statement.

Flash EPROM Programming is going to start. System will not be usable until Programming of Flash EPROM is successfully complete. In case of any error, existing Flash EPROM must be replaced by new program Flash EPROM.

**Step 6:** As the gray statement, press the <Y> key to updating the new BIOS. And then the <Message> box will show the <Programming Flash EPROM>, and the gray statement shows <Please Wait>.

**Step 7:** The BIOS update is successful, the message will show <Flash Update Completed - Pass>.

- 
- NOTE:** 1. After turn on the computer and the system didn't detect the boot procedure, please press the [F5] key immediately. The system will pass the CONFIG.SYS and AUTOEXEC.BAT files.
2. The BIOS Flash disk is not the standard accessory. Now the onboard BIOS is the newest BIOS, if user needs adding some functions in the future please contact technical supporting engineers, they will provide the newest BIOS for updating.
3. The file of AMIFLASH.EXE doesn't attach in the utility diskette. If user needs to update the BIOS version for some reasons please contact the technical supporting engineers, and notices the file of AMIFLASH.EXE has to use the Version 6.31.


## 7. SPECIFICATIONS

<b>CPU:</b>	Supports 25 to 133 Mhz Intel / AMD / Cyrix / ST / IBM 486 CPU .
<b>Chipset:</b>	ALI M1489/M1487 and C & T 65545
<b>Bus Interface:</b>	ISA (PC/AT) and non-stack through PC/104 bus
<b>RAM Memory:</b>	Supports FPM/EDO RAM, 72 MB maximum (8MB on-board and one 72-pin SIMMs w/o DRAM)
<b>Cache Size:</b>	512KB for standard
<b>VGA/LCD Display:</b>	1 MB VRAM (PCI bus, 1024X768/256 colors)
<b>HDC:</b>	One PCI IDE Supports LBA/Block mode access
<b>FDC:</b>	Supports two 5.25" or 3.5" floppy disk drives
<b>Parallel Port:</b>	1 bi-directional centronics type parallel port Supports SPP/EPP/ECP mode
<b>Serial Port:</b>	1 RS-232C and 1 RS-232C/RS-485
<b>Keyboard:</b>	PC/AT compatible keyboard
<b>Watchdog:</b>	Programmable watchdog timer 3 to 42 seconds time interval
<b>Speaker:</b>	On-board Buzzer and external speaker
<b>Real Time Clock:</b>	BQ3287MT or compatible chips with 128 bytes data RAM
<b>BIOS:</b>	AMI Flash BIOS (128KB, including VGA BIOS)
<b>Flash Disk:</b>	Supports 1 DiskOnChip socket
<b>BUS Drive Cap.:</b>	15 TTL level loads maximum
<b>CE Design-In:</b>	Add EMI components to COM ports, parallel port, CRT, keyboard, and PS/2 mouse
<b>Indicator:</b>	Power LED, and watchdog LED
<b>Power Req.:</b>	+5V only, 2.0A maximum (base on Intel DX4-100)
<b>PC Board:</b>	8 layers, EMI considered
<b>Dimensions:</b>	185 mmX122mm (7.29"X4.80")




## 8. PLACEMENT & DIMENSIONS

### 8.1 PLACEMENT



## 8.2 DIMENSIONS



Unit: mil (1 inch = 25.4 mm = 1000 mil)



## 9. PROGRAMMING RS-485 & INDEX

### 9.1 PROGRAMMING RS-485

The majority communicative operation of the RS-485 is in the same of the RS-232. When the RS-485 proceeds the transmission which needs control the TXC signal, and the installing steps are as follows:

- Step 1:** Enable TXC
- Step 2:** Send out data
- Step 3:** Waiting for data empty
- Step 4:** Disable TXC

---

**NOTE:** Please refer to the section of the "Serial Port" in the chapter "System Control" for the detail description of the COM port's register.

#### (1) Initialize COM port

- Step 1:** Initialize COM port in the receiver interrupt mode, and /or transmitter interrupt mode. (All of the communication protocol buses of the RS-485 are in the same.)
- Step 2:** Disable TXC (transmitter control), the bit 0 of the address of offset+4 just sets "0".

---

**NOTE:** Control the AR-B1476 CPU card's DTR signal to the RS-485's TXC communication.

#### (2) Send out one character (Transmit)

- Step 1:** Enable TXC signal, and the bit 0 of the address of offset+4 just sets "1".
- Step 2:** Send out the data. (Write this character to the offset+0 of the current COM port address)
- Step 3:** Wait for the buffer's data empty. Check transmitter holding register (THRE, bit 5 of the address of offset+5), and transmitter shift register (TSRE, bit 6 of the address of offset+5) are all sets must be "0".
- Step 4:** Disabled TXC signal, and the bit 0 of the address of offset+4 sets "0"

#### (3) Send out one block data (Transmit – the data more than two characters)

- Step 1:** Enable TXC signal, and the bit 0 of the address of offset+4 just sets "1".
- Step 2:** Send out the data. (Write all data to the offset+0 of the current COM port address)
- Step 3:** Wait for the buffer's data empty. Check transmitter holding register (THRE, bit 5 of the address of offset+5), and transmitter shift register (TSRE, bit 6 of the address of offset+5) are all sets must be "0".
- Step 4:** Disabled TXC signal, and the bit 0 of the address of offset+4 sets "0"

#### (4) Receive data

The RS-485's operation of receiving data is in the same of the RS-232's.

**(5) Basic Language Example**

**a.) Initial 86C450 UART**

```
10 OPEN "COM1:9600,m,8,1"AS #1 LEN=1
20 REM Reset DTR
30 OUT &H3FC, (INP(%H3FC) AND &HFA)
40 RETURN
```

**b.) Send out one character to COM1**

```
10 REM Enable transmitter by setting DTR ON
20 OUT &H3FC, (INP(&H3FC) OR &H01)
30 REM Send out one character
40 PRINT #1, OUTCHR$
50 REM Check transmitter holding register and shift register
60 IF ((INP(&H3FD) AND &H60) >0) THEN 60
70 REM Disable transmitter by resetting DTR
80 OUT &H3FC, (INP(&H3FC) AND &HEF)
90 RETURN
```

**c.) Receive one character from COM1**

```
10 REM Check COM1: receiver buffer
20 IF LOF(1)<256 THEN 70
30 REM Receiver buffer is empty
40 INPSTR$=""
50 RETURN
60 REM Read one character from COM1: buffer
70 INPSTR$=INPUT$(1,#1)
80 RETURN
```

## 9.2 INDEX

Name	Function	Page
CN1	Hard disk (IDE) connector	3-2
CN2	FDD port connector	3-3
CN3	LCD panel display connector	4-3
CN4	Parallel port connector	3-3
CN5	RS-232 connector COM-B	3-8
CN6	PS/2 mouse connector	3-10
CN7	64 pin PC/104 connector bus A & B	3-4
CN8	40 pin PC/104 connector bus C & D	3-4
CN9	Keyboard connector	3-9
DB1	CRT connector	4-1
DB2	RS-232 connector COM-A	3-8
SIMM1	Socket for DRAM SIMMs	3-12
J1	Watchdog LED header	3-6
J2	External speaker header	3-9
J3	HDD LED header	3-6
J4	RS-485 connector	3-8
J5	LCD control connector	4-2
J6	External power LED & keyboard lock header	3-6
J7	External PS/2 mouse connector	3-10
J8	Reset header	3-10
J9	AUX. Keyboard connector	3-9
J10	Power connector	3-9
J11	Touch Screen Connector	4-2
LED1	Watchdog LED	
LED2	Power LED	
P1 & P2	CPU logic core voltage select	3-11
JP1	Write-through/Write-back CPU select	3-12
JP2	COM-B RS-485 terminator select	3-7
JP3	DE/E signal from M or LP select	4-2
JP4	COM-B RS-485 adapter select	3-7
JP5	AMD 3X/4X CPU select	3-11
JP6	CPU clock multiplier select	3-11
JP7	PCI clock select	3-11
JP8	PS/2 mouse IRQ12 setting	3-10
JP9	COM-A RS-485 adapter select	3-7
CP1	Cache Size Select	3-12
SW1	COM-B RS232/RS-485 Select	3-7
	DiskOnChip Memory Address Setting	3-13
	Watchdog I/O Port Address Select	5-6

**Note:**

If the content in Setting is inconsistent with CD-ROM. Please refer to the Setting as priority.