

AT & T, INC.

6300 XT

... continued from previous page

SYSTEM BOARD USER CONFIGURABLE SETTINGS		
Function	Jumper/Switch	Position
í Factory configured - do not alter	JA	N/A
í Factory configured - do not alter	JB	N/A
í Clock enabled	JC	Closed
Clock disabled	JC	Open
í Factory configured - do not alter	JD	N/A
í Clock battery enabled	JE	Closed
Clock battery disabled	JE	Open
í NPU enabled	SW0/5	Off
NPU disabled	SW0/5	On
í Serial interface select 8250	SW0/6	On
Serial interface select 8350	SW0/6	Off
í BIOS type select 2732	SW0/8	On
BIOS type select 2764	SW0/8	Off
í Disk drive select 96 TPI	SW1/1	Off
Disk drive select 48 TPI	SW1/1	On
í Disk drive select fast start-up	SW1/2	Off
Disk drive select slow start-up	SW1/2	On

DRAM CONFIGURATION				
Size	Bank 0	Bank 1	Bank 2	Bank 3
128KB	(9) 4164	(9) 4164	NONE	NONE
256KB	(9) 4164	(9) 4164	(9) 4164	(9) 4164
512KB	(9) 4464	(9) 4464	NONE	NONE
640KB	(9) 4164	(9) 4164	(9) 41256	(9) 41256

DRAM SWITCH CONFIGURATION				
Size	SW0/1	SW0/2	SW0/3	SW0/4
128KB	Off	On	On	On
256KB	On	Off	On	On
512KB	On	On	Off	On
640KB	Off	On	Off	On

VIDEO CONFIGURATION		
Size	SW1/5	SW1/6
80 columns	On	Off
40 columns	Off	On


HARD DRIVE CONFIGURATION		
Setting	SW1/3	SW1/4
Enabled	Off	Off
Disabled	On	On

Continued on next page ...

AT & T, INC.
6300 XT

... continued from previous page

FLOPPY DRIVE CONFIGURATION		
Drives installed	SW1/7	SW1/8
1	On	On
2	Off	On



CRT CONTROLLER BOARD CONNECTIONS			
Purpose	Location	Purpose	Location
To bus converter board	J8	Monitor	J12
To system board at J1	J9	To display enhancement board	J13
To bus converter board	J10	+15V Power	P2
To system board at J2	J11		

CRT CONTROLLER BOARD USER CONFIGURABLE SETTINGS		
Function	Jumper	Position
í Oscillator select internal	JF	pins 2 & 3 closed
Oscillator select on display enhancement board	JF	pins 4 & 5 closed
í Clock select internal	JF	pins 5 & 6 closed
Oscillator select 24MHz	JF	pins 1 & 2 closed