



CoreModule™/3SXi

Technical Manual

P/N: 5001131

Revision: C

Ampro Computers, Incorporated
4757 Hellyer Avenue ■ San Jose, CA 95138
Tel (408) 360-0200 ■ FAX (408) 360-0220
WEBSITE: www.ampro.com

NOTICE

DISCLAIMER

Ampro Computers, Incorporated makes no representations or warranties with respect to the contents of this manual or of the associated Ampro software products, and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Ampro shall under no circumstances be liable for incidental or consequential damages or related expenses resulting from the use of this product, even if it has been notified of the possibility of such damages. Ampro reserves the right to revise this publication from time to time without obligation to notify any person of such revisions. If errors are found, please contact Ampro at the address listed on the title page of this document.

TRADEMARKS

The Ampro logo is a registered trademark, and Ampro, Little Board, StackPlane, MiniModule, MiniBackplane, and CoreModule are trademarks of Ampro Computers, Inc. All other marks are the property of their respective companies.

TECHNICAL SUPPORT

- **Telephone technical support is available from 8:00 AM to 5:00 PM, Pacific time. The telephone number is 800 966-5200. (Please have the product you wish to discuss at hand when you call.)**
 - **E-mail address: techsupport@ampro.com**
 - **Web site: <http://www.ampro.com>**
 - **Ampro Technical Support Bulletin Board (BBS): 408 720-1332**
-

REVISION HISTORY

REVISION	REASON FOR CHANGE	DATE
A	Initial Release	1/97
B	Production Release	7/97
C	Update Mech & Environ Specs	7/97

© 1997 AMPRO COMPUTERS INCORPORATED

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of Ampro Computers, Incorporated.

PREFACE

This manual is for designers of systems based on the Ampro CoreModule/3SX*i* CPU, a PC/AT compatible modular computing engine. This manual contains information on hardware requirements and connections, and details about how to program the device and integrate it with other devices to create an embedded system customized to your requirements.

There are three chapters, organized as follows:

- **Chapter 1—Introduction.** General information pertaining to the CoreModule/3SX*i* CPU, its features, and technical specifications.
- **Chapter 2—Configuration and Installation.** A description of the jumper options, connector pinouts, and hardware-related technical information needed to configure and install the module.
- **Chapter 3—Operation.** A description of software-related system features. Includes instructions on how to use the BIOS SETUP feature to configure your system. Includes descriptions of specialized utilities provided with the Development Kit.

TABLE OF CONTENTS

CHAPTER 1—INTRODUCTION

1.1	General Description	1-1
1.2	Features	1-1
1.3	Enhanced Reliability	1-3
1.4	Software	1-4
1.5	Designing CoreModule Systems	1-5
1.5.1	CoreModule Development Chassis	1-5
1.6	CoreModule/3SXi Specifications	1-6
1.6.1	CPU/Motherboard	1-6
1.6.2	Onboard Peripherals	1-6
1.6.3	Embedded-PC System Enhancements.....	1-7
1.6.4	Support Software.....	1-7
1.6.5	Mechanical and Environmental Specifications	1-8

CHAPTER 2—CONFIGURATION AND INSTALLATION

2.1	Introduction	2-1
2.1.1	Interface Connector Summary.....	2-1
2.1.2	Jumper Configuration Options	2-3
2.2	DC Power	2-4
2.2.1	Power Requirements	2-5
2.2.2	Setting the CPU Speed (W8)	2-5
2.2.3	Backup Battery.....	2-5
2.3	DRAM.....	2-6
2.3.1	Shadowing.....	2-6
2.3.2	Expanded Memory and Extended Memory.....	2-6
2.4	Math Coprocessor	2-7
2.5	Serial Ports	2-7
2.5.1	I/O Addresses.....	2-7
2.5.2	Interrupt Assignments.....	2-7
2.5.3	ROM-BIOS Installation of the Serial Ports	2-8
2.5.4	Serial Port Connectors (J3, J9)	2-8
2.5.5	Configuring Serial 2 for RS-485 (J10, W1, W10)	2-9
2.5.6	RS-485 Twisted-Pair Cabling Using RJ11 Connectors	2-10
2.5.7	Serial Console	2-11
2.5.8	Serial Downloader	2-11
2.6	Multimode Parallel Port	2-11
2.6.1	I/O Addresses.....	2-11
2.6.2	ROM-BIOS Installation of Parallel Ports	2-12
2.6.3	Interrupts.....	2-12
2.6.4	DMA Channels.....	2-12
2.6.5	Parallel Port Connector (J15).....	2-12
2.6.6	IEEE-1284-Compliant Cables.....	2-14

2.7 Floppy Disk Interface	2-14
2.7.1 Floppy Drive Considerations	2-14
2.7.2 Floppy Interface Configuration	2-15
2.7.3 Floppy Interface Connector (J8)	2-15
2.8 IDE Hard Disk Interface	2-16
2.8.1 IDE Connector (J6)	2-17
2.8.2 IDE Cable Adapter	2-18
2.8.3 IDE Interface Configuration	2-18
2.9 Byte-wide Socket	2-19
2.9.1 Addressing the Byte-wide Socket	2-20
2.9.2 Byte-Wide S0's Interaction with the OEM Flash Memory	2-21
2.9.3 Solid State Disk (SSD) Drives	2-22
2.9.4 Jumpering the Byte-Wide Socket	2-22
2.9.5 Using EPROMs	2-23
2.9.6 Using Flash EPROMs	2-24
2.9.7 Using SRAMs	2-25
2.9.8 Byte-Wide Socket Signals	2-25
2.10 Battery-Backed Clock	2-26
2.11 Watchdog Timer	2-27
2.12 Utility Connector (J5)	2-27
2.12.1 Speaker Connections	2-28
2.12.2 Push-button Reset Connection	2-28
2.12.3 Keyboard Connections	2-29
2.12.4 External Battery Connections	2-29
2.13 AT Expansion Bus	2-29
2.13.1 On-board MiniModule Expansion	2-30
2.13.2 Using Standard PC and AT Bus Cards	2-30
2.13.3 Bus Expansion Guidelines	2-30
2.13.4 Expansion Bus Connector Pinouts	2-32

CHAPTER 3—OPERATION

3.1 Introduction	3-1
3.2 SETUP Overview	3-1
3.3 SETUP Page 1—Standard (CMOS) SETUP	3-4
3.3.1 Date and Time	3-4
3.3.2 Floppy Drives	3-5
3.3.3 IDE Hard Disk Drives	3-5
3.3.4 Video	3-6
3.3.5 DRAM Memory	3-6
3.3.6 Error Halt	3-6
3.3.7 Video Shadow RAM	3-7
3.3.8 System POST	3-7
3.4 SETUP Page 2—Options/Peripheral Configuration	3-8
3.4.1 Extended BIOS	3-8
3.4.2 Advanced Power Management BIOS	3-9
3.4.3 Serial Ports	3-9
3.4.4 Parallel Port	3-9

3.4.5 Floppy Interface Enable.....	3-10
3.4.6 IDE Interface Enable	3-10
3.4.7 Mono/Color Selection.....	3-11
3.4.8 Hot Key Setup Enable	3-11
3.4.9 Video State.....	3-11
3.4.10 Blank Post Test	3-11
3.4.11 Byte-wide Socket and OEM Flash Configuration	3-12
3.4.12 Serial Boot Loader Enable	3-12
3.4.13 Watchdog Timer Configuration	3-12
3.5 SETUP Page 3—SCSI Hard Disk.....	3-14
3.5.1 SCSI Drive Parameter Setup.....	3-15
3.6 SETUP Page 4—Serial Console	3-17
3.7 The SETUP.COM Program.....	3-19
3.7.1 Creating Configuration Files with SETUP.COM	3-19
3.8 Operation with DOS.....	3-20
3.9 Serial Ports	3-21
3.9.1 Using the RS-485 Interface.....	3-21
3.9.2 Serial Console Features	3-22
3.9.3 Serial Booting and Serial Programming	3-24
3.9.4 Using a Serial Modem	3-24
3.10 Enhanced Parallel Port.....	3-25
3.10.1 Standard and Bi-Directional Operation (SPP)	3-26
3.10.2 EPP and ECP Operation	3-29
3.11 Byte-Wide Socket	3-30
3.11.1 Accessing the Byte-Wide Socket and OEM Flash Device.....	3-30
3.11.2 Accessing Large Devices	3-31
3.11.3 Flash EPROM Programming.....	3-32
3.12 SCSI Controller	3-33
3.12.1 The Ampro SCSI BIOS.....	3-33
3.13 PC Speaker	3-33
3.14 Watchdog Timer	3-34
3.15 Powerfail Monitor.....	3-35
3.16 System Memory Map	3-35
3.17 System I/O Map	3-36

FIGURES

Figure 1–1. Mechanical Dimensions	1–9
Figure 1–2. Block Diagram	1–10
Figure 2–1. Connector and Jumper Locations	2–3
Figure 2–2. Serial 2 Interface Selection	2–9
Figure 2–3. DMA Channel Selection (W5, W6).....	2–12
Figure 2–4. Using 28- and 32- pin Devices in 32-pin Sockets	2–20
Figure 2–5. Stacking PC/104 Modules with the CoreModule/3SX <i>i</i> CPU	2–30
Figure 3–1. SETUP Page 1.....	3–4
Figure 3–2. SETUP Page 2.....	3–8
Figure 3–3. SETUP Page 3.....	3–14
Figure 3–4. SETUP Page 4.....	3–18
Figure 3–5. RS-485 Interface Wiring.....	3–22

TABLES

Table 1–1. Summary of SETUP Options.....	1–4
Table 2–1. Connector Usage Summary	2–2
Table 2–2. Configuration Jumper Summary	2–4
Table 2–3. J7 Power Connector	2–4
Table 2–4. J7 Mating Connectors	2–5
Table 2–5. Serial Port I/O Addresses and Interrupts	2–7
Table 2–6. Serial Port Connectors (J3, J9).....	2–8
Table 2–7. J3 and J9 Mating Connector.....	2–8
Table 2–8. RS-485 Termination using W10.....	2–9
Table 2–9. RS-485 Serial Port 2 Connector (J10)	2–10
Table 2–10. J10 Mating Connector.....	2–10
Table 2–11. J10/RJ11 Cable Wiring	2–10
Table 2–12. Parallel Port Address Configuration.....	2–11
Table 2–13. Parallel Port Connector (J4).....	2–13
Table 2–14. J4 Mating Connector.....	2–13
Table 2–15. Supported Floppy Formats	2–14
Table 2–16. Floppy Disk Interface Connector (J8).....	2–16
Table 2–17. J8 Mating Connector.....	2–16
Table 2–18. IDE Drive Interface Connector (J6)	2–17
Table 2–19. J6 Mating Connector.....	2–18
Table 2–20. Typical Byte-wide Devices	2–19
Table 2–22. Window Size and Address Selection	2–20
Table 2–23. EPROM Jumpering for S0.....	2–23
Table 2–24. Flash EPROM Jumpering for S0	2–24
Table 2–25. SRAM and NOVRAM Jumpering for S0.....	2–25
Table 2–26. Byte-Wide Jumper Pin Signals (W3).....	2–26
Table 2–27. Watchdog Timer Setup	2–27
Table 2–28. Utility Connector (J5).....	2–28
Table 2–29. J5 Mating Connector.....	2–28
Table 2–30. Keyboard Connector (J5).....	2–29
Table 2–31. AT Expansion Bus Connector, A1-A32 (P1)	2–33

Table 2-32. AT Expansion Bus Connector, B1-B32 (P1)	2-34
Table 2-33. AT Expansion Bus Connector, C0-C19 (P2)	2-35
Table 2-34. AT Expansion Bus Connector, D0-D19 (P2).....	2-36
Table 2-35. Interrupt Channel Assignments	2-37
Table 2-36. DMA Channel Assignments.....	2-38
Table 3-1. Functions on Each SETUP Page	3-2
Table 3-2. Serial Port Resources	3-9
Table 3-3. Parallel Port Resources	3-9
Table 3-4 Parallel Port Modes.....	3-10
Table 3-5. Floppy Controller Resources	3-10
Table 3-6. IDE Controller Resources.....	3-11
Table 3-7. Byte-Wide Memory and Onboard Flash Configuration.....	3-12
Table 3-8. SETUP.COM Command Switches	3-19
Table 3-9. Required Serial Console Commands	3-23
Table 3-10. Parallel Port Register Map.....	3-25
Table 3-11. Parallel Port Use	3-27
Table 3-12. Parallel Port Register Bits	3-28
Table 3-13. Standard and PS/2 Mode Register Bit Definitions.....	3-29
Table 3-14. Segment Addressing in Large Memory Devices	3-32
Table 3-15. CoreModule/3SXi Memory Map.....	3-36
Table 3-16. CoreModule/3SXi I/O Map	3-37

CHAPTER 1

INTRODUCTION

1.1 GENERAL DESCRIPTION

The CoreModule/3SX*i* CPU is an exceptionally high integration, high performance, 386SX-based PC/AT compatible system in the PC/104 form factor. This rugged and high quality single-board system contains all the component subsystems of a PC/AT motherboard plus the equivalent of several PC/AT expansion boards.

Key functions included on the CoreModule/3SX*i* module are CPU, RAM, embedded-PC BIOS, keyboard and speaker interfaces, two serial ports, a multimode IEEE-1284 enhanced parallel port, floppy drive controller and IDE hard disk controller. In addition, the CoreModule/3SX*i* CPU includes a comprehensive set of system extensions and enhancements that are specifically designed for embedded systems. It is designed to meet the size, power consumption, temperature range, quality, and reliability demands of embedded applications.

Among the many embedded-PC enhancements that ensure fail-safe embedded system operation are a watchdog timer and an onboard bootable "solid state disk" (SSD) capability. The unit requires a single +5 Volt power source and offers "green PC" power-saving modes under support of Advanced Power Management (APM) BIOS functions (APM Release 1.1-compliant).

The CoreModule/3SX*i* CPU is particularly well suited to demanding environments such as embedded or portable applications. The flexibility of the CoreModule/3SX*i* CPU makes system design quick and easy. Stack it with Ampro MiniModules™ or other PC/104-compliant expansion modules, use the Ampro MiniBackplane and ordinary plug-in cards, or use it as the computing engine in a fully customized application.

1.2 FEATURES

CPU/Motherboard

The CoreModule/3SX*i* CPU implements a fully PC-compatible motherboard architecture, with an 80386SX CPU running at 25 MHz.

The standard DRAM compliment of the CoreModule/3SX*i* CPU is 2M bytes, soldered on the board. A model with 4M bytes is also available. For DRAM expansion, you can order an Ampro custom memory module which allows you to add an additional 4M bytes.

Serial Ports

The board provides two PC-compatible RS-232C serial ports, implemented using 16C550-type UARTs. These UARTs are equipped with 16-byte FIFO buffers to improve throughput. Baud rates up to 115K baud are supported. Onboard voltage converters provide the RS-232C voltage levels from the +5 volt supply.

The second serial port can be configured for either RS-232C or RS-485. RS-485 uses a bi-directional differential-pair signaling scheme. RS-485 is generally used for a serial bus. Up to 32 nodes can be bussed together, sharing a single twisted-pair cable.

Parallel Port

An enhanced bi-directional parallel port interface conforms to the IEEE-1284 standard. It provides new features attractive to embedded system designers, including increased speed, an internal FIFO buffer, and DMA transfer capability.

Floppy Interface

An onboard floppy disk interface provides access to standard floppy drives. The interface supports up to two floppy drives, 5.25 inch or 3.5 inch, in any combination.

IDE Interface

An onboard IDE interface provides hard disk and CD-ROM drive access. The interface supports up to two drives. The BIOS supports hard drives greater than 528 M bytes through Logical Block Addressing (LBA).

Enhanced Embedded-PC BIOS

One of the most valuable features of the CoreModule/3SXi CPU is its enhanced embedded-PC BIOS, which includes an extensive set of functions that meet the unique requirements of embedded system applications. These enhancements include:

- Solid State Disk (SSD) support (see below)
- SCSI services—full SCSI BIOS services are integrated with the module's hard disk support
- Watchdog timer—monitors the boot process and provides a watchdog function call for applications
- Fast boot operation—normal or accelerated POST, selectable by SETUP options
- Configurable POST display—select what will be displayed at boot time
- Fail-safe boot support—intelligently retries boot devices until successful
- Battery-free boot support—saves system SETUP information in non-volatile EEPROM
- Serial console option—lets you use a serial device as a console
- Serial loader option—supports loading boot code from an external serial source
- EEPROM access function—512 bits of EEPROM storage available to user; useful for serialization, copy protection, security, etc.
- OEM customization hooks—can execute custom code prior to system boot via ROM extensions; allows sophisticated system customization without BIOS modification

Modular PC/104 Expansion Bus

The CoreModule/3SXi CPU provides a PC/104-compatible expansion bus for additional system functions. This bus, a compact version of the standard PC ISA bus, offers compact, self-stacking, modular expandability. The growing list of PC/104 modules available from Ampro and hundreds of other PC/104 vendors includes such functions as communications interfaces, LAN interfaces, video framegrabbers, digital signal processors (DSPs), data acquisition and control functions, and many specialized interfaces and controllers.

In addition, you can mount the CoreModule/3SXi CPU on your own custom application-specific base board using its PC/104 expansion bus interface as a rugged and reliable interconnect. This eliminates the need for you to design a PC engine for your product and facilitates easy upgrades and troubleshooting.

Byte-Wide Socket and Solid State Disk (SSD)

An important feature of the CoreModule/3SX*i* CPU is its byte-wide memory socket, in which you can install a bootable "solid state disk" (SSD) or other embedded application software.

An SSD substitutes EPROMs, Flash EPROMs, battery-backed SRAMs, or Non-Volatile RAM (NOVRAM) modules for conventional rotating-media drives. Using Ampro's SSD/DOS Support Software, any DOS-based application, including the operating system, utilities, drivers, and application programs, can be run from SSD without modification. SSD operation is also supported by a growing number of real-time operating systems.

The module's 32-pin byte-wide socket is configurable for nearly every available 28-pin and 32-pin byte-wide memory device. The socket supports all varieties of devices, CMOS SRAM, SRAM non-volatile modules, EPROM, and Flash EPROM. It accommodates devices from 32K bytes to 1M byte and larger using a simple memory-paging scheme implemented with custom BIOS calls.

To support the use of 12 volt Flash memory devices in the byte-wide socket, the board is equipped with an onboard 5 volt to 12 volt converter.

OEM Flash Memory

The system BIOS is stored in a portion of an onboard Flash memory device. The remaining part of the Flash memory device can be used by OEMs for embedded software. Ampro provides a utility for programming this memory. The onboard Flash memory device is accessed as a second byte-wide memory device, using the same custom BIOS calls provided in Ampro's extended BIOS that are used to access the byte-wide memory socket.

Two models of the CoreModule/3SX*i* are available. One has a 128K byte onboard Flash memory device, 64K bytes of which are used for the ROM BIOS, and the remaining 64K bytes available for OEM Flash memory. Another version comes equipped with a 1M byte Flash memory device, with all but 64K bytes available for OEM use. This larger version permits using the OEM Flash memory with Ampro's SSD/DOS to create a read-only solid state disk for the operating system and application programs. Or, using OEM Flash True Flash File system (TFFS), you can create a solid state disk with full read/write capability.

1.3 ENHANCED RELIABILITY

Reliability is especially important in embedded computer systems. Ampro, specializing in embedded system computers and peripherals, knows that embedded systems must be able to run reliably in rugged, hostile, and mission-critical environments without operator intervention. Over the years, Ampro has evolved system designs and a comprehensive testing program to ensure a reliable and stable system for harsh and demanding applications. These include:

ISO 9001 Manufacturing. Ampro is a certified ISO 9001 vendor.

Regulatory testing. Knowing that many embedded systems must qualify under ESD, EMC emissions, and susceptibility testing, Ampro designs boards with careful attention to EMI issues. Boards are tested in standard enclosures to ensure that they can pass such tests. Tests include CE MARK directives EMC EN55022 and EN55011, ESD EN 61000-4-4, RF susceptibility ENV 50140, EFT EN 61000-4-5, and conducted emissions at US voltages per FCC Subpart 15.

Wide-range temperature testing. Ampro Engineering qualifies all of its designs by extensive thermal and voltage margin testing.

Shock and Vibration Testing. Boards intended for use in harsh environments are tested for shock and vibration durability to MIL-STD 202F, Method 214A, Table 214I, Condition D at 5 minutes per axis for random vibration, and to MIL-STD 202F, Method 213B, Table 213-1, Condition A for resistance to mechanical shock. (Contact your Ampro sales representative to obtain *Shock and Random Vibration Test Report for the CoreModule/3SXi CPU* for details.)

1.4 SOFTWARE

The vast array of commercial and public-domain software for the IBM PC and PC/AT is usable in CoreModule/3SXi CPU based systems. You can use the most popular software development tools (editors, compilers, debuggers, etc.) for developing code for your application. With this software and the standard Ampro-supplied utilities and drivers, you can quickly tailor a system to your needs.

Use the board's SETUP function for all system configuration. SETUP can be invoked using a "hot-key" combination (CTRL-ALT-ESC) or from the DOS command line using a utility program, SETUP.COM, available on the Common Utilities diskette. Table 1-1 summarizes the configuration parameters you can modify using SETUP.

Table 1-1. Summary of SETUP Options

- Date and time in the battery-backed real-time clock
- Floppy drive quantity and type
- IDE Hard disk drive quantity and type
- Video controller type (for an external video controller)
- Serial port enable/disable
- Parallel port enable/disable/mode
- Byte-wide socket address and size
- OEM Flash memory address and size
- Serial console option
- Video BIOS Shadow RAM enable
- SCSI disk drive parameters (using Ampro SCSI adapter)
- DOS hard disk map
- Choice of default boot drive (hard disk or floppy)
- Enable/Disable *hot-key* access to SETUP
- Watchdog timer startup time-out
- Serial loader enable/disable/port selection
- POST speed options
- POST screen display and blanking options

SETUP information is stored in both the battery-backed CMOS RAM-portion of the real-time clock, and in a configuration EEPROM. For a complete discussion of SETUP, see Chapter 3.

1.5 DESIGNING COREMODULE SYSTEMS

The CoreModule/3SXi CPU affords a great deal of flexibility in system design. You can build a system using only the CoreModule, serial or parallel devices for input/output, and a Solid State Disk drive in the byte-wide socket or OEM Flash device.

Self-stacking Modules—The simplest way to expand a CoreModule system is with self-stacking Ampro MiniModules. MiniModules are available for a wide variety of functions. There are MiniModules that provide video interfaces, from monochrome through Super VGA, including flat panel displays. Other MiniModules provide additional serial and parallel ports, Ethernet LAN adapter, PCMCIA interface, sound card, and other functions. You can stack the MiniModules with the CoreModule and avoid the need for bus cables, card cages, and backplanes.

MiniModules mount directly on the PC/104 bus connector of the CoreModule. PC/104-compliant modules can be stacked with an inter-board spacing of ~0.66 inches. Thus, a 3-module system fits in a 3.6 inch by 3.8 inch by 2.4 inch space. A complete description of self-stacking options with various Ampro MiniModules and other PC/104-compatible modules can be found in Ampro Application Note AAN-9402, available from Ampro.

MiniBackplane Systems—You can also use a CoreModule/3SXi system with an Ampro MiniBackplane and standard PC/AT plug-in cards. Using the MiniBackplane, two standard cards can be added.

OEM Motherboard—You can add the CoreModule/3SXi CPU as the computing engine to a dedicated OEM logic or interface board. Compatible connectors can be arranged on the OEM “motherboard”, and the CoreModule/3SXi CPU can be mounted directly on these connectors. Not only does this eliminate the need for OEMs to design their own CPU subsystem, but it also allows for substitution of new models as technology changes, without requiring an expensive redesign of the motherboard.

1.5.1 CoreModule Development Chassis

Whatever your CoreModule application, there will always be a need for an engineering development cycle. To help developers quickly assemble an embedded system, Ampro offers the CoreModule Development Chassis. It includes a power supply, floppy disk drive, hard disk, a StackPlane/AT (for mounting the CoreModule and additional MiniModules or other PC/104-compliant modules), speaker, I/O connectors, and a two-slot PC backplane.

The Development chassis provides a “known good” environment for your development work. You can install the CoreModule/3SXi CPU, MiniModules or conventional expansion boards, keyboards, monitors, and I/O devices to quickly create a platform for your hardware and software engineering needs. Often, development chassis are used in repair and support facilities as well, and on the production floor for system test. Contact your Ampro sales representative for information.

1.6 COREMODULE/3SXi CPU SPECIFICATIONS

The following section provides technical specifications for the CoreModule/3SXi CPU.

1.6.1 CPU/Motherboard

- CPU: 25 MHz 386SX

- System RAM: 2M or 4M bytes DRAM (soldered on the board)
 - Provision for an Ampro custom 4M byte memory module
 - Supports up to 8M bytes of DRAM, 4M bytes onboard plus one 4M byte memory module.
- Shadow RAM support provides fast system and video BIOS execution
- 14 interrupt channels (8259-equivalent) (IRQ12 is not supported.)
- 7 DMA channels (8237-equivalent)
- 3 programmable counter/timers (8254-equivalent)
- Standard PC/AT keyboard port
- Standard PC speaker port with .1 watt output drive
- Battery-backed real-time clock and CMOS RAM, with support for battery-free operation
- Award ROM BIOS with Ampro embedded-system extensions

1.6.2 Onboard Peripherals

This section describes standard peripherals found on every CoreModule/3SXi CPU.

- Two buffered serial ports with full handshaking
 - Implemented with 16550-equivalent controllers with built-in 16-byte FIFO buffers
 - Onboard generation of RS-232C signal levels
 - The second port supports RS-485
 - Logged as COM1 and COM2 by DOS. May be disabled using SETUP.
- Multimode Parallel Port
 - Superset of standard LPT printer port
 - Bi-directional data lines
 - IEEE-1284 (EPP/ECP) compliant
 - Standard hardware supports all four IEEE-1284 protocol modes
 - Internal 16-byte FIFO buffer
 - DMA option for data transfers

- Floppy Disk Controller
 - Supports one or two drives
 - Reliable digital phase-locked loop circuit
 - Supports all standard PC/AT formats: 360K, 1.2M, 720K, 1.44M
- IDE Disk Controller
 - Standard PC-compatible IDE hard disk controller
 - Supports up to two devices, generally hard disk drives or CD-ROM drives. (CD-ROM drives require a driver.)
 - BIOS supports drives larger than 528 M bytes through Logical Block Addressing (LBA)

1.6.3 Embedded-PC System Enhancements

- 32-pin byte-wide memory socket:
 - Usable with 32K to 1M byte byte-wide memory devices, including EPROMs, Flash EPROMs, SRAMs, and NOVRAMs (Non-volatile RAMs)
 - Backup battery automatically converts SRAM to NOVRAM
 - Onboard programming of 5 V and 12 V Flash EPROMs
 - Configurable as 64K or 128K byte window, addressed in the range of D0000h to EFFFFh
 - Usable with DiskOnChip read/write Flash memory device
 - Supports a PCMCIA memory card connection via an Ampro Memory Card Adapter
 - Supported by Ampro SSD Support Software and many third-party operating systems
 - OEM Flash Memory—an additional 64K (or 960K by special order) of onboard Flash memory for OEM use. Operates like a second byte-wide socket.
- 2K-bit configuration EEPROM:
 - Stores system SETUP parameters
 - Supports battery-free boot capability
 - 512 bits are available for OEM use
- Watchdog Timer
 - Utilizes the onboard real-time clock alarm function
 - Timeout triggers a hardware reset or non-maskable interrupt

1.6.4 Support Software

- Enhanced Embedded-PC BIOS Features:
 - Solid State Disk (SSD) support
 - SCSI services (supports SCSI interfaces found on Ampro MiniModule boards.)
 - Watchdog timer (WDT) support

- Fast boot and blank POST options
- Fail-safe boot logic
- Battery-free boot
- Serial console option
- Serial loader option
- EEPROM access function
- BIOS OEM customization hooks

See the Ampro Embedded-PC BIOS data sheet for additional details about these features.

- Software Utilities Included
 - SETUP utility
 - Watchdog timer support
 - Serial access and development support

1.6.5 Mechanical and Environmental Specifications

- Dimensions:
 - Board Envelope: 3.6 x 3.8 x 0.92 inches (90.2 x 95.9 x 23.4 mm.). Refer to Figure 1–1 for mounting dimensions.
 - Board-to-board spacing: 0.6 inches (15.2 mm.)
- Provision for system expansion with one or more Ampro MiniModule products or other PC/104 expansion modules.
- Power requirements (typical, with 4M bytes DRAM installed):
 - 25 MHz configuration: 450MA at +5V ±5%
 - Standby power mode: 240MA at +5V ±5%
- Operating environment:
 - Standard: 0° to 70° C (with adequate airflow)
 - Extended temperature range can be tested by special order. Contact Ampro for details.
 - 5% to 95% relative humidity (non-condensing)
- Storage temperature: -55° to +85° C
- Weight:
 - 3.4 Oz. (95 gm)
- PC/104 expansion bus
 - Stackthrough 16-bit bus connectors, for expansion via PC/104 Version 2 "double-stackthrough" (DST) modules
 - Four mounting holes
- 6-layer PCB using latest surface mount technology

Note

Contact Ampro regarding custom configurations and special order options.




Figure 1-1. Mechanical Dimensions




Figure 1-2. Block Diagram

CHAPTER 2

CONFIGURATION AND INSTALLATION

2.1 INTRODUCTION

This chapter covers configuration and installation of the CoreModule/3SXi CPU. It includes the board's connector signals and pinouts, external device requirements, interconnection cable wiring, and jumper configuration options.

The topics covered in this chapter are:

- Power Connector
- DRAM memory
- RS-232C/RS-485 serial ports
- Enhanced parallel port
- Floppy disk interface
- IDE hard disk interface
- 32-pin byte-wide socket
- OEM Flash memory
- Utility connector (Keyboard, PC speaker, reset button, external battery)
- Watchdog timer
- Battery-backed clock
- PC/104-compatible expansion bus

2.1.1 Interface Connector Summary

Refer to Figure 2-1 for the locations of the connectors (P1, P2, J3 - J10) and configuration jumpers (W1 - W9).

Table 2-1 summarizes the use of the I/O connectors and Table 2-2 summarizes use of the configuration jumpers.

Each interface is described in its own section, showing connector pinouts, signal definitions, required mating connectors, and configuration jumper options.

Many of the connectors have a *key pin* removed. This allows you to block the corresponding cable connector socket to help prevent improper assembly. Table 2-1 indicates which pins are key pins, and Figure 2-1 shows their locations.

Table 2–1. Connector Usage Summary

Connector	Function	Size	Key Pin
P1A/B	PC/104 Expansion Bus	64-Pin	B10
P2C/D	PC/104 Expansion Bus	40-pin	C19
J3	Serial 1	10-pin	10
J4	Parallel Port	26-pin	26
J5	Utility/Keyboard	10-pin	None
J6	IDE Hard Disk Interface	44-pin 2 mm	20
J7	Power, +5V; +12V, -12V, and -5V to PC/104 Bus	8-pin	None
J8	Floppy Disk Interface	34-pin	6
J9	Serial 2, RS-232C	10-pin	10
J10	Serial 2, RS-485	2-pin	None


Connectors

Most of the I/O connectors are dual-row headers for use with insulation displacement connectors (IDC) and flat ribbon cable. J5 is usually implemented with discrete wires rather than flat ribbon cable. J10 is a 2-pin connector for an RS-485 twisted-pair cable.

A number of the connectors have “key pins”. Install a blocking key in the corresponding connector socket on the mating ribbon cable to prevent misalignment.

You can design a PC board assembly, made with female connectors in the same relative positions as the CoreModule’s connectors, to eliminate cables, meet packaging requirements, add EMI filtering, or customize your installation in other ways.

The PC/104-compatible expansion bus appears on two connectors (P1 and P2). You can expand the system with Ampro MiniModule products or other PC/104-compliant expansion modules. These modules stack directly on the P1 and P2 connectors, or you can use conventional or custom expansion hardware, including solutions available from Ampro. Contact your Ampro sales representative for information about alternatives offered by Ampro.



(Key pins on connectors are shaded.)

Figure 2–1. Connector and Jumper Locations

2.1.2 Jumper Configuration Options

Ampro installs option jumpers in default positions so that in most cases the CoreModule/3SXi CPU requires no special jumpering for standard operation. You can connect the power and peripherals and operate it immediately. The only jumpers of concern are those that configure the byte-wide socket for the device you install.

Jumper-pin arrays are designated W1, W2 and so forth. Jumper pins are spaced 2 mm apart. A square solder pad identifies pin 1 of each jumper array. Table 2–2 is a summary of jumper use. In the Default column, two numbers separated by a slash (for example, 1/2) means that pins 1 and 2 are shorted with a 2 mm jumper block.

Table 2–2. Configuration Jumper Summary

Jumper Group	Function	Default	Description
W1	RS-232C/RS-485 Select	1/2	1/2=RS-232C; 2/3=RS-485
W2	BIOS/OEM Flash programming power enable	Off	Vpp for Flash EPROM programming
W3	Byte-Wide Socket Configuration		See “Jumpering the Byte-Wide Socket” in Chapter 2
W4	Watchdog Timer Output Selection	Off	See “Watchdog Timer” on Page 2–27.
W5	DMA ACK1/ACK3	Off	Parallel port DMA ACK select
W6	DMA REQ1/REQ3	Off	Parallel port DMA REQ select
W7	Byte-Wide Backup Power Select	1/2	(1/2) enables external battery backup for S0
W8	Byte-Wide Battery Backup Power	Off	On enables backup for S0
W9	BIOS/Byte-Wide Swap	On	Off enables access of a system BIOS from S0.
W10	RS-485 Termination	Off	On for 100 ohm terminator

2.2 DC POWER

To power the module and to supply power to the PC/104 expansion bus, connect the voltages you need for your system to J7. Refer to Table 2–3 for power connections and Table 2–4 for mating connector information.

Table 2–3. J7 Power Connector

Pin	Connection
1, 7	Ground
2, 8	+5VDC
4	+12VDC
5	-5VDC
6	-12VDC

Table 2–4. J7 Mating Connectors

Connector Type	Mating Connector
Discrete Wire, 8-pin	MOLEX Housing 22-55-2081 Pin 16-02-0103

2.2.1 Power Requirements

The CoreModule/3SXi CPU requires only +5VDC ($\pm 5\%$) for operation. The ± 9 volts for the RS-232 ports is generated onboard from the +5VDC supply.

The module is equipped with a +5 volt to +12 volt voltage converter circuit for programming 12 volt Flash EPROMs. The supply is switched electronically, controlled by the FLASHWRI program (supplied with the CoreModule/3SXi CPU Development Kit). Note that this supply is not intended to supply 12 volts to peripherals, and is not connected to the 12 volt input pin on the power connector or on the PC/104 connector. There may be a requirement for an external +12 volt supply, depending on what peripherals you connect to the CoreModule system.

The exact power requirement of the CoreModule/3SXi CPU system depends on several factors, including the quantity of DRAM, installed byte-wide memory device, the peripheral connections, and which, if any, MiniModule products or other expansion boards are attached to the PC/104 bus. For example, AT keyboards draw their power from the board, and there can be some loading from the serial and parallel ports. Consult the specifications in Chapter 1 for the basic power requirements of your model.

If you use a switching power supply, be sure it regulates properly with the load your system draws. Some switching power supplies do not regulate properly unless they are loaded to some minimum value. If this is the case with your supply, consult the manufacturer about additional loading, or use another supply or another type of power source (such as a linear supply, batteries, etc.).

2.2.2 CPU Speed

The CPU speed is fixed at 25MHz. There is no user adjustment.

2.2.3 Backup Battery

You can add an external 3.6 volt lithium battery to the Utility Connector, J5, to power the onboard real-time clock and to back up an SRAM installed in the byte-wide socket. Connect the positive terminal to J5-9 and the negative terminal to J5-1.

Here is the formula for calculating battery life (in hours):

$$\text{Battery life} = (\text{battery mA-hour specification} \div (1 \text{ uA} + \text{SRAM backup current})) \times \text{Duty Cycle}$$

The real-time clock battery drain is approximately 1 uA. To calculate battery life, divide the battery rating by the sum of the clock current and the SRAM current. Then, multiply that result by the duty cycle of the battery. That is, estimate the percentage of time the battery supplies power (while the system is off).

2.3 DRAM

Standard boards have 2M or 4M bytes of DRAM installed on the board. There is also a position for an Ampro custom memory module which currently allows adding 4M bytes of additional DRAM. Contact your Ampro sales representative for the latest information about Ampro's custom memory modules.

When the system boots, the BIOS measures the amount of memory installed and configures the internal memory controller for that amount. (No jumpering or manual configuration is required.) The amount of memory the BIOS measured can be displayed by running SETUP. Saving SETUP automatically stores this figure in the Configuration Memory.

Note

If you change the amount of memory installed, you must run SETUP again to save the new value in the Configuration Memory.

Onboard memory is allocated as follows (standard for the PC architecture):

- The first 640K bytes of DRAM are assigned to the DOS region 00000h to 9FFFFh.
- DRAM in the top 384K bytes of the first 1M byte is not available for user programs. DRAM is mapped into the top 64K to shadow the ROM BIOS. DRAM can also be mapped into a portion of this region to shadow a video BIOS (a SETUP option). (Shadowing is described in the following section.)
- The remaining memory is mapped to extended memory starting at the 1M byte boundary.

2.3.1 Shadowing

One way to improve system performance is to “shadow” the ROM BIOS and video BIOS. When the system operates directly from ROM code, it accesses an 8-bit memory device. When the ROM contents are shadowed, the contents are copied into system DRAM where they are accessed as 16-bit wide data. Shadowing a BIOS ROM substantially enhances system performance, especially when an application or operating system repeatedly accesses the ROM. ROM BIOS shadowing is built into the Ampro Extended BIOS. There is no user setting. Shadowing the video BIOS is a SETUP option. For information about how to set the video BIOS shadowing option, refer to the SETUP section in Chapter 3.

2.3.2 Expanded Memory and Extended Memory

Memory above the 1 megabyte boundary is called “extended” memory. It is a contiguous linear block of memory. Some programs require that memory be available as “expanded” (or “EMS”) memory, which makes memory available as pages rather than as a contiguous block. The exact manner for accessing expanded memory is defined in the EMS LIM 4.0 specification.

You can convert the board's extended memory into expanded memory using DOS EMS emulation utilities. Current versions of DOS provide EMS emulation utilities (such as EMM386) that conform to the LIM 4.0 specification. Refer to your DOS technical documentation for instructions for using their EMS emulation utility.

2.4 MATH COPROCESSOR

The 386SX CPU does not contain a floating point math coprocessor. There are no configuration jumpers or options for a math coprocessor.

2.5 SERIAL PORTS

The CoreModule/3SX*i* module provides two standard RS-232C serial ports at J3 and J9. At your option, the second serial port can be configured as an RS-485 port.

You can use the serial ports for printers, modems, terminals, remote hosts, or other RS-232C serial devices. Many devices, such as printers and modems, require handshaking in one or both directions. Consult the documentation for the device(s) you use for information about handshaking, cabling, and other interface considerations.

Use of the RS-485 option offers a low cost, easy-to-use communications and networking multidrop interface that is ideally suited to a wide variety of embedded applications requiring low-to-medium-speed data transfer between two or more systems.

The serial ports are based on a 16550 UART-compatible controller. This is an advanced UART that has a 16-byte FIFO buffer to improve throughput.

Both serial ports support software selectable standard baud rates up to 115.2K baud, 5-8 data bits, and 1, 1.5, or 2 stop bits. Note that the IEEE RS-232C specification limits the serial port to 19.2K baud on cables up to 50 feet in length.

2.5.1 I/O Addresses

The serial ports appear at the standard port addresses as shown in Table 2-5. These are fixed assignments and cannot be changed. Each serial port, however, can be independently disabled using the SETUP function, freeing its I/O addresses for use by other devices installed on the PC/104 expansion bus. For information about serial port configuration using SETUP, see Chapter 3.

Table 2-5. Serial Port I/O Addresses and Interrupts

Port	I/O Address	Interrupt
Serial 1	3F8h - 3FFh	4
Serial 2	2F8h - 2FFh	3

2.5.2 Interrupt Assignments

As shown in Table 2-5, Interrupt 4 (IRQ4) is assigned to Serial 1 and Interrupt 3 (IRQ3) to Serial 2. These assignments can be disabled, but they cannot be changed. When a serial port is disabled, its IRQ is available to other peripherals installed on the PC/104 expansion bus. For information about disabling the serial ports using SETUP, see Chapter 3.

2.5.3 ROM-BIOS Installation of the Serial Ports

Normally, the ROM BIOS supports Serial 1 as the DOS COM1 device, Serial 2 as the DOS COM2 device, and so on. If you disable a serial port, and there is no substitute serial port in the system, then the ROM-BIOS assigns the COM designations as it finds the serial ports, starting from the primary serial port and searching to the last one. Thus, for example, if Serial 1 is disabled, the ROM-BIOS assigns COM1 to Serial 2 (unless another Serial 1 is discovered). The ROM BIOS scans I/O addresses for serial ports in the following order: 3F8h, 2F8h, 3E8h, 2E8h.

2.5.4 Serial Port Connectors (J3, J9)

Serial 1 appears on connector J3 and Serial 2 appears on connector J9. Table 2–6 gives the connector pinout and signal definitions for both ports. Both connectors are wired the same.

In addition, the table indicates the pins to which each signal must be wired for compatibility with standard DB25 and DB9 connectors. The serial port pinout is arranged so that you can use a flat ribbon cable between the header and a standard DB9 connector. Normally PC serial ports use male “DB” connectors. Table 2–7 shows the manufacturer’s part numbers for ribbon cable mating connectors to J3 and J9.

Table 2–6. Serial Port Connectors (J3, J9)

Pin	Signal Name	Function	In/Out	DB25 Pin	DB9 Pin
1	DCD	Data Carrier Detect	In	8	1
2	DSR	Data Set Ready	In	6	6
3	RXD	Receive Data	In	3	2
4	RTS	Request To Send	Out	4	7
5	TXD	Transmit Data	Out	2	3
6	CTS	Clear to Send	In	5	8
7	DTR	Data Terminal Ready	Out	20	4
8	RI	Ring Indicator	In	22	9
9	GND	Signal Ground	-	7	5
10	N/A	Key pin	-	-	-

Table 2–7. J3 and J9 Mating Connector

Connector Type	Mating Connector
Ribbon	3M 3473-7010
Discrete Wire	MOLEX Housing 22-55-2101 Pin 16-02-0103

2.5.5 Configuring Serial 2 for RS-485 (J10, W1, W10)

Serial 2 provides circuitry for both an RS-232C and RS-485 interface. Using jumpers, you can configure the port to support either interface (but not both at the same time).

The RS-232C interface appears on J9. Table 2–6 shows the pinout for J9. The RS-485 interface appears on the two-pin connector, J10. Table 2–9 shows the pinout for J10.

Figure 2–2 shows how to set W1 to select the output interface for Serial 2.




Figure 2–2. Serial 2 Interface Selection

Note

The RS-485 and RS-232C interfaces share some circuitry. If you configure Serial 2 for RS-485, do not connect a serial device to J9. Similarly, if you configure Serial 2 for RS-232C, do not connect anything to J10.

The RS-485 interface specification requires that both ends of the twisted-pair cable be terminated with 100 ohm resistors. You can terminate the RS-485 interface on J10 with a resistor provided on the CoreModule/3SXi. To terminate the line, install a jumper on W10.

Table 2–8. RS-485 Termination using W10

W10	Result
On	Connects a 100 ohm termination resistor between J10-1 (+I/O) and ground.
Off	No termination

Table 2–9. RS-485 Serial Port 2 Connector (J10)

Pin	Signal Name
1	+I/O
2	-I/O

Table 2–10. J10 Mating Connector

Connector Type	Mating Connector
Discrete Wire (Locking Connector)	MOLEX Housing 22-01-2027 Pin 08-55-0102

For further information about the RS-485 interface, see Chapter 3, Section 3.9 Serial Ports.

2.5.6 RS-485 Twisted-Pair Cabling Using RJ11 Connectors

Connector J10 is used for an RS-485 twisted-pair connection. In RS-485 multidrop installations, standard RJ11 modular telephone connector jacks are often used to attach standard twisted-pair cables between systems.

RJ11 modular connectors have 6 available contact positions, but only 4 are populated. The 4 center conductors are wired so that the two outside and the two inside conductors are connected together. This eliminates any confusion about pin numbering conventions, as a reversal of connections has no effect. In addition, the lines have been chosen to minimize the possibility of circuit damage should the unit be accidentally plugged into a standard telephone outlet. (It sets the phone line to its “offhook” state to prevent the phone from ringing.)

The recommended wiring for a J10-to-RJ11 cable is shown in Table 2–11.

Table 2–11. J10/RJ11 Cable Wiring

J10 Pin	RJ11 Pin	Signal	Standard Wire Color
	1	N/C	
2	2	- I/O Signal	Black
1	3	+ I/O Signal	Red
1	4	+ I/O Signal	Green
2	5	- I/O Signal	Yellow
	6	N/C	

When connecting the RS-485 port into a multidrop network, the devices at the ends of the network should be terminated with a 100 ohm resistor. Installing a jumper on W10 connects a termination resistor across the RS-485 line on the CoreModule/3SXi.

2.5.7 Serial Console

Unique to Ampro is ROM BIOS support for using a serial console (keyboard and display) in place of the conventional video controller, monitor, and keyboard. See Chapter 3 for an explanation of the serial console option.

2.5.8 Serial Downloader

Also unique to Ampro is ROM BIOS support for downloading a program from a host computer via a serial port. The downloaded program is then run as if it had been loaded from disk. See Chapter 3 for an explanation of the serial download option.

2.6 MULTIMODE PARALLEL PORT

The CoreModule/3SX*i* incorporates a multimode parallel port. This port supports four modes of operation:

- Standard PC/AT printer port (output only)
- PS/2-compatible bi-directional parallel port (SPP)
- Enhanced Parallel Port (EPP)
- Extended Capabilities Port (ECP)

See “Multimode Parallel Port” in Chapter 3 for a description of the parallel port’s modes.

This section lists the pinout of the parallel port connector and describes how to configure it for its I/O port and interrupt assignments, and how to assign a DMA channel to the port when operating in ECP mode. Refer to Chapter 3 for programming information, including how to use the port for bi-directional I/O.

2.6.1 I/O Addresses

The parallel port functions are controlled by eight I/O ports and their associated register and control functionality. By enabling the parallel port in SETUP, you configure the parallel port as the primary port (typically LPT1). You may disable the port to free the hardware resources for other peripherals.

Table 2–12 lists the parallel port addresses.

Table 2–12 Parallel Port Address Configuration

Selection	I/O Address
Primary	378h - 37Fh
Disable	None

For details about the parallel port I/O addresses and the data, status, control, EPP, and ECP port bit definitions, refer to the Parallel Port section in Chapter 3.

2.6.2 ROM-BIOS Installation of Parallel Ports

Normally, the BIOS assigns the name LPT1 to the primary parallel port, and LPT2 to the secondary parallel port (if present in the system), and so on. However, the BIOS scans the standard addresses for parallel ports and if it only finds a secondary port, it assigns LPT1 to that one. The BIOS scans for parallel ports in the following address order: 3BCh, 378h, 278h.

2.6.3 Interrupts

The parallel port can be configured to generate an interrupt request upon a variety of conditions, depending on the mode the port is in. (These are described in Chapter 3.) In most applications, the interrupt is not used. The standard parallel port interrupts are:

- Primary port IRQ7
- Secondary port IRQ5

The parallel port on the CoreModule/3SXi is assigned IRQ7 when enabled in SETUP. It cannot be changed.

2.6.4 DMA Channels

In ECP enhancement mode, the parallel port can send and receive data under control of an on-board DMA controller. DMA channels operate with a request/acknowledge handshake protocol between an internal DMA controller and the parallel port logic. You can select DMA request (DRQ) and DMA Acknowledge (DACK) assignments using the jumpers at W5 and W6. The parallel port may use either DMA channel 1 or DMA channel 3. To select DMA channel 1, shunt jumper W5 (1/2) and W6 (1/2). To select DMA channel 3, shunt jumper W5 (2/3) and W6 (2/3). See Figure 2–3.




Figure 2–3. DMA Channel Selection (W5, W6)

If you will not be using DMA with the parallel port, leave the jumpers off. This makes the DMA controls available to other peripherals installed on the expansion bus.

2.6.5 Parallel Port Connector (J4)

Connection to the parallel port is through connector J4. Table 2–13 gives this connector's pinout and signal definitions. You can use a flat ribbon cable between J4 and a female DB25 connector. The table also gives the connections from the header pins to the DB25 connector. Table 2–14 gives manufacturer's part numbers for mating connectors.

Table 2–13. Parallel Port Connector (J4)

J4 Pin	Signal Name	Function	In/Out	DB25 Pin
1	STROBE*	Output data strobe	OUT	1
3	Data 0	LSB of printer data	I/O	2
5	Data 1		I/O	3
7	Data 2		I/O	4
9	Data 3		I/O	5
11	Data 4		I/O	6
13	Data 5		I/O	7
15	Data 6		I/O	8
17	Data 7		MSB of printer data	I/O
19	ACK*	Character accepted	IN	10
21	BUSY	Cannot receive data	IN	11
23	PAPER OUT	Out of paper	IN	12
25	SEL OUT	Printer selected	IN	13
2	AUTOFD*	Autofeed	OUT	14
4	ERROR	Printer error	IN	15
6	INIT*	Initialize printer	OUT	16
8	SEL IN	Selects printer	OUT	17
26	N/A	Key pin		
10,12, 14,16 18,20 22,24	GROUND	Signal ground	N/A	18-25
Data lines: 24 mA sink (.4 V max.), 12 mA source (2.4 V min.). Control lines: 24 mA sink (.4 V max.), open collector with 4.7K pull-ups.				

Table 2–14. J4 Mating Connector

Connector Type	Mating Connector
RIBBON	3M 3399-7600
DISCRETE WIRE	MOLEX HOUSING 22-55-2262 PIN 16-02-0103

Note

For maximum reliability, keep the cable between the board and the device it drives to 10 feet or less in length.

2.6.6 IEEE-1284-Compliant Cables

Using the parallel port for high-speed data transfer in ECP/EPP modes requires special cabling for maximum reliability.

Some of the parameters for a compliant IEEE-1284 cable assembly include:

- All signals are twisted pair with a signal and ground return
- Each signal and ground return should have a characteristic unbalanced impedance of 62 +/- 6 ohms within a frequency band of 4 to 16 MHz
- The wire-to-wire crosstalk should be no greater than 10%

Please refer to the IEEE-1284 standard for the complete list of requirements for a compliant cable assembly, including recommended connectors. For information about the IEEE-1284 standard, see Enhanced Parallel Port in Chapter 3.

Latch Up Protection

The parallel port incorporates chip protection circuitry on some inputs, designed to minimize the possibility of CMOS “latch up” due to a printer or other peripheral being powered up while the CoreModule/3SXi is turned off.

2.7 FLOPPY DISK INTERFACE

The onboard floppy disk controller and ROM BIOS support one or two floppy disk drives in any of the standard DOS formats shown in Table 2–15

Table 2–15. Supported Floppy Formats

Capacity	Drive Size	Tracks	Data Rate
360K	5-1/4 inch	40	250 KHz
1.2M	5-1/4 inch	80	500 KHz
720K	3-1/2 inch	80	250 KHz
1.44M	3-1/2 inch	80	500 KHz

2.7.1 Floppy Drive Considerations

Nearly any type of soft-sectored, single or double-sided, 40 or 80 track, 5-1/4 inch or 3-1/2 inch floppy disk drive is usable with this interface. Using higher quality drives improves system reliability. Here are some considerations about the selection, configuration, and connection of floppy drives to the CoreModule/3SXi CPU .

- **Drive Interface**—The drives must be compatible with the board’s floppy disk connector signal interface, as described below. Ampro recommends any standard PC-or AT-compatible 5-1/4 inch or 3-1/2 inch floppy drive.
- **Drive Quality**—Use high quality, DC servo, direct drive motor floppy disk drives.
- **Drive Select Jumpering**—Jumper both drives for the second drive select (standard on PC drives).
- **Floppy Cable**—For systems with two drives, use a floppy cable with conductors 10-16 twisted between the two drives. This is standard practice for PC-compatible systems.
- **Drive Termination**—Resistive terminations should be installed only on the drive connected to the last interface cable connector (farthest from the board). Near-end cable termination is provided on the CoreModule/3SXi CPU.
- **Head Load Jumpering**—When using drives with a Head Load option, jumper the drive for head load with motor on rather than head load with drive select. This is the default for PC-compatible drives.
- **Drive Mounting**—If you mount a floppy drive very close to the Little Board or another source of EMI, you may need to place a thin metal shield between the disk drive and the device to reduce the possibility of electromagnetic interference.

2.7.2 Floppy Interface Configuration

The floppy interface is configured using SETUP to set the number and type of floppy drives connected to the system. Refer to the SETUP section in Chapter 3 for details.

If you don’t use the floppy interface, disable it in SETUP. This frees its I/O addresses (3F0h - 3F7h), DMA2, and IRQ6 for use by other peripherals installed on the PC/104 bus.

2.7.3 Floppy Interface Connector (J8)

Table 2–16 shows the pinout and signal definitions of the floppy disk interface connector, J8. The pinout of J8 meets the AT standard for floppy drive cables. Table 2–17 shows the manufacturer’s part numbers for mating connectors.

Table 2–16. Floppy Disk Interface Connector (J8)

Pin	Signal Name	Function	In/Out
2	RPM/-RWC	Speed/Precomp	OUT
4	N/A	(Not used)	N/A
6	N/A	Key pin	N/A
8	-IDX	Index Pulse	IN
10	-MO1	Motor On 1	OUT
12	-DS2	Drive Select 2	OUT
14	-DS1	Drive Select 1	OUT
16	-MO2	Motor On 2	OUT
18	-DIRC	Direction Select	OUT
20	-STEP	Step	OUT
22	-WD	Write Data	OUT
24	-WE	Write Enable	OUT
26	-TRKO	Track 0	IN
28	-WP	Write Protect	IN
30	-RDD	Read Data	IN
32	-HS	Head Select	OUT
34	-DCHG	Disk Change	IN
1-33	(all odd)	Signal grounds	N/A

Table 2–17. J8 Mating Connector

Connector Type	Mating Connector
Ribbon	3M 3414-7600
Discrete Wire	MOLEX Housing 22-55-2342 Pin 16-02-0103

2.8 IDE HARD DISK INTERFACE

The CoreModule/3SXi CPU provides an interface for one or two Integrated Device Electronics (IDE) hard disk drives. IDE drives, the most popular and cost-effective type of hard drive currently available, have an internal hard disk controller. There are also many CD-ROM drives designed to use the IDE interface. If you attach a CD-ROM drive to the IDE port, you will need a driver (supplied by the CD-ROM drive manufacturer or your operating system) to access the device .

2.8.1 IDE Connector (J6)

The IDE interface appears at connector J6, a 44-pin, dual-row 2 mm. right-angle connector. Table 2–18 shows the interface signals and pin outs for the IDE interface connector. Table 2–19 shows manufacturer’s part numbers for mating connectors to J6.

Note

For maximum reliability, keep IDE drive cables less than 18 inches long.

Table 2–18. IDE Drive Interface Connector (J6)

Pin	Signal Name	Function	In/Out
1	-HOST RESET	Reset signal from host	OUT
3	HOST D7	Data bit 7	I/O
4	HOST D8	Data bit 8	I/O
5	HOST D6	Data bit 6	I/O
6	HOST D9	Data bit 9	I/O
7	HOST D5	Data bit 5	I/O
8	HOST D10	Data bit 10	I/O
9	HOST D4	Data bit 4	I/O
10	HOST D11	Data bit 11	I/O
11	HOST D3	Data bit 3	I/O
12	HOST D12	Data bit 12	I/O
13	HOST D2	Data bit 2	I/O
14	HOST D13	Data bit 13	I/O
15	HOST D1	Data bit 1	I/O
16	HOST D14	Data bit 14	I/O
17	HOST D0	Data bit 0	I/O
18	HOST D15	Data bit 15	I/O
20	KEY	Keyed pin	N/C
21	RSVD	Reserved	N/C
23	-HOST IOW	Write strobe	OUT
25	-HOST IOR	Read strobe	OUT
27	RSVD	Reserved	N/C
28	RSVD	Reserved	N/C
29	RSVD	Reserved	N/C
31	HOST IRQ14	Drive interrupt request	IN

Table 2–15. IDE Drive Interface Connector (J6) (cont.)

Pin	Signal Name	Function	In/Out
32	RSVD	Reserved	N/C
33	HOST A1	Drive address 1	OUT
34	RSVD	Reserved	N/C
35	HOST AD0	Drive address 0	OUT
36	HOST AD2	Drive address 2	OUT
37	-HOST CS0	Chip select	OUT
38	-HOST CS1	Chip select	OUT
39	-HOST SLV/ACT	Drive active/drive slave	10K Pull-up
41, 42	+5V	Power	OUT
2, 19, 22, 24, 26, 30, 40, 43	GND	Ground	OUT
21, 28, 29	N/C	No Connection	-

Table 2–19. J6 Mating Connector

Connector Type	Mating Connector
Ribbon Cable, 1 mm. 44 cond.	3M 3625/44
Ribbon Cable Connector	ASTRON AT-IDCSK-44-11-GF

2.8.2 IDE Cable Adapter

Many IDE hard drives and CD-ROM drives have 40-pin connectors with .1 inch pin spacing. Ampro makes an adapter board that you can install on your drive to convert it from the larger 40-pin format to the 44-pin 2 mm. format to make it compatible with the 2 mm. cable defined by the components listed in Table 2–19. For details, ask your Ampro sales representative about the *IDE Cable Adapter*.

2.8.3 IDE Interface Configuration

Use SETUP to specify your IDE hard disk drive type. Refer to the SETUP section in Chapter 3 for details.

If you do not find a drive type whose displayed parameters match the drive you are using, use drive type 48 or 49. These allow you to manually enter the drive's parameters. The drive manufacturer provides the drive parameters—check the drive's documentation for the proper values to enter.

If you are using a newer IDE drive, use drive type AUTO. It automatically configures the drive type parameters from information provided by the drive itself. The Autoconfigure function is described in Chapter 3.

If you use an IDE drive in your system, you can still add SCSI drives or other SCSI peripherals. The Ampro ROM BIOS provides a means for allowing both IDE and SCSI drives on the same system. See the SETUP description in Chapter 3 for details.

2.9 BYTE-WIDE SOCKET

The CoreModule/3SX*i* CPU has a 32-pin onboard byte-wide memory socket, designated **S0**. This socket can accept a wide variety of EPROM, Flash EPROM, SRAM, and nonvolatile RAM (NOVRAM) devices. Battery backup power can be connected to S0 using a jumper option to make a standard SRAM “non-volatile” (retains data while system power is off).

You can use a memory device installed in the byte-wide socket for a variety of purposes:

- Simple program storage
- BIOS extension
- Solid State Disk (SSD) drive

Table 2–20 shows representative byte-wide memory devices that can be installed in the byte-wide socket. The table gives examples of generic part numbers, the size of the device (K bytes), and the DIP package pin count. It also lists the SSD device type, used by the Ampro Solid State Disk (SSD) Support Software to identify memory devices.

Table 2–20. Typical Byte-wide Devices

SSD Device Type	Size	Package Pins	Generic Part Number
EPROMs			
EPROM32	32K byte	28	27C256
EPROM64	64K byte	28	27C512
EPROM128	128K byte	32	27C010
EPROM256	256K byte	32	27C020
EPROM512	512K byte	32	27C040
EPROM1024	1024K byte	32	27C080
Flash EPROMs			
EPROM128	128K bytes	32	28F010
EPROM256	256K bytes	32	28F020
EPROM512	512K bytes	32	29F040

Table 2–21. Typical Byte-wide Devices (Cont.)

SRAMs			
SRAM32	32K bytes	28	43256
SRAM128	128K bytes	32	62204
SRAM512	512K bytes	32	434000

The pinout of the 32-pin socket can be configured to comply with both the 28-pin and 32-pin JEDEC standards. You can install a 28-pin device in the 32-pin socket. Install the 28-pin device with pin 1 oriented to the socket's pin 3, as indicated in Figure 2–4.




Figure 2–4. Using 28- and 32- pin Devices in 32-pin Sockets

2.9.1 Addressing the Byte-wide Socket

Use `SETUP` to specify the size and starting address of the byte-wide socket, and whether the BIOS enables the socket upon system initialization.

Table 2–22 lists the possible settings for sizes and address ranges of the byte-wide socket.

Note

When the byte-wide socket is enabled, the memory address space it uses is unavailable for other devices, even if no memory device is installed in the socket. You must disable the byte-wide socket in SETUP before you can use the memory space for other purposes.

Table 2–22. Window Size and Address Selection

Window	Address
DISABLE	N/A
64K	D0000-DFFFFh
64K	E0000-EFFFFh
128K	D0000-EFFFFh

The size of the device installed in the byte-wide socket is not limited to 128K bytes. Using a page addressing scheme, devices (or modules) up to 1M bytes can be used. Higher address lines (A16-A19) are synthesized and can be set by software using Ampro extended BIOS function calls. A description and examples of byte-wide page control are provided in Chapter 3.

If devices larger than 64K bytes are installed, you must select which page is visible in the address window. A page is 64K bytes. (If the size is set to 128K bytes, a single 128K byte window is established. Paging is only available with the 64K window setting.) The Ampro Extended BIOS provides convenient software calls to manage enabling/disabling the socket and selecting pages. Refer to Chapter 3 for details about the byte-wide extended ROM-BIOS calls.

If you install a device that is smaller than the selected window size, the contents of the device are duplicated in the byte-wide socket's memory space. For example, the software will see two copies of a 32K device in a 64K window, and 4 copies in a 128K window.

ROM-BIOS Extensions

The system can be configured to run its application from the byte-wide socket instead of loading it into DRAM from a disk drive. This technique, known as a ROM BIOS extension, directly executes the application during the Power On Self Test (POST) instead of booting from floppy or hard disk. The ROM-BIOS extension concept, and its practical implementation, is discussed in Ampro Application Notes AAN-8702 and AAN-9003.

Performance Issues

Note that executing programs directly from the byte-wide socket can adversely affect system performance. There are a number of factors that can contribute to the performance impact:

- The byte-wide device is substantially slower than DRAM, as it is an 8-bit device instead of 16-bit.
- The device is accessed from the PC expansion bus which is much slower than the high-speed processor memory bus.

You can improve performance substantially by copying the contents of the byte-wide device into RAM and executing the RAM copy.

2.9.2 OEM Flash Memory

Access to the byte-wide socket is integrated with access to an onboard Flash memory device, designated the **OEM Flash Memory** in SETUP. The OEM Flash memory acts as a second byte-wide device, in that you access it through the same code mechanisms as the byte-wide socket. These mechanisms are described in Chapter 3. (There are no jumpers to configure the OEM Flash memory.)

Only one of the two devices can be enabled at a time. When you enable the OEM Flash memory (using an extended BIOS call), the byte-wide is automatically disabled, and vice-versa.

The first 64K bytes of the Flash memory device hold the ROM BIOS. The remaining portion can be used by OEMs or end-users in a manner similar to the byte-wide socket. In the standard version of the CoreModule/3SXi, the remaining portion is 64K bytes (the second 64K portion of a 128K device). By special order, you can substitute a 1M byte Flash device. As with the 128K device, the first 64K is used for the ROM BIOS. The remaining area is available for the embedded system. (Contact your Ampro Sales Representative for details about ordering the larger memory size.)

Set the address parameters for both the byte-wide socket and the OEM Flash device with SETUP. Refer to Chapter 3 for details.

2.9.3 Solid State Disk (SSD) Drives

Using the Ampro Solid State Disk (SSD) Support Software, you can configure an EPROM, Flash EPROM, or SRAM solid-state device, installed in the byte-wide socket, or the OEM Flash device, to act as a solid-state floppy disk drive.

No custom programming is required. Regular DOS-compliant programs, including standard DOS utilities, can be used without modification. Ampro's SSD support software creates data image files, based on your application programs and operating system, which are programmed into the device you install in the byte-wide socket. The Ampro ROM-BIOS treats the device like one or more disk drives, loading the programs into DRAM for execution. You can use SSD drives in addition to, or instead of, normal floppy and hard disk drives. You can increase the system SSD capacity by adding one or more of Ampro's SSD expansion modules.

If your board is equipped with the optional 1M byte OEM Flash device, you can install the TrueFFS Flash file system in it. This creates a fully read/write-capable solid state disk without adding any additional components to your system. Instructions on how to configure the OEM Flash device with TrueFFS Flash file system is in the TrueFFS manual that comes with the software.

2.9.4 Jumpering the Byte-Wide Socket

You must jumper the byte-wide socket for the device you install. Jumper array W3 configures S0 for a particular device type.

Table 2-23 shows how to install jumpers for a variety of supported EPROM memory devices.

Table 2-24 shows how to install jumpers for a variety of supported Flash EPROM memory devices.

Table 2-25 shows how to install jumpers for a variety of supported SRAM and NOVRAM memory devices.

2.9.5 Using EPROMs

Table 2–23 shows the jumpering for supported EPROM devices. If you install an EPROM, make sure the jumper on W8 is removed and the jumper on W7 is on pins 1/2 to prevent premature discharge of the onboard backup battery. Some EPROMs draw current through their chip select lines (or other pins) when powered down.

Table 2–23. EPROM Jumpering for S0

EPROM	Pins	Jumper Diagram
8K EPROM 27C64 16K EPROM 27C128 8K EEPROM 28C64	28	
32K EPROM 27C256	28	
64K EPROM 27C512	28	
128K EPROM 27C010	32	
256K EPROM 27C020	32	
512K EPROM 27C040	32	
1M EPROM 27C080	32	

2.9.6 Using Flash EPROMs

Flash programming power for +12V Flash devices is provided by an onboard power supply. You do not need to connect an external +12V power supply to program Flash devices. Programming power is switched under software control so that it is applied only during the actual programming process (to prevent accidental corruption of the data). A utility for programming supported Flash devices is included on the utility disk that is provided with the CoreModule/3SXi CPU Development Kit.

If you install a Flash EPROM, make sure the jumper on W8 is removed and the jumper on W7 is on pins 1/2 to prevent premature discharge of the onboard backup battery. Some Flash EPROMs draw current through their chip select lines (or other pins) when powered down.

Table 2–24. Flash EPROM Jumpering for S0

Flash EPROM Typical Devices	Pins	Jumper Diagram
32K 5V Flash EPROM 29C256	28	
32K 5V Flash EPROM 28C256	28	
64K 5V Flash EPROM 29F512 128K 5V Flash EPROM 29F010 256K 5V Flash EPROM 29F020 512K 5V Flash EPROM 29F040	32	
32K 12V Flash EPROM 28F256 64K 12V Flash EPROM 28F512 128K 12V Flash EPROM 28F010 256K 12V Flash EPROM 28F020	32	

2.9.7 Using SRAMs

If you install an SRAM, you can provide backup power from the battery when power is off by shorting W8 and W7-2/3. If you use the SRAM for “scratchpad” storage and do not want to retain data when power is off, remove the jumper from W8 and install a jumper on W7-1/2.

A typical 165 milliamp-hour external battery provides sufficient current for the onboard real-time clock for a 10 year life, but if you are going to battery-back-up a device in S0, Ampro recommends a larger battery. For calculating battery life, see page 2–5, Backup Battery.

Table 2–25. SRAM and NOVRAM Jumpering for S0

SRAM Typical Devices		Pins	Jumper Diagram
32K SRAM 32K NOVRAM	Dallas 43256 Benchmarq DS1230Y BQ4011Y	28	
128K SRAM 128K NOVRAM	Dallas 628128 Benchmarq DS1245Y BQ4013Y	32	
512K SRAM 512K NOVRAM	Dallas 628512 Benchmarq DS1650Y BQ4015Y		
<p>NOTE: W7 and W8 are show configured for (self-powered) NOVRAMs. To configure W7 and W8 for SRAM battery backup, install a jumper on W8 and move the jumper on W7 to 2/3.</p>			

2.9.8 Byte-Wide Socket Signals

W3 is used to configure the byte-wide socket for specific memory devices. In addition, jumpers W7 and W8 control the backup battery to S0 for use with SRAMs.

Table 2–26 lists the signals that appear on the pins of W3.

Table 2–26. Byte-Wide Jumper Pin Signals (W3)

W3 Pin	Signal Name	Description
1	N/C	No connection
2	A19	Address A19
3	Pin 29	Connection to pin 29 of the byte-wide socket
4	A14	Address SA14 from the expansion bus
5	Vcc or backup battery	Connected to the center pin of W7. W7-1 connects to +5V. W7-3 connects to the backup battery.
6	Vpp	Programming power for Flash devices
7	Pin 1	Connection to pin 1 of the byte-wide socket
8	-SMEMW	Write strobe
9	Pin 3	Connection to pin 3 of the byte-wide socket
10	Pin 30	Connected to pin 30 of the byte-wide socket
11	N/C	No Connection
12	A18	Address A18
13	Pin 31	Connection to pin 31 of the byte-wide socket
14	A15	Address SA15 from the expansion bus
15	A17	Address A17

W7 and W8 Options

Some EPROMs draw power through their chip select lines when Vcc is off. This could drain the real-time clock battery if it were connected to such a device. Removing the jumper from **W8** disconnects the battery from the byte-wide circuit (leaving it connected to the real-time clock) and prevents an EPROM from draining the battery prematurely.

Some byte-wide devices require more current than can be handled by the power switch that controls Vcc to the byte-wide socket. The power switch is designed to switch between battery power and Vcc for an SRAM which has very low current drain. If you are using a Flash memory or EPROM in the byte-wide socket, set W7-1/2 to connect the memory device directly to Vcc rather than through the power switch (W7-2/3).

2.10 BATTERY-BACKED CLOCK

An AT-compatible battery-backed real-time clock (with CMOS RAM) is standard on the CoreModule/3SXi CPU. The clock can be powered by a 3.6 volt Lithium battery connected to the Utility Connector, J5. Battery drain for the clock is less than 1 uA.

Use the Ampro SETUP utility to set the current time and date in the real-time clock, as well as SETUP information in the CMOS RAM portion of the clock chip (configuration memory).

The contents of the configuration memory are also stored in an onboard EEPROM. The ROM BIOS reads the EEPROM to get configuration information if the CMOS RAM data is lost. This means that the board will function without the battery. Note that without a battery, the real-time clock date and time will not be correct.

2.11 WATCHDOG TIMER

A unique feature of the onboard clock circuitry is a watchdog timer. You can program this timer to generate an interrupt or reset signal if the programmed time interval expires before the timer is reinitialized. Use SETUP to select the time interval. The options are: Disable, 30 seconds, 60 seconds, and 90 seconds.

The watchdog timer uses the standard alarm feature of the real-time clock. In a standard AT, the alarm output is connected to IRQ8. On the CoreModule/3SX*i* CPU you can also jumper the alarm output to I/O Channel Check (-IOCHCK) or RESET with W4. I/O Channel Check is the bus signal that triggers a non-maskable interrupt (NMI). RESET is a hard reset signal, the same as pressing the Reset button. Watchdog timer responses are summarized in Table 2–27.

Table 2–27. Watchdog Timer Setup

Jumper W4	SETUP	WDT Response
W4-1/2 Shorted	Enabled	Hardware Reset
W4-2/3 Shorted	Enabled	I/O Channel Check (NMI)
W4 Open	Enabled	IRQ8 turns off interrupt. System continues unaffected.
W4 Open	Disabled	No action.

Note

If you use the MS-DOS operating system, you cannot use the watchdog timer to monitor the boot process. MS-DOS resets the alarm clock in the real-time clock at boot time.

2.12 UTILITY CONNECTOR (J5)

Six functions appear on the 10-pin connector at J5. These are:

- PC speaker
- Push-button reset switch
- Standard PC keyboard interface
- External back-up battery for the real-time clock and byte-wide S0

Table 2–28 shows the pinout and signal definitions of the Utility Connector. Since there are connections for diverse features on this single connector, you would usually choose a discrete-wire connector rather than a ribbon cable connector, though this is not a requirement. Table 2–29 shows manufacturer’s part numbers for both types of mating connectors.

Table 2–28. Utility Connector (J5)

Pin	Signal Name	Function
1	Speaker +	PC audio signal output
2	BATV-	Negative terminal of external backup battery
3	Reset	Manual reset button.
4	N/C	No connection
5	Keyboard Data	Keyboard serial data
6	Keyboard Clock	Keyboard clock
7	Ground	Keyboard ground
8	Keyboard Power	Keyboard +5V power
9	BATV+	Positive terminal of external backup battery
10	N/C	No connection

Table 2–29. J5 Mating Connector

Connector Type	Mating Connector
Ribbon	3M 3473-7010
Discrete Wire	MOLEX Housing 22-55-2101 Pin 16-02-0103

2.12.1 Speaker Connections

The board supplies about 100 mW for a speaker on J5-1. Connect the other side of the speaker to ground (J5-2). A transistor amplifier buffers the speaker signal. Use a small general purpose 2 or 3 inch permanent magnet speaker with an 8 ohm voice coil. Refer to Chapter 3 for an explanation of the PC speaker circuit architecture.

2.12.2 Push-button Reset Connection

J5-3 provides a connection for an external normally-open momentary switch to manually reset the system. Connect the other side of the switch to ground. The reset signal is “de-bounced” on the board.

2.12.3 Keyboard Connections

You can connect an AT (not PC) keyboard to the keyboard port. J5-5 through J5-8 provide this function. Normally, AT keyboards include a cable that terminates in a male 5-pin DIN plug for connection to an AT. Table 2–30 gives the keyboard connector pinout and signal definitions, and includes corresponding pin numbers of a normal AT DIN keyboard connector.

Table 2–30. Keyboard Connector (J5)

J5 Pin	Signal Name	DIN Pin
5	Keyboard Clock	1
6	Keyboard Data	2
N/C	No connection	3
7	Ground	4
8	Keyboard power	5

2.12.4 External Battery Connections

To connect an external battery, connect its positive terminal to J5-9 and its negative terminal to J5-2. Use a 3.6 volt lithium cell.

The battery is connected by a low-drop Schottky diode. Two blocking devices are in series with the battery, complying with UL recommendations for lithium batteries.

2.13 AT EXPANSION BUS

The PC/AT expansion bus appears on a pair of header connectors at P1 and P2. P1 is a 64-pin female dual-row header. P2 is a 40-pin female dual-row header. Pins from both headers extend through the board, providing male connections for PC/104-compliant peripherals or other devices.

The PC-bus subset of the expansion bus connects to the first 62 positions of P1; the two additional positions of P1 (A32 and B32) are added grounds to enhance system reliability. Connector P2 replaces the 36-pin edge card connector of a conventional ISA expansion bus. It has extra ground positions at each end of the connector (C0, D0, D19). (C19 is a key pin.) The extra grounds C0 and D0 are numbered “0” to keep the pin numbers of the remaining signals on the connector the same as those on the standard ISA bus. The layout of signals on P1 and P2 is compliant with the PC/104 bus specification (IEEE P996.1 (proposed)). PC/104-compatible expansion modules can be installed on the CoreModule/3SX*i* CPU expansion bus.

The buffered output signals to the expansion bus are standard TTL level signals. All inputs to the CoreModule/3SX*i* CPU operate at TTL levels and present a typical CMOS load to the expansion bus. The current ratings for most output signals driving the AT expansion bus are shown in Table 2–31 through Table 2–34 , and indicate how the signals are terminated on the CoreModule/3SX*i* CPU.

2.13.1 Onboard MiniModule Expansion

You can install one or more Ampro MiniModule products or other PC/104 modules on the CoreModule/3SX*i* CPU expansion connectors. When installed on P1 and P2, the expansion modules fit

within the CoreModule/3SX*i* CPU's outline dimensions. Most Ampro MiniModule products have stackthrough connectors compatible with the PC/104 Version 2.1 specification. You can stack several modules on the CoreModule/3SX*i* CPU headers. Each additional module increases the thickness of the package by 0.66 inches (17 mm). See Figure 2–5.




Figure 2–5. Stacking PC/104 Modules with the CoreModule/3SX*i* CPU

2.13.2 Using Standard PC and AT Bus Cards

Ampro offers several options that allow you to add conventional 8-bit and 16-bit ISA expansion cards to the CoreModule/3SX*i* CPU system. Contact Ampro for further information about optional bus expansion products.

2.13.3 Bus Expansion Guidelines

Note

Ampro does not recommend the use of ribbon cables for bus expansion in production configurations. If cables are unavoidable, the following guidelines apply.

There are restrictions when attaching peripherals to the expansion bus with ribbon cables. If cables are too long or improperly terminated, noise and cross-talk introduced by the ribbon cables can cause errors. Ampro strongly recommends that you conform to the following guidelines:

Cable Length and Quality—In general, keep the bus expansion cable as short as possible. Long cables reduce system reliability.

- Do not use cables longer than 6 inches.
- Carefully measure signal quality on each bus line. You may need to add termination to correct signal degradation.

Backplane Quality—If you connect a backplane to the CoreModule/3SXi CPU, be sure to use a high quality backplane that minimizes signal crosstalk. Use a backplane that has power and ground planes between trace layers, and run guard traces between sensitive bus signals.

Eliminating Reset and TC Noise—Many cards have asynchronous TTL logic inputs that are susceptible to noise and crosstalk. The active high RESET and TC bus lines are especially vulnerable. You can make these signals more reliable by adding a 200 pF to 500 pF capacitor between the signal and ground to prevent false triggering by filtering noise on the signals. These RESET and TC filters are included on most Ampro backplane expansion products.

Bus Termination

Some backplanes include bus termination to improve system reliability by matching backplane impedance to the rest of the system. The IEEE-P996 draft specification for the AT expansion bus recommends the use of AC termination (sometimes called “snubbers”) rather than resistive termination. The recommended AC termination is a 50 to 100 pF capacitor, in series with a 50 to 100 ohm resistor, from each signal to ground. Ampro provides positions for OEM addition of AC termination on most bus expansion products. These positions are designed to accommodate 9-pin 8-terminator Single Inline Package (SIP) terminators.

Here are some manufacturer part numbers for 9-pin, eight-terminator devices with 100 pF capacitors in series with 100 ohm resistors:

- Dale CSRC-09C30-101J-101M
- Bourns 4609H-701-101/101

Caution

Do not use resistive bus termination! If the signal requires termination, use AC termination only.

The actual requirements for signal termination depend on system configuration, interconnecting bus cable, and on the number and type of expansion modules used. It is the system engineer’s responsibility to determine the need for termination.

For engineering development purposes, you can expand a CoreModule/3SXi system by connecting short ribbon cables to the header connectors. Ampro makes a small ribbon cable connector assembly, the *Double Stackthrough (DST) Cable Adapter*, that you can use to connect standard ribbon cables to the female expansion bus connectors on the CoreModule/3SXi CPU. Contact your Ampro sales representative for more information about the DST Cable Adapter.

2.13.4 Expansion Bus Connector Pinouts

Table 2–31 through Table 2–34 show the pinout and signal functions on the PC/104-compliant expansion bus connectors.

The CoreModule/3SXi CPU does not generate $\pm 12\text{VDC}$ or -5VDC for the expansion bus. If devices on the bus require these voltages, they can be supplied to the bus connector from the Power Connector (J7).

You do not need to add a +12V supply to program Flash EPROMs installed in the byte-wide socket, or for the onboard Flash device. An onboard supply provides the programming voltage. However, this supply does not provide power to the expansion bus. Most Ampro expansion products provide onboard DC-to-DC converters to convert the +5V supply to other voltages they require.

The expansion bus pin numbers shown in the following tables correspond to the scheme normally used on ISA expansion bus card sockets. Rather than numerical designations (1, 2, 3) they have alpha-numeric designations (A1, A2..., B1, B2..., etc.)

Table 2–31. AT Expansion Bus Connector, A1-A32 (P1)

Pin	Signal Name	Function	In/Out	Drive Level	PU/PD/S *
A1	IOCHCK*	bus NMI input	IN	N/A	
A2	SD7	Data bit 7	I/O	6 mA	4.7K PU
A3	SD6	Data bit 6	I/O	6 mA	4.7K PU
A4	SD5	Data bit 5	I/O	6 mA	4.7K PU
A5	SD4	Data bit 4	I/O	6 mA	4.7K PU
A6	SD3	Data bit 3	I/O	6 mA	4.7K PU
A7	SD2	Data bit 2	I/O	6 mA	4.7K PU
A8	SD1	Data bit 1	I/O	6 mA	4.7K PU
A9	SD0	Data bit 0	I/O	6 mA	4.7K PU
A10	IOCHRDY	Processor Ready Ctrl	IN	N/A	1K PU
A11	AEN	Address Enable	I/O	12 mA	
A12	SA19	Address bit 19	I/O	6 mA	
A13	SA18	Address bit 18	I/O	6 mA	
A14	SA17	Address bit 17	I/O	6 mA	
A15	SA16	Address bit 16	I/O	6 mA	
A16	SA15	Address bit 15	I/O	6 mA	
A17	SA14	Address bit 14	I/O	6 mA	
A18	SA13	Address bit 13	I/O	6 mA	
A19	SA12	Address bit 12	I/O	6 mA	
A20	SA11	Address bit 11	I/O	6 mA	
A21	SA10	Address bit 10	I/O	6 mA	
A22	SA9	Address bit 9	I/O	6 mA	
A23	SA8	Address bit 8	I/O	6 mA	
A24	SA7	Address bit 7	I/O	6 mA	
A25	SA6	Address bit 6	I/O	6 mA	
A26	SA5	Address bit 5	I/O	6 mA	
A27	SA4	Address bit 4	I/O	6 mA	
A28	SA3	Address bit 3	I/O	6 mA	
A29	SA2	Address bit 2	I/O	6 mA	
A30	SA1	Address bit 1	I/O	6 mA	
A31	SA0	Address bit 0	I/O	6 mA	
A32	GND	Ground	N/A	N/A	

* PU = pull up; PD = pull down; S = resistance in series. All values in ohms.

Table 2–32. AT Expansion Bus Connector, B1-B32 (P1)

Pin	Signal Name	Function	In/Out	Drive Level	PU/PD/S *
B1	GND	Ground	N/A	N/A	
B2	RESETDRV	System reset signal	OUT	12 mA	
B3	+5V	+5 Volt power	N/A	N/A	
B4	IRQ9	Interrupt request 9	IN	N/A	27K PU
B5	-5V	To J16-3	N/A	N/A	
B6	DRQ2	DMA request 2	IN	N/A	
B7	-12V	To J16-1	N/A	N/A	
B8	ENDXFR*	Zero wait state	IN	N/A	
B9	+12V	To J10-1	N/A	N/A	
B10	Key	Key pin	N/A	N/A	
B11	SMEMW*	Mem Write(lwr 1MB)	I/O	12 mA	33 S
B12	SMEMR*	Mem Read(lwr 1MB)	I/O	12 mA	33 S
B13	IOW	I/O Write	I/O	8 mA	33 S, 10K PU
B14	IOR	I/O Read	I/O	8 mA	33 S, 10K PU
B15	DACK3*	DMA Acknowledge 3	OUT	6 mA	
B16	DRQ3	DMA Request 3	IN	N/A	
B17	DACK1*	DMA Acknowledge 1	OUT	6 mA	
B18	DRQ1	DMA Request 1	IN	N/A	
B19	REFRESH*	Memory Refresh	I/O	24 mA	33 S,4.7K PU
B20	SYSCLK	Sys Clock	OUT	12 mA	
B21	IRQ7	Interrupt Request 7	IN	N/A	27K PU
B22	IRQ6	Interrupt Request 6	IN	N/A	27K PU
B23	IRQ5	Interrupt Request 5	IN	N/A	27K PU
B24	IRQ4	Interrupt Request 4	IN	N/A	27K PU
B25	IRQ3	Interrupt Request 3	IN	N/A	27K PU
B26	DACK2*	DMA Acknowledge 2	OUT	6 mA	
B27	TC	DMA Terminal Count	OUT	12 mA	
B28	BALE	Address latch enable	OUT	12 mA	
B29	+5V	+5V power	N/A	N/A	
B30	OSC	14.3 Mhz clock	OUT	6 mA	33 S
B31	GND	Ground	N/A	N/A	
B32	GND	Ground	N/A	N/A	

* PU = pull up; PD = pull down; S = resistance in series. All values in ohms.

Table 2–33. AT Expansion Bus Connector, C0-C19 (P2)

Pin	Signal Name	Function	In/Out	Drive Level	PU/PD/S *
C0	GND	Ground	N/A	N/A	
C1	SBHE	Bus High Enable	I/O	12 mA	
C2	LA23	Address bit 23	I/O	24 mA	
C3	LA22	Address bit 22	I/O	24 mA	
C4	LA21	Address bit 21	I/O	24 mA	
C5	LA20	Address bit 20	I/O	24 mA	
C6	LA19	Address bit 19	I/O	24 mA	
C7	LA18	Address bit 18	I/O	24 mA	
C8	LA17	Address bit 17	I/O	24 mA	
C9	MEMR*	Memory Read	I/O	12 mA	33 S, 10K PU
C10	MEMW*	Memory Write	I/O	12 mA	33 S, 10K PU
C11	SD8	Data Bit 8	I/O	12 mA	4.7K PU
C12	SD9	Data Bit 9	I/O	12 mA	4.7K PU
C13	SD10	Data Bit 10	I/O	12 mA	4.7K PU
C14	SD11	Data Bit 11	I/O	12 mA	4.7K PU
C15	SD12	Data Bit 12	I/O	12 mA	4.7K PU
C16	SD13	Data Bit 13	I/O	12 mA	4.7K PU
C17	SD14	Data Bit 14	I/O	12 mA	4.7K PU
C18	SD15	Data Bit 15	I/O	12 mA	4.7K PU
C19	Key	Key Pin	N/A	N/A	

* PU = pull up; PD = pull down; S = resistance in series. All values in ohms.

Table 2–34. AT Expansion Bus Connector, D0-D19 (P2)

Pin	Signal Name	Function	In/Out	Drive Level	PU/PD/S *
D0	GND	Ground	N/A	N/A	
D1	MEMCS16*	16-bit Mem Access	IN	N/A	330 PU
D2	IOCS16*	16-bit I/O Access	IN	N/A	330 PU
D3	IRQ10	Interrupt Request 10	IN	N/A	27K PU
D4	IRQ11	Interrupt Request 11	IN	N/A	27K PU
D5	IRQ12	Interrupt Request 12	IN	N/A	27K PU
D6	IRQ15	Interrupt Request 15	IN	N/A	27K PU
D7	IRQ14	Interrupt Request 14	IN	N/A	27K PU
D8	DACK0*	DMA Acknowledge 0	OUT	6mA	
D9	DRQ0	DMA Request 0	IN	N/A	
D10	DACK5*	DMA Acknowledge 5	OUT	6mA	
D11	DRQ5	DMA Request 5	IN	N/A	
D12	DACK6*	DMA Acknowledge 6	OUT	6mA	
D13	DRQ6	DMA Request 6	IN	N/A	
D14	DACK7*	DMA Acknowledge 7	OUT	6mA	
D15	DRQ7	DMA Request 7	IN	N/A	
D16	+5V	+5 Volt Power	N/A	N/A	
D17	MASTER*	Bus Master Assert	IN	N/A	330 PU
D18	GND	Ground	N/A	N/A	
D19	GND	Ground	N/A	N/A	

* PU = pull up; PD = pull down; SER = resistance in series. All values in ohms.

2.13.5 Interrupt and DMA Channel Usage

The AT bus provides several interrupt and DMA control signals. When you expand the system with MiniModule products or plug-in cards that require either interrupt or DMA support, you must select which interrupt or DMA channel to use. Typically this involves switches or jumpers on the module. In most cases, these are not shared resources. It is important that you configure the new module to use an interrupt or DMA channel not already in use. For your convenience, Table 2–35 and Table 2–36 provide a summary of the normal interrupt and DMA channel assignments on the CoreModule/3SXi CPU.

Table 2–35. Interrupt Channel Assignments

Interrupt	Function
IRQ0	ROM BIOS clock tick function, from Timer 0 *
IRQ1	Keyboard interrupt *
IRQ2	Cascade input for IRQ8-15 *
IRQ3	Serial 2
IRQ4	Serial 1
IRQ5	Available
IRQ6	Floppy controller
IRQ7	Parallel port
IRQ8	Reserved for battery-backed clock alarm *
IRQ9	Available
IRQ10	Available
IRQ11	Available
IRQ12	Available
IRQ13	Available
IRQ14	IDE hard disk controller
IRQ15	Available

* Unavailable on the PC/104 bus.

Table 2–36. DMA Channel Assignments

Channel	Function
0	Available for 8-bit transfers
1	Available for 8-bit transfers
2	Floppy controller
3	Available for 8-bit transfers
4	Cascade for channels 0-3
5	Available for 16-bit transfers
6	Available for 16-bit transfers
7	Available for 16-bit transfers

CHAPTER 3

OPERATION

3.1 INTRODUCTION

This chapter provides the information you need to software configure your CoreModule/3SXi CPU. The first section describes the SETUP function. It describes each option that can be set using SETUP. Additional sections describe important options you can set for each major functional block of the board.

Note

The SETUP descriptions in the following section also contain much useful information about each SETUP topic. Review these sections even if you already know how to set the SETUP parameters.

This chapter presumes you have some familiarity with DOS (PC-DOS, MS-DOS, or DR DOS). It does not attempt to describe the standard DOS and ROM BIOS functions. Refer to the appropriate DOS and PC reference manuals for information about DOS, its drivers and utilities, and about the software interface of the onboard ROM-BIOS. Where Ampro has added to or modified standard functions, these will be described.

The Ampro Common Utilities manual contains detailed descriptions of the Ampro utility programs supplied on the Utility diskette that is included with the CoreModule/3SXi CPU Development Kit.

3.2 SETUP OVERVIEW

Many options provided on the CoreModule/3SXi CPU are controlled by the SETUP function. You have access to these options when you activate the SETUP function. The parameters are displayed on four screens. To configure the board, you modify the fields on these screens and save the results in the onboard *configuration memory*. The configuration memory consists of portions of the CMOS RAM in the battery-backed real-time clock chip and an Ampro-unique configuration EEPROM. To enhance embedded-system reliability, the contents of the EEPROM mirror the contents of the CMOS memory. The EEPROM retains your configuration information even if the clock's backup battery should fail. If you choose to use the CoreModule/3SXi CPU without a battery, the system takes its SETUP parameters from the EEPROM, providing battery-free operation.

The SETUP information is retrieved from configuration memory when the board is powered up or when it is rebooted with a CTL-ALT-DEL key pattern. Changes made to the SETUP parameters (with the exception of the real-time clock time and date settings) do not take effect until the board is rebooted.

The SETUP function is located in the ROM BIOS. It can be accessed using CTRL-ALT-ESC while the computer is in the Power On Self Test (POST), just prior to booting up. This is called *hot key* access. The screen will display a message indicating when you can enter CTRL-ALT-ESC. You may also enter the SETUP function from the DOS command line using the SETUP.COM program provided on the Ampro Common Utilities diskette .

1. Functions on Each SETUP Page

Page	Menu Name	Functions
1	Standard (CMOS/EEPROM) Configuration	Set date and time Define floppy drives Define IDE hard disks Select video type Display DRAM quantity Set error halt conditions Enable/disable video shadow RAM Set POST display option
2	Options/Peripheral Configuration	Enable/disable extended BIOS functions Enable/disable APM BIOS functions Enable/disable serial ports Enable/disable/configure parallel port Enable/disable floppy interface Enable/disable IDE interface Configure Mono/Color Enable/disable hot key access to SETUP Set video display state Select POST display option Configure byte-wide and OEM Flash memories Enable/disable serial boot loader Enable/disable watchdog timer
3	Extended SCSI and Hard Disk configuration	Set SCSI controller parameters Configure SCSI disk map Select floppy or hard disk boot Configure DOS disk map
4	Extended Serial Console Configuration	Configure serial port parameters for serial console output Configure serial port output handshake option Configure serial port parameters for serial console input Delete/include console port from DOS COM table
* SETUP pages 3 and 4 are available when you enable Extended BIOS from SETUP		

Note

Some SETUP options can put your system into an unrecoverable state. For instance, you might set a display option that prevents you from seeing the SETUP screens. Installing a jumper between J3-7 and J3-8 (Serial 1 DTR and RI) temporarily sets all SETUP functions to their default state, bypassing the SETUP parameters stored in the configuration memory so that you can reenter SETUP and correct the problem.

3.3 SETUP PAGE 1—STANDARD (CMOS) SETUP

The first SETUP page contains the parameters normally saved in CMOS RAM plus some additional parameters unique to the CoreModule/3SXi CPU. The only parameters not also saved in the EEPROM memory are the real-time clock date and time. If no battery is used or if the battery fails, the date and time will not be accurate. All other parameters are saved in the EEPROM.

Figure 3–1 shows what can be configured using SETUP page 1. Sections following the figure describe each option.

	Standard (CMOS/EEPROM) Setup					
Date (mm/dd/yy)	9/20/96			Time (hh:mm:ss)	10:08:00	
1st Floppy	1.4M					
2nd Floppy	1/2M					
		Cyls	Heads	Sectors	Precomp	Landzone
ATA/IDE Disk 1	17	655	14	17	0	0
ATA/IDE Disk 2	None					
Video	EGA/VGA					
Base Memory	640					
Extended Memory	1024					
Error Halt	NO HALT ON ANY ERROR					
Video Shadow RAM	Enabled					
System POST	Normal					
PgDn or (D)own for Extended Setup						
[Enter] Moves Between Items, + - Selects Values						
(E)xit to quit without change, or (S)ave to record changes						

Figure 3–1. SETUP Page 1

3.3.1 Date and Time

The time shown on the first SETUP screen is continuously updated and reflects the current state of the hardware real-time clock. The new time and date that you enter is immediately written to the device. Enter the date in the form *mm/dd/yy*. Enter the time in 24-hour format, in the form *hh:mm:ss*.

The ROM BIOS maintains the *system* real-time clock. It is incremented approximately 18.2 times per second by an interrupt from timer/counter 0. The ROM BIOS automatically initializes the *system* real-time clock from the *hardware* real-time clock upon system reset or power up. The accuracy of the hardware real-time clock depends, of course, on your connecting a battery to the appropriate terminals

on J5, the Utility connector. If no battery is attached, the system time information will not remain accurate after a power cycle.

3.3.2 Floppy Drives

The ROM BIOS supports all of the popular DOS-compatible floppy disk formats. This includes all the 5-1/4 inch and 3-1/2 inch floppy formats—360K, 720K, 1.2M, and 1.44M. (Note: some formats are not supported by early versions of DOS.) In addition, the ROM BIOS supports dual-capacity use of high density floppy drives. That is, you can read and boot from 360K floppies in a 1.2M 5-1/4 inch drive, and from 720K floppies in a 1.44M 3-1/2 inch drive.

Drive Parameter Setup

Enter the number and type of floppy drives in the system. If the drives connected to the system do not match the parameters in the configuration memory, POST displays an error message. To eliminate the error message, set the drive parameters to match your floppy drives.

3.3.3 IDE Hard Disk Drives

The ROM BIOS supports one or two hard disk drives connected to the IDE interface. The BIOS allows you to mix IDE drives in combination with SCSI hard disk drives. (Use the IDE SETUP parameters for IDE drives only. SCSI hard drives are configured on SETUP screen 3.)

The IDE SETUP parameters are used for setting the physical parameters of the drives you install in your system. Physical drives can have one or more logical partitions. You can install up to eight *logical* drives or drive partitions, but only two physical drives. (Older versions of DOS may limit the number of logical drives you can install.)

To configure the system for one or two IDE drives, set the drive parameters with SETUP, as outlined here:

- **Drive Types**—The configuration memory contains a default list of parameters that specify the physical format of each drive. Each *type* specifies the total number of cylinders, the number of sectors per cylinder, number of heads, cylinder to begin precompensation, and landing zone cylinder number. The drive manufacturer supplies these parameters. The list contains “legacy values”, standard for PCs—a number of older (smaller) drives are defined.

Two special drive types, 48 and 49, let you enter drive parameters manually. If no built-in drive type matches your drive, select drive type 48 or 49 and enter the drive parameters in the fields provided.

Drive type **AUTO** selects **Autoconfigure**. Autoconfigure queries the drive for its parameters. Most modern drives will respond to the query, allowing the BIOS to set the drive parameter values automatically. This option also provides Logical Block Addressing (LBA) capability, which is used to support drives larger than 512M bytes.

Note

LBA uses a translation scheme to convert physical heads, sectors and cylinders to logical block numbers. Due to differences in the translation schemes used by different system BIOSes, LBA-compatible drives that have been formatted on Ampro systems may not function properly in other systems that support LBA mode. However, due to the intelligent translation algorithm in the Ampro BIOS, drives formatted in other systems are likely to be usable on the CoreModule/3SXi CPU. Note that this only applies to IDE drives that support LBA mode. Consult the technical literature for your specific drive to find out if it supports LBA mode.

- **Drive Selection**—Besides specifying the physical characteristics of each IDE drive, you also must specify how they are to be used by the ROM BIOS. Two factors control how they are used, drive number jumper(s) and the DOS disk map.
 1. An IDE drive can be jumpered as a **master** or **slave**. Each manufacturer's drive is different, so you must refer to the drive's technical literature to find out how to jumper the drives you install. Drives default to **master** from the factory, so if you only have one IDE drive in a system it is generally already set up properly.
 2. Use the SETUP Extended SCSI and Hard Disk Configuration menu (SETUP page 3) to enter your IDE drive(s) in the DOS disk map. Disk 1 in the map will be logged by DOS as drive C, Disk 2 as drive D, and so on. See the description of SETUP page 3 for details.

Once you have set the system's configuration memory, the IDE drive(s) can be formatted and otherwise prepared normally. Refer to your operating system and disk drive documentation for specific procedures and requirements.

3.3.4 Video

Specify the initial video mode. Select **Mono**, **Color40**, **Color80**, or **EGA/VGA**. If your video display card is VGA, super VGA, or any other high resolution standard, specify **EGA/VGA** no matter how it is configured to come up.

3.3.5 DRAM Memory

The ROM BIOS automatically sets the amount of memory it discovers during Power-On Self-Test (POST) and stores the result when you save the configuration values when exiting SETUP. If you change the amount of memory installed on the board, however, you must run SETUP and do a **save** when you exit. This updates the configuration memory to reflect the new memory size. Until you do this, an error message will appear during POST.

Note that if an error message appears during POST when you have not changed the amount of memory installed, it indicates that at least part of the memory is not functioning properly.

3.3.6 Error Halt

Select which kinds of errors will halt the POST. If you plan to use the module without a keyboard, be sure to set this option to *not* halt on keyboard error.

3.3.7 Video Shadow RAM

This option, when enabled, allows the ROM BIOS to copy the contents of a video BIOS into DRAM. The actual video BIOS ROM on the video controller is disabled, and DRAM is mapped into the address space it occupied. This speeds up video BIOS accesses. Ampro video controllers are designed to allow video BIOS shadowing. If you are using a video controller from another manufacturer, it may not support shadowing. In that case, set video BIOS shadowing to “Disabled.”

3.3.8 System POST

At boot time, the BIOS runs a series of tests called the “Power On Self Test”, or POST. There are options in the Ampro BIOS to customize the POST to control how fast the computer powers up and to control what the user sees at power up time. The choices are:

- **Normal**—Displays the results of all tests
- **Fast**—Faster than Normal POST because it uses a shorter memory test
- **Express**—Skips most tests and does not display POST test results on the screen

3.4 SETUP PAGE 2—OPTIONS/PERIPHERAL CONFIGURATION

Use SETUP page 2 to enable or disable many of the functions and peripherals provided on the CoreModule/3SXiCPU. Figure 3–2 shows what can be configured on SETUP page 2, and the sections that follow describe each parameter.

```

                                CM/3SXi Options/Peripheral Configuration

CoreModule Extended BIOS ..... Enabled
Advanced Power Mgmt BIOS ..... Enabled
Serial Port 1 ..... Enabled
Serial Port 2 ..... Enabled
Parallel Port ..... Enabled   Mode SPP
Floppy Interface ..... Enabled
IDE Interface ..... Enabled
Mono/Color Jumper ..... Color

Socket S0 ..... 64K @ D0000h
OEM Flash ..... 64K @ E0000h
Default Socket ..... S0

Video State ..... Enabled
Blank POST Test ..... Enabled
Serial Boot Loader ..... Disabled
Watchdog Timer ..... Disabled
Hot Key Setup ..... Enabled

      (S)ave to Record Extended Setup
    [Enter] Moves Between Items,      + - Selects Values
    (E)xit to quit without change, or (S)ave to record changes

```

Figure 3–2. SETUP Page 2

3.4.1 Extended BIOS

Normally, the Ampro Extended BIOS is enabled. This allows access to SETUP pages three and four and the features they define. If you do not want to use the BIOS extensions, you can disable them using this parameter. (Some UNIX implementations or other operating systems may require disabling the extended portion of the BIOS.) Ampro Application Note AAN-9210 documents the features in the extended BIOS, including the application program interface specifications.

3.4.2 Advanced Power Management BIOS

The CoreModule/3SXi CPU BIOS incorporates an Advanced Power Management BIOS (APM) compliant with Advanced Power Management (APM) BIOS Interface Specification Revision 1.1, created

by Intel and Microsoft. This SETUP option allows you to enable or disable access to the APM BIOS functions. Note that this option does not enable or disable power management on the CoreModule, it enables or disables access to the APM BIOS that drivers or applications use to control power management features.

3.4.3 Serial Ports

Use SETUP to independently enable or disable either of the two onboard serial ports. (When you use SETUP to enable or disable a port, the change does not take effect until you reboot the system.)

The I/O addresses and interrupt assignments (IRQs) for the serial ports cannot be changed. The following table lists the I/O addresses and IRQs of each port. These resources are freed for use by other peripherals installed on the PC/104 bus when their respective ports are disabled.

Table 3–2. Serial Port Resources

Port	Address	Interrupt
Serial 1	3F8h – 3FFh	IRQ4
Serial 2	2F8h – 2FFh	IRQ3

Normally, the BIOS logs Serial 1 and Serial 2 as COM1 and COM2. Note, however, that COM1 and COM2 are logical designations, not physical values. When the system boots, the BIOS scans the standard serial port addresses and installs the first port it finds as COM1. If it finds a second port, it installs that one as COM2, and so on. If you disable a serial port, the designations of all higher-numbered COM ports will change.

For more information about the serial ports, see Serial Ports, page 3—21.

3.4.4 Parallel Port

You enable or disable the CoreModule/3SXi parallel port using the **Parallel Port** option on this SETUP page. You set the parallel port mode (SSP, EPP, or ECP) by setting the **Mode** option.

Table 3–3 summarizes the resources that are used when the parallel port is enabled.

3. Parallel Port Resources

Selection	I/O Address	Interrupt
Primary	0378h - 037Fh	IRQ7
Disable	None	None

The I/O ports and interrupt request channel are freed for use by other peripherals installed on the PC/104 bus when the parallel port is disabled.

Normally, the BIOS logs in the primary and secondary parallel ports as LPT1 and LPT2. Note, however, that LPT1 and LPT2 are logical designations, not physical values. When the system boots, the BIOS scans the standard parallel port addresses and installs the first port it finds as LPT1. If it finds a second

port, it installs that one as LPT2, and so on. If you disable a parallel port, the designations of all higher-numbered LPT ports will change.

Setting the Parallel Port Mode

Set the parallel port mode to either **SPP**, **EPP**, or **ECP**.

Table 3–4 Parallel Port Modes

Mode	Description
SPP	Standard Parallel Port (default)—Bi-directional, compatible with standard and PS/2 ports.
EPP	Enhanced Parallel Port—Bi-directional, compatible with standard and PS/2 ports, but adding automatic read- and write- cycle modes.
ECP	Extended Capabilities Port—IEEE-1284-compliant port. Provides interlocking handshaking, 16-byte FIFO buffer, optional DMA transfer capability, and optional RLE data compression.

For more information about the parallel port, see Enhanced Parallel Port on page 3–25.

3.4.5 Floppy Interface Enable

Enable or disable the onboard floppy interface. When disabled, the I/O ports assigned to the floppy controller become available, allowing them to be used by other devices installed on the expansion bus. Table 3–5 lists the resources used by the floppy controller.

5. Floppy Controller Resources

Selection	I/O Address	IRQ	DMA
Enabled	03F2h Digital Output Register 03F4h Main Status Register 03F5h Data Register 03F7h Control Register	IRQ6	DMA 2
Disable	None	None	None

3.4.6 IDE Interface Enable

Enable or disable the onboard IDE hard disk interface. When disabled, the I/O ports and IRQ assigned to the IDE controller become available, allowing them to be used by other devices installed on the expansion bus. Table 3–6 lists the resources used by the IDE interface.

6. IDE Controller Resources

Selection	I/O Address	Interrupt
Enabled	01F0h - 01F7 Control and Data Registers	IRQ14

	03F7h	Shared with FDC	
Disable	None		None

If you have an IDE drive attached to J6, just disabling the IDE interface will not free the interrupt, IRQ14, since it is connected directly to the drive. You must disconnect the cable.

3.4.7 Mono/Color Selection

Set the Mono/Color selection to Mono only if you have a monochrome monitor connected to a monochrome (MDA) video adapter. In all other cases, set this option to Color. Set it to Color even if you have a VGA monochrome monitor attached to a VGA or SuperVGA adapter.

3.4.8 Hot Key Setup Enable

In some embedded systems, you do not want an end-user to use the *hot-key* sequence (CTRL-ALT-ESC) to enter SETUP. You can enable or disable hot-key access to SETUP with this parameter. (This also prevents “+++” from entering SETUP when using the serial console feature.)

3.4.9 Video State

You can set this option to Enabled or Inhibited. Inhibited *blanks* the display until your program makes a call to the Video Restore State function in the video BIOS (via INT10h). This provides a means of controlling what appears on the screen when the system starts up. This option can be used to inhibit the POST test display and everything else that DOS or an application would display, until a call is made to the video BIOS.

The following is an example of code that reenables the display inhibited by this option:

```

;=====
init:  mov ah,1ch
       mov al,-1
       mov bx,414Dh
       mov cx,5052h
       int 10h
;=====

```

3.4.10 Blank Post Test

Enable or disable POST display. If set to **Disabled**, the messages from the POST will not be sent to the console. To inhibit display of a broader range of system and application messages, see Video State, above.

3.4.11 Byte-Wide Socket and OEM Flash Memory Configuration

The byte-wide socket, S0, and the user portion of the OEM Flash memory device can be independently configured for its *starting address* and the *size* of the memory block in which it appears to the processor, or it can be disabled. You can also specify which device is enabled at boot time. (This is the “Default Socket” SETUP option.) Note that only one can be enabled at boot time.

Table 3–7 lists the socket address configuration options that are available.

7. Byte-Wide Memory and Onboard Flash Configuration

Size	Address
Disabled	None
64K bytes	D0000h – DFFFFh
64K bytes	E0000h – EFFFFh
128K bytes (Available only for S0)	D0000h – EFFFFh

If you configure both devices to occupy the same address space (or overlap), only one device will be visible to the CPU. This will be either the default socket (enabled during POST) or the socket that was last enabled. The Ampro BIOS provides a call for enabling and disabling each device. A code example is shown on page 3–30. Refer to Ampro Application Note AAN-9210 for a complete description of the BIOS functions that control the byte-wide sockets.

Devices larger than 64K can be installed in the byte-wide socket, independent of the memory block size setting. The memory block size setting specifies a “window” in which the memory device is visible. You can use an extended BIOS call to select which 64K page of the byte-wide device is visible to the processor. A code example is shown on page 3–31.

You must also set hardware jumpers to configure the byte-wide socket for the device you install in S0. Refer to Chapter 2 for jumper positions. If you are using the byte-wide socket for Solid State Disk (SSD), using Ampro’s Solid State Disk software, follow the directions for setting the byte-wide socket that are in the SSD Technical Manual.

3.4.12 Serial Boot Loader Enable

This parameter enables or disables the Serial Boot Loader option in the Ampro ROM BIOS. The serial boot loader allows you to boot from either of the onboard serial ports, much in the same way you would boot from a local hard disk or from a LAN. A description of the Serial Boot Loader is provided in the Ampro Common Utilities manual (see SERLOAD and SERPROG), and in Ampro Application Note AAN-9403. If you are not using the Serial Boot Loader, set this parameter to “Disabled.”

3.4.13 Watchdog Timer Configuration

This parameter allows you to set the time duration of the watchdog timer for monitoring the boot process. You can set it to 30, 60, or 90 seconds, or you can disable it.

Further information about the watchdog timer can be found later in this chapter under “Watchdog Timer.” A description of the WATCHDOG utility program can be found in the Ampro Common Utilities manual.

3.5 SETUP PAGE 3—SCSI HARD DISK

A unique feature of the CoreModule/3SXi CPU is that its ROM BIOS contains hard disk support functions that allow easy integration of SCSI and IDE drives. Use this SETUP screen to configure for your hard disk drives and other SCSI peripherals. Figure 3–3 shows SETUP screen 3, and descriptions of each field are provided in sections below.

```

Extended SCSI and Hard Disk Configuration

SCSI /BIOS Services..... Enabled
SCSI Initiator ID..... 7
SCSI Disk I/O Retries..... 10

SCSI Disk Map

SCSI 1..... Id 0, Lun 0
SCSI 2..... Not Active
SCSI 3..... Not Active
SCSI 4..... Not Active
SCSI 5..... Not Active
SCSI 6..... Not Active
SCSI 7..... Not Active

DOS Disk Map

Default Boot Device..... Floppy
1st Hard Disk..... SCSI Disk 1
2nd Hard Disk..... IDE Disk 1
3rd Hard Disk..... Not Active
4th Hard Disk..... Not Active
5th Hard Disk..... Not Active
6th Hard Disk..... Not Active
7th Hard Disk..... Not Active
8th Hard Disk..... Not Active

[Enter] Moves Between Items,      + - Selects Values
(E)xit to quit without change, or (S)ave to record changes

```

Figure 3–3. SETUP Page 3

With the Ampro Extended BIOS, SCSI hard disks are available to DOS through standard ROM BIOS functions (INT 13). (SCSI interface hardware is available on a variety of Ampro add-on products.) SCSI functions are in the SCSI BIOS portion of the ROM BIOS. The ROM BIOS hard disk support allows direct system booting from SCSI Common Command Set direct access devices. Other types of SCSI direct access devices can be used to provide a compatible hard disk function. These include CD ROM drives, tape drives, SCSI RAM disks, and other peripherals.

Most DOS or Windows applications run normally in this SCSI-based hard disk environment. Programs nearly always use either DOS or ROM BIOS functions for disk drive access. It is rare for software to attempt to access hard disk controller hardware directly.

Utilities for SCSI drive formatting, and other SCSI functions are included on the Ampro Common Utilities diskette. These are described in the Ampro Common Utilities manual.

3.5.1 SCSI Drive Parameter Setup

If you add a SCSI device to your CoreModule/3SXi-based embedded system, you must set several SCSI drive parameters in the configuration memory using SETUP. This section describes the SETUP parameters found on the SCSI Disk Configuration screen.

SCSI Controller Parameters

- **SCSI/BIOS Services**—To use the SCSI BIOS for hard disks, it must be enabled. When disabled, the system will not boot from an attached SCSI drive, nor will standard disk-related BIOS calls (INT13) be able to see a drive. SCSI services are still available from BIOS calls in your program, even when SCSI/BIOS Services is disabled. Disabling the SCSI BIOS services will speed up system booting when you don't use the SCSI port.
- **SCSI Initiator ID**—The Ampro CoreModule/3SXi CPU is the *SCSI Initiator* in its transactions with SCSI target devices such as hard disk drives. Every SCSI device (target or initiator) must have a unique ID between 0 and 7. The default ID for the SCSI controller on the CoreModule/3SXi CPU is 7. It is the highest priority ID, and this ID tells the SCSI BIOS to reset the SCSI bus on system power up or reset. In most cases you will not change the default SCSI initiator ID.
- **SCSI Disk I/O Retries**—You can specify the number of read/write retries when using SCSI drives as DOS drives. The default is 10 retries.

SCSI Disk Map

- **Target Device IDs and LUNs**—The specification of SCSI target device IDs and Logical Unit Numbers (LUNs) are stored in the configuration memory. Enter the IDs and LUNs of the SCSI drives you have installed in your system. Assign each drive to a SCSI Disk position in the SCSI Disk Map. Normally, all SCSI LUNs default to 0.

The SCSI ID for target devices can be 0 to 6 (since the CPU is set for ID 7). A device's ID is usually set by jumpers or switches on the device. If you have multiple SCSI drives, assign each one a unique device ID.

DOS Disk Map

- **BOOT Device Specification**—You can choose to boot the system from a hard or floppy drive using the Default Boot Device parameter. You can specify Floppy for floppy A: or Hard Disk for drive C:. (When you select Hard Disk, the drive shown as 1st Hard Disk on the DOS Disk Map becomes the boot drive.)
- **DOS Disk Map**—Assign your disk drives, both IDE drives and SCSI drives, to positions on the DOS Disk Map. You can assign them in any order and in any mix. The 1st Hard Disk becomes drive C:, 2nd Hard Disk becomes drive D:, and so on. Any non-SCSI devices that will appear to the system as a drive should be configured in the DOS Disk Map as an AT Bus Drive. This includes any device that is installed with its own driver.

Note

SETUP screen 1, “Standard (CMOS) SETUP” is used for defining hard drives connected to the IDE interface. Do not attempt to use the IDE configuration menu to define disk drive parameters for SCSI-connected drives.

3.6 SETUP PAGE 4—SERIAL CONSOLE

The ROM BIOS includes a unique set of features which allow full access to the system at any time over standard RS232 serial ports. An embedded system may take advantage of these remote access capabilities using the serial console functions in the following ways:

Serial console—Use Serial 1 or Serial 2 as a console. Use a serial terminal to replace the standard video monitor and keyboard.

Serial boot loader—Boot from a serial port much like you would boot from a local hard disk or from a network. (This feature is enabled or disabled with the **Serial Boot Loader** option on Page 2 of SETUP.)

Serial programming—Automatically update system software, such as an SSD, through a serial port. This feature allows you to replace code in a Flash device installed in the byte-wide socket.

For more information about these serial console functions, see “Serial Console Features,” under “Serial Ports”, later in this chapter. For a thorough explanation of the remote host features, refer to Ampro Application Note AAN-9403.

Figure 3–4 shows the options you can set for the serial console. Since the DOS normally initializes the serial ports during boot, you have the option to remove the serial console port from DOS’s COM port table. By doing this, the values you set on SETUP screen 4 will remain after you boot DOS.




Figure 3–4. SETUP Page 4

Console Output Device—Select the console output device, either Video, Serial 1, Serial 2, or None.

Console Input Device—Select the console input device, either the PC Keyboard, Serial 1, Serial 2, or None.

Serial Console Output Setup—Enter the communication parameters for your console *output* serial port. Set the data length, stop bits, parity, and baud rate to match your serial output device.

Console Output Handshake—Enable or disable hardware handshaking. If enabled, the DSR and CTS signals control the data flow. Be sure to connect the DSR and CTS signals on the serial port's connector to the appropriate handshake signals on the external serial device's interface connector.

Serial Console Input Setup—Enter the communication parameters for your console *input* serial port. Set the data length, stop bits, parity, and baud rate to match your serial input device.

Delete from COM Port Table—When DOS boots, it initializes the system serial ports. (Different versions of DOS may set the ports to different default settings.) By enabling this option, the BIOS does not include your console serial device(s) in the COM port table. This prevents DOS from changing the values you assign to the port in this SETUP screen.

Caution

Be careful when changing the console configuration. If you specify “None” for console input and output, there will be no console access to the system. (You can recover from this state by removing the serial console plug from the primary serial port connector and shorting pins J3-7/8.)

3.7 THE SETUP.COM PROGRAM

You can use the SETUP.COM utility from the command line to access the same SETUP functions as the “hot key” code, CTRL-ALT-ESC. SETUP.COM also adds additional functionality, such as the ability to load and store configuration settings to a disk file. This same feature is used to store up to 512 bits of OEM information in the configuration memory EEPROM. SETUP.COM is on the Ampro Common Utilities diskette, included with the CoreModule/3SXi CPU Development Kit.

3.7.1 Creating Configuration Files with SETUP.COM

The Ampro SETUP utility, SETUP.COM, offers the following options for command line entry:

```
SETUP [-switches] [@file.ext | Wfile.ext]
```

The supported switches and their meaning are as follows:

Table 3–8. SETUP.COM Command Switches

Switch	Function
?	Display a usage help screen
T	Set the (hardware) real-time clock time and date from the current DOS time and date.
@ <i>file.ext</i>	Writes the specified file to the board's CMOS RAM and configuration EEPROM. Drive and path are optional in the file name.
W <i>file.ext</i>	Write CMOS RAM and EEPROM contents to the file specified. The file name may contain an optional drive and path.

You can save a copy of the current contents of the board's configuration memory to a disk file by using the **W** switch. The data saved includes the entire contents of the nonvolatile configuration EEPROM. The first 512 bits are the SETUP information (excluding time and date). The next 512 bits are available for OEM storage. See Ampro Application Note AAN-8805 for a description of how to use the OEM storage portion of the EEPROM.

Note

If the SETUP is changed, the system must be rebooted before writing a configuration file using the SETUP W option. Otherwise, the changes will not appear in the setup file.

The file you create with this menu option can be used as a source for programming the configuration memory of a CoreModule/3SXi CPU at a later time.

For example, the following command initializes the EEPROM values with a previously saved configuration:

```
C>SETUP @SYSTEM.A
```

Assuming you created the file SYSTEM.A with SETUP's write option, SETUP will initialize the EEPROM configuration memory and CMOS RAM using the contents of SYSTEM.A.

Note

The system must be rebooted before new configuration information will take effect.

Using SETUP to save and load configuration memory parameters can be useful when many boards must be initialized automatically, for instance, during production, or when you want to change between several predefined system configurations.

3.8 OPERATION WITH DOS

The CoreModule/3SXi CPU supports IBM's PC-DOS or Microsoft's MS-DOS, Version 3.3 or later, or any version of Digital Research's DR DOS as the disk operating system. Any differences between these similar operating systems are noted in the text where applicable.

Caution

Sometimes MS-DOS is customized by a manufacturer for a specific system and may not work on the CoreModule/3SXi CPU. Use DR DOS (supplied by Ampro), IBM PC-DOS (supplied by IBM), or the generic version of MS-DOS (supplied by Microsoft on an OEM basis).

EMS Option—The CoreModule/3SXi CPU can emulate the Lotus-Intel-Microsoft Expanded Memory Specification Version 4.0 (LIM EMS 4.0), with the memory management capability of the 80386SX CPU, under control of a device driver. Such drivers are available with the newer versions of DOS. With Microsoft MS-DOS, the driver is called EMM386.EXE.

Serial Ports—DOS normally supports the board's two serial ports as COM1 and COM2.

At boot time, DOS initializes the serial ports, assigning them their COM port designations and their communication parameter settings. Although this might vary with different types and versions of DOS, typical communication parameter settings are 9600 baud, even parity, 7 bits, and 1 stop bit.

Usually an application program that uses a serial port will access the port's hardware and reinitialize the communication parameters to other values, based on settings that the user has entered when configuring the application program.

Parallel Port—The Parallel Printer port is normally the DOS LPT1 device. Most application software uses LPT1 as the default printer port. If you enable the port, printing to it is automatic.

The following DOS commands can be used to test printing with a parallel printer:

A>> <u>COPY filename.ext LPT1</u>	Prints contents of <i>filename.ext</i>
A>> <u>DIR >LPT1</u>	Prints the directory

In addition, the <PrtSc> (Print Screen) key will print the contents of the video screen to the LPT1 device. Also, you can use the Printer Echo function to print all characters typed on the keyboard. The command <Ctrl-P> enables the Printer Echo function. Entering <Ctrl-P> again disables Printer Echo.

Disk Drives—Older versions of DOS require you to divide disk drives larger than 32M bytes into more than one partition. More recent versions permit drives to be up to 2G bytes, though IDE drives are BIOS limited to 512M bytes. Drives larger than 512M bytes must use the **Auto** configuration type in SETUP or use a vendor supplied driver to access the entire drive.

3.9 SERIAL PORTS

This section describes uses for the serial ports on the CoreModule/3SXi CPU, including:

- Using the RS-485 interface
- The serial console feature
- Serial booting
- Serial downloading and programming
- Using a serial modem


3.9.1 Using the RS-485 Interface

This section describes the RS-485 interface circuit and discusses some RS-485 concepts to aid in using the interface in an embedded system.

RS-485 provides for half-duplex operation. It is a 5 volt differential interface, which has greater immunity against noise and interference than single-wire interfaces. This interface will drive cable lengths up to 4000 feet reliably at 57.6K bps. All communication, both transmission and reception, occurs via a single pair of wires. There are no handshaking lines.

RS-485 supports multidrop operation. That is, more than two devices can be connected to the same RS-485 balanced line. To prevent signal contention, only one transmitter is enabled at a time. The CoreModule/3SXi RS-485 transmitter is controlled by Serial 2's RTS signal. At power up, RTS is in its inactive state, ready to receive. When it is time to transmit, the RTS signal is made active, enabling the transmitter. It is the responsibility of the user's software to prevent two transmitters from being enabled at the same time.

Figure 3–5 illustrates the CoreModule/3SXi RS-485 interface wiring.



5. RS-485 Interface Wiring

The following are some examples of interconnection schemes that can be used to take advantage of the RS-485 serial connection:

- **One-way Broadcast**—A single device uses an RS-485 signal pair to transmit data to many receiving devices. To enable the broadcaster’s transmitter, the RTS signal is turned on (True, High, Active) and left on. If the device is to be a receiver, RTS must be turned off and left off.
- **Simple Bi-Directional Communication**—Two devices use a single RS-485 bi-directional pair for half-duplex, two-way transmission of data. The Adapter’s transceiver is placed in the send or receive mode under control of the network software. This can be done using a simple alternation scheme or by messages contained within data packets.
- **Multidrop Network**—More than two devices share an RS-485 signal pair, for both transmission and reception of data. Only one device is permitted to talk at any one time. As with simple bi-directional communication, the board’s RS-485 transceiver is placed in receive mode unless it is the one permitted to transmit. One popular way of managing who is the transmitter is by a “token passing scheme. Each node is assigned an ID number. Whoever transmits also sends the ID of the next node allowed to transmit. If a node does not need to transmit, it just immediately sends the “token” to its next node. This simple scheme is easy to implement and trouble free. Time-outs can be implemented in software to prevent a lockup should a node fail to pass the token properly.

3.9.2 Serial Console Features

To use the serial console features, connect the serial console device(s) to Serial 1 or Serial 2. Use SETUP to configure the CoreModule/3SXi CPU to use its serial console support feature. The configuration memory stores serial console configuration parameters.

Caution

Be careful when changing the console configuration using SETUP. If you specify “None” for console input and output, there will be no console access to the system. (You can recover from this state by removing the serial console plug from the primary serial port connector and shorting pins J3-7/8.)

SETUP provides separate configurations for serial console input and output. Thus, you can use a serial port (and attached serial device) for either or both input and output. For instance, you can use a modem or other serial device for input, and a standard video display for output. Or you can use a standard keyboard for input and an ASCII terminal for serial display, or use an ASCII terminal for both input and output.

To use an ASCII terminal as the console device for your system, set both the input and output parameters to Serial Port 1 (or 2), and set the serial baud rate, data length, and stop bits to match the setting of your terminal. For proper display of SETUP and POST messages from the BIOS, you must use an IEEE-compatible terminal that implements the standard ASCII cursor commands. The required commands and their hexadecimal codes are listed in Table 3–9.

Table 3–9. Required Serial Console Commands

Hex	Command
08	Backspace
0A	Line Feed
0B	Vertical Tab
0C	Non-destructive Space
0D	Carriage Return

Note

Some programs that emulate an ASCII terminal do not properly support the basic ASCII command functions shown in Table 3–9. Ampro provides a suitable PC terminal emulator program, TVTERM, on the Common Utilities diskette.

After booting this system, the keyboard and screen of the terminal become the system console. The programs you use this way must use ROM BIOS video functions (rather than direct screen addressing) for their display I/O. You can enter keyboard data from both the external serial device and the standard AT keyboard.

Note

DOS programs that write directly to video RAM will not display properly on a serial console device.

COM Port Table

When the system boots, DOS initializes the serial ports to 9600 baud (typical). To preserve the selected console port parameters stored in SETUP, the ROM BIOS can be instructed to delete the selected console port from the internal COM port table, normally used by DOS to locate the serial ports. With the port deleted from the COM port table, DOS cannot change its parameters. If you use a serial console, be sure to select the option that deletes the console port from the COM port table.

Serial Handshake

The serial console device data format and the CoreModule/3SX*i* CPU serial port data format must match for the devices to properly communicate. In addition, the hardware handshake behavior must be compatible. Normally, a serial port's Data Set Ready (DSR) and Clear To Send (CTS) input handshake signals must be true (active) for the ROM BIOS to send data out. On the CoreModule/3SX*i* CPU, the hardware handshake can be enabled or disabled with SETUP. When hardware handshaking is enabled, be sure to connect the DSR and CTS signals to appropriate handshake signals on the external serial device's interface connector. As an alternative, loop the CoreModule/3SX*i*'s serial output handshake signals to its input signals as follows:

- DTR (out) to DSR (in)
- RTS (out) to CTS (in)

3.9.3 Serial Booting and Serial Programming

Serial console functionality has been expanded to incorporate two additional features useful in embedded applications.

- The *serial boot* facility enables the CoreModule/3SXi CPU to boot from code downloaded through a serial port in a manner similar to booting from a local hard disk or from a network.
- The *serial programming* facility permits updating Flash memory devices installed in the byte-wide socket over the serial port. It can also be used to program the OEM Flash device.

Refer to Ampro Application Note AAN-9403 for a complete description of these features. Refer to the Ampro Common Utilities manual for descriptions of SERLOAD and SERPROG, utility programs used to support serial booting and serial programming.

3.9.4 Using a Serial Modem

You can use any of the RS232C ports as a modem interface. You will not need to concern yourself with serial port initialization since most PC communications programs control the serial port hardware directly. If your program does not do this, use the DOS MODE command to initialize the port.

When installing a modem, be sure to connect appropriate input and output handshake signals, depending on what your communications software requires. Standard PC-compatible serial modem cables that connect all of the proper signals correctly are commonly available. The signal arrangement on the serial port connectors is described in Chapter 2.

Many powerful communications programs are available to control modem communications. Some of these programs offer powerful “script” languages that allow you to generate complex automatically functioning applications with little effort.

3.10 ENHANCED PARALLEL PORT

The enhanced parallel printer port is a superset of the standard PC-compatible printer port. It supports three modes of operation:

- **Standard PC/AT printer port (SPP)**—Centronics-type output only printer port, compatible with the original IBM PC printer port. Sometimes it is called a PS/2-compatible parallel port. It behaves the same as the standard PC/AT port on outputs, and provides an input mode as well.
- **Enhanced Parallel Port (EPP)**—Bi-directional parallel port, compatible with the Standard and PS/2 ports, and adding automatic read- and write-cycle modes. Automatically generates input and output handshaking signals for increased throughput. Data flow is monitored by a watchdog timer (separate from the board's watchdog timer) to ensure reliable transfers.
- **Extended Capabilities Parallel Port (ECP)**—Compliant with the IEEE-1284 Extended Capabilities Port Protocol and ISA Standard (Rev 1.09, January 7, 1993), developed by Microsoft. The ECP mode provides the highest level throughput for the parallel port. It provides interlocking handshaking, a 16-byte FIFO buffer, DMA transfers (optional), hardware RLE data compression (optional), and well-defined software protocols.

The low-level software interface to the parallel port consists of eight addressable registers. The address map of these registers is shown in Table 3-10.

10. Parallel Port Register Map

Register Name	Address
Data Port	Base address
Status Port	Base address + 1
Control Port	Base address + 2
EPP Address Port	Base address + 3
EPP Data Port 0	Base address + 4
EPP Data Port 1	Base address + 5
EPP Data Port 2	Base address + 6
EPP Data Port 3	Base address + 7
Note: EPP registers are only accessible when in EPP mode	

3.10.1 Standard and Bi-Directional Operation (SPP)

You can use the parallel port as a standard output-only printer port or as a bi-directional data port with up to 12 output lines and 17 input lines. The bi-directional mode can be very valuable in custom applications. For example, you might use it to control parallel-connected external peripherals, an LCD display, scan keyboards, sense switches, or interface with optically isolated I/O modules. All data and interface control signals are TTL-compatible.

To use the parallel port in standard or bi-directional modes, set the parallel port **Mode** option on page 2 of SETUP to **SPP**.

Note

Note that the term “mode” in this section is used for both the **SPP/EPP/ECP Mode** as set with SETUP, and for input and output modes that port can be in when in the **SPP Mode**. For clarity, the port’s **SETUP Mode** setting will be in bold type and capitalized to distinguish it from the various modes that the port can be in when in the **SPP Mode**.

The default mode of the port in **SPP Mode** is output only, to make the port compatible with the original IBM PC parallel port. To use the port as a bi-directional data port, put it in bi-directional mode with a Ampro extended BIOS call, as shown in the following code example.

```

;-----
; Code to set the parallel port mode to "bi-directional"
;-----
MOV  AH,0CDh    ; AMPRO command
MOV  AL,0Ch     ; AMPRO function
MOV  BX,01h     ; Bi-directional mode (00 for output-only)
INT  13h

```

Once the port is in bi-directional mode, you can dynamically change the port between input and output states by directly accessing the control register at I/O address 37Ah.. The initial state of the port after the BIOS call is input. A “1” written to 37Ah-bit 5 sets the port to input; a “0” sets it to output.

The following example is code for dynamically changing the primary parallel port’s direction (the code assumes that the port is in **SPP Mode**).

```

;-----
; Code to change the parallel port direction to input
;-----
MOV  DX,37Ah
IN   AL,DX
OR   AL,20h    ;set bit 5
OUT  DX,AL
;
;-----
; Code to change the parallel port direction to output
;-----
MOV  DX,37Ah
IN   AL,DX
AND  AL,0DFh   ;clear bit 5
OUT  DX,AL

```

Using control lines for Input/Output

Besides the eight data lines, you can use the four control lines (-STROBE, -AUTOFD, -INIT, and -SEL IN) as general purpose output lines when the port is set to **SPP Mode**. Similarly, you can use the five status lines (-ERROR, SEL OUT, PAPER EMPTY, -ACK, and BUSY) as general purpose input lines.

You can also read the four control lines and use them as input lines. These lines have open collector drivers with 4.7K ohm pull-ups. To use a control line as an input line, you must first write to its corresponding bit in the control register. Refer to Table 3-12 for the parallel port control register bit definitions. If the line is inverting, write a "0", otherwise write a "1". This will cause the line to float (pulled up by the 4.7K ohm resistors). When they float, you can use them as inputs. Table 3-11 is a summary of the uses of the parallel port lines.

Table 3-11. Parallel Port Use

Signal Type	Number of Lines	Function	Output Drive
Data	8 lines	Read/Write	24 mA @ .5V 12 mA @ 2.4V
Control	4 lines	Read/Write*	12 mA @.5V 4.7K PU
Status	5 lines	Read Only	--
* Open collector control lines convert to TTL outputs in EPP and ECP modes. Output under those conditions is 4 mA @ 2.4V			

Parallel Port Interrupt Enable

Bit 4 in the control register, IRQEN, (see Table 3-12) enables the parallel port interrupt. If this bit is high, then a rising edge on the -ACK (IRQ) line will produce an interrupt on IRQ7.

Table 3–12. Parallel Port Register Bits

Register	Bit	Signal Name or Function	In/Out	Active High/Low	J15 Pin	DB25F Pin
DATA (378h)	0	Data 0	I/O	High	3	2
	1	Data 1	I/O	High	5	3
	2	Data 2	I/O	High	7	4
	3	Data 3	I/O	High	9	5
	4	Data 4	I/O	High	11	6
	5	Data 5	I/O	High	13	7
	6	Data 6	I/O	High	15	8
	7	Data 7	I/O	High	17	9
STATUS (379h)	0	0	In	---	---	---
	1	0	---	---	---	---
	2	0	---	---	---	---
	3	ERROR*	In	Low	4	15
	4	SLCT	In	High	25	13
	5	PE	In	High	23	12
	6	ACK* (IRQ)	In	Low	19	10
	7	BUSY	In	High	21	11
CONTROL (37Ah)	0	STROBE*	Out*	Low	1	1
	1	AUTOFD*	Out*	Low	2	14
	2	INIT*	Out*	High	6	16
	3	SLC	Out*	High	8	17
	4	IRQEN	---	High	---	---
	5	PCD	---	High	---	---
	6	1	---	---	---	---
	7	1	---	---	---	---
* Can also be used as input (see text).						

Register Bit Definitions

Table 3–13 defines the register bits shown in the “Signal Name or Function” column in Table 3–12.

13. Standard and PS/2 Mode Register Bit Definitions

Signal Name	Full Name	Description
ERR*	Error	Reflects the status of the ERROR* input. 0 means an error has occurred.
SLCT	Printer selected status	Reflects the status of the SLCT input. 1 means a printer is on-line.
PE	Paper end	Reflects the status of the PE input. 1 indicates paper end.
ACK*	Acknowledge	Reflects the status of the ACK* input. 0 indicates a printer received a character..
BUSY*	Busy	Reflects the complement of the BUSY input. 0 indicates a printer is busy.
STROBE	Strobe	This bit is inverted and output to the STROBE* pin.
AUTOFD	Auto feed	This bit is inverted and output to the AUTOFD* pin.
INIT*	Initiate output	This bit is output to the INIT* pin.
SLC	Printer select input	This bit is inverted and output to the pin. It selects a printer.
IRQEN	Interrupt request enable	When set to 1, interrupts are enabled. An interrupt is generated by the positive-going ACK* input.
PCD	Parallel control direction	When set to 1, port is in input mode. In printer mode, the printer is always in output mode regardless of the state of this bit.
PD0-PD7	Parallel Data Bits	

3.10.2 EPP and ECP Operation

When set to either EPP or ECP Mode, the board’s parallel port is compliant with the IEEE-1284 Extended Capabilities Port Protocol and ISA Standard (Rev 1.09, January 7, 1993), developed by Microsoft. The IEEE-1284 specification is complex and is beyond the scope of this manual. Contact IEEE Customer Service and request IEEE Std 1284 for information about EPP and ECP operation.

IEEE Customer Service
445 Hoes Lane
PO Box 1331
Piscataway, NJ 08855-1331 USA
Phone: (800) 678-IEEE (in the US and Canada)
(908) 981-0060 (outside the US and Canada)
FAX: (908) 981-9667
Telex: 833233

3.11 BYTE-WIDE SOCKET

The 32-pin byte-wide memory socket S0 supports a variety of 28- and 32-pin JEDEC pinout memory devices, including EPROM, Flash EPROM, NOVRAM, and SRAM. If you have a backup battery attached to the Utility connector, you can configure the socket to supply backup battery power to convert an SRAM into a Non-Volatile RAM (NOVRAM). Chapter 2 gives examples of the memory devices the socket will support.

Ampro's solid state disk (SSD) drive support in the ROM BIOS and optional SSD Support Software treat the byte-wide socket as one or more DOS disk devices, containing up to 1M byte of storage. The socket is highly configurable with jumpers to accept nearly any common JEDEC byte-wide device. Instructions on how to configure the byte-wide socket for common devices are in Chapter 2.

Access Time

A device used in the byte-wide socket must have access times of 250 nS or less.

Content Mirroring

If you install a device smaller than the memory window specified in SETUP, (for example, a 32K byte component in a 64K window) the contents will appear as multiple copies in the socket's address window.

OEM Flash Memory Device

The CoreModule/3SXi CPU has an onboard Flash memory, 64K of which is used to store the ROM BIOS. The remainder is available for semi-permanent storage of programs or data. The amount of available OEM Flash memory on the CoreModule varies between 64K and 960K, depending on the model. Contact your Ampro sales representative for details about CoreModule/3SXi models.)

The onboard Flash memory is architecturally equivalent to a second byte-wide socket. It uses the same software mechanisms in the BIOS to control access. It is also configured with SETUP in the same way as the byte-wide socket. It is designated **OEM Flash** in SETUP.

The BIOS accesses the byte-wide S0 and the OEM Flash memory, S1, as 8-bit devices on the PC expansion bus. If you are using both devices, your application program must manually enable and disable them, as only one can be enabled at a time.

3.11.1 Accessing the Byte-Wide Socket and OEM Flash Device

To access the byte-wide socket or the OEM Flash device, it must be enabled. Using SETUP, you can cause either device to be enabled at boot time. This places the contents of the enabled device at the address you specified in SETUP and the processor can access this memory in a normal fashion. If you want to use both the byte-wide socket and the OEM Flash device, you will need to enable each device as it is needed, as only one can be enabled at a time.

Here is a simple assembly language routine showing how to use an Ampro extended-BIOS call to enable or disable the byte-wide memory socket, S0, or the OEM Flash memory. (This code selects the first 64K page on large devices.) Note that when you enable a device, the BIOS call automatically disables the opposite device.

```

;-----
; Access control code for a byte-wide socket (S0 or the
; OEM Flash memory)
;-----
MOV  AH,0CDH          ; AMPRO function call
MOV  AL,nn            ; Use 03 for S0; 04 for the OEM Flash memory
MOV  BL,nn            ; Use 01 to turn ON or 00 to turn OFF
MOV  BH,00            ; Selects page 0 of the device
MOV  CX,414DH         ; Ampro identifier('AM')
INT  13H

```

3.11.2 Accessing Large Devices

For byte-wide devices over 64K bytes, select the 64K byte window size in SETUP. You then use software to select which segment of the device you want to appear in that window, using code equivalent to that illustrated below and using the values shown in Table 3-14. Table 3-14 gives the byte (in hex) to write to the BH register to select each 64K segment of a large device.

This assembly language routine can be used to select pages when accessing large memory devices:

```

;-----
; Page select code for a byte-wide socket (S0 or the
; OEM Flash memory)
;-----
MOV  AH,0CDH          ; AMPRO function call
MOV  AL,nn            ; Use 03 for S0; 04 for the OEM Flash memory
MOV  BL,nn            ; Use 01 to turn ON or 00 to turn OFF
MOV  BH,x0h           ; The upper nibble of BH contains the page
                       ; number for devices larger than 64 K.
MOV  CX,414Dh         ; Ampro identifier ('AM')
INT  13H

```


Table 3–14. Segment Addressing in Large Memory Devices

Device Size	64KB Segments	Segment Address (BH Value)	
128K	2	First Second	BH=00h BH=10h
256K	4	First Second Third Fourth	BH=00h BH=10h BH=20h BH=30h
512K	8	First Second Third Fourth Fifth Sixth Seventh Eighth	BH=00h BH=10h BH=20h BH=30h BH=40h BH=50h BH=60h BH=70h
1M	16	First Second Third Fourth Fifth Sixth Seventh Eighth Ninth Tenth Eleventh Twelfth Thirteenth Fourteenth Fifteenth Sixteenth	BH=00h BH=10h BH=20h BH=30h BH=40h BH=50h BH=60h BH=70h BH=80h BH=90h BH=A0h BH=B0h BH=C0h BH=D0h BH=E0h BH=F0h

128K Special Case

If you install a 128K byte device in the byte-wide socket, you can set the starting address to D0000h and the window size to 128K. It will occupy the entire D0000h - EFFFFh address region. This allows you to access the entire device without switching between windows. (The 128K byte window size is not available for the OEM Flash device, nor can it be used with Ampro's SSD/DOS Support Software.)

3.11.3 Flash EPROM Programming

To program a Flash device in byte-wide socket S0 or the OEM Flash memory, use the FLASHWRI.EXE utility supplied on the Common Utilities diskette. The Common Utilities manual describes its operation.

Programming power is handled automatically for both 5V and 12V Flash devices. The board provides 12V power for programming 12V Flash EPROMs. There are no jumpers to set (other than the Vpp jumper, W2-6), as the onboard 12V Flash programming supply is controlled by software.

You can also develop your own Flash programming routines using extended BIOS calls in the ROM BIOS. Refer to Ampro Application Note AAN-9210 for information about the extended BIOS call provided for Flash programming power. (Note that there is a 5 mS delay for the 12V Flash programming supply to come up to its full voltage after being switched on by software.)

3.12 SCSI CONTROLLER

A SCSI controller can serve many purposes, including controlling hard disk drives, tape drives, text scanners, and printer and communications servers. The ROM BIOS supports booting DOS from a SCSI device such as a hard disk. With Ampro's ROM BIOS support, you can use any device compatible with the SCSI Common Command Set (CCS) for "direct access devices." Ampro has several MiniModule products that can be used to provide a SCSI interface for a CoreModule/3SX*i* CPU system.

The CoreModule/3SX*i* Development Kit comes with a diskette containing an assortment of SCSI utilities for use with DOS. It includes a SCSI hard disk formatting utility that allows low-level formatting and changing the disk interleaving. Refer to the Ampro Utilities manual for details about using the SCSI utilities.

Besides direct access, SCSI devices include sequential access devices (tape), printer devices, read-only devices (CD-ROM), and processor devices (CPUs). These device types require special application programs, utilities, or driver software not included on the Ampro Utility diskette. Contact Ampro Technical Support for information about connecting these devices to an Ampro SCSI interface.

Hard disk support for operating systems other than DOS may or may not be available through the ROM BIOS hard disk driver. This depends on two things: whether the operating system in question uses ROM-BIOS calls exclusively for the hard disk function; and whether the operating system has any special ROM BIOS constraints, such as reentrancy. Some operating systems—multitasking ones in particular such as UNIX—bypass the BIOS and attempt to program the hard disk controller directly. With such systems, you must modify the operating system to add an appropriate SCSI hard disk driver that can take advantage of the SCSI interface. An alternative is to use the IDE interface instead of SCSI, as the IDE drive standard is more widely supported on PC platforms.

3.12.1 The Ampro SCSI BIOS

You can use a variety of mass storage devices with the SCSI universal bus interface and command protocols. Ampro has added a further layer of universality, the SCSI BIOS.

The SCSI BIOS, a set of low level functions in the ROM BIOS, is a hardware-independent interface between system software and SCSI peripherals. Using SCSI BIOS calls, programmers can write software for SCSI devices without concern for the operational details of the SCSI interface. Also, the SCSI BIOS enables you to import software from other environments more safely, quickly, and easily.

Application Note AAN-8804, available from Ampro, provides details of the SCSI BIOS functions.

3.13 PC SPEAKER

The CoreModule's motherboard logic includes a standard AT-compatible speaker port. The speaker logic signal is buffered by a transistor amplifier, and provides about 100 mW to an external 8 ohm speaker.

The audio output is based on two signals: the output of Timer 2; and the programming of two bits, 0 and 1, at I/O port 61h. Bit 1 of I/O port 61h is one term of a 2-input AND gate. The other term is the output

from Timer 2. Thus, setting bit 1 to a logic 1 enables the output of Timer 2 to the speaker, and a logic 0 disables it. Disabling Timer 2 by setting bit 0 of port 61h to a 0 causes its output to go high. Then you can use bit 1 of port 61h to control the speaker directly.

3.14 WATCHDOG TIMER

The purpose of a watchdog timer function is to restart the system should some mishap occur. Possible problems include: a failure to boot properly; the application software losing control; temporary power supply problems including spikes, surges, or interference; the failure of an interface device; unexpected conditions on the bus; or other hardware or software malfunctions. The watchdog timer helps assure proper start-up after an interruption.

The CoreModule/3SX*i* CPU ROM BIOS supports the board's watchdog timer function in two ways:

- There is an initial watchdog timer setting, specified using SETUP, which determines whether the watchdog timer will be used to monitor the system boot, and if so, how long the time-out is (30, 60, or 90 seconds).
- There is a special ROM-BIOS function which may be used by application software to start, stop, and retrigger the watchdog timer function.

The initial time-out should be set (using SETUP) to be long enough to guarantee that the system can boot and pass control to the application. Once the system is booted and the application is running, the application must periodically retrigger the timer so that a watchdog timer time-out does not occur. If the time-out does occur, the system will respond in a manner determined by how the watchdog timer jumper, W3, is set (see Chapter 2).

The following assembly language routine illustrates how to reset the watchdog timer using an Ampro extended BIOS function call:

```

;-----
; Watchdog timer control program
;-----
MOV   AH,0C3h           ; Watchdog Timer BIOS function
MOV   AL,nn             ; Use "00" to disable; "01" to enable
                           ; timer.
MOV   BX,mm             ; Selects time, in seconds
                           ;(00-FFh; 1-255 seconds)

INT   15h

```

Ampro provides a simple DOS program that can be used from the command line or in a batch program to manage the watchdog timer. It is called WATCHDOG, and is described in the Ampro Common Utilities manual.

Note

Some operating systems, including some versions of DOS, turn off the real-time clock alarm at boot time. If your OS does this, make sure that your application program enables the alarm function using this BIOS call.

If you jumper the output of the Watchdog Timer to trigger a non-maskable interrupt (NMI), an NMI IO Channel Check will be asserted by the real-time clock alarm circuit when it times out. For the system to respond to the NMI, the NMI circuit must be enabled. (In the PC architecture, the non-maskable interrupt can be masked.) To enable (unmask) the NMI, execute the following code.

```

;-----
; To enable NMI (IO channel check)
;-----
IN      AL,61H
AND     AL,NOT 08H
OUT     61H,AL
;-----

```

To use the NMI I/O Channel Check in a custom Watchdog Timer handler routine, the standard NMI handler would have to be replaced with your custom code. If you install your own NMI interrupt service routine, it can test to see if the I/O Channel Check NMI occurred by reading I/O port 61h, bit 6. Bit 6 is true (1) if the NMI occurred.

Note

Following the occurrence of an I/O Channel Check NMI, the function must be disabled and then re-enabled before the next one can occur.

3.15 POWERFAIL MONITOR

In embedded systems, it is important for the computer to execute a clean reset if its power supply fluctuates. In general, you would want to avoid erratic behavior that could result if the system voltage were to dip to marginal levels.

The CoreModule/386SX*i* has a built-in powerfail circuit that will generate a clean reset signal if power falls below 4.65V. It guarantees a minimum 140 mS reset signal, independent of how long the power falls below the 4.65V threshold.

3.16 SYSTEM MEMORY MAP

The CoreModule/3SX*i* CPU architecture allows it to address up to 64M bytes of memory. Table 3–15 shows how this memory is used.

The DRAM, the byte-wide socket, ROM BIOS, and OEM Flash memory occupy the first megabyte (starting at 00000h). You can install up to 8 megabytes of DRAM onboard with 4M bytes of base DRAM and a 4M byte custom add on memory module.

Table 3–15. CoreModule/3SXi Memory Map

Memory Address	Function
FF0000h - FFFFFFFh	Duplicates BIOS at 0F0000-0FFFFFFh.
100000h - FFFFFFFh	Extended memory
0F0000h - 0FFFFFFh	64K ROM BIOS.
0D0000h - 0FFFFFFh	Byte-wide socket S0 or OEM Flash, if enabled. Otherwise, free.
0C0000h - 0CBFFFh	VGA Video BIOS.
0A0000h - 0BFFFFh	Normally contains video RAM, as follows: CGA Video: B8000-BFFFFh Monochrome: B0000-B7FFFh EGA and VGA video: A0000-AFFFFh
000000h - 09FFFFh	Onboard DRAM

3.17 SYSTEM I/O MAP

Table 3-15 is a list of the I/O port assignments used on the CoreModule/3SXi CPU. The I/O port functions and addresses (except for a few “Ampro reserved” addresses) shown in Table 3-15 are all standard for PC compatibles from both a hardware and software perspective.

Typically, the ROM BIOS provides all the services needed to use the onboard devices and devices connected to I/O ports. If you need to directly program the standard functions, refer to a programming reference for the PC/AT.

Table 3–16. CoreModule/3SXi I/O Map

I/O Address	Function
03F8h - 03FFh	Primary serial port
03F2h - 03F7h	Floppy disk controller ports 3F2: FDC Digital output register 3F4: FDC Main status register 3F5: FDC Data register 3F7: FDC Control register 3F0, 3F1 Ampro reserved
0378h - 037Fh	Parallel port (configured as Primary)
02F8h - 02FFh	Secondary serial port
0278h - 027Fh	Parallel port (configured as Secondary)
0202h	Ampro reserved
01F0h - 01F7h	IDE hard disk interface
00F0h - 00FFh	Reserved
00C0h - 00DFh	DMA controller 2 (8237 equivalent)
00A0h - 00A1h	Interrupt controller 2 (8359 equivalent)
0092h	Fast A20 gate and CPU reset
0080h - 009Fh	DMA page registers (74LS61 equivalent)
0070h - 0071h	Real-time clock and NMI mask
0060h, 0064h 0061h	Keyboard controller (8042 equivalent) Port B
0040h - 0043h	Programmable timer (8254 equivalent)
0022h, 0023h	Ampro reserved
0020h - 0021h	Interrupt controller 1 (8359 equivalent)
0000h - 000Fh	DMA controller 1 (8237 equivalent)

Note

All I/O ports below 100h are reserved for internal system functions and should not be accessed.

INDEX

- 28-pin devices, in 32-pin sockets, 2–20

- AAN-8702, 2–21
- AAN-8804, SCSI BIOS, 3–33
- AAN-8805, EEPROM access, 3–19
- AAN-9003, 2–21
- AAN-9210, Extended BIOS, 3–8, 3–33
- AAN-9403, Serial boot, 3–12, 3–17, 3–24
- AC termination, 2–31
- AT bus, 2–29

- Backplane, quality, 2–31
- Balanced line, 3–21
- Battery, 2–5
 - Calculating life, 2–5
- Battery, external, 2–29
- Battery-backed clock, 2–26
- Bi-directional communication, 3–22
- BIOS, SCSI, 3–33
- Broadcast, 3–22
- Bus termination, 2–31
- Byte-wide, 1–3
 - Accessing large devices, 3–31
 - Addressing, 2–20
 - BIOS calls, 2–21
 - Configuration, 2–22, 3–12
 - Flash programming, 3–32
 - In memory map, 3–36
 - Serial programming, 3–17
 - Socket, 3–30
 - Socket signals, 2–25
 - Sockets, 2–19

- Cables, 2–2
 - Expansion bus, 2–31
 - Floppy, 2–15
 - IDE, 2–17
 - Keyboard, 2–28
 - Modem, 3–24
 - Parallel port, 2–12
 - Utility, 2–28
- Clock, 2–26, 3–4

- COM port table, 3–24
- Configuration
 - Summary, 2–3
- Configuration, Byte-wide, 2–22
- Connector
 - Parallel port (J15), 2–13
- Coprocessor, math, 2–7
- CPU, 1–1
- CTRL-ALT-ESC, 3–1
- Cursor commands, 3–23

- DC Power, 2–4
- DIN plug, keyboard, 2–29
- Direction, parallel port, 3–25
- Disk, floppy, 2–14, 3–5
- Disk, IDE, 2–16, 3–5
- Disk, SCSI, 3–33
- DMA, 2–37
- DOS, 3–20
 - and SCSI, 3–33
 - MODE command, 3–24
- DRAM, 2–6, 3–6

- Embedded-PC System Enhancements, 1–7
- EMS, 3–20
- Environmental specifications, 1–8
- Expanded memory, 2–6
- Expansion bus, 1–2, 2–29
- Expansion bus, ribbon cables, 2–31
- Extended memory, 2–6
- External battery, 2–29

- Filtering, PC bus, 2–31
- Flash EPROMs, 2–24
- Floppy drives, 2–14, 3–5
- Floppy interface, 1–2, 2–14, 3–10

- Half-duplex, 3–21
- Hard disk drives, SCSI, 3–14
- Hard drives, partitioning, 3–21
- Hot key setup, 3–11

I/O map, 3–36
IDE hard drives, 3–5
IDE interface, 1–2, 2–16, 3–10
IEEE 1284, 3–25, 3–29
Installation, custom, 2–2
Installation, MiniModules, 2–2, 2–30
Interface, floppy disk, 2–14
Interface, IDE, 2–16
Interrupts, 2–37

Jumpering, byte-wide, 2–22
Jumpering, general information, 2–3

LIM 4.0, 2–6, 3–20
Lithium battery, external, 2–29

Math coprocessor, 2–7
Mating connector (J15), 2–13
Mechanical specifications, 1–8
Memory map, 3–35
Memory, expanded, 2–6
Memory, extended, 2–6
MiniModule installation, 2–30
Modem, 3–23, 3–24
Motherboard, 1–1
Multidrop, 3–21, 3–22
Multimode Parallel Port, 3–25

Onboard Flash memory, 3–12

Parallel port, 1–2, 2–11, 3–21, 3–25
Parallel port configuration, 2–11
Parallel port connector (J15), 2–13
Parallel port, extended mode, 3–25
Partitioning hard drives, 3–21
PC/104 bus, 1–2
Performance, system, 2–21
Port, Serial, 2–7
Ports, 3–20
POST, SETUP, 3–7
Power requirements, 2–5
Power supplies, switching, 2–5
Power, DC, 2–4

POWERGOOD signal, 2–27
Printer port, 2–11
Pushbutton reset, 2–28

Real-time clock, 2–5, 2–26, 3–4
Reset, pushbutton, 2–28
RJ11 modular connector, 2–10
ROM BIOS, 3–20
ROM BIOS, video functions, 3–23
ROM-BIOS, extension, 2–21
RS-485, 2–9
RS-485 twisted-pair, 2–10

SCSI

BIOS, 3–33
Controller, 3–33
Utilities, 3–33
SCSI BIOS, 3–14
SCSI drive setup, 3–15
SCSI hard disk drives, 3–14
SCSI utilities, 3–14
Serial boot, 3–24
Serial boot loader, 3–12
Serial console, 3–22
Serial console option, 3–17, 3–24
Serial port, 1–1, 2–7, 3–9, 3–20
Serial programming, 3–24
SETUP, 2–6, 2–18, 2–20, 3–1
Setup, SCSI drives, 3–15
Shadowing, 2–6, 2–21, 3–7
Snubbers, 2–31
Solid state disk (SSD), 1–3, 3–30
Speaker, 2–28
Speaker, 3–33
SRAMs, 2–25
SSD, 1–3, 2–22
Switching power supplies, 2–5
System Expansion, 2–2
System, performance, 2–6

Termination, 2–10
Termination, AT bus, 2–29
Termination, floppy drives, 2–15
Termination, PC bus, 2–31
Timer, watchdog, 2–27
Token passing, 3–22

UNIX, 3–33

Utilities, SCSI, 3–33

Video, 3–23

WATCHDOG, 3–34

Watchdog timer, 2–27, 3–12, 3–34