

PCA-6277

Full-size dual socket 370
Intel® Pentium® III proces-
sorbased PCI/ISA-bus
CPU card

Copyright notice

This document is copyrighted, 2001, by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements upon the rights of third parties which may result from its use.

Acknowledgements

- AWARD is a trademark of AWARD Software, Inc.
- IBM and PC are trademarks of International Business Machines Corporation.
- Intel® and Pentium® III are trademarks of Intel Corporation.
- MS-DOS is a trademark of Microsoft Corporation.
- SMC is a trademark of Standard Microsystems Corporation.
- WinBond is a trademark of Winbond Corporation.
- VIA is a registered trademark of VIA Technologies Inc.
- Adaptec is a registered trademark of Adaptec Inc.

All other product names or trademarks are the properties of their respective owners.

A Message to the Customer

Advantech customer services

Each and every Advantech product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Advantech equipment is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Advantech has come to be known.

Your satisfaction is our primary concern. Here is a guide to Advantech's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

Technical support

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone.

So please consult this manual first. If you still cannot find the answer, gather all the information or questions that apply to your problem, and with the product close at hand, call your dealer. Our dealers are well trained and ready to give you the support you need to get the most from your Advantech products. In fact, most problems reported are minor and are able to be easily solved over the phone.

In addition, free technical support is available from Advantech engineers every business day. We are always ready to give advice on application requirements or specific information on the installation and operation of any of our products.

PCA-6277 Series comparison table

Model	PCA-6277V-00A1	PCA-6277VE-00A1	PCA-6277E2-00A1	PCA-6277F-00A1
CPU: Dual Intel®Pentium® III Socket 370	✓	✓	✓	✓
System chipset: VIA Apollo Pro 133 A	✓	✓	✓	✓
BIOS: Award P&P Flash BIOS	✓	✓	✓	✓
L2 Cache: 256 KB (on CPU)	✓	✓	✓	✓
Max. System RAM: 2 GB (4 x 168-pin sockets)	✓	✓	✓	✓
ISA High Drive: up to 64 mA	✓	✓	✓	✓
USB Port	4	4	4	4
2 EIDE connectors	✓	✓	✓	✓
2 serial, 1 parallel ports	✓	✓	✓	✓
VGA: AGP/VGA (ATI Rage 128 Pro 4 XL)	✓	✓	✓	✓
Dual LAN: 10/100Base-T Ethernet (chipset: Realtek 8139C)	X	Single	Dual	Dual
Ultra160 SCSI (Adaptec AIC-7892)	X	X	X	✓
VGA SDRAM	32 MB	32 MB	32 MB	32 MB

Product warranty

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, type of PC, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any on-screen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return material authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Initial Inspection

Before you begin installing your card, please make sure that the following materials have been shipped:

- 1 PCA-6277 dual socket 370 Pentium III® processor-based single board computer
- 2 Pentium III® processor (optional), 2 cooling fan, P/N: 1759207200
- 1 PCA-6277 startup Manual
- 1 CD driver utility and manual (in PDF format)
- 4 SCSI driver disks (optional)
- 1 FDD cable, P/N: 1701340703
- 2 UDMA 66 HDD cables, P/N: 1701400452
- 1 printer (parallel port) cable & COM port cable kit, P/N: 1700060305
- 1 ATX-to-PS/2 power cable, P/N: 1700000450
- 1 ivory cable for PS/2 keyboard and PS/2 mouse, P/N: 1700060202
- 1 SCSI cable (optional), P/N 1701060000
- 1 USB cable (optional), P/N 1700100170

If any of these items are missing or damaged, contact your distributor or sales representative immediately.

We have carefully inspected the PCA-6277 mechanically and electrically before shipment. It should be free of marks and scratches and in perfect working order upon receipt.

As you unpack the PCA-6277, check it for signs of shipping damage. (For example, damaged box, scratches, dents, etc.) If it is damaged or it fails to meet the specifications, notify our service department or your local sales representative immediately. Also notify the carrier. Retain the shipping carton and packing material for inspection by the carrier. After inspection, we will make arrangements to repair or replace the unit.

Contents

Hardware Configuration	1
1.1 Introduction	2
1.2 Features	3
1.3 Specifications	5
1.3.1 System	5
1.3.2 Memory	5
1.3.3 Input/Output	6
1.3.4 VGA interface	6
1.3.5 SCSI interface	6
1.3.6 Ethernet LAN	6
1.3.7 Industrial features	7
1.3.8 Mechanical and environmental specifications	7
1.4 Board Layout: Main Features	8
1.5 Jumpers and Connectors	9
1.6 Board Layout: Jumper and Connector Locations	13
1.7 Safety Precautions	16
1.8 Jumper Settings	17
1.8.1 How to set jumpers	17
1.8.2 CMOS clear (J1)	18
1.8.3 Watchdog timer output (J2)	18
1.9 System Memory	19
1.9.1 Sample calculation: DIMM memory capacity	19
1.9.2 Supplementary information about DIMMs	20
1.10 Memory Installation Procedures	21
1.11 Cache Memory	21
1.12 CPU Installation	22
1.13 Dual Processor Systems	23
Chapter 2 Connecting Peripherals	25
2.1 Introduction	26

2.2	Primary (CN1) and Secondary (CN2)	
	IDE Connectors	26
2.3	Floppy Drive Connector (CN3)	27
2.4	Parallel Port (CN4)	28
2.5	USB Port (CN6)	29
2.6	USB Ports (CN31 and CN32)	30
2.7	VGA Connector (CN7)	30
2.8	10/100Base-T Ethernet Connectors	
	(CN8 and CN34).....	31
2.9	Serial Ports (CN9: COM1; CN10: COM2)	31
2.10	PS/2 Keyboard and Mouse Connectors	
	(CN11 and CN33).....	33
2.11	External Keyboard Connector (CN12)	33
2.12	Infrared (IR) Connector (CN13)	34
2.13	CPU_A Fan Connector (CN14)	34
2.14	CPU_B Fan Connector (CN15)	34
2.15	Front Panel Connectors (CN16, CN17, CN18,	
	CN19, CN21 and CN22)	35
	2.15.1 Keyboard lock and power LED (CN16).....	35
	2.15.2 External speaker (CN17).....	35
	2.15.3 Reset (CN18).....	36
	2.15.4 HDD LED (CN19).....	36
2.16	ATX Power Control Connectors (CN20 and CN21).	37
	2.16.1 ATX feature connector (CN20) and soft power	
	switch connector (CN21).....	37
	2.16.2 Controlling the soft power switch.....	38
2.17	SM Bus Connector (CN23)	38
Chapter 3 Award BIOS Setup		39
3.1	Introduction	40
3.2	Entering Setup	40
3.3	Standard CMOS Setup	41
	3.3.1 CMOS RAM backup.....	41
3.4	Advanced BIOS Features	42
	3.4.1 Virus Warning.....	42

3.4.2	CPU Internal Cache / External Cache	42
3.4.3	CPU L2 Cache ECC Checking	43
3.4.4	First/Second/Third/Other Boot Device	43
3.4.5	Swap Floppy Drive	43
3.4.6	Boot UP Floppy Seek	43
3.4.7	Boot Up NumLock Status	43
3.4.8	Gate A20 Option	43
3.4.9	Typematic Rate Setting	43
3.4.10	Typematic Rate (Chars/Sec)	44
3.4.11	Typematic Delay (msec)	44
3.4.12	Security Option	44
3.4.13	MPS Version Control For OS [1.1]	44
3.4.14	OS Select for DRAM > 64MB	44
3.4.15	Video BIOS Shadow	44
3.4.16	EPA Logo Show	45
3.5	Advanced Chipset Features	45
3.5.1	DRAM Clock	46
3.5.2	SDRAM Cycle Length	46
3.5.3	Bank Interleave	46
3.5.4	Memory Hole	47
3.5.5	P2C/P2P Concurrency	47
3.5.6	System BIOS Cacheable	47
3.5.7	AGP Aperture Size	47
3.5.8	AGP-4X Mode	47
3.5.9	AGP Driving Control	48
3.5.10	AGP Fast Write	48
3.5.11	Onboard USB	48
3.5.12	USB Keyboard Support	48
3.5.13	USB Mouse Support	48
3.5.14	CPU to PCI Write Buffer	48
3.5.15	PCI Dynamic Bursting	49
3.5.16	PCI Master 0 WS Write	49
3.5.17	PCI Delay Transaction	49
3.5.18	PCI#2 Access #1 Retry	49
3.5.19	AGP Master 1 WS Write	49

3.5.20	AGP Master 1 WS Read	50
3.5.21	Memory Parity/ ECC Check	50
3.6	Integrated Peripherals	50
3.6.1	On-Chip Primary/Secondary PCI IDE	50
3.6.2	IDE Primary Master/Slave PIO/UDMA Mode, IDE Secondary Master/Slave PIO/UDMA Mode (Auto)	51
3.6.3	Init Display First	51
3.6.4	IDE HDD Block Mode	51
3.6.5	Onboard FDD Controller.....	52
3.6.6	Onboard Serial Port 1 (3F8H/IRQ4)	52
3.6.7	Onboard Serial Port 2 (2F8H/IRQ3)	52
3.6.8	UART 2 Mode Select	52
3.6.9	Onboard Parallel Port (378H/IRQ7)	53
3.6.10	Onboard Parallel Port Mode (ECP + EPP)	53
3.6.11	ECP Mode Use DMA	53
3.6.12	EPP Mode Select	53
3.7	Power Management Setup	54
3.7.1	Power Supply Type	54
3.7.2	ACPI function	54
3.7.3	Power Management	55
3.7.4	PM Control by APM	55
3.7.5	Video Off Option	56
3.7.6	Video Off Method	56
3.7.7	MODEM Use IRQ	56
3.7.8	Soft-Off by PWRBTN	56
3.7.9	State After Power Failure	57
3.7.10	Wake Up Events	57
3.8	Wake Up Event	58
3.8.1	VGA	58
3.8.2	LPT & COM	58
3.8.3	HDD & FDD	58
3.8.4	Power On by LAN	58
3.8.5	Power On by Modem	59
3.8.6	Power On by Alarm	59

3.9 PnP/PCI Configurations	60
3.9.1 PnP OS Installed	60
3.9.2 Reset Configuration Data	60
3.9.3 Resources controlled:	60
3.9.4 PCI/VGA Palette Snoop	61
3.9.5 Assign IRQ for VGA	61
3.9.6 Assign IRQ for US13	61
3.10 PC Health Status	61
3.10.1 Current CPU1 Temperature	61
3.10.2 Current CPU 2 Temperature	61
3.10.3 Current CPUFAN1 Speed	62
3.10.4 Current CPUFAN2 Speed	62
3.10.5 CPU_1 VCORE	62
3.10.6 CPU_2 VCORE	62
3.10.7 +3.3V/+5V/+12V	62
3.11 Load Setup Defaults	63
3.12 Password Setting	63
3.13 Save & Exit Setup	64
3.14 Exit Without Saving	64
Chapter 4 AGP SVGA Setup	65
4.1 Before You Begin	66
4.2 Features	66
4.3 VGA Installation	67
4.4 AGP Installation	68
Chapter 5 LAN Configuration	71
5.1 Introduction	72
5.2 Features	72
5.3 Driver Installation	73
5.4 Windows 9X Drivers Setup Procedure	74
5.5 Windows NT Drivers Setup Procedure	81
5.6 Windows 2000 Drivers Setup Procedure	88

Chapter 6 Onboard Security Setup	95
6.1 Introduction	96
6.2 Installation	96
6.3 Windows 9x Drivers Setup Procedure	97
Chapter 7 SCSI Setup and Configurations	101
7.1 Introduction	102
7.2 Understanding SCSI	102
7.3 SCSI IDs	103
7.4 Terminating the SCSI Bus	104
7.5 Configuring the SCSI interface with SCSISelect.....	105
7.6 Starting SCSISelect	106
7.7 Using SCSISelect Settings	107
7.8 Using SCSI Disk Utilities	111
7.9 Installation under Windows NT/Windows 2000	112
7.10 Windows 9X Driver setup procedure	113
7.11 Windows 2000 Driver Setup Procedure	122
7.12 Windows NT Driver Setup Procedure	133
Chapter 8 IDE Driver Setup	141
8.1 Installation	142
Appendix A Programming the Watchdog Timer	147
A.1 Programming the Watchdog Timer	148
Appendix B Pin Assignments	151
B.1 IDE Hard Drive Connector (CN1, CN2).....	152
B.2 Floppy Drive Connector (CN3).....	153
B.3 Parallel Port Connector (CN4).....	154
B.4 USB Connector (CN6).....	155
B.5 VGA Connector (CN7)	155
B.6 Ethernet 10/100Base-T RJ-45 Connector (CN8, CN34)	156
B.7 COM1/COM2 RS-232 Serial Port (CN9, CN10)....	156
B.8 Keyboard and Mouse Connector (CN11)	157

B.9	External Keyboard Connector (CN12)	157
B.10	IR Connector (CN13)	158
B.11	CPU_A Fan Power Connector (CN14)	158
B.12	CPU_B Fan Power Connector (CN15)	159
B.13	Power LED and Keylock Connector (CN16)	159
B.14	External Speaker Connector (CN17)	160
B.15	Reset Connector (CN18)	160
B.16	HDD LED Connector (CN19)	161
B.17	ATX Feature Connector (CN20)	161
B.18	ATX Soft Power Switch (CN21)	162
B.19	Extension I/O Board Connector (CN27)	162
B.20	Extension I/O Board Connector (CN28)	163
B.21	SM Bus Connector (CN29)	164
B.22	PS/2 Mouse Connector (CN33)	164
B.23	System I/O Ports	165
B.24	DMA Channel Assignments	166
B.25	Interrupt Assignments	166
B.26	1st MB Memory Map	167
B.27	PCI Bus Map	167

Tables

Table 1-1: Jumpers	9
Table 1-2: Connectors	10
Table 1-3: CMOS clear (J1)	18
Table 1-4: Watchdog timer output (J2)	18
Table 1-5: DIMM module allocation table	19
Table 1-6: DIMM memory capacity sample calculation	19
Table 2-1: Serial port connections (COM1, COM2)	32
Table 2-2: PS/2 or ATX power supply LED status	35
Table B-1: IDE hard drive connector (CN1, CN2)	152
Table B-2: Floppy drive connector (CN3)	153
Table B-3: Parallel port connector (CN4)	154
Table B-4: USB1/USB2 connector (CN6)	155
Table B-5: VGA connector (CN7)	155
Table B-6: Ethernet 10/100Base-T RJ-45 connector (CN8, CN34)	156
Table B-7: COM1/COM2 RS-232 serial port (CN9, CN10)	156
Table B-8: Keyboard and mouse connector (CN11)	157
Table B-9: External keyboard connector (CN12)	157
Table B-10: IR connector (CN13)	158
Table B-11: CPU fan power connector (CN14)	158
Table B-12: CPU fan power connector (CN15)	159
Table B-13: Power LED and keylock connector (CN16)	159
Table B-14: External speaker (CN17)	160
Table B-15: Reset connector (CN18)	160
Table B-16: HDD LED connector (CN19)	161
Table B-17: ATX feature connector (CN20)	161
Table B-19: Extension I/O board connector (CN27)	162
Table B-18: ATX soft power switch (CN21)	162
Table B-20: Extension I/O board connector (CN28)	163
Table B-21: SM bus connector (CN29)	164
Table B-22: PS/2 mouse connector (CN33)	164
Table B-23: System I/O ports	165
Table B-24: DMA channel assignments	166
Table B-25: Interrupt assignments	166
Table B-26: 1st MB memory map	167
Table B-27: PCI bus map	167

Figures

Figure 1-1: Board layout: main features	8
Figure 1-2: Board layout: jumper and connector locations	13
Figure 1-3: SCSI daughter board layout	14
Figure 1-4: Extension I/O daughter board	15

CHAPTER 1

Hardware Configuration

This chapter provides background information on the PCA-6277. It will show you how to configure the card to match your application and prepare it for installation into your PC..

Sections include:

- Introduction
- Features
- Specifications
- Board Layout
- Jumpers and Connectors
- Safety Precautions
- Jumper Settings
- System Memory
- Memory Installation Procedures
- Cache Memory
- CPU Installation

1.1 Introduction

The PCA-6277 Series all-in-one industrial grade dual CPU card uses Intel's highly acclaimed Pentium® III processor, together with the VIA Apollo Pro133A chipset. The card works with standard ISA or PCI/ISA-bus passive backplanes.

The CPU provides 256 KB on-CPU L2 cache, eliminating the need for external SRAM chips. It has two PCI EIDE interfaces (for up to four devices) and a floppy disk drive interface (for up to two devices). Other features include two RS-232 serial ports (16C550 UARTs with 16-byte FIFO or compatible), one enhanced parallel port (supports EPP/ECP) and four USB (Universal Serial Bus) ports. The PCI enhanced IDE controller supports Ultra DMA 33/66/100 and PIO Mode 4 operation. This provides data transfer rates of up to 33/66/100 MB/sec. System BIOS supports boot-up from an IDE CD-ROM, SCSI CD-ROM, LS-120, IDE HDD, SCSI HDD, ZIP-100, LAN, and FDD.

A backup of CMOS data is stored in the Flash memory, which protects data even after a battery failure. Also included is a 63-level watchdog timer, which resets the CPU or generates an interrupt if a program cannot be executed normally. This enables reliable operation in unattended environments.

The PCA-6277 Series offers several impressive industrial features such as a VGA (AGP) controller, an ultra 160 SCSI controller, dual 10/100 Base-T networking controller, four DIMM slots for a total of 2 GB RAM memory, and an ISA High Drive. All these make it an ideal choice for applications that require both high performance and full functionality.

Note: Some of the features mentioned above are not available with all models. For more information about the specifications of a particular model, see Section 1.3 Specifications.

1.2 Features

1. **Fan status monitoring and alarm:** To prevent system overheating and damage, the CPU fan can be monitored for speed and failure. The fan is set for its normal RPM range and alarm thresholds.
2. **Temperature monitoring and alarm:** To prevent system overheating and damage, the CPU card supports processor thermal sensing and auto-protection.
3. **Voltage monitoring and alarm:** System voltage levels are monitored to ensure stable current flows to critical components. Voltage specifications will become even more critical for processors of the future. Thus monitoring will become ever more necessary to ensure proper system configuration and management.
4. **ATX soft power switch:** Through the BIOS, the power button can be defined as the "Standby" (aka "Suspend" or "Sleep") button or as the "Soft-Off" button (see Section 3.6.6 Soft-off by PWR-BTN). Regardless of the setting, pushing the power button for more than 4 seconds will enter the Soft-Off mode.
5. **Power-on by modem (requires modem):** This allows a computer to be turned on remotely through an internal or external modem. Users can thus access information on their computers from anywhere in the world.
6. **Power-on by LAN:** This allows you to remotely power up your system through your network by sending a wake-up frame or signal. With this feature, you can remotely upload/ download data to/from systems during off-peak hours.
7. **Message LED:** Chassis LEDs now act as information providers. The way a particular LED illuminates indicates the stage the computer is in. A single glimpse provides useful information to the user.

8. **Jumper free mode:** When enabled, this allows processor settings and easy overclocking of frequency and Vcore voltages all through the BIOS setup. Easy-to-use DIP switches instead of jumpers are included in case you want to manually adjust the processor's external frequency.
9. **CMOS RAM backup:** When BIOS CMOS setup has been completed, data in the CMOS RAM is automatically backed up to the Flash ROM. This is particularly useful in industrial environments which may cause soft errors. Upon such an error occurring, BIOS will check the data, and automatically restore the original data for booting.
10. **More:**
 - **Power On by Alarm:** Powers up your computer at a certain time
 - **Virus warning:** During and after system boot-up, any attempt to write to the boot sector or partition table of the hard disk drive will halt the system. In this case, a warning message will be displayed. You can then run your anti-virus program to locate the problem

1.3 Specifications

1.3.1 System

- **CPU:** Dual Intel Pentium® III processor, up to 1GHz, FSB 100/133 MHz
- **BIOS:** Award Flash BIOS, 2 Mb
- **System Chipset:** VIA Apollo Pro133A (VT82C694X + VT82C686B)
- **Green function:** Supports power management operation via BIOS. Activated by keyboard or mouse activity
- **PCI enhanced IDE hard disk drive interface:** Supports up to four IDE large hard disk drives or other enhanced IDE devices. Supports PIO mode 4 (16.67 MB/s data transfer rate) and Ultra DMA 33/66/100 (33/66/100 MB/s data transfer rate). BIOS enabled/disabled
- **Floppy disk drive interface:** Supports up to two floppy disk drives, 5¼" (360 KB and 1.2 MB) and/or 3½" (720 KB, 1.44 MB, and 2.88 MB). BIOS enabled/disabled

1.3.2 Memory

- **RAM:** Up to 2GB in four available 168-pin DIMM sockets. Supports PC100/PC133-compliant SDRAMs
- **ECC (parity DRAM only):** Modules can detect multi-bit memory errors. Correction of 1-bit memory errors

1.3.3 Input/Output

- **Bus interface:** PCI/ISA bus, PICMG compliant
- **Enhanced parallel port:** Configurable to LPT1, LPT2, LPT3, or disabled. Standard DB-25 female connector provided. Supports EPP/ECP
- **Serial ports:** Two RS-232 ports with 16C550 UARTs (or compatible) with 16-byte FIFO buffer. Supports speeds up to 115.2 Kbps. Ports can be individually configured to COM1, COM2 or disabled
- **Keyboard and PS/2 mouse connector:** Two 6-pin mini-DIN connector is located on the mounting bracket for easy connection to a keyboard or PS/2 mouse. An onboard keyboard pin header connector is also available
- **ISA driver current:** 64 mA (High Drive)

1.3.4 VGA interface

- **Supports AGP 4X, 133 MHz**
- **Controller:** ATIRAGE 128 PRO™ 4XL
- **Display memory:** 32 MB VRAM

1.3.5 SCSI interface

- **SCSI:** Supports ultra 160 SCSI up to 160 MB/sec.
- **Chipset:** Adaptec AIC-7892

1.3.6 Ethernet LAN

- **Supports dual 10/100Base-T Ethernet networking**
- **Chipset:** Realtek 8139C

1.3.7 Industrial features

- **Watchdog timer:** Can generate a system reset or IRQ11. The watchdog timer is programmable, with each unit equal to one second (63 levels). The program uses I/O port hex 443h to control the watchdog timer

1.3.8 Mechanical and environmental specifications

- **Operating temperature:** 0 ~ 60° C (depends on CPU)
- **Storage temperature:** -40 ~ 60° C (-40 ~ 140° F)
- **Humidity:** 20 ~ 95% non-condensing
- **Power supply voltage:** +5 V, ±12 V
- **Power consumption:** Typical: +5V @ 11.8A, -5V@0.1A
+12V @ 0.5A, -12V @ 0.1A
(Dual Pentium III 1 GHz, 384 MB SDRAM)
- **Board size:** 338 x 122 mm (13.3" x 4.8")
- **Board weight:** 0.5 kg (1.2 lb)

1.4 Board Layout: Main Features




Figure 1-1: Board layout: main features

1.5 Jumpers and Connectors

Connectors on the PCA-6277 board link it to external devices such as hard disk drives and a keyboard. In addition, the board has a number of jumpers used to configure your system for your application.

The tables below list the function of each of the board jumpers and connectors. Later sections in this chapter give instructions on setting jumpers. Chapter 2 gives instructions for connecting external devices to your card.

Table 1-1: Jumpers

Label	Function
J1	CMOS clear
J2	Watchdog timer output

Table 1-2: Connectors

Label	Function
CN1	Primary IDE connector
CN2	Secodary IDE connector
CN3	Floppy driver connector
CN4	Parallel port
CN6	USB port
CN7	VGA connector
CN8	10/100Base-T Ethernet connector 1
CN9	Serial port: COM1
CN10	Serial port: COM2
CN11	PS/2 keyboard and mouse connector
CN12	External keyboard connector
CN13	Infrared (IR) connector
CN14	CPU_A FAN connector
CN15	CPU_B FAN Connector
CN16	Power LED and keyboard lock
CN17	External speaker
CN18	Reset connector
CN19	HDD LED connector
CN20	ATX feature connector
CN21	ATX soft power switch
CN27	Extension I/O board connector
CN28	Extension I/O board connector
CN29	SM BUS Connector
CN30	SCSI Daughter board

Extension I/O board

Daughter board

CN31 USB port 0, 1

CN32 USB port 2, 3

CN33 PS/2 mouse connector

CN34 10/100Base-T Ethernet connector 2

SCSI Daughter board

CN50 68 pin U160 SCSI connector

CN51 Ultra Wide SCSI Connector

CN52 Ultra Wide SCSI Connector

1.6 Board Layout: Jumper and Connector Locations




Figure 1-2: Board layout: jumper and connector locations




Figure 1-3: SCSI daughter board layout




Figure 1-4: Extension I/O daughter board

1.7 Safety Precautions

Warning! *Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on.*



Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

Caution! *Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges.*



As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

1.8 Jumper Settings

This section provides instructions on how to configure your card by setting jumpers. It also includes the card's default settings and your options for each jumper.

1.8.1 How to set jumpers



You configure your card to match the needs of your application by setting jumpers. A jumper is a metal bridge that closes an electrical circuit. It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” (or turn ON) a jumper, you connect the pins with the clip. To “open” (or turn OFF) a jumper, you remove the clip. Sometimes a jumper consists of a set of three pins, labeled 1, 2, and 3. In this case you connect either pins 1 and 2, or 2 and 3.

A pair of needle-nose pliers may be useful when setting jumpers.

1.8.2 CMOS clear (J1)

The PCA-6277 CPU card contains a jumper that can erase CMOS data and reset the system BIOS information. Normally this jumper should be set with pins 1-2 closed. If you want to reset the CMOS data, set J1 to 2-3 closed for just a few seconds, and then move the jumper back to 1-2 closed. This procedure will reset the CMOS to its default setting.

Table 1-3: CMOS clear (J1)



Function	Jumper setting	
* Keep CMOS data	1-2 closed	
Clear CMOS data	2-3 closed	

* default setting

1.8.3 Watchdog timer output (J2)

The PCA-6277 contains a watchdog timer that will reset the CPU or send a signal to IRQ11 in the event the CPU stops processing. This feature means the PCA-6277 will recover from a software failure or an EMI problem. The J2 jumper settings control the outcome of what the computer will do in the event the watchdog timer is tripped.

Table 1-4: Watchdog timer output (J2)

Function	Jumper setting	
IRQ11	1-2 closed	
* Reset	2-3 closed	

* default setting

1.9 System Memory

The top-left edge of the PCA-6277 contains four sockets for 168-pin dual inline memory modules (DIMMs). All three sockets use 3.3 V unbuffered synchronous DRAMs (SDRAM). DIMMs are available in capacities of 16, 32, 64, 128, 256 or 512 MB. The sockets can be filled in any combination with DIMMs of any size, giving your PCA-6277 single board computer between 16 MB and 2 GB of memory. Use the following table to calculate the total DRAM memory within your computer:

Table 1-5: DIMM module allocation table

Socket number	168-pin DIMM memory
1	(16, 32, 64, 128, 256 or 512 MB) x 1
2	(16, 32, 64, 128, 256 or 512 MB) x 1
3	(16, 32, 64, 128, 256 or 512 MB) x 1
4	(16, 32, 64, 128, 256 or 512 MB) x 1

1.9.1 Sample calculation: DIMM memory capacity

Suppose you install a 128 MB DIMM into your PCA-6277's socket 1 and a 32 MB DIMM into sockets 2 and 3 and 4. Your total system memory is 224 MB, calculated as follows:

Table 1-6: DIMM memory capacity sample calculation

Socket number	168-pin DIMM memory	Total memory
1	128 MB x 1	128 MB
2	32 MB x 1	32 MB
3	32 MB x 1	32 MB
4	32 MB x 1	32 MB
Total memory		224 MB

1.9.2 Supplementary information about DIMMs

Your PCA-6277 can accept SDRAM memory chips (with or without parity). Also note:

- If the PCA-6277 operates at 133/100 MHz, only use PC-133/PC-100 compliant DIMMs. Most systems will not even boot if non-compliant modules are used. This is due to strict timing issues involved at this speed.
- SDRAM chips are usually thinner and have higher pin density than EDO chips.
- Modules with 9 chips/side support ECC; modules with 8 chips/side do not support ECC.
- Single-sided modules are typically 16, 32, 64 or 128 MB; double-sided modules are usually 32, 64, 128, or 256 MB.
- PCA-6277 does not support register memory

1.10 Memory Installation Procedures

To install DIMMs, first make sure the two handles of the DIMM socket are in the "open" position. i.e. The handles lean outward. Slowly slide the DIMM module along the plastic guides on both ends of the socket. Then press the DIMM module right down into the socket, until you hear a click. This is when the two handles have automatically locked the memory module into the correct position of the DIMM socket. To remove the memory module, just push both handles outward, and the memory module will be ejected by the mechanism in the socket.

1.11 Cache Memory

Since the second level (L2) cache has been embedded into the Intel® Pentium® III processor, you do not have to take care of either SRAM chips or SRAM modules. The built-in second level cache in the Pentium® III processor yields much higher performance than the external cache memories. The cache size in the Intel® Pentium® III processor is 256 KB.

1.12 CPU Installation

The PCA-6277 provides a dual socket 370 for an Intel® Pentium® III processor. The CPU on the board must have a fan or heat sink attached, to prevent overheating.

Warning: *Without a fan or heat sink, the CPU will overheat and cause damage to both the CPU and the motherboard.*



To install a CPU, first turn off your system and remove its cover. Locate the processor socket 370.

1. Make sure the socket 370 lever is in the upright position. To raise the lever, pull it out to the side a little and raise it as far as it will go.
2. Place the CPU in the empty socket. Follow the instructions that came with the CPU. If you have no instructions, complete the following procedure. Carefully align the CPU so it is parallel to the socket and the notches on the corners of the CPU correspond with the notches on the inside of the socket. Gently slide the CPU in. It should insert easily. If it does not insert easily, pull the lever up a little bit more.
3. Press the lever down. The plate will slide forward. You will feel some resistance as the pressure starts to secure the CPU in the socket. This is normal and will not damage the CPU.

When the CPU is installed, the lever should snap into place at the side of the socket.

Note: *To remove a CPU, pull the lever out to the side a little and raise it as far as it will go. Lift out the CPU.*

1.13 Dual Processor Systems

The dual processor function of the PCA-6277 is a special design for Socket 370 CPUs. The PCA-6277 supports Intel® SMP (Symmetric Multiple Processor) specifications. It is equipped with two PGA 370 sockets with which you can install two Socket 370 processors. Of course, if desired, only one Socket 370 processor need be installed. A single Socket 370 processor can be installed in PGA 370 socket CPU-1 (default setting).

To install two Socket 370 processors, we strongly recommend you uses the same speed CPUs. Otherwise, your system may not operate properly.

For best performance, you should use an OS (operating system) that supports multi-processors. The following OS can support multi-processor functions: Microsoft Windows NT (3.5x, 4.x and 5.x), Windows 2000® server, Windows® Advanced server, SCO UNIX, FreeBSD 3.0 or later, and Linux. This list is not necessarily exhaustive. Check with your OS vendor for more information.

You can also use Microsoft Windows 3.1, 95 or 98. However, these do not support SMP specifications. Therefore, using two processors will yield the same result as using a single processor.

Note: *The PCA-6277 cannot manage the SMP function by itself. Therefore, if you use an incorrect CPU or OS which causes the SMP function to fail, you are likely to suffer damage to your hardware and/or software. Advantech cannot take any responsibility for damage in such circumstances.*

CHAPTER 2

Connecting Peripherals


This chapter tells how to connect peripherals, switches, and indicators to the PCA-6277 board.

2.1 Introduction

You can access most of the connectors from the top of the board while it is installed in the chassis. If you have a number of cards installed or have a packed chassis, you may need to partially remove the card to make all the connections.

Note: If your chassis has only one empty expansion slot to accommodate the CPU card, you can replace the standard dual-slot bracket with the single-slot bracket included in your PCA-6277 package, in which case you will have to access the connectors (CN31~34) on the extension I/O board from inside the chassis.

2.2 Primary (CN1) and Secondary (CN2) IDE Connectors



You can attach up to four IDE (Integrated Drive Electronics) drives to the PCA-6277's built-in controller. The primary (CN1) and secondary (CN2) connectors can each accommodate two drives.

Wire number 1 on the cable is red or blue and the other wires are gray. Connect one end to connector CN1 or CN2 on the CPU card. Make sure that the red/blue wire corresponds to pin 1 on the connector (in the upper right hand corner). See Chapter 1 for help finding the connector.


Unlike floppy drives, IDE hard drives can connect in either position on the cable. If you install two drives to a single connector, you will need to set one as the master and the other as the slave. You do this by setting the jumpers on the drives. If you use just one drive per connector, you should set each drive as the master. See the documentation that came with your drive for more information.

Connect the first hard drive to the other end of the cable. Wire 1 on the cable should also connect to pin 1 on the hard drive connector, which is labeled on the drive circuit board. Check the documentation that came with the drive for more information.

Connect the second hard drive to the remaining connector (CN2 or CN1), in the same way as described above.

Note: The PCA-6277 supports the Ultra ATA/100 interface and requires special IDE cables as well as a software driver to enable this function.


2.3 Floppy Drive Connector (CN3)



You can attach up to two floppy disk drives to the PCA-6277's onboard controller. You can use 3.5" (720 KB, 1.44/2.88 MB) drives.

The card comes with a 34-pin daisy-chain drive connector cable. On one end of the cable is a 34-pin flat-cable connector. On the other end are two sets of 34-pin flat-cable connector (usually used for 3.5" drives). The set on the end (after the twist in the cable) connects to the A: floppy drive. The set in the middle connects to the B: floppy drive.


2.4 Parallel Port (CN4)



The parallel port is normally used to connect the CPU card to a printer. The PCA-6277 includes an onboard parallel port, accessed through a 26-pin flat-cable connector, CN4. The card comes with an adapter cable which lets you use a traditional DB-25 connector. The cable has a 26-pin connector on one end and a DB-25 connector on the other, mounted on a retaining bracket. The bracket installs at the end of an empty slot in your chassis, giving you access to the connector.

To install the bracket, find an empty slot in your chassis. Unscrew the plate that covers the end of the slot. Screw in the bracket in place of the plate. Next, attach the flat-cable connector to CN4 on the CPU card. Wire 1 of the cable is red or blue, and the other wires are gray. Make sure that wire 1 corresponds to pin 1 of CN4. Pin 1 is on the upper right side of CN4.


2.5 USB Port (CN6)



The USB interface is accessed through a 10-pin flat-cable connector, CN6. The adapter cable has a 10-pin connector on one end and a USB connector on the bracket.

The USB interface can be disabled in the system BIOS setup.


2.6 USB Ports (CN31 and CN32)



The PCA-6277 provides four ports of USB (Universal Serial Bus) interface, which gives complete Plug & Play and hot swapping for up to 127 external devices. The USB interface complies with USB Specification Rev. 1.0 and is fuse-protected.


The USB interface can be disabled in the system BIOS setup.

2.7 VGA Connector (CN7)





The PCA-6277 includes an AGP SVGA interface that can drive conventional CRT displays. CN7 is a standard 15-pin D-SUB connector commonly used for VGA. Pin assignments for CRT connector CN7 are detailed in Appendix B.

2.8 10/100Base-T Ethernet Connectors (CN8 and CN34)



The PCA-6277 is equipped with one or two high-performance 32-bit PCI-bus Ethernet interfaces, which are fully compliant with IEEE 802.3/u 10/100 Mbps CSMA/CD standards. They are supported by all major network operating systems and are 100% Novell NE-2000 compatible. The RJ-45 jacks on the rear plate provide convenient 10/100Base-T RJ-45 operation.

2.9 Serial Ports (CN9: COM1; CN10: COM2)



The PCA-6277 offers two serial ports, CN9 as COM1 and CN10 as COM2. These ports can connect to serial devices, such as a mouse or a printer, or to a communications network.

Table 2-1: Serial port connections (COM1, COM2)


Connector	Ports	Address	Interrupt
CN9	COM1	3F8*, 3E8	IRQ4
CN10	COM2	2F8*, 2E8	IRQ3

* default settings

The IRQ and address ranges for both ports are fixed. However, if you want to disable the port or change these parameters later, you can do this in the system BIOS setup.


Different devices implement the RS-232 standard in different ways. If you are having problems with a serial device, be sure to check the pin assignments for the connector.

2.10 PS/2 Keyboard and Mouse Connectors (CN11 and CN33)




Two 6-pin mini-DIN connectors (CN11 and CN33) on the card mounting bracket provide connection to a PS/2 keyboard and a PS/2 mouse, respectively. CN11 can also be connected to an adapter cable (P/N: 1700060202, available from Advantech) for connecting to both a PS/2 keyboard and a PS/2 mouse.

2.11 External Keyboard Connector (CN12)




In addition to the PS/2 mouse/keyboard connector on the PCA-6277's ear plate, there is also an extra onboard external keyboard connector. This gives system integrators greater flexibility in designing their systems.

2.12 Infrared (IR) Connector (CN13)




This connector supports the optional wireless infrared transmitting and receiving module. This module mounts on the system case. You must configure the setting through the BIOS setup (see Chapter 3).

2.13 CPU_A Fan Connector (CN14)



This connector supports cooling fans of 2A or less.


2.14 CPU_B Fan Connector (CN15)



This connector supports cooling fans of 2 A or Less

2.15 Front Panel Connectors (CN16, CN17, CN18, CN19, CN21 and CN22)

There are several external switches to monitor and control the PCA-6277.



2.15.1 Keyboard lock and power LED (CN16)


CN16 is a 5-pin connector for the keyboard lock and power on LED. Refer to Appendix B for detailed information on the pin assignments. If a PS/2 or ATX power supply is used, the system's power LED status will be as indicated below:

Table 2-2: PS/2 or ATX power supply LED status

Power mode	LED (PS/2 power)	LED (ATX power)
System On	On	On
System Suspend	Fast flashes	Fast flashes
System Off	Off	Slow flashes

2.15.2 External speaker (CN17)

CN17 is a 4-pin connector for an external speaker. If there is no external speaker, the PCA-6277 provides an onboard buzzer as an alternative. To enable the buzzer, set pins 3-4 as closed.



2.15.3 Reset (CN18)

Many computer cases offer the convenience of a reset button. Connect the wire from the reset button.




2.15.4 HDD LED (CN19)

You can connect an LED to connector CN19 to indicate when the HDD is active.



2.16 ATX Power Control Connectors (CN20 and CN21)



2.16.1 ATX feature connector (CN20) and soft power switch connector (CN21)

The PCA-6277 can support an advanced soft power switch function if an ATX power supply is used. To enable the soft power switch function:

1. Take the specially designed ATX-to-PS/2 power cable out of the PCA-6277's accessory bag.
2. Connect the 3-pin plug of the cable to CN20 (ATX feature connector).
3. Connect the power on/off button to CN21. (A momentary type of button should be used.)

Note: *If you will not be using an ATX power connector, make sure that pins 2-3 of CN20 are closed.*

Warnings: *1. Make sure that you unplug your power supply when adding or removing expansion cards or other system components. Failure to do so may cause severe damage to both your CPU card and expansion cards.*



2. ATX power supplies may power on if certain motherboard components or connections are touched by metallic objects.

Important: Make sure that the ATX power supply can take at least a 720 mA load on the 5 V standby lead (5VSB). If not, you may have difficulty powering on your system and/or supporting the "Wake-on-LAN" function.

2.16.2 Controlling the soft power switch

Users can also identify the current power mode through the system's power LED (see Section 2.13.1).

2.17 SM Bus Connector (CN23)

This connector can be used for external devices which need to be connected to the SM bus (system management bus).

CHAPTER 3

Award BIOS Setup

This chapter describes how to set the card's BIOS configuration data.

3.1 Introduction

Award's BIOS ROM has a built-in setup program that allows users to modify the basic system configuration. This type of information is stored in battery-backed memory (CMOS RAM) so that it retains the setup information when the power is turned off.

3.2 Entering Setup

Turn on the computer and check for the “patch code”. If there is a number assigned to the patch code, it means that the BIOS supports your CPU.

If there is no number assigned to the patch code, please contact Advantech's applications engineer to obtain an up-to-date patch code file. This will ensure that your CPU's system status is valid.

After ensuring that you have a number assigned to the patch code, press to allow you to enter the setup.




Figure 3-1: Award BIOS Setup initial screen

3.3 Standard CMOS Setup

Choose the “Standard CMOS Features” option from the “Initial Setup Screen” menu, and the screen below will be displayed. This menu allows users to configure system components such as date, time, hard disk drive, floppy drive, display, and memory.




Figure 3-2: Standard CMOS features screen

3.3.1 CMOS RAM backup

The CMOS RAM is powered by an onboard button cell battery.

When BIOS CMOS Setup has been completed, CMOS RAM data is automatically backed up to Flash ROM. If conditions in a harsh industrial environment cause a soft error, BIOS will recheck the data and automatically restore the original data for booting.

Note: If you intend to update CMOS RAM data, you have to click on “DEL” within two seconds of the “CMOS checksum error...” display screen message appearing. Then enter the “Setup” screen to modify the data. If the “CMOS checksum error...” message appears again and again, please check to see if you need to replace the battery in your system.

3.4 Advanced BIOS Features

The “Advanced BIOS Features” screen appears when choosing the “Advanced BIOS Features” item from the “Initial Setup Screen” menu. It allows the user to configure the PCA-6277 according to his particular requirements.

Below are some major items that are provided in the Advanced BIOS Features screen.

A quick booting function is provided for your convenience. Simply enable the Quick Booting item to save yourself valuable time.




Figure 3-3: Advanced BIOS features screen (1)

3.4.1 Virus Warning

If enabled, a warning message and alarm beep activates if someone attempts to write here. The commands are “Enabled” or “Disabled.”

3.4.2 CPU Internal Cache / External Cache

Enabling this feature speeds up memory access. The commands are “Enabled” or “Disabled.”

3.4.3 CPU L2 Cache ECC Checking

Enabling allows CPU L2 cache checking. The commands are “Enabled” or “Disabled.”

3.4.4 First/Second/Third/Other Boot Device

The BIOS tries to load the OS with the devices in the sequence selected.

Choices are: Floppy, LS/ZIP, HDD, SCSI, CDROM, LAN, Disabled.

3.4.5 Swap Floppy Drive

Logical name assignments of floppy drives can be swapped if there is more than one floppy drive. The commands are “Enabled” or “Disabled.”

3.4.6 Boot UP Floppy Seek

Selection of the command “Disabled” will speed the boot up. Selection of “Enabled” searches disk drives during boot up.

3.4.7 Boot Up NumLock Status

This feature selects the “power on” state for NumLock. The commands are “Enabled” or “Disabled.”

3.4.8 Gate A20 Option

Normal The A20 signal is controlled by the keyboard controller.

Fast (Default) The A20 signal is controlled by the chipset.

3.4.9 Typematic Rate Setting

The typematic rate is the rate key strokes repeat as determined by the keyboard controller. The commands are “Enabled” or “Disabled.”

Enabling allows the typematic rate and delay to be selected.

3.4.10 Typematic Rate (Chars/Sec)

BIOS accepts the following input values (characters/second) for typematic rate: 6, 8, 10, 12, 15, 20, 24, 30.

3.4.11 Typematic Delay (msec)

Typematic delay is the time interval between the appearance of two consecutive characters, when holding down a key. The input values for this category are: 250, 500, 750, 1000 (msec).

3.4.12 Security Option

This setting determines whether the system will boot up if the password is denied. Access to Setup is, however, always limited.

System The system will not boot, and access to Setup will be denied if the correct password is not entered at the prompt.

Setup The system will boot, but access to Setup will be denied if the correct password is not entered at the prompt.

Note: To disable security, select "PASSWORD SETTING" in the main menu. At this point, you will be asked to enter a password. Simply press <Enter> to disable security. When security is disabled, the system will boot, and you can enter Setup freely.

3.4.13 MPS Version Control For OS [1.1]

3.4.14 OS Select for DRAM > 64MB

This setting allows selecting an OS with greater than 64MB of RAM. Commands are "Non-OS2" or "OS2."

3.4.15 Video BIOS Shadow

Enable copies video BIOS to share RAM for performance improving. Choices are Enable, Disable.




Figure 3-4: Advanced BIOS features screen (2)

3.4.16 EPA Logo Show

Energy Star Log from Environmental Protection Agency. Choices are: Enable, Disable.

3.5 Advanced Chipset Features

By choosing the “Advanced Chipset Features” option from the “Initial Setup Screen” menu, the screen below will be displayed. This sample screen contains the manufacturer’s default values for the PCA-6277, as shown in Figure 3-5:

Note: DRAM default timings have been carefully chosen and should ONLY be changed if data is being lost. Please first contact technical support.




Figure 3-5: Advanced chipset features screen (1)

3.5.1 DRAM Clock

This item allows you to control the DRAM speed. The Choice: Host Clock, CLK-33M.

3.5.2 SDRAM Cycle Length

When synchronous DRAM is installed, the number of clock cycles of CAS latency depends on the DRAM timing. Do not reset this field from the default value specified by the system designer. The Choice: 2, 3.

3.5.3 Bank Interleave

This item allows you to select the value in this field, depending on whether the board has paged DRAMs or EDO (extended data output)

DRAMs. The Choice: EDO 50ns, EDO 60ns, Slow, Medium, Fast, Turbo.

3.5.4 Memory Hole

In order to improve performance, certain space in memory is reserved for ISA cards. This memory must be mapped into the memory space below 16MB. The Choice: 15M-16M, Disabled.

3.5.5 P2C/P2P Concurrency

This item allows you to enable/disable the PCI to CPU, CPU to PCI concurrency. The Choice: Enabled, Disabled

3.5.6 System BIOS Cacheable

Selecting *Enabled* allows caching of the system BIOS ROM at F0000h-FFFFFh, resulting in better system performance. However, if any program writes to this memory area, a system error may result. The choice: Enabled, Disabled.

3.5.7 AGP Aperture Size

Select the size of Accelerated Graphics Port (AGP) aperture. The aperture is a portion of the PCI memory address range dedicated for graphics memory address space. Host cycles that hit the aperture range are forwarded to the AGP without any translation. The Choice: 4M, 8M, 16M, 32M, 65M, 128M, 256M.

3.5.8 AGP-4X Mode

This item allows you to enable / disable the AGP-4X Mode. The Choice: Enabled, Disabled.

3.5.9 AGP Driving Control

This item allows you to adjust the AGP driving force. Choose *Manual* to key in a AGP Driving Value in the next selection. This field is recommended to set in Auto for avoiding any error in your system. The Choice: Auto, Manual.

3.5.10 AGP Fast Write

This item allows you to adjust the AGP driving force. The Choice: Min=0000~Max=00FF.

3.5.11 Onboard USB

This should be enabled if your system has a USB installed on the system board and you want to use it. Even when so equipped, if you add a higher performance controller, you will need to disable this feature. The choice: Enabled, Disabled.

3.5.12 USB Keyboard Support

Select *Enabled* if your system contains a Universal Serial Bus (USB) controller and you have a USB keyboard. The choice: Enabled, Disabled.

3.5.13 USB Mouse Support

Select *Enabled* if your system contains a Universal Serial Bus (USB) controller and you have a USB mouse. The choice: Enabled, Disabled.

3.5.14 CPU to PCI Write Buffer

When this field is *Enabled*, writes from the CPU to the PCI bus are

buffered, to compensate for the speed differences between the CPU and the PCI bus. When *Disabled*, the writes are not buffered and the CPU must wait until the write is complete before starting another write cycle. The choice: Enabled, Disabled..

3.5.15 PCI Dynamic Bursting

When *Enabled*, every write transaction goes to the write buffer. Burstable transactions then burst on the PCI bus and nonburstable transactions don't. The choice: Enabled, Disabled

3.5.16 PCI Master 0 WS Write

When *Enabled*, writes to the PCI bus are executed with zero wait states. The choice: Enabled, Disabled

3.5.17 PCI Delay Transaction

The chipset has an embedded 32-bit posted write buffer to support delay transactions cycles. Select *Enabled* to support compliance with PCI specification version 2.1. The choice: Enabled, Disabled

3.5.18 PCI#2 Access #1 Retry

When disabled, PCI#2 will not be disconnected until access finishes (default). When enabled, PCI#2 will be disconnected if max retries are attempted without success. The choice: Enabled, Disabled

3.5.19 AGP Master 1 WS Write

When *Enabled*, writes to the AGP(Accelerated Graphics Port) are executed with one wait states. The choice: Enabled, Disabled

3.5.20 AGP Master 1 WS Read

When *Enabled*, read to the AGP (Accelerated Graphics Port) are executed with one wait states. The choice: Enabled, Disabled

3.5.21 Memory Parity/ ECC Check

Enabled add a parity check to the boot-up memory test. Select Enabled when only system DRAM contains parity. The Choice: Enable, Disable.




Figure 3-6: Advanced Chipset Feature (2)

3.6 Integrated Peripherals

3.6.1 On-Chip Primary/Secondary PCI IDE

If you enable IDE HDD Block Mode, the enhanced IDE driver will be enabled. Leave IDE HDD Block Mode on the default setting.

3.6.2 IDE Primary Master/Slave PIO/UDMA Mode, IDE Secondary Master/Slave PIO/UDMA Mode (Auto)

Each channel (Primary and Secondary) has both a master and a slave, making four IDE devices possible. Because each IDE device may have a different Mode timing (0, 1, 2, 3, 4), it is necessary for these to be independent. The default setting “Auto” will allow autodetection to ensure optimal performance.




Figure 3-7: Integrated peripherals (1)

3.6.3 Init Display First

This item allows you to choose which one to activate first, PCI Slot or AGP. The choices: PCI Slot, AGP.

3.6.4 IDE HDD Block Mode

You can enable the Primary IDE channel and/or the Secondary IDE channel. Any channel not enabled is disabled. This field is for systems with only SCSI drives.

3.6.5 Onboard FDD Controller

When enabled, this field allows you to connect your floppy disk drives to the onboard floppy disk drive connector instead of a separate controller card. If you want to use a different controller card to connect the floppy disk drives, set this field to Disabled.

3.6.6 Onboard Serial Port 1 (3F8H/IRQ4)

The settings are Auto 3F8/IRQ4, 2F8/IRQ3, 3E8/IRQ4, 2E8/IRQ3, and Disabled for the on-board serial connector.

3.6.7 Onboard Serial Port 2 (2F8H/IRQ3)

The settings are Auto 3F8/IRQ4, 2F8/IRQ3, 3E8/IRQ4, 2E8/IRQ3, and Disabled for the on-board serial connector.

3.6.8 UART 2 Mode Select

This item allows you to select UART mode. The choices: HPSIR, ASKIR, Standard.




Figure 3-8: Integrated peripherals (2)

3.6.9 Onboard Parallel Port (378H/IRQ7)

This field sets the address of the on-board parallel port connector. You can select either 3BC/IRQ7, 378/IRQ7, 278/IRQ5 or Disabled. If you install an I/O card with a parallel port, make sure there is no conflict in the address assignments. The CPU card can support up to three parallel ports, as long as there are no conflicts for each port.

3.6.10 Onboard Parallel Port Mode (ECP + EPP)

This field allows you to set the operation mode of the parallel port. The setting “Normal” allows normal speed operation, but in one direction only. “EPP” allows bidirectional parallel port operation at maximum speed. “ECP” allows the parallel port to operate in bidirectional mode and at a speed faster than the maximum data transfer rate. “ECP + EPP” allows normal speed operation in a two-way mode.

3.6.11 ECP Mode Use DMA

This selection is available only if you select “ECP” or “ECP + EPP” in the Parallel Port Mode field. In ECP Mode Use DMA, you can select DMA channel 1, DMA channel 3, or Disable. Leave this field on the default setting.

3.6.12 EPP Mode Select

This field allows you to select EPP port type 1.7 or 1.9. The choices: EPP1.7, 1.9.

3.7 Power Management Setup

The power management setup controls the CPU card's "green" features to save power. The following screen shows the manufacturer's defaults:




Figure 3-9: Power management setup screen

3.7.1 Power Supply Type

The Choice: AT, ATX

3.7.2 ACPI function

This item allows you to enable/disable the Advanced Configuration and Power Management (ACPI). The choice: Enabled, Disabled.

3.7.3 Power Management

This category allows you to select the type (or degree) of power saving and is directly related to the following modes:

1. HDD Power Down
2. Doze Mode
3. Suspend Mode

There are four selections for Power Management, three of which have fixed mode settings.

Disable (default)	No power management. Disables all four modes
Min. Power Saving	Minimum power management. Doze Mode = 1 hr. Standby Mode = 1 hr., Suspend Mode = 1 hr., and HDD Power Down = 15 min.
Max. Power Saving	Maximum power management NOT ONLY AVAILABLE FOR SL CPU'S. Doze Mode = 1 min., Standby Mode = 1 min., Suspend Mode = 1 min., and HDD Power Down = 1 min.
User Defined	Allows you to set each mode individually. When not disabled, each of the ranges are from 1 min. to 1 hr. except for HDD Power Down which ranges from 1 min. to 15 min. and disable.

3.7.4 PM Control by APM

When enabled, an Advanced Power Management device will be activated to enhance the Max. Power Saving mode and stop the CPU internal clock. If Advance Power Management (APM) is installed on your system, selecting Yes gives better power savings. If the Max. Power Saving is not enabled, this will be preset to No.

3.7.5 Video Off Option

When enabled, this feature allows the VGA adapter to operate in a power saving mode.

Always On	Monitor will remain on during power saving modes
Suspend N---> Off	Monitor blanked when the systems enters the Suspend mode.
Susp,Sby N---> Off	Monitor blanked when the system enters either Suspend or Standby modes.
All Modes N> Off	Monitor blanked when the system enters any power saving mode.

3.7.6 Video Off Method

This determines the manner in which the monitor is blanked.

V/H SYNC+Blank	This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.
Blank Screen	This option only writes blanks to the video buffer.
DPMS	Select this option if your monitor supports the Display Power Management Signaling (DPMS) standard of the Video Electronics Standards to select video power management values.

3.7.7 MODEM Use IRQ

This determines the IRQ in which the MODEM can use. The choices: 3, 4, 5, 7, 9, 10, 11, NA.

3.7.8 Soft-Off by PWRBTN

If you choose “Instant-Off”, then pushing the ATX soft power switch button once will switch the system to “system off” power mode. You can choose “Delay 4 sec.” If you do so, then pushing the button for more than 4 seconds will turn off the system, whereas pushing the button momentarily (for less than 4 seconds) will switch the system to “suspend” mode.

3.7.9 State After Power Failure

This field lets you to determine the state that your computer returns after a power failure. If sets to Off, the PC will not boot after a power failure. If sets to On, the PC will restart after a power failure. If sets to Auto, the PC will go back to the previous state before a power failure occurred. For instance, if the PC is power-on when power system fails, the PC will restart when power system is working again. If the PC is power-ff when power system fails, the PC will not boot when power system is working again. The Choice: Off, On, Auto.

3.7.10 Wake Up Events

Please see Section 3.8

3.8 Wake Up Event




Figure 3-10: PC health status screen

3.8.1 VGA

When *Enabled*, you can set the VGA awakens the system.

3.8.2 LPT & COM

When *On* of LPT & COM, any activity from one of the listed system peripheral devices or IRQs wakes up the system.

3.8.3 HDD & FDD

When *On* of HDD & FDD, any activity from one of the listed system peripheral devices wakes up the system.

3.8.4 Power On by LAN

This shows you to wake up the system via LAN from the remote host. The Choice: Enable, Disable.

3.8.5 Power On by Modem

When enabled, an input signal on the serial Ring Indicator (RI) line (in other words, an incoming call on the modem) awakens the system from a soft off state. The Choice: Enable, Disable.

3.8.6 Power On by Alarm

When enabled, you can set the date and time at which the RTC (real-time clock) alarm awakens the system from Suspend mode. The Choice: Enable, Disable.

3.9 PnP/PCI Configurations

3.9.1 PnP OS Installed

This feature allows you to install the PnP OS. The commands are “yes” or “no.”

3.9.2 Reset Configuration Data

Note: This is left “Disabled.” Select “Enabled” to reset Extended System Configuration Data (ECSD) if you have installed a new add-on and your OS won’t boot and you need to reconfigure.




Figure 3-11: PnP/PCI configurations screen

3.9.3 Resources controlled:

The commands here are “Auto” or “manual.” Choosing “manual” requires you to choose resources from each following sub-menu. “Auto” automatically configures all of the boot and Plug and Play devices but you must be using Windows 95 or above.

3.9.4 PCI/VGA Palette Snoop

This is left at “Disabled” and “Enable..”

3.9.5 Assign IRQ for VGA

3.9.6 Assign IRQ for US13

3.10 PC Health Status




Figure 3-12: PC health status screen

3.10.1 Current CPU1 Temperature

This shows you the current CPU1 temperature.

3.10.2 Current CPU 2 Temperature

This shows you the current CPU2 temperature.

3.10.3 Current CPUFAN1 Speed

This shows you the current CPUFAN1 speed.

3.10.4 Current CPUFAN2 Speed

This shows you the current CPUFAN2 speed.

3.10.5 CPU_1 VCORE

This shows CPU1 core voltage.

3.10.6 CPU_2 VCORE

This shows CPU2 core voltage.

3.10.7 +3.3V/+5V/+12V

This shows you the voltage of +3.3V/+5V/+12V

3.11 Load Setup Defaults

“LOAD SETUP DEFAULTS” loads the values required by the system for maximum performance.

3.12 Password Setting

To change the password:

1. Choose the “Set Password” option from the “Initial Setup Screen” menu and press <Enter>.

The screen will display the following message:

```
Enter Password:
```

Press <Enter>.

2. If the CMOS is good or if this option has been used to change the default password, the user is asked for the password stored in the CMOS. The screen will display the following message:

```
Confirm Password:
```

Enter the current password and press <Enter>.

3. After pressing <Enter> (ROM password) or the current password (user-defined), you can change the password stored in the CMOS. The password must be no longer than eight (8) characters.

Remember, to enable the password setting feature, you must first select either “Setup” or “System” from the “Advanced BIOS Features” menu.

3.13 Save & Exit Setup

If you select this and press <Enter>, the values entered in the setup utilities will be recorded in the CMOS memory of the chipset. The microprocessor will check this every time you turn your system on and compare this to what it finds as it checks the system. This record is required for the system to operate.

3.14 Exit Without Saving

Selecting this option and pressing <Enter> lets you exit the setup program without recording any new values or changing old ones.

CHAPTER 4

AGP SVGA Setup

The PCA-6277 features an onboard PCI AGP/VGA interface. This chapter provides instructions for installing and operating the software drivers on the display driver CD included in your package.

4.1 Before You Begin

To facilitate the installation of the enhanced display device drivers and utility software, you should read the instructions in this chapter carefully before you attempt installation. The enhanced display drivers for the PCA-6277 board are located on the software installation CD. You must install the drivers and utility software by using the supplied SETUP program for DOS drivers.

Note: The files on the software installation CD are compressed. Do not attempt to install the drivers by copying the files manually. You must use the supplied SETUP program to install the drivers.

Before you begin, it is important to note that most display drivers need to have the relevant software application already installed in the system prior to installing the enhanced display drivers. In addition, many of the installation procedures assume that you are familiar with both the relevant software applications and operating system commands. Review the relevant operating system commands and the pertinent sections of your application software's user's manual before performing the installation.

4.2 Features

- Built-in ATI RAGE 128 PRO™ 4XL multimedia accelerator
- Supports AGP 4X mode with sideband addressing and AGP texturing
- PC 98 compliant
- Superior 3D performance achieved through a floating point setup engine rated at 1.5 million triangles/sec
- Integrated 250 MHz DAC allows 85 Hz refresh at 1600 x 1200 resolution
- Complete local language support
- Power management for full VESA DPMS and EPA Energy Star compliance

- User-friendly installation for Windows 95 and Windows NT
- AGP 1.0 interface
- Supports SDRAM and SGRAM at up to 125 MHz memory clock providing bandwidth up to 2 GB/S across a 128-bit interface.
- Integrates superior video features. These include filtered sealing of 720 pixel DVD content, and MPEG-2 motion compensation for software DVD

4.3 VGA Installation

First, insert CD drive. Then follow the Icons for your PCA Series model number.

Click on the right driver for the auto-installation.

If you are using Win98 or Win2000, please install AGP4x driver first.



4.4 AGP Installation

First, insert CD drive. Then follow the Icons for your PCA Series model number.


Click on AGP Drivers "Auto" for Auto-installation.



1. In the Setup, click on "next."



2. In the Installation Information, choose turbo mode or standard. Then click on "Next."



3. The installation is complete click on "Yes" to restart the system.



CHAPTER 5

LAN Configuration

The PCA-6277 features an onboard LAN interface. This chapter gives detailed information on Ethernet configuration. It shows you how to configure the card to match your application requirements.

5.1 Introduction

The PCA-6277 features an optional 32-bit 10/100 Mbps Ethernet network interface. This interface supports bus mastering architecture and auto-negotiation features. Therefore standard twisted-pair cabling with RJ-45 connectors for both 10 Mbps and 100 Mbps connections can be used. Extensive driver support for commonly-used network systems is also provided.

5.2 Features

- Realtek RTL8139C Ethernet LAN controller (fully integrated 10Base-T/100Base-TX)
- Supports Wake-on-LAN remote control function
- Supports up to 128 K bytes Boot ROM
- PCI Bus Master complies with PCI Rev. 2.2
- MAC & PHY (10/100 Mbps) interfaces
- Complies to IEEE 802.3X 10Base-T and IEEE 802.3u 100Base-T interfaces
- 3.3 V power supply with 5 V tolerant I/Os
- Dual RJ-45 connector give auto-detection of 10 Mbps or 100 Mbps network data transfer rates and connected cable types
- Supports CardBus. The CIS can be stored in 93C56 or expansion ROM
- Enhancements on ACPI, PCI power management
- Compliant to PC99 standard

5.3 Driver Installation

The PCA-6277's onboard Ethernet interface supports all major network operating systems.

The BIOS automatically detects the LAN while booting, and assigns an IRQ level and I/O address. No jumpers or switches are required for user configuration.


Note: Operating system vendors may post driver updates on their websites. Please visit the websites of OS vendors to download updated drivers.

5.4 Windows 9X Drivers Setup Procedure


Note 1: If you are using Windows 98SE, your system will find the LAN device "PCI Ethernet Controller". You must first remove this device from your system, and then restart your computer. Then you will be ready to install the correct driver by following the procedure below.

Note 2: The CD-ROM drive is designated as "E" throughout this section.


1. In the "Windows" screen, click on "Start" and select "Settings". Then click on the "Control Panel" icon to select "System".



2. In the "System Properties" window, select the "Device Manager" tab. Select "View devices by type", and navigate to: Computer\Other devices\PCI Ethernet Controller. Highlight "PCI Ethernet Controller" and click on "Properties".



3. In the "PCI Ethernet Controller Properties" window, select the "Driver" tab. Then click on "Update Driver..."



4. In the "Update Device Driver Wizard" window, click on "Next".




5. Click "Next".




6. In the following "Update Device Driver Wizard" window, select "Specify a location:". Type in: "E:\Drv_Lan\RTL8139C\WIN98". Then click on "Next".




7. In the following "Update Device Driver Wizard" window, click on "Next".




8. In the "Copying Files..." window, the correct file path should be: E:\PCA6277\LAN\WIN98. When you have the correct location, click on "OK".




9. When the "Insert Disk" window appears, insert the utility CD into the CD-ROM drive. Then click on "OK".



- When the "Update Device Driver Wizard" window shows, click on finish.




- In the "System Settings change" window, select click on "Yes".




5.5 Windows NT Drivers Setup Procedure

Note: The CD-ROM drive is designated as "E" throughout this section.


1. In the "Windows NT" screen, click on "Start" and select "Settings". Then click on the "Control Panel" icon to select "Network".




2. In the "Network" window, select the "Adapters" tab. Then click on "Add...".




3. In the "Select Network Adapter" window, click on "Have Disk...".




4. When the "Insert Disk" window appears, insert the utility CD into the CD-ROM drive. The correct file path is:
E:\Drv_Lan\RTL8139C\WINNT4. When you have the correct file path, click on "OK".




5. In the "Select OEM Option" window, click on "OK".




6. In the "Network Setup Wizard", click on "Next".




7. In the "Network Setup Wizard", choose "TCP/IP Protocol" and "NETBEUI Protocol." Then, click on "Next."




8. In the "Network Setup Wizard", click on "Next."




9. In the "Network Setup Wizard", click on "Next."




10. In the "Windows NT Setup" click on "Continue"




12. In the "Duplex mod", click "OK"




13. In the "Network" window, select the "Adapters" tab. Under "Network Adapters:", highlight "Realtek RTL8139CA/B/C(8130). PCI Fast Ethernet Ad.". Then click on "Close".



- In the "Microsoft TCP/IP Properties" window, select the "IP Address" tab. Then select "Specify an IP address". Type in the IP Address and Subnet Mask details. Then click on "OK".




- In the "Network Settings Change" window, click on "Yes".




5.6 Windows 2000 Drivers Setup Procedure

Note: The CD-ROM drive is designed as "E" throughout this section.


1. In the "Windows 2000" screen, click on " Start" and select " settings". Then click on the " Control Panel" icon to select "system".




2. In the " System Properties" window, select the " Device Manag-er".



3. In "Device Manager" screen, follow the screen instructions, to click on "Properties".



4. In the following screen, to click on "Update Driver".




5. Click on "Next".




6. Following the highlighted item, and click on "Next".




7. Click on "Have Disk".




8. Key in "E:\Drv_Lan\RTL8139c\WIN2000", then click on "OK".




9. To highlight the following item, and click "Next".



10. Click "Next".



11. Click "Finish" to complete the installation.



Onboard Security Setup

This chapter explains OBS concepts and provides instructions for installing the relevant software drivers. This is done using the driver CD included in your PCA-6277 package.

6.1 Introduction

Onboard security (OBS) functions monitor key hardware. They help you maintain your system's stability and durability.

The PCA-6277 can monitor 5 sets of system positive voltages, 2 sets of system negative voltages, CPU cooling fan speed, and CPU temperature.

The positive system voltage sets which can be monitored include:

- CPU core voltage: 1.3 V ~ 3.3 V, according to Intel specifications.
- Transmission voltage from CPU to chipset: typically 1.5 V.
- Chipset voltage: typically 3.3 V.
- Main voltage: +5 V, +12 V.

The negative system voltage sets which can be monitored include:

- Main voltage: -5 V, -12 V.

6.2 Installation


the following sections, refer to the one that provides driver setup procedure for the operating system you are using.

6.3 Windows 9x Drivers Setup Procedure


1. Insert the driver CD into your system's CD-ROM drive. In a few seconds, the software installation main menu appears, as shown in the following figure. Click on the "WIN 9X" button under the "OBS DRIVERS" heading.




2. When you will see the following message, make sure you have closed all other programs, then click on “Next.”




3. Click on “Browse” to choose destination folder. Then, click on “Next”




4. Select an existing folder. Then, click on “Next”



5. After the setup is completed. You can view OBS setting by running this utility.



6. It is recommended that you load the default values for all OBS settings. However, if desired, you can establish new conditions for voltage, fan speed, and temperature.



SCSI Setup and Configurations

The PCA-6277 features an onboard SCSI interface. This chapter provides basic SCSI concepts and instructions for installing the software drivers with the SCSI driver disks/CD included in your package.

7.1 Introduction

The PCA-6277 is equipped with an Adaptec AIC-7892 single-chip PCI-to-SCSI host adapter which provides a powerful Ultra 160 multitasking interface between your computer's PCI bus and SCSI devices (disk drives, CD-ROM drives, scanners, tape backups, removable media drives, etc.). Ultra 160 is a new generation of SCSI technology that expands SCSI performance from 80 MBytes/sec to 160 MBytes/sec. Up to a total of 15 SCSI devices can be connected to the SCSI connector through the AIC-7892.

The AIC-7892 combines this Ultra 160 SCSI technology with Adaptec's SpeedFlex™ technology. SpeedFlex allows the Adaptec SCSI card 29160 to be backwards compatible with previous generations of SCSI products, while allowing newer Ultra 160 SCSI devices to operate at the higher 160 MBytes/sec rate.

If you need to configure the SCSI, the onboard SCSI Select configuration utility allows you to change host adapter settings without opening the computer or handling the board. The SCSI Select utility also contains a utility to low-level format and verifies the disk media on your hard disk drives.

Note: If any peripheral is attached to the Ultra2 SCSI segment and is running at SE mode, one or more Ultra/Ultra Wide peripherals will be attached to the Ultra2 SCSI segment and will cause the Ultra2 SCSI segment to run at speeds up to 40 MBytes/sec instead of 80 MBytes/sec.

7.2 Understanding SCSI

SCSI (pronounced “scuzzy”) stands for Small Computer Systems Interface. SCSI is an industry standard computer interface for connecting SCSI devices to a common SCSI bus.

A SCSI bus is an electrical pathway that consists of a SCSI interface (such as the AIC-7892) installed in a computer and one or more SCSI devices. SCSI cables are used to connect the devices to the SCSI interface. For the SCSI bus to function properly, a unique SCSI ID must

be assigned to the SCSI interface and each SCSI device connected to it, and the SCSI bus must be properly terminated.

7.3 SCSI IDs

Each device attached to the AIC-7892, as well as the AIC-7892 itself, must be assigned a unique SCSI ID number from 0 to 15. A SCSI ID uniquely identifies each SCSI device on the SCSI bus and determines priority when two or more devices are trying to use the SCSI bus at the same time.

Refer to the device's documentation to set the SCSI ID. Here are some general guidelines for SCSI IDs:

- For internal SCSI devices, the SCSI ID usually is set by configuring a jumper on the device.
- For external SCSI devices, the SCSI ID usually is set with a switch on the back of the device.
- SCSI ID numbers don't have to be sequential, as long as the AIC_7892 and each device has a different number.
- For example, you can have an internal SCSI device with ID 0, and an external SCSI device with ID 6.
- SCSI ID 7 has the highest priority on the SCSI bus. The priority of the remaining IDs, in descending order, is 6 to 0, then 15 to 8.
- The on-board SCSI interface is preset to SCSI ID 7 and should not be changed. This gives it the highest priority on the SCSI bus.
- Most internal SCSI hard disk drives come from the factory pre-set to SCSI ID 0.
- If you have 8-bit (or Narrow) SCSI devices, they must use SCSI IDs 0, 1, 2, 3, 4, 5, or 6. SCSI ID 0 is recommended for the first SCSI hard disk drive.
- If you are booting your computer from a SCSI hard disk drive connected to the AIC-7892, the Boot SCSI ID setting in the

be

SCSISelect utility must correspond to the SCSI ID of the device from which you are booting. By default, the Boot SCSI ID is set to 0. We recommend that you do not change this setting.

- In Windows® 95/98, you can use the Device Manager to determine which SCSI ID is assigned to each installed SCSI device.

7.4 Terminating the SCSI Bus

To ensure reliable communication on the SCSI bus, the ends of the SCSI bus must be properly terminated. This is accomplished when the device at the end of the each cable, or the end of the cable itself, has a terminator installed (or enabled). Terminators must be removed, or termination must be disabled, on devices between the ends of each cable.

Since the method for terminating a SCSI device can vary widely, refer to the device's documentation for instructions on how to enable or disable termination. Here are some general guidelines for termination:

- Internal Ultra 160 and Ultra 2 SCSI devices come from the factory with termination disabled and cannot be changed. Proper termination for internal Ultra 160 and Ultra2 SCSI devices is provided by a 68-pin Internal LVD (low voltage differential) SCSI cable, which has a built-in terminator at its end.
- Termination on non-Ultra 160 and Ultra2 internal SCSI devices usually is controlled by manually setting a jumper or a switch on the device, or by physically removing or installing one or more resistor modules on the device.
- Termination on most external SCSI devices is controlled by installing or removing a SCSI terminator. However, termination on some external SCSI devices is enable or disabled by setting a switch on the back of the SCSI device.
- The last external Ultra160 or Ultra2 SCSI device *must* be terminated with an LVD/SE (low voltage differential/single ended) terminator plug to ensure that the device will operate at its maximum speed. If you use a different kind of terminator plug, the data I/O rate will decrease.

By default, termination on the AIC-7892 itself is set to *Automatic* (the preferred method). We recommend that you do not change this default setting.

7.5 Configuring the SCSI interface with SCSISelect

SCSISelect, included with the AIC-7892, enables you to change SCSI settings without opening the computer. SCSISelect also enables you to low-level format or verify the disk media of your SCSI hard disk drives. The following table lists the available and default settings for each SCSISelect option.

Note: The default settings are appropriate for most systems. Run SCSISelect if you need to change or view current settings, or if you would like to run the SCSI disk utilities. See the descriptions of each option starting on page 113.

SCSISelect Options	Available Settings	Default Setting
SCSI Bus Interface		
Definitions:		
Host Adapter SCSI ID	0-15	7
SCSI Parity Checking	Enable, Disabled	Enabled
Host Adapter SCSI Termination		
LVD/SE Connectors	Automatic, Enabled, Disabled	Automatic
SE Connectors	Automatic Low On/High On Low Off/High Off Low Off/High On	Automatic
Boot Device Options:		
Boot SCSI ID	0-15	0
Boot LUN Number ¹	0-7	0

SCSISelect Options	Available Settings	Default Setting
SCSI Device Configuration:		
Sync Transfer Rate (MBytes/sec)	160, 80.0, 53.4, 40.0, 32.0, 26.8, 20.0, 16.0, 13.4, 10.0 ASYN	160
Initiate Wide Negotiation	Yes, No	Yes (enabled)
Enable Disconnection	Yes, No	Yes (enabled)
Send Start Unit Command	Yes, No	Yes (enabled)
Enable Write Back Cache ²	N/C (No Change) Yes, No	N/C (No Change)
BIOS Multiple LUN Support ²	Yes, No	No (disabled)
Include in BIOS Scan ²	Yes, No	Yes (enabled)
Advanced Configuration Options:		
Reset SCSI Bus at IC Initialization	Enabled, Disabled	Enabled
Display <Ctrl><A> Messages during BIOS Initialization	Enabled, Disabled	Enabled
Extended BIOS Translation for DOS Drives > 1 GByte	Enabled, Disabled	Enabled
Verbose/Silent Mode	Verbose, Silent	Verbose
Host Adapter BIOS	Enabled Disabled : Not Scan Disabled: Scan Bus	Enabled
Domain Validation ²	Enabled, Disabled	Enabled
Support Removable Disks Under BIOS as Fixed Disks ²	Disabled Boot Only, All Disks	Disabled
BIOS Support for Bootable CD_ROM ²	Enabled, Disabled	Enabled
BIOS Support for Int 13 Extensions ²	Enabled, Disabled	Enabled

¹ Setting is valid only if Multiple LUN Support is enabled.

² Settings are valid only if host adapter BIOS is enabled.

7.6 Starting SCSISelect

Follow these steps to start SCSISelect:

1. Turn on or restart your system.
During the startup process, pay careful attention to the messages that appear on your screen.
2. When the following message appears on your screen, press the Ctrl-A keys simultaneously (this message appears for only a few seconds):

Press <Ctrl><A> for SCSISelect (TM) Utility!

3. From the menu that appears, use the arrow keys to move the cursor to the option you want to select, then press **ENTER**.

Note: If you have difficulty viewing the display, press F5 to toggle between color and monochrome modes. (This feature may not work on some monitors.)

Exiting SCSISelect

Follow these steps to exit SCSISelect:

1. Press **ESC** until a message prompts you to exit (if you changed any settings, you are prompted to save the changes before you exit.)
2. At the prompt, select **YES** to exit, then press any key to reboot the computer. Any changes you made in SCSISelect take effect after the computer boots.

7.7 Using SCSISelect Settings

To select an option, use the arrow keys to move the cursor to the option, then press **ENTER**.

In some cases, selecting an option displays another menu. You can return to the previous menu at any time by pressing **ESC**.

To restore the original SCSISelect default values, press **F6** from the main SCSISelect screen.

SCSI Bus Interface Definitions

- **Host Adapter SCSI ID**-(Default: 7) Sets the SCSI ID for the SCSI card. The Adaptec SCSI Card 29160 is set at 7, which gives it the highest priority on the SCSI bus. We recommend that you do not change this setting.
- **SCSI Parity Checking**-(Default: *Enabled*) When set to **Enabled**, verifies the accuracy of data transfer on the SCSI bus. Leave this setting enabled unless any SCSI device connected to the Adaptec SCSI Card 29160 does not support SCSI parity.

- **Host Adapter SCSI Termination**-(Default: *Automatic*) Determines the termination setting for the SCSI card. The default setting for both the LVD/SE (low voltage differential/single ended) connectors and SE connectors is *Automatic*, which allows the SCSI card to adjust the termination as needed depending on the configuration of the connected SCSI devices. We recommend that you do not change these settings.

Boot Device Options

- **Boot SCSI ID**-(Default: *0*) Specifies the SCSI ID of your boot device. We recommend that you do not change the default setting.
- **Boot LUN Number**-(Default: *0*) Specifies which LUN (Logical Unit Number) to boot from on your boot device. This setting is not valid unless Multiple LUN Support is **Enabled** (see *Advanced Configuration Options* on page 115)

SCSI Device Configuration

SCSI Device Configuration options can be set individually for each connected SCSI device.

Note: To configure settings for a SCSI device, you must know its SCSI ID (see Using Disk Utilities on page 23.)

- **Sync Transfer Rate**-(Default: *160*) Determines the maximum synchronous data transfer rate that the SCSI card supports. Use the maximum value of 160 MBytes/sec.
- **Initiate Wide Negotiation**-(Default: *Yes*) When set to **Yes**, the SCSI card attempts 16-bit data transfer (wide negotiation.) When set to **No**, the SCSI card uses 8-bit data transfer unless the SCSI device requests wide negotiation.

*Note: Set Initiate Wide Negotiation to **NO** if you are using an 8-bit SCSI device that hangs or exhibits other performance problems with 16-bit data transfer rate enabled.*

- **Enable Disconnection**-(Default: *Yes*) When set to **Yes**, allows the SCSI device to disconnect from the SCSI bus. Leave the setting at **Yes** if two or more SCSI device is connected, changing the setting to **No** results in slightly better performance.
- **Send Start Unit Command**-(Default: *Yes*) When set to **Yes**, the Start Unit Command is sent to the SCSI device at bootup.

The following three options have no effect if the SCSI Card BIOS is disabled. (The SCSI Cards BIOS is normally enabled by default.)

- **Enable Write Back Cache**-(Default: *N/C*) Can be used to enable or disable the write-back cache on SCSI disk drives connected to the host adapter. Leave this option at its default setting of N/C (no change), which usually allow for optimum drive performance.
- **BIOS Multiple LUN Support**-(Default: *No*) Leave this setting at **No** if the device does not have multiple Logical Unit Numbers (LUNs.) When set to **Yes**, the SCSI card BIOS provides boot support for a SCSI device with multiple LUNs (for example, a CD “juke box” device in which multiple CDs can be accessed simultaneously.)
- **Include in BIOS Scan**-(Default: *Yes*) When set to **Yes**, the SCSI card BIOS includes the device as part of its BIOS scan at bootup.

Advanced Configuration Options

Note: Do not change the Advanced Configuration Options unless absolutely necessary.

- **Reset SCSI Bus at IC Initialization**-(Default: *Enabled*) When set to **Enabled**, the SCSI card generates a SCSI bus reset during its power-on initialization and after a hard reset.
- **Display <Ctrl> <A> Messages during BIOS Initialization**-(Default: *Enabled*) When set to **Enabled**, the SCSI card BIOS displays the Press <Ctrl> <A> for SCSISelect (TM) Utility! message on your screen during system bootup. If this setting disabled, you can still invoke the SCSISelect Utility by pressing <Ctrl> <A> after the SCSI card BIOS banner appears.

- **Extended BIOS Translation for DOS Drives > 1 GByte**-(Default: *Enabled*) When set to **Enabled**, provides an extended translation scheme for SCSI hard disks with capacities greater than 1 GByte. This setting is necessary only for MS-DOS 5.0 or above; it is not required for other operating systems, such as NetWare or UNIX.

Caution: Changing the translation scheme destroys all data on the drive. Be sure to back your disk drives before changing the translation scheme.

Use the MS-DOS Fdisk command to partition a disk larger than 1GByte controlled by the SCSI card BIOS, when using DOS, Windows 3.1.x, or Windows 95/98.

- **Verbose/Silent Mode**-(Default: *Verbose*) When set to *Verbose*, the SCSI card BIOS displays the host adapter model on the screen during system buildup. When set to **Silent**, the message is not displayed during bootup.
- **Host Adapter BIOS (Configuration Utility Reserves BIOS Space)**-(Default: *Enabled*) Enables or disables the SCSI card BIOS.
 - Leave at **Enabled** to allow the SCSI card BIOS to scan and initialize all SCSI devices.
 - Set to **Disabled: Not scan** if the devices on the SCSI bus (for example, CD-ROM drives) are controlled by software drivers and do not need the BIOS, and you do not want the BIOS to scan the SCSI bus..Chapter 9 SCSI Setup and Configurations **117**
 - Set to **Disabled: Scan Bus** if you do not need the BIOS, but you want it to scan the SCSI devices on the bus and you need to spin up the devices.

The following four options have no effect when the SCSI Card BIOS is disabled. (The SCSI Card BIOS is normally enabled by default.)

- **Domain Validation**—(Default: *Enabled*) Determines the optimal transfer rate for each device on the SCSI bus and sets transfer rates accordingly. Displays the resulting data transfer rate.

- **Support Removable Disks Under BIOS as Fixed Disks**— (Default: *Disabled*) Determines which removable-media drives are supported by the SCSI card BIOS. Choices are as follows:
 - **Disabled**— No removable-media drives are treated as hard disk drives. Software drivers are required because the drives are not controlled by the BIOS.
 - **Boot Only**—Only the removable-media drive designated as the boot device is treated as a hard disk drive.
 - **All Disks**—All removable-media drives supported by the BIOS are treated as hard disk drives.

*Caution: You may lose data if you remove a removable-media cartridge from a SCSI drive controlled by the SCSI card BIOS while the drive is on. If you want to be able to remove the media while the drive is on, install the removable-media software driver and set Support Removable Disks Under BIOS as Fixed Disks to **Disabled**.*

- **BIOS Support for Bootable CD-ROMs**—(Default: *Enabled*) When set to **Enabled**, the SCSI card BIOS allows the computer to boot from a CD-ROM drive.
- **BIOS Support for Int 13 Extensions**—(Default: *Enabled*) When set to **Enabled**, the SCSI card BIOS supports Int 13h extensions as required by Plug-and-Play. The setting can be either enabled or disabled if your system is not Plug-and-Play.

7.8 Using SCSI Disk Utilities

To access the SCSI disk utilities, follow these steps:

1. Select the **SCSI Disk Utilities** option from the menu that appears after starting *SCSISelect*. *SCSISelect* scans the SCSI bus (to determine the devices installed) and displays a list of all SCSI IDs and the devices assigned to each ID.
2. Use the arrow keys to move the cursor to a specific ID and device, then press **Enter**.

3. A small menu appears, displaying the options Format Disk and Verify Disk Media.
- **Format Disk**—Allows you to perform a low-level format on a hard disk drive. *Most SCSI disk devices are preformatted at the factory and do not need to be formatted again.*

Caution: A low-level format destroys all data on the drive. Be sure to back up your data before performing this operation. You cannot abort a low-level format once it is started.

- **Verify Disk Media**—Allows you to scan the media of a hard disk drive for defects. If the utility finds bad blocks on the media, it prompts you to reassign them; if you select *yes*, those blocks are no longer used. Pressing **Esc** at any time aborts the utility.


7.9 Installation under Windows NT/Windows 2000

If you are only using SCSI hard drives without any IDE HDD drive installed. Please follow these steps:


1. Insert Windows NT/Windows 2000 CD Disk.
2. Press F6 immediately when it displays: “Set up is inspecting your computer’s hardware configuration.”
3. Then it enter SCSI installation. Please insert SCSI driver floppy disk.

7.10 Windows 9X Driver setup procedure


1. In the window 9x screen, click on “start” and select “setting.” Then click on the “Control Panel” icon to select “System”



2. In the “System properties”, choose “PCI SCSI Bus Controller.” Then click on “Properties”




3. Click on “Update Driver”




4. Click on “Next”




5. Recommend to search for a better driver




6. If the SCSI driver is supplied in floppy disk, click on “Floppy disk drives.” Then, click on “Next.” If the SCSI driver is supplied in CD-ROM disk, click on “CD-ROM Drive.” Then, click on “Next”




7. In the “Update Device Driver Wizard” click on “Next.”



8. The installation is completed. Click on “Finish.”




9. Click on “Yes” to restart the system.




7.11 Windows 2000 Driver Setup Procedure


1. In the windows 2000 screen, click on “start” and select “Setting.” Then click on the “Control Panel” icon to select “System.”



2. Click on “Device Manager.”



3. Select Adapter AIC-7892. Click on mouse right button, and it will pop up a menu. Then click on “Properties.”




4. Choose “Driver” and then click on “Update Driver.”




5. In the “Upgrade Device Driver Wizard”, click on “Next.”




6. Select to display a list of known drivers, and then click on “Next.”




7. Click on “Have Disk” to find the drivers.




8. Click on “Browse” to select the directory where the drivers are stored. If the drivers are supplied in floppy disk, select “A:\ ” After the directory path is chosen, click on the “OK.”



9. Choose Adaptec AIC-7892-Ultra 160 SCSI. Then click on “Next.”



10. Click on the “Next.”




11. Click on “Finish” to complete the installation.




7.12 Windows NT Driver Setup Procedure


In the Windows NT screen, click on “Start” and select “Setting.” Then click on the “Control Panel” icon to select “SCSI Adapter.”




2. In the SCSI Adapter, choose “Drivers.” Click on “Add” to install SCSI driver.




3. Click on “Have Disk.”




4. Click on “Browse” to select the drivers. If the SCSI driver is supplied in floppy disk, choose the directory A:1.



5. Click the SCSI driver, and then click “OK.”



6. The installation of SCSI Driver is completed. Click on “OK.”



CHAPTER 8

IDE Driver Setup

This chapter provides the driver setup procedure for IDE drivers. The IDE driver enables the performance of bus mastering functions on ATA-capable Hard Disk Drives and CD-ROMs.


8.1 Installation

First, insert CD drive. Then follow the Icons for your PCA Series model number.


Click on the IDE Drivers "Auto" for auto-insstallation.




1. Click on "Next."




2. Choose install, and then click on "Next."



3. Click on "Yes" to continue the installation.



4. Click on "Finish" to complete the installation.



Programming the Watchdog Timer

The PCA-6277 is equipped with a watchdog timer that resets the CPU or generates an interrupt if processing comes to a standstill for any reason. This feature ensures system reliability in industrial standalone or unmanned environments.

A.1 Programming the Watchdog Timer

To program the watchdog timer, you must write a program which writes I/O port address 443 (hex). The output data is a time interval value. The value range is from 01 (hex) to 3F (hex), and the related time interval is 1 sec. to 63 sec.

Data	Time Interval
01	1 sec.
02	2 sec.
03	3 sec.
04	4 sec.
•	•
•	•
•	•
3F	63 sec.

After data entry, your program must refresh the watchdog timer by rewriting I/O port 443 (hex) while simultaneously setting it. When you want to disable the watchdog timer, your program should read I/O port 443 (hex).

The following example shows how you might program the watchdog timer in BASIC:

```
10      REM  Watchdog timer example program
20      OUT &H443, data REM  Start and restart the watchdog
30      GOSUB 1000 REM  Your application task #1,
40      OUT &H443, data REM  Reset the timer
50      GOSUB 2000 REM  Your application task #2,
60      OUT &H443, data REM  Reset the timer
70      X=INP (&H443) REM  Disable the watchdog timer
80      END

1000     REM  Subroutine #1, your application task
.       .
.       .
.       .
1070    RETURN
2000     REM  Subroutine #2, your application task
.       .
.       .
.       .
2090    RETURN
```


Pin Assignments

This appendix contains information of a detailed or specialized nature. It includes:

- IDE Hard Drive Connector
- Floppy Drive Connector
- Parallel Port Connector
- USB Connector
- VGA Connector
- Ethernet 10/100Base-T RJ-45 Connector
- COM1/COM2 RS-232 Serial Port
- Keyboard and Mouse Connector
- External Keyboard Connector
- IR Connector
- CPU_A Fan Power Connector
- CPU_B Fan Power Connector
- Power LED and Keylock Connector
- External Speaker Connector
- Reset Connector
- HDD LED Connector
- ATX Feature Connector
- ATX Soft Power Switch
- H/W Monitor Alarm
- SM Bus Connector
- Extension I/O Board Connector
- PS/2 Mouse Connector
- System I/O Ports
- DMA Channel Assignments
- Interrupt Assignments
- 1st MB Memory Map

B.1 IDE Hard Drive Connector (CN1, CN2)




Table B-1: IDE hard drive connector (CN1, CN2)

Pin	Signal	Pin	Signal
1	IDE RESET*	2	GND
3	DATA 7	4	DATA 8
5	DATA 6	6	DATA 9
7	DATA 5	8	DATA 10
9	DATA 4	10	DATA 11
11	DATA 3	12	DATA 12
13	DATA 2	14	DATA 13
15	DATA 1	16	DATA 14
17	DATA 0	18	DATA 15
19	SIGNAL GND	20	N/C
21	DISK DMA REQUEST	22	GND
23	IO WRITE	24	GND
25	IO READ	26	GND
27	IO CHANNEL READY	28	GND
29	HDACKO*	30	GND
31	IRQ14	32	N/C
33	ADDR 1	34	N/C
35	ADDR 0	36	ADDR 2
37	HARD DISK SELECT 0*	38	HARD DISK SELECT 1*
39	IDE ACTIVE*	40	GND

* low active

B.2 Floppy Drive Connector (CN3)




Table B-2: Floppy drive connector (CN3)

Pin	Signal	Pin	Signal
1	GND	2	FDHDIN*
3	GND	4	N/C
5	N/C	6	FDEDIN*
7	GND	8	INDEX*
9	GND	10	MOTOR 0*
11	GND	12	DRIVE SELECT 1*
13	GND	14	DRIVE SELECT 0*
15	GND	16	MOTOR 1*
17	GND	18	DIRECTION*
19	GND	20	STEP*
21	GND	22	WRITE DATA*
23	GND	24	WRITE GATE*
25	GND	26	TRACK 0*
27	GND	28	WRITE PROTECT*
29	GND	30	READ DATA*
31	GND	32	HEAD SELECT*
33	GND	34	DISK CHANGE*

* low active

B.3 Parallel Port Connector (CN4)




Table B-3: Parallel port connector (CN4)

Pin	Signal	Pin	Signal
1	STROBE*	14	AUTOFD*
2	D0	15	ERR
3	D1	16	INIT*
4	D2	17	SLCTINI*
5	D3	18	GND
6	D4	19	GND
7	D5	20	GND
8	D6	21	GND
9	D7	22	GND
10	ACK*	23	GND
11	BUSY	24	GND
12	PE	25	GND
13	SLCT	26	N/C

* low active

B.4 USB Connector (CN6)




Table B-4: USB1/USB2 connector (CN6)

Pin	USB1 Signal	Pin	USB2 Signal
1	+5 V	6	+5 V
2	UV-	7	UV-
3	UV+	8	UV+
4	GND	9	GND
5	Chassis GND	10	N/C

B.5 VGA Connector (CN7)




Table B-5: VGA connector (CN7)

Pin	Signal	Pin	Signal
1	RED	9	V_{CC}
2	GREEN	10	GND
3	BLUE	11	N/C
4	N/C	12	SDT
5	GND	13	H-SYNC
6	GND	14	V-SYNC
7	GND	15	SCK
8	GND		

B.6 Ethernet 10/100Base-T RJ-45 Connector (CN8, CN34)



Table B-6: Ethernet 10/100Base-T RJ-45 connector (CN8, CN34)

Pin	Signal	Pin	Signal
1	XMT+	5	N/C
2	XMT-	6	RCV-
3	RCV+	7	N/C
4	N/C	8	N/C

B.7 COM1/COM2 RS-232 Serial Port (CN9, CN10)



Table B-7: COM1/COM2 RS-232 serial port (CN9, CN10)

Pin	Signal
1	DCD
2	RXD
3	TXD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	RI

B.8 Keyboard and Mouse Connector (CN11)




Table B-8: Keyboard and mouse connector (CN11)

Pin	Signal
1	KB DATA
2	MS DATA
3	GND
4	V_{CC}
5	KB CLOCK
6	MS CLOCK

B.9 External Keyboard Connector (CN12)




Table B-9: External keyboard connector (CN12)

Pin	Signal
1	CLK
2	DATA
3	NC
4	GND
5	V_{CC}

B.10 IR Connector (CN13)




Table B-10: IR connector (CN13)

Pin	Signal	Pin	Signal
1	+5 V	2	N/C
3	FIRRX	4	CIRRX
5	IR_RX	6	+5VSB
7	GND	8	N/C
9	IR_TX	10	N/C

B.11 CPU_A Fan Power Connector (CN14)



Table B-11: CPU fan power connector (CN14)

Pin	Signal
1	GND
2	+12 V
3	Detect

B.12 CPU_B Fan Power Connector (CN15)



Table B-12: CPU fan power connector (CN15)

Pin	Signal
1	GND
2	+12 V
3	Detect

B.13 Power LED and Keylock Connector (CN16)

You can use an LED to indicate when the CPU card is on. Pin 1 of CN16 supplies the LED's power, and Pin 3 is the ground.

You can use a switch (or a lock) to disable the keyboard so that the PC will not respond to any input. This is useful if you do not want anyone to change or stop a program which is running. Simply connect the switch from Pin 4 to Pin 5 of CN16.




Table B-13: Power LED and keylock connector (CN16)

Pin	Function
1	LED power (+5 V)
2	NC
3	GND
4	Keyboard lock
5	GND

B.14 External Speaker Connector (CN17)

The CPU card has its own buzzer. You can also connect it to the external speaker on your computer chassis.




Table B-14: External speaker (CN17)

Pin	Function
1	+5 V _{CC}
2	GND
3	Internal buzzer
4	Speaker out

B.15 Reset Connector (CN18)



Table B-15: Reset connector (CN18)

Pin	Signal
1	RESET
2	GND

B.16 HDD LED Connector (CN19)



Table B-16: HDD LED connector (CN19)

Pin	Signal
1	LED0 (LED-)
2	Vcc(LED+)

B.17 ATX Feature Connector (CN20)



Table B-17: ATX feature connector (CN20)

Pin	Signal
1	PS-ON
2	V _{CC}
3	V _{CC} SB

B.18 ATX Soft Power Switch (CN21)



Table B-18: ATX soft power switch (CN21)

Pin	Signal
1	5VSB
2	PWR-BTN

B.19 Extension I/O Board Connector (CN27)

Table B-19: Extension I/O board connector (CN27)

Pin	Signal	Pin	Signal
1	D+ (USB3)	11	D- (USB1)
2	D+ (USB2)	12	D- (USB0)
3	D- (USB3)	13	Vcc (USB1)
4	D- (USB2)	14	Vcc (USB0)
5	Vcc (USB3)	15	GND (USB1)
6	Vcc (USB2)	16	GND (USB0)
7	GND (USB3)	17	5VSB
8	GND (USB2)	18	ACT LED (LAN2)
9	D+ (USB1)	19	LINK (LAN 2)
10	D+ (USB0)	20	SPEED-100Mbps (LAN 2)

B.20 Extension I/O Board Connector (CN28)

Table B-20: Extension I/O board connector (CN28)

Pin	Signal	Pin	Signal
1	TXC+ (DVI)	11	TX0+ (DVI)
2	TXC- (DVI)	12	TX0- (DVI)
3	FP_SDAT (DVI)	13	TXD+ (LAN2)
4	FP_SCLK (DVI)	14	GND
5	H_DEC (DVI)	15	RXIN+ (LAN2)
6	FP_VCC (DVI)	16	TXD- (LAN2)
7	TX2+ (DVI)	17	MS DATA (PS/2 MS)
8	TX2- (DVI)	18	RXIN- (LAN2)
9	TX1+ (DVI)	19	MS CLOCK (PS/2 MS)
10	TX1- (DVI)	20	MS_VCC (PS/2 MS)

B.21 SM Bus Connector (CN29)



Table B-21: SM bus connector (CN29)

Pin	Signal
1	SMB_CLK
2	SMB_DATA

B.22 PS/2 Mouse Connector (CN33)




Table B-22: PS/2 mouse connector (CN33)

Pin	Signal
1	MS DATA
2	N/C
3	GND
4	V_{cc}
5	MS CLOCK
6	N/C

B.23 System I/O Ports

Table B-23: System I/O ports

Addr. range (Hex)	Device
000-01F	DMA controller
020-021	Interrupt controller 1, master
022-023	Chipset address
040-05F	8254 timer
060-06F	8042 (keyboard controller)
070-07F	Real-time clock, non-maskable interrupt (NMI) mask
080-09F	DMA page register
0A0-0BF	Interrupt controller 2
0C0-0DF	DMA controller
0F0	Clear math co-processor
0F1	Reset math co-processor
0F8-0FF	Math co-processor
1F0-1F8	Fixed disk
200-207	Game I/O
278-27F	Parallel printer port 2 (LPT3)
290-297	On-board hardware monitor
2F8-2FF	Serial port 2
300-31F	Prototype card
360-36F	Reserved
378-37F	Parallel printer port 1 (LPT2)
380-38F	SDLC, bisynchronous 2
3A0-3AF	Bisynchronous 1
3B0-3BF (LPT1)	Monochrome display and printer adapter
3C0-3CF	Reserved
3D0-3DF	Color/graphics monitor adapter
3F0-3F7	Diskette controller
3F8-3FF	Serial port 1
443	Watchdog timer

B.24 DMA Channel Assignments

Table B-24: DMA channel assignments

Channel	Function
0	Available
1	Available
2	Floppy disk (8-bit transfer)
3	Available
4	Cascade for DMA controller 1
5	Available
6	Available
7	Available

B.25 Interrupt Assignments

Table B-25: Interrupt assignments

Priority	Interrupt#	Interrupt source
1	NMI	Parity error detected
2	IRQ0	Interval timer
3	IRQ1	Keyboard
-	IRQ2	Interrupt from controller 2 (cascade)
4	IRQ8	Real-time clock
5	IRQ9	Cascaded to INT 0A (IRQ 2)
6	IRQ10	Available
7	IRQ11	Available
8	IRQ12	PS/2 mouse
9	IRQ13	INT from co-processor
10	IRQ14	Fixed disk controller
11	IRQ15	Available
12	IRQ3	Serial communication port 2
13	IRQ4	Serial communication port 1
14	IRQ5	Parallel port 2
15	IRQ6	Diskette controller (FDC)
16	IRQ7	Parallel port 1 (print port)

B.26 1st MB Memory Map

Table B-26: 1st MB memory map

Addr. range (Hex)	Device
F0000h - FFFFFh	System ROM
C8000h - EFFFFh	Unused
C0000h - C7FFFh	VGA BIOS
B8000h - BFFFFh	CGA/EGA/VGA text
B0000h - B7FFFh	Unused
A0000h - AFFFFh	EGA/VGA graphics
00000h - 9FFFFh	Base memory

B.27 PCI Bus Map

Table B-27: PCI bus map

Function	Signals: Device ID	INT# pin	GNT# pin
Onboard LAN1	AD24	INT E	
Onboard LAN2	AD21	INT H	GNT A
Onboard SCSI	AD20	INT A	GNT E
Bridge	AD22		GNT F
PCI slot 1	AD31	INT B, C, D, A	GNT A
PCI slot 2	AD30	INT C, D, A, B	GNT B
PCI slot 3	AD29	INT D, A, B, C	GNT C
PCI slot 4	AD28	INT A, B, C, D	GNT D

Note: In the PCA-6277 LAN devices use "GNT A" signals via PCI slot 1. Therefore, PCI slot 1 cannot be used for plug-in bus master add-on cards such as SCSI cards or LAN cards.

