

USER'S MANUAL
A48 MAIN BOARD



482A4801

Printed in Taiwan 2000


INDEX

This user's manual describes the jumper setting of A48 Main Board. For detailed technical information, please refer to CDs attached with PC system unit.

Table of Contents	Page
Technical details	
1. Jumpers location diagram for A48 main board	1
2. Memory configuration	2
3. Jumper setting	3 – 5


All other registered and unregistered trademarks are trademarks of their respective holders

1. Jumpers Location Diagram for "A48" V2.X M/B



2. Memory configuration for "A48" V2.X main board

- **System Memory's Configuration.**




The A48 mother board provides Auto-bank SIMM socket and supports 32-bit SIMM module operation. Install **one 72-pin SIMM module** in any of the four SIMM sockets will enable system to work.

Remark:

Please refer to above figure for SIMM socket. SIMM 1 and SIMM 2 stand for Bank 0, SIMM 3 and SIMM 4 stand for Bank 1.

Please make sure to install the same memory type at SIMM 1 and SIMM 2 for Bank 0, and same memory type at SIMM 3 and SIMM 4 for Bank 1. The memory won't be recognized if different memory type installed at the same Bank.

- **VGA Memory's Configuration.**



VGA memory	
1MB (EDO)	U19 , U20 installed
2MB (EDO)	U18 , U19 , U20 , U21 installed

IMPORTANT

The A48 on board PCI VGA ID is set on #31, if a PCI add-on card to be installed, please set its ID at #1 -#30 to avoid conflict

3. Jumper settings

CPU selection: JP18 , JP5 , JP6 , JP8

CPU	JP18	JP5	JP6	JP8
Intel Pentium 75	1-2 , 3-4	off	off	1-2 , 3-4
Intel Pentium 90	1-2	off	off	1-2 , 3-4
Intel Pentium 100	3-4	off	off	1-2 , 3-4
Intel Pentium 120	1-2	off	on	1-2 , 3-4
Intel Pentium 133	3-4	off	on	1-2 , 3-4
Intel Pentium 150	1-2 , 3-4	on	off	1-2 , 3-4
Intel Pentium 166	3-4	on	on	1-2 , 3-4
Intel Pentium 200	3-4	on	off	1-2 , 3-4
AMD 5k86-P75	1-2 , 3-4	off	off	1-2 , 3-4
AMD 5k86-P90	1-2	off	off	1-2 , 3-4
AMD 5k86-P100	3-4	off	off	1-2 , 3-4
AMD 5k86-P133	3-4	off	on	1-2 , 3-4

Cache RAM size selection: JP14

Cache RAM size	JP14
256KB (32Kb*32)	2-3
512KB (64Kb*32)	1-2

Keyboard Controller selection: JP10

K/B Controller	JP10
Built-in core logic	on
IC 8042	off

Reserved: JP3, JP4, JP7, JP15, JP17, JP22

Real Time Clock Controller selection: JP9

RTC Controller	JP9
Dallas 12887	off
Built-in core logic	on

Clean CMOS data (Dallas 12887 only): JP20

RTC Controller	JP20
Normal operation	off
Clean CMOS data	on

ROM BIOS type selection: JP1

ROM BIOS type	JP1
+5V EPROM or Flash ROM	2-3
+12V Flash ROM	1-2

DMA channel selection for ECP mode of Parallel Port: JP19

DMA channel	JP19
DMA 3	1-3 , 2-4
DMA 1	3-5 , 4-6

The Pin 1 assignment of the connector of COM1: JP2

Pin 1 signal	JP2
*DCD1	1-2
+5Vdc	3-4
+12Vdc	5-6

The Pin 2 assignment of the connector of COM2: JP13

Pin 1 signal	JP13
*DCD2	1-2
+5Vdc	3-4
+12Vdc	5-6

USB headers: J2 , J3

Pin #	Pin assignment
1	Vcc
2	USB data
3	USB data
4	GND

IR header: JP21

Pin #	Pin assignment
1	IR RX 2
2	GND
3	IR TX 2
4	Vcc

Header for LAN slot: LAN1

Header for FAN: J6 , J7