

CONTENTS

CHAPTER 1 INTRODUCTION

1-1	Introduction.....	1
1-2	Feature	2
1-3	Specification	3
1-4	Board Layout	5
1-5	Junper Setting	6

CHAPTER 2 HARDWARE SETUP

2-1	System Block Diagram	8
2-2	Installing Memory	9
2-3	Peripheral Connection.....	14
2-4	Case Connections	17

CHAPTER 3 SOFTWARE SETUP

3-1	BIOS Setup	21
3-2	How to install The EMS Driver	24

APPENDIX A	SERVICE INFORMATION 29
------------	---------------------	---------

CHECKLIST

The GSH286 main board package should contain the following :

- * The GSH286 main board
- * This manual

CHAPTER 1

INTRODUCTION

1-1 Introduction

The GSH286 main board is an cost-effective compromise between the power of a 16-bit internal architecture and the convenience of full compatibility with the IBM PC/AT and OS/2. The board therefore allows the microprocessor to operate with all the advantages of a high speed memory page interleave system, with multi-tasking and multi-user capabilities.

This manual has been designed to be useful for two purpose. If your GSH286 main board is already set up in a functioning system you may want to review the manual to familiarize yourself with the features of the board and where things are. For those who want to alter the board's configuration or upgrade it, the manual will serve as a guide to both procedure and specifications.

1-2 Features

- * Haif size 4 layers PCB.
- * System speed would be adjusted by software or hardware.
- * 8 bit signal BIOS PROM.
- * Optional for 80287 math coprocessor socket.
- * Support on-board up to 5MB memory include 1MB DIP RAM & 4MB SIMM.
- * On-board LIM EMS 4.0 hardware support.
- * On-board shadow RAM support.
- * Real time clock and calendar circuit.

* Sixteen interrupts.

* Seven DMA channel.

1-3 Specification

Base board central processor : 80286-16 (20)

Main memory

On board memory model	: 512K, 1M, 2M, 3M, 4M, 5M
Maximum memory	: 16M
DRAM access cycle time	: 100ns (80ns For 20MHz)
Memory type	: 1MB DIP RAM & 4MB SIP

Data bus width : 16 bits

Corprocessor : Synchronous model
running at CPU clock

I/O slots : 6 expansion slots
16 bits * 5
8 bits * 1

Environment

Ambient Temperature	
operating	: 0 to +55 C
non-operating	: -30 to +70 C

Relative Humidity : 0 to +85 %
noncondensing


Altitude : 0 to 10,000 feet

Vibration : random variation
0 to 1000 Hz

Physical characteristics : lenth 330 mm
width 218 mm

Power requirements : +5V +- 5%
: 180W

1-4 Board Layout



1-5 Jumper Setting

JP17 - JP22 : Setting On Board Memory Size

1 - 2 : on board 4MB

2 - 3 : on board 5MB

JP3 - Display Mode Select

OPEN : MONO CLOSE : COLOR

JP5 - External Battery Connector

SPEAK - Speaker Connector

RESET - Reset Connector

TUBLED - Turbo LED Indicator Connector

TUBSW - Turbo Switch Connector

KEYLOCK - Keyboard Inhibited And Power On
LED Indicator Connector

KB1 - Keyboard Connector


PS1 - Power Supply Connector

CHAPTER 2

HARDWARE SETUP

This board is designed using two state-of-the-art highly integrated CMOS VLSI devices such that the dimension of the board can be minimize to half size. The board would fit in virtually any system unit case from standard AT to tower cases.

2-1 System Block Diagram



2-2 Installing Memory

This section covers types of memory applicable to the GSH286 mainboard and the structure of the memory subsystem.

The board support on board up to 4MB or 5MB total memory depend on the setting of jumper JP17 through jumper JP22. Default setting for the on board memory size will be 4MB. The on board memory subsystem has four banks that use DIP RAM chips and SIP memory modules. Please refer to following FIG 2-2.1 and FIG 2-2.2 board layout for where the four banks physically located. DRAM access time can be used 100ns or 80ns.


*** Memory configuration for 4MB maximum ***

JP17 - JP22 : Setting on board memory size

1 - 2 short : For 4MB Maximum (Default)

Total size	bank 0	bank 1
	44256 DIP	
512K	or 256K SIP	*
	44256 DIP	44256 DIP
1MB	or 256K SIP	or 256K SIP
	44256 DIP	44256 DIP
2MB	1MB SIP	*
	256K SIP	1MB SIP
2.5MB	256K SIP	1MB SIP
	1MB SIP	1MB SIP
4MB	1MB SIP	1MB SIP

FIG 2-2.1:



*** Memory configuration for 5MB maximum ***

JP17 - JP22 : Setting on board memory size


2 - 3 short : For 5MB Maximum

Total size	bank 0	bank 1	bank 2	bank3
512K	44256 DIP	*	*	*
1MB	44256 DIP	44256 DIP	*	*
2MB	44256 DIP	44256 DIP	256K SIP	256K SIP
3MB	44256 DIP	44256 DIP	1MB SIP	1MB SIP
5MB	44256 DIP	44256 DIP	1MB SIP	1MB SIP



NOTE :

If set for 5MB maximum memeory space, bank 0 and bank 1 must be filled with 44256K and 41256K first.


FIG 2-2.2



2-3 Peripheral Connections



PS1



*** Power Supply Connector (PS1) ***

Pin	Description
1	Power Good
2	+ 5 V
3	+ 12 V
4	- 12 V
5	Ground
6	Ground
7	Ground
8	Ground
9	- 5 V
10	+ 5 V
11	+ 5 V
12	+ 5 V

*** Keyboard Connector (KB1) ***

Pin	Description
1	KEYCLK (Clock)
2	KEYDAT (Data)
3	N/C
4	Ground
5	+ 5 V

*** External Battery Connector (JP5) ***


There is an internal battery already inside GSH-286. This internal battery will charge automatically as you turn the system power on. But please be understood that it later system configuration will loss because this internal battery has discharged all electricity. It will take six to twelve hours to recharge the internal battery as you turn on the system power again. In order to prevent from above phenomena , you could connect an external battery when you do not use this system.

NOTE : Please take out the jumper cap of JP6 when you could connect an external battery to JP5.

Pin	Description
1	Battery (+)
2	Key
3	Ground
4	Ground

2-4 Case Connections

There are five connectors on the GSH286 board that can be attached to indicators or devices on a system case if they are presented. Following are these five connector :



*** Speaker Connector (SPEAK) ***

Pin	Description
1	Speaker data out
2	Key
3	Ground
4	+ 5 V

*** Reset Connector (RESET) ***

There are two ways to reset system. One is hardware reset. The other is software reset.

1. Hardware : Set short jumper RESET for reset
2. Software : Hold down the <Ctrl> and <Alt> and the press the key.

*** Tubro LED Connector (TUBLED) ***

It indicates turbo mode (high speed) when TURBO LED lights. Otherwise it indicates normal mode (low speed) when TURBO LED does not light.

*** Turbo Switch Connector (TUBSW) ***

The speed of the system can be charge by either the software or the hardware switch.

1. Hardware : Setting TUBSW jumper

Turbo mode - Close

Normal mode - Open

2. Software : Using keyboard

Turbo mode - Hold down the <Ctrl> and
<Alt> keys and the press
the < + > key

Normal mode - Hold down the <Ctrl> and
<Alt> keys and the press
the < - > key

*** Keylock Connector (KEYLOCK) ***

There are two function of keylock connector. One is keyboard inhibition (pin 4 and pin 5). The other one is power on indication by LED (pin 1 and pin 3). The keyboard will be locked when pin 4 and pin 5 short so that no data could be keyed in. The specifications of keylock connector pin-out are below :

Pin	Description
1	Power for LED Power-ON light
2	Key (pin removed)
3	Ground
4	Keylock
5	Ground

CHAPTER 3

SOFTWARE SETUP

3-1 BIOS Setup

The AMI 286 BIOS setup program is used to establish the system hardware setup. In general, you will not to modify the configuration in CMOS RAM, unless following cases happen:

- * CMOS options not set
- * Memory size mismatch
- * Hard Disk or Floppy disk type set-up error
- * Display configuration mismatch
- * CMOS battery is low
- * To increase hard disk of floppy disk driver
- * Set EMS to enable or disable

The AMI 286 BIOS provides not only the standard IBM AT configuration setup but also the also the ex-

tended setup such as shadow RAM, 287 wait state, fast (/normal page mode select and even more: the diagnostic program. The initial prompt after turning on will tell to press key if you wish to run the setup program . Once the setup screen is brought up (please refer to table 3-1), you can use the cursor key and the <PgUp>, <PgDn> keys to modify the conten of each field. Please select the appropriate configuration according to you hardware components (i.e. harddisk, flpooy drive , display card...)

*** BIOS Shadow ***

If enabled, the BIOS will deduct 64K memory from total memory and make a copy of either the main BIOS or the video BIOS into this 64K memory. This will improve the system performance since now the BIOS is executed from the RAM.

Table 3-1 Configuration Setup

CMOS SETUP (c) Copyright 1985-1990, American Megatrends Inc.,											
Date (mn/date/year) : Tue, May 28 1991						Base memory size : 640 KB					
Time (hour/min/sec) : 13 : 22 : 44						Ext. memory size : 320 KB					
Floppy drive A : 1.2 MB, 5h"						Numeric processor : Not installed					
Floppy drive B : Not installed											
Hard disk C: type : 17						Cyln Head WPCOM LZone Sect Size					
Hard disk D: type : Not installed						977 5 300 977 17 41 MB					
Primary display : VGA or EGA											
Keyboard : Installed											
BIOS shadow option : Main shadow											
Scratch RAM option : 1											
Co-processor wait : Disabled											
Fast Page mode : Enabled											
EMS function : Disabled											
Options:-											
360 KB 5h", 1.2 MB 5h",											
720 KB 3h", 1.44 MB 3h", Not installed											
ESC = Exit, ↑ → ↑ = Select, PgUp/PgDn = Modify											
		Sun	Mon	Tue	Wed	Thu	Fri	Sat			
		28	29	30	1	2	3	4			
		5	6	7	8	9	10	11			
		12	13	14	15	16	17	18			
		19	20	21	22	23	24	25			
		26	27	28	29	30	31	1			
		2	3	4	5	6	7	8			

*** Fast/Normal Page Mode Select ***

If enabled, the BIOS will arrange the memory space higher than 640K as EMS memory. You will also need to install the EMS driver in order to make EMS memory usable by application program. Installation the EMS driver will be described in in the later section.

*** Coprocessor Wait State ***

The field provide you the selection of wait states for the 80287 math coprocess.

3-2 How To Install The EMS Driver.

If you need to install the EMS driver in order to make EMS memory usable by application program, please connect with the supplier which will support you the master EMS driver. The

driver file is named "GEMM.sys" and it's compatible with the "EMS LIM 4.0" specifications. To install the driver, use text editor to modify the "CONFIG.SYS " to include the following line :

```
DEVICE = [d:][path]GEMM.SYS[options]
```

Where [d:] and [path] is the disk drive and the path containing the GEMM.SYS file. If you copy the GEMM.SYS into the root directory of your boot disk drive, you may ignore these two terms.

When no option is given, GEMM.SYS will automatically enable all available EMS page between segment C000 to DFFF. If any BIOS exist in those segment , that segment window will be disabled. Four option available in this EMS driver. They are described as follows:

/E:# EMS page mode

0	=	C000 - DFFF	max 8 physical pages
1	=	C000 - EFFF	max 12 physical pages
2	=	4000 - 7FFF	max 32 physical pages

/R:# Set Shadow RAM area

0	=	C000	ON
1	=	C400	ON
2	=	C800	ON
3	=	CC00	ON
4	=	F000 - F7FF	ON
5	=	F800 - FFFF	ON

/U:# User memory area set

0	=	C000	ON
1	=	C400	ON
2	=	C800	ON
3	=	CC00	ON
4	=	D000	ON
5	=	D400	ON
6	=	D800	ON
7	=	DC00	ON

/X:# Driver HMA set

- 0 = This option will copy the EMS driver to segment F400-F7FF. This option will save about 16K in the bsae memory.
- 1 = This option will install the EMS driver in the conventional manner . The EMS driver will occupy the system memory.
- 2 = This option will install the EMS driver in the segment EC00-EFFF.

) Examples :

•
•
DEVICE = GEMM.SYS

Default setting, no any other shadow RAM is set in addition to BIOS's setup. The driver is copied to segment F400-F7FF.

DEVICE = GEMM.SYS /R:0 /R:5

This will set the shadow RAM at location C000
) - C3FF (video BIOS) and F800-FFFF (system BIOS).
The driver is stored in segment F400-F7FF.

DEVICE = GEMM.SYS /R:0 /R:5 /X:1

This line will gives the same function as previous line except that the driver is loaded in the system memory.

3-3 Run The AMI Diagnostic

) The on-board AMI BIOS support not only the basic

setup program for maintaining system configuration but also provide you a versatile diagnostic program allow you to check the system components includes harddisk, floppy drive, display card, CPU and peripherals. The diagnostic program also provide a harddisk low level format utility that allow you to low level format the harddisk. To invoke diagnostic program, follow the same direction as described in section 3-1. The screen after depress the key will prompt following :

```
Exit for Boot
Run setup
Run diagnostic
```

Use cursor key to select "Run diagnostic" program.

Appendix A : Service Information

Before calling Customer Support Service, have this information ready :

- * Part and serial number of the product.*
- * Purchase order number, for repair and shipping charges.*
- * Your shipping and billing address.*
- * Your telephone number and contract person.*

Shipping To Customer Service

When corresponding with Customer Support Service, refer to the authorization number on the packing slip, the purchase order, and any other related documents.

Because the repaired or replacement board will be in the default configuration, return your board in its original state :

- 1. Put the jumpers in the default positions.*
- 2. Remove all optional equipment, such as expansion cards and the math coprocessor.*
- 3. Disconnect the battery from the real-time clock.*
- 4. Write a note to describe the problem as detail as possible*

Protect the equipment from damage during transportation

- 1. Place boards in antistatic bags and then in padded shipping bags.*
- 2. Protect the product with protective padding such as flow pack or foam.*

INFORMATION OF CUSTOMER'S SYSTEM PROBLEM SETTLEMENT SHEET

To : _____ Attn : _____ FAX #Reception : _____
From : _____ CC : _____ Ref No : _____
Date : _____ / _____ / _____ Page : _____ of : _____

1. **CUSTOMER DATA**

Name : _____ Tel No : _____ FAX No : _____
Address : _____
Contact person : _____

2. **SPECIFICATION OF MOTHER BOARD**

Model No : _____ Serial No : _____
On board memory : _____ KB CPU type & brand _____
RAM : type _____ KB - _____ ns ☐ DIP ☐ MODULE brand _____
CACHE memory : _____ KB part No _____ * _____ - _____ ns brand _____

3. **ADD ON CARD**

Viedo : type _____ Model No _____ brand _____
Controller : type _____ Model No _____ brand _____
LAN card : type _____ Model No _____ brand _____

4. **POWER SUPPLY** : _____ watts _____ brand _____

5. **OTHER** : _____

6. **APPLICATION SOFTWARE** : _____

7. **DESCRIPTION OF PROBLEM** : _____

8. **SOLUTION** : _____

