Preface

Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the material contained herein, may be reproduced without written consent of the author.

Version 1.0

Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. The manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

Trademark Recognition

Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corp.

MMX, Pentium, Pentium-III, Pentium-III, Celeron are registered trademarks of Intel Corporation.

Other product names used in this manual are the properties of their respective owners and are acknowledged.

Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment onto an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Shielded interconnect cables and a shielded AC power cable must be employed with this equipment to ensure compliance with the pertinent RF emission limits governing this device. Changes or modifications not expressly approved by the system's manufacturer could void the user's authority to operate the equipment.

Preface

Declaration of Conformity

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation

Canadian Department of Communications

This class B digital apparatus meets all requirements of the Canadian Interferencecausing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Réglement sur le matériel brouilieur du Canada.

About the Manual

The manual consists of the following:

Chapter 1 Introducing the Motherboard	Describes features of the motherboard.		
	Go to	¢	page 1
Chapter 2	Describes installation of motherboard components.		
	Go to	Ð	page 7
Chapter 3	Provides information on us ing the BIOS Setup Utility.		
	Go to	₽	page 25
Chapter 4	Describes the mothe software		motherboard
	Go to	⇔	page 45

Preface

ii

TABLE OF CONTENTS

Preface	i
Chapter 1	1
Introducing the Motherboard	1
Introduction	1
Feature	2
Motherboard Components	4

Chapter 2	7
Installing the Motherboard	7
Safety Precautions	7
Choosing a Computer Case	7
Installing the Motherboard in a Case	7
Checking Jumper Settings	8
Setting Jumpers	8
Checking Jumper Settings	9
Jumper Settings	9
Installing Hardware	10
Installing the Processor	10
Installing Memory Modules	12
Expansion Slots	16
Connecting Optional Devices	
Installing a SATA Hard Drive	
Connecting I/O Devices	21
Connecting Case Components	22
Front Panel Header	24

Chapter 3	25
Using BIOS	25
About the Setup Utility	
The Standard Configuration	25
Entering the Setup Utility	25
Resetting the Default CMOS Values	26
Using BIOS	27
Standard CMOS Setup	
Advanced Setup	
Advanced Chipset Setup	31

Integrated Peripherals	
Power Management Setup	
PCI/PnP Setup	
PC Health Status	
Load Default Settings	
Load Non Disk	
Supervisor Password	41
User Password	
Save & Exit Setup	
Exit Without Saving	
Updating the BIOS.	

Chapter 4	45
Using the Motherboard Software	45
About the Software CD-ROM	45
Auto-installing under Windows XP/Vista	45
Running Setup	46
Manual Installation	50
Utility Software Reference	50

iv

Chapter 1 Introducing the Motherboard

Introduction

Thank you for choosing the IC43T-A motherboard. This motherboard is a high performance, enhanced function motherboard designed to support the LGA775 socket Intel[®] Core[™] 2 Extreme/Core[™] 2 Quad/Core[™] 2 Duo/Pentium[®] Dual-Core/Celeron[®] 400 series processors for high-end business or personal desktop markets.

The motherboard incorporates the Intel Eaglelake P43 Northbridge (NB) and Intel ICH10 Southbridge (SB) chipsets. The Northbridge supports a Front Side Bus (FSB) frequency of 1333/1066/800 MHz using a scalable FSB Vcc_CPU. The memory controller supports DDR2 memory DIMM frequencies of 800/667. It supports four DDR2 sockets with maximum memory size of 32 GB*. DDR2 memory bandwidth of 12.8 GB/s in dual-channel symmetric mode assuming DDR2 800 MHz. High resolution graphics via one PCI Express x16 slot, intended for Graphics Interface, is fully compliant to the PCI Express Base Specification Revision 2.0.

The ICH10 Southbridge supports two PCI slots which are PCI v2.3 compliant. In addition, three PCI Express x1 slots are supported, fully compliant to the PCI Express Base Specification, Revision 1.1. It implements an EHCI compliant interface that provides 480 Mb/s bandwidth for ten USB 2.0 ports (four USB ports and three USB 2.0 headers support additional six USB ports). The Southbridge supports six SATA ports with maximum transfer rate up to 3.0 Gb/s each.

There is an advanced full set of I/O ports in the rear panel, including PS/2 mouse and keyboard connectors, COM, four USB ports, one LAN port and audio jacks for microphone, line-in and line-out.



*Due to the DRAM maximum size (2 GB per DIMM) at present, the memory maximum size we have tested is 8 GB.

Feature

Processor

This motherboard uses an LGA775 type of Intel[®] CoreTM 2 Extreme/CoreTM 2 Quad/ CoreTM 2 Duo/Pentium[®] Dual-Core/Celeron[®] Dual-Core/Celeron[®] 400 series that carries the following features:

- Accommodates Intel[®] Core[™] 2 Extreme/Core[™] 2 Quad/Core[™] 2 Duo/ Pentium[®] Dual-Core/Celeron[®] Dual-Core/Celeron[®] 400 series processors
- Supports a system bus (FSB) of 1333/1066/800 MHz

Chipset

The P43 Northbridge (NB) and ICH10 Southbridge (SB) chipsets are based on an innovative and scalable architecture with proven reliability and performance.

P43 (NB)

- Supports 36-bit host bus addressing, allowing the CPU to access the entire 64 GB of the memory address space.
- 2 GB/s point-to-point Direct Media Interface (DMI) to ICH10 (1 GB/s each direction)
- One, 16-lane PCI Express x16 port for Graphics Attach, compliant to the PCI Express Base Specification revision 2.0
- Supports 512-Mb and 1-Gb DDR2 and 512-Mb, 1-Gb,and 2-Gb DDR3 DRAM technologies for x8 and x16 devices

ICH10 (SB)

- Enhanced DMA Controller, interrupt controller, and timer functions
 - Compliant with PCI Express Base Specification, revision 1.1
 - Compliant with PCI v2.3 specificaiton
- Compliant with SATA 3.0 Gb/s Host Controller
- Integrated USB 2.0 Host Controller

Memory

- Supports DDR2 800/667 DDR2 SDRAM with Dual-channel architecture
- Accommodates four unbuffered DIMMs
- 4 x 240-pin DDR2 DIMM socket support up to 32 GB*

Audio

- 5.1 Channel High Definition Audio Codec
- ADCs supports 96k/48k/44.1kHz sample rate
- Meets Microsoft WLP 3.08 Vista premium and mobile PCs audio requirements
- Direct Sound 3D[™] compatible



*Due to the DRAM maximum size (2 GB per DIMM) at present, the memory maximum size we have tested is 8 GB.

Onboard LAN

- Supports PCI Express[™] 1.1
- Integrated 10/100/1000 transceiver
- Wake-on-LAN and remote wake-up support

Expansion Options

The motherboard comes with the following expansion options:

- One PCI Express x16 slot for Graphics Interface
- Three PCI Express x1 slots
- Two 32-bit PCI v2.3 compliant slots
- Six 7-pin SATA connectors

Integrated I/O

The motherboard has a full set of I/O ports and connectors:

- Two PS/2 ports for mouse and keyboard
- One Serial port
- Four USB ports
- One LAN port
- Audio jacks for microphone, line-in and line-out

BIOS Firmware

The motherboard uses AMI BIOS that enables users to configure many system features including the following:

- Power management
- Wake-up alarms
- CPU parameters
- CPU and memory timing

The firmware can also be used to set parameters for different processor clock speeds.



1. Some hardware specifications and software items are subject to change without prior notice.

2. Due to chipset limitation, we recommend that motherboard be operated in the ambiance between 0 and 50 $^\circ$ C.



Motherboard Components

4

Table of Motherboard Components

LABEL	C O MPO NENTS		
	LGA775 socket Intel [®] Core [™] 2 Extreme/		
1. CPU Socket	Core [™] 2 Quad/Core [™] 2 Duo/Pentium [®] Dual-Core/		
	Celeron® Dual-Core/Celeron® 400 series processors		
2. DDR2_DIMM1~4	240-pin DDR2 SDRAM slots		
3. CPU_FAN	CPU cooling fan connector		
4. ATX_POWER	Standard 24-Pin ATX Power connector		
5. SATA1~6	Serial ATA connectors		
6. F_PANEL	Front Panel Switch/LED header		
7. F_USB1~3	Front Panel USB headers		
8. USBPWR_F1~2	Front Panel USB Power Select jumpers		
9. SPK	Speaker header		
10. CLR_CMOS	Clear CMOS jumper		
11. SYS_FAN	System cooling fan connector		
12. SPDIFO	SPDIF out header		
13. CD_IN	Analog Audio Input connector		
14. F_AUDIO	Front Panel Audio header		
15. PCI1~2	32-bit add-on card slots		
16. PCIE1~3	PCI Express x1 slots		
17. PCIEX16	PCI Express x16 graphics card slot		
18. USBPWR_R1	Rear Panel USB/PS2 Power Select jumper		
19. ATX12V	4-pin +12V power connector		

This concludes Chapter 1. The next chapter explains how to install the motherboard.

Memo

Introducing the Motherboard

6

Chapter 2 Installing the Motherboard

Safety Precautions

- Follow these safety precautions when installing the motherboard
- Wear a grounding strap attached to a grounded device to avoid damage from static electricity
- Discharge static electricity by touching the metal case of a safely grounded object before working on the motherboard
- Leave components in the static-proof bags they came in
- Hold all circuit boards by the edges. Do not bend circuit boards

Choosing a Computer Case

There are many types of computer cases on the market. The motherboard complies with the specifications for the ATX system case. Some features on the motherboard are implemented by cabling connectors on the motherboard to indicators and switches on the system case. Make sure that your case supports all the features required. And make sure that your case has sufficient power and space for all drives that you intend to install.

Most cases have a choice of I/O templates in the rear panel. Make sure that the I/O template in the case matches the I/O ports installed on the rear edge of the motherboard.

This motherboard carries an ATX form factor of 305×210 mm. Choose a case that accommodates this form factor.

Installing the Motherboard in a Case

Refer to the following illustration and instructions for installing the motherboard in a case.

Most system cases have mounting brackets installed in the case, which correspond the holes in the motherboard. Place the motherboard over the mounting brackets and secure the motherboard onto the mounting brackets with screws.

Ensure that your case has an I/O template that supports the I/O ports and expansion slots on your motherboard.





Do not over-tighten the screws as this can stress the motherboard.

Checking Jumper Settings

This section explains how to set jumpers for correct configuration of the motherboard.

Setting Jumpers

Use the motherboard jumpers to set system configuration options. Jumpers with more than one pin are numbered. When setting the jumpers, ensure that the jumper caps are placed on the correct pins.

The illustrations show a 2-pin jumper. When the jumper cap is placed on both pins, the jumper is SHORT. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is OPEN.

This illustration shows a 3-pin jumper. Pins 1 and 2 are SHORT



OPEN



SHORT

Checking Jumper Settings

The following illustration shows the location of the motherboard jumpers. Pin 1 is labeled.



Jumper Settings

Jumper	Туре	Description	Setting (default)	
CLR_CMOS	3-pin	CLEAR CMOS	1-2: NORMAL 2-3: CLEAR Before clearing the CMOS, make sure to turn the system off.	CLR_CMOS
USBPWR_R1	3-pin	Rear USB/PS2 Power Select Jumper	1-2: VCC 2-3: 5VSB	1 USBPWR_R1
USBPWR_F1~2	3-pin	Front Panel USB Power Select Jumper	1-2: VCC 2-3: 5VSB	1 USBPWR_F1~2



1. To avoid the system instability after clearing CMOS, we recommend users to enter the main BIOS setting page to "Load Default Settings" and then "Save & Exit Setup".

- 2. Make sure the power supply provides enough 5VSB voltage before selecting the 5VSB function.
- 3. It is required that users place the USBPWR_F1~2 & USBPWR_R1 cap onto 2-3 pin rather than 1-2 pin as default if you want to wake up the computer by USB/PS2 KB/Mouse.

Installing Hardware

Installing the Processor



Caution: When installing a CPU heatsink and cooling fan make sure that you DO NOT scratch the motherboard or any of the surface-mount resistors with the clip of the cooling fan. If the clip of the cooling fan scrapes across the motherboard, you may cause serious damage to the motherboard or its components.

On most motherboards, there are small surface-mount resistors near the processor socket, which may be damaged if the cooling fan is carelessly installed.

Avoid using cooling fans with sharp edges on the fan casing and the clips. Also, install the cooling fan in a well-lit work area so that you can clearly see the motherboard and processor socket.

Before installing the Processor

This motherboard automatically determines the CPU clock frequency and system bus frequency for the processor. You may be able to change the settings in the system Setup Utility. We strongly recommend that you do not over-clock processors or other components to run faster than their rated speed.



Warning:

1. Over-clocking components can adversely affect the reliability of the system and introduce errors into your system. Over-clocking can permanently damage the motherboard by generating excess heat in components that are run beyond the rated limits.

2. Always remove the AC power by unplugging the power cord from the power outlet before installing or removing the motherboard or other hardware components.

This motherboard has an LGA775 socket. When choosing a processor, consider the performance requirements of the system. Performance is based on the processor design, the clock speed and system bus frequency of the processor, and the quantity of internal cache memory and external cache memory.

CPU Installation Procedure

The following illustration shows CPU installation components.

- A. Read and follow the instructions shown on the sticker on the CPU cap.
 - B. Unload the cap
 - · Use thumb & forefinger to hold the lifting tab of the cap.
 - · Lift the cap up and remove the cap completely from the socket.
- C. Open the load plate
 - · Use thumb & forefinger to hold the hook of the lever, pushing down and pulling aside unlock it.
 - · Lift up the lever.
 - · Use thumb to open the load plate. Be careful not to touch the contacts.
- D. Install the CPU on the socket
 - · Orientate CPU package to the socket. Make sure you match triangle marker to pin 1 location.
- E. Close the load plate
 - Slightly push down the load plate onto the tongue side, and hook the lever.
 - · CPU is locked completely.
- F. Apply thermal grease on top of the CPU.
- G. Fasten the cooling fan supporting base onto the CPU socket on the motherboard.
- H. Make sure the CPU fan is plugged to the CPU fan connector. Please refer to the CPU cooling fan user's manual for more detail installation procedure.

 - 1. To achieve better airflow rates and heat dissipation, we suggest that you use a high quality fan with 3800 rpm at least. CPU fan and heatsink installation procedures may vary with the type of CPU fan/ heatsink supplied. The form and size of fan/heatsink may also vary.

2. DO NOT remove the CPU cap from the socket before installing a CPU.

3. Return Material Authorization (RMA) requests will be accepted only if the motherboard comes with the cap on the LGA775 socket.











Installing Memory Modules

This motherboard accommodates four memory modules. It can support four 240-pin DDR2 800/667. The total memory capacity is 32 GB*.

DDR2 SDRAM memory module table

Memory module	Memory Bus
DDR2 667	333 MHz
DDR2 800	400 MHz

You must install at least one module in any of the four slots. The total memory capacity is up to 32 GB*.

The four DDR2 memory sockets (DDR2_DIMM1, DDR2_DIMM2, DDR2_DIMM3, DDR2_DIMM4) are divided into two channels and each channel has two memory sockets as following:

► Channel 0: DDR2_DIMM1, DDR2_DIMM2

► Channel 1: DDR2_DIMM3, DDR2_DIMM4



Do not remove any memory module from its antistatic packaging until you are ready to install it on the motherboard. Handle the modules only by their edges. Do not touch the components or metal parts. Always wear a grounding strap when you handle the modules.



*Due to the DRAM maximum size (2 GB per DIMM) at present, the memory maximum size we have tested is 8 GB.

Installation Procedure

Refer to the following to install the memory modules.

- 1 This motherboard supports unbuffered DDR2 SDRAM only.
- 2 Push the latches on each side of the DIMM slot down.
- 3 Align the memory module with the slot. The DIMM slots are keyed with notches and the DIMMs are keyed with cutouts so that they can only be installed correctly.
- 4 Check that the cutouts on the DIMM module edge connector match the notches in the DIMM slot.
- 5 Install the DIMM module into the slot and press it firmly down until it seats correctly. The slot latches are levered upwards and latch on to the edges of the DIMM.
- 6 Install any remaining DIMM modules.



Installing the Motherboard

Table A: DDR2 (memory module) QVL (Qualified Vendor List)

The following DDR2 800/667 memory modules have been tested and qualified for use with this motherboard.

Туре	Size	Vendor	Module Name
5		Apacer	78.91G92.9K5
		Micron	MT4HTF6464AY-667E1
	512 MB	PSC	AL6E8E63J-6E1
		Ramxel	RML1520M38D6F-667
		Samsung	PC2-5300U-555-12-D3
		Anacar	78.01G9O.9K5
		Арасы	AU01GE667C5KBGC
		Corsair	VS1GB667D2
		Hexon	HYNT7AUDR-30M48
	1.00	Kingston	KVR667D2N5
	IGD	Micron	MT8HTF 12864AY-667E1
DDP2 667		PSC	AL7E8E63B-6E1T
DDK2 007			AL7E8F63J-6E1
			AL7E8F73C-6E1
	Samsung	GOLD BAR M378T2863DZS 0742	
	Aeneon	AET860UD00-30DB08X	
		Apacer	78.A1G9O.9K4
	1 CB	Hexon	HYNT8AUDR-30M88
		Hynix	HYMP125U64AP8-Y5 AB-A 0623
	2 GD	Kingston	KVR667D2N5/2G
		LeadMax	PC2-5300U
		PSC	AL8E8F73C-6E1
		Qimonda	HYS64T256020EU-3S-C2
	4 GB	Aeneon	AET960UD00-30D

Type	Size	Vendor	Module Name
/F-		Kingston	KVR800D2N5/512 1.8V 9905315-019.A02LF
	512 MB	Micron	MT8HTF6464AY-80ED4
		Qimonda	HYS72T64000HU-2.5-B
		A-DATA	M2G VD 6G3I41P0U1E5E
			AET760UD00-30DB97X
		Aeneon	AET 760 UD 00-25 DC 08 X
			AU01GE800C5KBGC
		Apaœr	78.01GAO.9K5
			78.01GA0.9L5
		Geil	Geil Millenary/Geil/GL2L64M088BA18H
		Hexon	ELPT7AUDR-25M48
		H ynix	HYMP112U64CP8-S6 AB
	1 G B	Kingston	KVR800D2N5/1G 1.8V 9905316-054.A01LF
		KingMax	KLDD48F-B8KU5 NGES
		Nanya	NT1GT64U88D0BY-AD
		Ramaxel	RML1320EH38D7F-800
		Someung	GOLD BAR M378T2953EZ3-CE7 0726
		Samsung	M378T2863EHS-CF7 0849
		Silicon Power	SP001GBLRU800S01
		Transcend	507301-1571
DDD2800		Unifosa	GU 341 G 0 ALE PR 6 B 2 C 6 C E
DDR2800		A-DATA	RED A-DATA M2OMI6H3J4720L1C5Z
		Aeneon	AET 860UD 00-25DC08X
		Apacer	78.A1GAO.9K4
			78.A1GC0.9L4
		CORSAIR	CM2X2048-6400C5
		Geil	Geil Platinum Edition Geil/Boxed
		Hexon	ELPT8AUDR-25M88
		H ynix	HYMP125U64CP8-S6 AB
		Kinaston	KVR800D2N5/2G
	2 G B		KVR800D2N6/2G-SP
		KingMax	KLDE88F-B8KU5 NHES
		Micron	MT16HTF25664AY-800E1
		Nanya	NT2GT64U8HD0BY-AD
		PSC	AL8E8F73C-8E1
		Qimonda	HYS64T256020EU-25F-C2
		Samsung	M378T5663QZ3-CF7
		canoung	M378T5663EH3-CF7
		Silicon Power	SP002GBLRU800S01
		Unifosa	GU342G0ALEPR692C6CE
	4 GB	Aeneon	AET960UD00-25D
		Samsung	M378T5263AZ3-CF70819

Installing the Motherboard

14

Туре	Size	Vendor	Module Name
	6 1 GB Kingston Micron Qimonda 2 GB Micron	Kingston	KVR1066D2N7/1G 1.8V/ 9905316- 106.A01LF
DDR2 1066		Micron	MT8HTF 12864AY-1GAE1
22112 1000		HYS64T128020EU-19F-C	
		Micron	MT16HTF25664AY-1GAE1



Users please be noted that DDR2 1066 MHz is validated to run at 800 MHz only.

Expansion Slots

Installing Add-on Cards

The slots on this motherboard are designed to hold expansion cards and connect them to the system bus. Expansion slots are a means of adding or enhancing the motherboard's features and capabilities. With these efficient facilities, you can increase the motherboard's capabilities by adding hardware that performs tasks that are not part of the basic system.



PCIEX16	Slot	The PCI Express x16 slot is used to install the external PCI Express graphics cards that are fully compliant to the PCI Express Base Specification Revision 2.0.
PCIE1~3 Slots		The PCI Express x1 slots are fully compliant to the PCI Express Base Specification Revision 1.1.
PCI1~2 S	ilots	This motherboard is equipped with two standard PCI slots. PCI stands for Peripheral Component Interconnect and is a bus standard for expansion cards, which for the most part, is a supplement of the older ISA bus standard. The PCI slots on this board are PCI v2.3 compliant.
Log .	Before in carefully. configure	stalling an add-on card, check the documentation for the card If the card is not Plug and Play, you may have to manually the card before installation.

Installing the Motherboard

16

Follow these instructions to install an add-on card:

- 1 Remove a blanking plate from the system case corresponding to the slot you are going to use.
- 2 Install the edge connector of the add-on card into the expansion slot. Ensure that the edge connector is correctly seated in the slot.
- 3 Secure the metal bracket of the card to the system case with a screw.





For some add-on cards, for example graphics adapters and network adapters, you have to install drivers and software before you can begin using the add-on card.

Connecting Optional Devices

Refer to the following for information on connecting the motherboard optional devices



F_AUDIO: Front Panel Audio header

This header allows the user to install auxiliary front-oriented microphone and lineout ports for easier access.

Pin	Signal Name	Pin	Signal Name
1	PORT 1L	2	AUD_GND
3	PORT 1R	4	PRESENCE#
5	PORT 2R	6	SENSE1_RETURN
7	SENSE_SEND	8	KEY
9	PORT 2L	10	SENSE2_RETURN

SPDIFO: SPDIF out header

This is an optional header that provides an S/PDIF (Sony/Philips Digital Interface) output to digital multimedia device through optical fiber or coaxial connector.

Pin	Signal Name	Function
1	SPDIF	SPDIF digital output
2	+5VA	5V analog Power
3	Key	No pin
4	GND	Ground

F_USB1~3: Front Panel USB headers

The motherboard has four USB ports installed on the rear edge I/O port array. Additionally, some computer cases have USB ports at the front of the case. If you have this kind of case, use auxiliary USB connector to connect the front-mounted ports to the motherboard.

Pin	Signal Name	Function
1	USBPWR	Front Panel USB Power
2	USBPWR	Front Panel USB Power
3	USB_FP_P0-	USB Port 0 Negative Signal
4	USB_FP_P1-	USB Port 1 Negative Signal
5	USB_FP_P0+	USB Port 0 Positive Signal
6	USB_FP_P1+	USB Port 1 Positive Signal
7	GND	Ground
8	GND	Ground
9	Key	Nopin
10	NC	Not connected



Please make sure that the USB cable has the same pin assignment as indicated above. A different pin assignment may cause damage or system hang-up.

SATA1~6: Serial ATA connectors

These connectors are used to support the new Serial ATA devices for the highest date transfer rates (3.0 Gb/s), simpler disk drive cabling and easier PC assembly. It eliminates limitations of the current Parallel ATA interface. But maintains register compatibility and software compatibility with Parallel ATA.

Pin	Signal Name	Pin	Signal Name
1	Ground	2	TX+
3	TX-	4	Ground
5	RX-	6	RX+
7	Ground	-	-

CD_IN: Analog Audio Input connector

Pin	Signal Name	Function
1	CD_L	CD In left channel
2	GND	Ground
3	GND	Ground
4	CD_R	CD In right channel

Installing a SATA Hard Drive

About SATA Connectors

Your motherboard features six SATA connectors supporting a total of six drives. SATA refers to Serial ATA (Advanced Technology Attachment) is the standard interface for the IDE hard drives which are currently used in most PCs. These connectors are well designed and will only fit in one orientation. Locate the SATA connectors on the motherboard and follow the illustration below to install the SATA hard drives.

Installing Serial ATA Hard Drives

To install the Serial ATA (SATA) hard drives, use the SATA cable that supports the Serial ATA protocol. This SATA cable comes with a SATA power cable. You can connect either end of the SATA cable to the SATA hard drive or the connector on the motherboard.



Refer to the illustration below for proper installation:

- 1 Attach either cable end to the connector on the motherboard.
- 2 Attach the other cable end to the SATA hard drive.
- 3 Attach the SATA power cable to the SATA hard drive and connect the other end to the power supply.







This motherboard does not support the "Hot-Plug" function.

Installing the Motherboard

20

Connecting I/O Devices

The backplane of the motherboard has the following I/O ports:



PS2 Mouse	Use the upper PS/2 port to connect a PS/2 pointing device.
PS2 Keyboard	Use the lower PS/2 port to connect a PS/2 keyboard.
Serial Port (COM)	Use the COM port to connect serial devices such as mice or fax/modems.
USB Ports	Use the USB ports to connect USB devices.
LAN Port	Connect an RJ-45 jack to the LAN port to connect your computer to the network.
Audio Ports	Use the three audio ports to connect audio devices. The first jack is for stereo line-in signal. The second jack is for stereo line-out signal. The third jack is for microphone.

Connecting Case Components

After you have installed the motherboard into a case, you can begin connecting the motherboard components. Refer to the following:

- 1 Connect the CPU cooling fan cable to CPU_FAN.
- 2 Connect the system cooling fan connector to SYS_FAN.
- 3 Connect the standard power supply connector to ATX_POWER.
- 4 Connect the auxiliary case power supply connector to **ATX12V**.
- 5 Connect the case switches and indicator LEDs to the **F_PANEL**.
- 6 Connect the case speaker cable to SPK.



Connecting 24-pin power cable





The ATX_POWER 24-pin connector allows you to connect to ATX v2.x



With ATX v2.x power supply, users please note that when installing 24-pin power cable, the latches of power cable and the ATX_POWER match perfectly.

24-pin power cable

Connecting 4-pin power cable



The ATX12V power connector is used to provide power to the CPU.



When installing 4-pin power cable, the latches of power cable and the ATX12V match perfectly.

4-pin power cable

CPU_FAN: CPU Cooling FAN Power Connector

Pin	Signal Name	Function
1	GND	System Ground
2	+12V	Power +12V
3	Sense	Sensor
4	Control	CPU FAN control

Users please note that the fan connector supports the CPU cooling fan of $1.1A \sim 2.2A$ (26.4W max) at +12V.

SYS_FAN: System cooling FAN Power Connector

Í	Pin	Signal Name	Function
ľ	1	GND	System Ground
	2	+12V	Power +12V
ĺ	3	Sense	Sensor

ATX_POWER: ATX 24-pin Power Connector

Pin	Signal Name	Pin	Signal Name
1	+3.3V	13	+3.3V
2	+3.3V	14	-12V
3	Ground	15	Ground
4	+5V	16	PS_ON
5	Ground	17	Ground
6	+5V	18	Ground
7	Ground	19	Ground
8	PWRGD	20	-5V
9	+5VSB	21	+5V
10	+12V	22	+5V
11	+12V	23	+5V
12	+3.3V	24	Ground

ATX12V: ATX 12V Power Connector

Pin	Signal Name
1	Ground
2	Ground
3	+12V
4	+12V

SPK: Internal speaker header

Pin	Signal Name
1	VCC
2	Key
3	GND
4	Signal

Front Panel Header

The front panel header (F_PANEL) provides a standard set of switch and LED headers commonly found on ATX or Micr ATX cases. Refer to the table below for information:



Pin	Signal	Function	Pin	Signal	Function
1	HD_LED_P	Hard disk LED (+)	2	FP PWR/SLP	*MSG LED (+)
3	HD_LED_N	Hard disk LED (-)	4	FP PWR/SLP	*MSG LED (-)
5	RST_SW_N	Reset Switch (-)	6	PWR_SW_P	Power Switch (+)
7	RST_SW_P	Reset Switch (+)	8	PWR_SW_N	Power Switch (-)
9	RSVD	Reserved	10	Key	Nopin
* MSG LED (dual color or single color)					

* MSG LED (dual color or single color)

Hard Drive Activity LED

Connecting pins 1 and 3 to a front panel mounted LED provides visual indication that data is being read from or written to the hard drive. For the LED to function properly, an IDE drive should be connected to the onboard IDE interface. The LED will also show activity for devices connected to the SCSI (hard drive activity LED) connector.

Power/Sleep/Message waiting LED

Connecting pins 2 and 4 to a single or dual-color, front panel mounted LED provides power on/off, sleep, and message waiting indication.

Reset Switch

Supporting the reset function requires connecting pin 5 and 7 to a momentarycontact switch that is normally open. When the switch is closed, the board resets and runs POST.

Power Switch

Supporting the power on/off function requires connecting pins 6 and 8 to a momentary-contact switch that is normally open. The switch should maintain contact for at least 50 ms to signal the power supply to switch on or off. The time requirement is due to internal de-bounce circuitry. After receiving a power on/off signal, at least two seconds elapses before the power supply recognizes another on/off signal.

This concludes Chapter 2. The next chapter covers the BIOS.

Installing the Motherboard

24

Chapter 3

Using BIOS

About the Setup Utility

The computer uses the latest "American Megatrends Inc." BIOS with support for Windows Plug and Play. The CMOS chip on the motherboard contains the ROM setup instructions for configuring the motherboard BIOS.

The BIOS (Basic Input and Output System) Setup Utility displays the system's configuration status and provides you with options to set system parameters. The parameters are stored in battery-backed-up CMOS RAM that saves this information when the power is turned off. When the system is turned back on, the system is configured with the values you stored in CMOS.

The BIOS Setup Utility enables you to configure:

- Hard drives, diskette drives and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power Management features

The settings made in the Setup Utility affect how the computer performs. Before using the Setup Utility, ensure that you understand the Setup Utility options.

This chapter provides explanations for Setup Utility options.

The Standard Configuration

A standard configuration has already been set in the Setup Utility. However, we recommend that you read this chapter in case you need to make any changes in the future.

This Setup Utility should be used:

- when changing the system configuration
- when a configuration error is detected and you are prompted to make changes to the Setup Utility
- when trying to resolve IRQ conflicts
- when making changes to the Power Management configuration
- when changing the password or making other changes to the Security
 Setup

Entering the Setup Utility

When you power on the system, BIOS enters the Power-On Self Test (POST) routines. POST is a series of built-in diagnostics performed by the BIOS. After the POST routines are completed, the following message appears:

Press DEL to enter SETUP

Press the delete key to access the BIOS Setup Utility. CMOS Setup Utility -- Copyright (C) 1985-2008, American Megatrends, Inc.



Resetting the Default CMOS Values

When powering on for the first time, the POST screen may show a "CMOS Settings Wrong" message. This standard message will appear following a clear CMOS data at factory by the manufacturer. You simply need to Load Default Settings to reset the default CMOS values.

Note: Changes to system hardware such as different CPU, memories, etc. may also trigger this message.



Using BIOS

Using BIOS

When you start the Setup Utility, the main menu appears. The main menu of the Setup Utility displays a list of the options that are available. A highlight indicates which option is currently selected. Use the cursor arrow keys to move the highlight to other options. When an option is highlighted, execute the option by pressing <Enter>.

Some options lead to pop-up dialog boxes that prompt you to verify that you wish to execute that option. Other options lead to dialog boxes that prompt you for information.

Some options (marked with a triangle \blacktriangleright) lead to submenus that enable you to change the values for the option. Use the cursor arrow keys to scroll through the items in the submenu.

In this manual, default values are enclosed in parenthesis. Submenu items are denoted by a triangle \blacktriangleright .



The default BIOS setting for this motherboard applies for most conditions with optimum performance. It is not suggested to change the default values in the BIOS setup and the manufacture takes no responsibility to any damage caused by changing the BIOS settings.

BIOS Navigation Keys

The BIOS navigation keys are listed below:

KEY	FUNCTION
ESC	Exits the current menu
tl⇔	Scrolls through the items on a menu
+/-/PU/PD	Modifies the selected field's values
Enter	Select
F9	Load a default optimized setting
F10	Saves the current configuration and exits setup
F1	Displays a screen that describes all key functions



For the purpose of better product maintenance, the manufacture reserves the right to change the BIOS items presented in this manual. The BIOS setup screens shown in this chapter are for reference only and may differ from the actual BIOS. Please visit the manufacture's website for updated manual.

Standard CMOS Setup

This option displays basic information about your system.

CMOS Setup Utility -- Copyright (C) 1985-2008, American Megatrends, Inc. Standard CMOS Setup

Date (www mm:dd:y Time (hh: mm:ss)	y) Wed 05/06/2009 00:08:51	Help Item
 SATA1 SATA2 SATA3 SATA4 SATA5 SATA6 IDE BusMaster 	Not Detected Not Detected Not Detected Not Detected Not Detected Not Detected Enabled	Use [Enter], [TAB] or [SHIFT-TAB] to select a field. Use [+] or [-] to configure system Date.
t I · Move	Enter: Select +/-/: Value E10: S	ave ESC: Evit

F1:General Help F9: Load Default Settings

Date & Time

The Date and Time items show the current date and time on the computer. If you are running a Windows OS, these items are automatically updated whenever you make changes to the Windows Date and Time Properties utility.

►SATA1~6

This motherboard supports six SATA channels and each channel allows one SATA device to be installed.

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc.
SATA1

SATA1		Help Item
Device : Not Detected	evice : Not Detected	
Type LBA/Large Mode Block (Multi-Sector Transfer) PIO Mode DMA Mode S.M.A.R.T. 32Bit Data Transfer	Auto Auto Auto Auto Auto Enabled	of the device connected to the system.

†↓→→ : Move Enter : Select +/-/: Value F10: Save ESC: Exit F1:General Help F9: Load Default Settings



Type (Auto)

Use this item to configure the type of the IDE device that you specify. If the feature is enabled, it will enhance hard disk performance by reading or writing more data during each transfer.

LBA/Large Mode (Auto)

Use this item to set the LBA/Large mode to enhance hard disk performance by optimizing the area the hard disk is visited each time.

Block (Multi-Sector Transfer) (Auto)

If the feature is enabled, it will enhance hard disk performance by reading or writing more data during each transfer.

PIO Mode (Auto)

Use this item to set the PIO mode to enhance hard disk performance by optimizing the hard disk timing.

DMA Mode (Auto)

DMA capability allows users to improve the transfer-speed and data-integrity for compatible IDE devices.

S.M.A.R.T. (Auto)

The S.M.A.R.T. (Self-Monitoring, Analysis and Reporting Technology) system is a diagnostics technology that monitors and predicts device performance. S.M.A.R.T. software resides on both the disk drive and the host computer.

32Bit Data Transfer (Enabled)

Use this item to enable or disable 32Bit Data Transfer.

Press <Esc> to return to the Standard CMOS Setup page.

IDE BusMaster (Enabled)

This item enables or disables the DMA under DOS mode. We recommend you to leave this item at the default value.

Press <Esc> to return to the main menu setting page.

Advanced Setup

This page sets up more advanced information about your system. Handle this page with caution. Any changes can affect the operation of your computer.

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc.

г			
	Thermal Management TM Status Limit CPUID MaxVal Enhanced Halt (C1E) Intel XD Bit Intel EIST Intel VT Quick Power on Self Test Boot Up Numlock Status APIC Mode 1st Boot Device 2nd Boot Device Boot Other Device	Enabled TM1/TM2 Disabled Enabled Enabled Enabled ON Enabled Hard Drive CD/DVD Removable Dev. Yes	Help Item For the processor its CPUID belows 0F41h. TM2 only can be enable un- der below setting. 1. Freq.>=3.6GHz FSB800 2. Freq.>=2.8GHz FSB533

↑↓→→ :Move Enter : Select +/-/: Value F10: Save ESC: Exit F1:General Help F9: Load Default Settings

Thermal Management (Enabled)

This item displays CPU's temperature and enables you to set a safe temperature to Prescott CPU.

TM Status (TM1/TM2)

This item displays CPU Monitor status.

Enhanced Halt (C1E) (Disabed)

This item enables or disables enhanced halt.

Limit CPUID MaxVal (Disabled)

Use this item to enable or disable the Max CPU ID value limit. When supports Prescott and LGA775 CPUs, enable this to prevent the system from "rebooting" when trying to install Windows NT 4.0.

Enhanced Halt (C1E) (Enabled)

This item enables or disables enhanced halt (C1E).

Intel XD Bit (Disabled)

This item allows users to enable or disable the Intel XD bit.

Intel EIST (Enabled)

This item allows users to enable or disable the EIST (Enhanced Intel SpeedStep technology).

Intel VT (Enabled)

When enabled, a VMM can utilize the additional hardware capabilities provided by Vandor Pool Technology.

Quick Power on Self Test (Enabled)

Enable this item to shorten the power on testing (POST) and have your system start up faster. You might like to enable this item after you are confident that your system hardware is operating smoothly.

Boot Up Numlock Status (ON)

This item defines if the keyboard Num Lock key is active when your system is started.

APIC Mode (Enabled)

This item allows you to enable or disable the APCI (Advanced Programmable Interrupt Controller) mode. APIC provides symmetric multi-processing (SMP) for systems, allowing support for up to 60 processors.

1st/2nd3rd Boot Device (Hard Drive/CD/DVD/Removable Dev.)

Use this item to determine the device order the computer used to look for an operating system to load at start-up time. The devices showed here will be different depending on the exact devices installed on your motherboard.

Boot Other Device (Yes)

When enabled, the system searches all other possible locations for an operating system if it fails to find one in the devices specified under the First, Second and Third boot devices.

Press <Esc> to return to the main menu setting page.

Advanced Chipset Setup

This page sets up more advanced information about your system. Handle this page with caution. Any changes can affect the operation of your computer.

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc. Advanced Chipset Setup

Memory Remap Feature	Enabled	Help Item
HPET	Enabled	ENABLE: Allow remapping of overlapped PCI memory above the total physical memory. DISABLE: Do not allow remapping of memory.

†↓→ ← :Move Enter : Select +//: Value F10: Save ESC: Exit F1:General Help F9: Load Default Settings

Memory Remap Feature (Enabled)

This item allows users to enable or disable memory hole remapping. HPET (Enabled)

This item enables or disables HPET (High Precision Event Timer) support.

Press <Esc> to return to the main menu setting page.

Integrated Peripherals

This page sets up some parameters for peripheral devices connected to the system. CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc. Integrated Peripherals

Onboard SATA Mode Onboard LAN Function Onboard LAN Boot ROM Onboard AUDIO Function Serial Port1 Address USB Functions Legacy USB Support	Enhanced Enabled Disabled Enabled 3F8&IRQ4 Enabled Enabled	Help Item Options Disabled Compatible Enhanced

t↓→ ← :Move Enter : Select +/-/: Value F10: Save ESC: Exit F1:General Help F9: Load Default Settings

OnBoard SATA Mode (Enhanced)

Use this item to show the Serial ATA Configuration options: Disabled, Compatible, Enhanced.

OnBoard LAN Function (Enabled)

Use this item to enable or disable the onboard LAN function.

OnBoard LAN Boot ROM (Disabled)

Use this item to enable or disable the booting from the onboard LAN or a network add-in card with a remote boot ROM installed.

OnBoard AUDIO Function (Enabled)

Use this item to enable or disable the onboard Audio function.

Serial Port1 Address (3F8/IRQ4)

Use this item to enable or disable the onboard COM1 serial port, and to assign a port address.

USB Functions (Enabled)

Use this item to enable or disable the USB function.

Legacy USB Support (Enabled)

Use this item to enable or disable support for legacy USB devices. Setting to Auto allows the system to detect the presence of USB device at startup. If detected, the USB controller legacy mode is enabled. If no USB device is detected, the legacy USB support is disabled.

Press <Esc> to return to the main menu setting page.

Power Management Setup

This page sets up some parameters for system power management operation.

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc. Power Management Setup

ACPI Suspend Type	S3 (STR)	Help Item
PWRON After PWR-Fail Resume by Ring Resume by PCI/PCI-E/Lan PME Resume by USB (S3) Resume By PS2 KB (S3) Resume By PS2 MS (S3) Resume on RTC Alarm	Power Off Disabled Disabled Disabled Disabled Disabled Disabled	Select the ACPI state used for System Suspend.
↑↓→←:Move Enter:Sele	ect +/-/: Value F10:	Save ESC: Exit

ACPI Suspend Type (S3(STR))

Use this item to define how your system suspends. In the default, S3, the suspend mode is a suspend to RAM, i.e, the system shuts down with the exception of a refresh current to the system memory.

PWRON After PWR-Fail (Power Off)

This item enables your computer to automatically restart or return to its operating status.

Resume By Ring (Disabled)

The system can be turned off with a software command. If you enable this item, the system can automatically resume if there is an incoming call on the Modem. You must use an ATX power supply in order to use this feature.

Resume By PCI/PCI-E/Lan PME (Disabled)

The system can be turned off with a software command. If you enable this item, the system can automatically resume if there is an incoming call on the PCI Modem or PCI LAN card. You must use an ATX power supply in order to use this feature. Use this item to do wake-up action if inserting the PCI card.

Resume By USB (S3) (Disabled)

This item allows you to enable/disable the USB device wakeup function from S3 mode.

Resume By PS2 KB (S3) (Disabled)

This item enables or disables you to allow keyboard activity to awaken the system from power saving mode.

Resume By PS2 MS (S3) (Disabled)

This item enables or disables you to allow mouse activity to awaken the system from power saving mode.

Resume on RTC Alarm (Disabled)

The system can be turned off with a software command. If you enable this item, the system can automatically resume at a fixed time based on the system's RTC (realtime clock). Use the items below this one to set the date and time of the wake-up alarm. You must use an ATX power supply in order to use this feature.

Press <Esc> to return to the main menu setting page.

PCI / PnP Setup

This page sets up some parameters for devices installed on the PCI bus and those utilizing the system plug and play capability.

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Ind	c.
PCI / PnP Setup	



F1:General Help F9: Load Default Settings

Init Display First (PCI)

Use this item to select which graphics controller to use as the primary boot devices.

Press <Esc> to return to the main menu setting page.

34

PC Health Status

On motherboards support hardware monitoring, this item lets you monitor the parameters for critical voltages, temperatures and fan speeds.

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc. PC Health Status

-=- System Hardware N	onitor-=-	Help Item
Smart Fan Function Shutdown Temperature CPU Temperature System Temperature CPU FAN Speed CPU Core VDIMM	Press Enter Disabled : 33°C/91°F : 22°C/89°F : 2934 RPM : 1.312 V : 1.856 V	

t → ← :Move Enter: Select +/-/: Value F10: Save ESC: Exit
F1:General Help F9: Load Default Settings

Smart Fan Function

Scroll to this item and press <Enter> to view the following screen: CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc. Smart Fan Function

CPU SMA	RT FAN Control	D	lisabled		Help Item	
					Options	
					Disabled Enabled	
	$\uparrow\downarrow → ← : Move$	Enter : Select	+/-/: Value	F10: Save	ESC: Exit	

I→→ : Move Enter: Select +/-/: Value F10: Save ESC: Exit F1:General Help F9: Load Default Settings

CPU SMART FAN Control (Disabled)

This item allows you to enable/disable the control of the CPU fan speed by chang-ing the fan voltage.

Press <Esc> to return to the PC Health Status page.

35

Shutdown Temperature (Disabled)

Enable you to set the maximum temperature the system can reach before powering down

System Component Characteristics

These items display the monitoring of the overall inboard hardware health events, such as System & CPU temperature, CPU & DIMM voltage, CPU & system fan speed,...etc.

- •
- CPU Temperature System Temperature •
- CPU FAN Speed
- ٠ CPU Core
- VDIMM

Press <Esc> to return to the main menu setting page.

Using BIOS

36

M.I.B. II (MB Intelligent Bios)

This page enables you to set the clock speed and system bus for your system. The clock speed and system bus are determined by the kind of processor you have installed in your system.

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc.
M.I.B.II (MB Intelligent BIOS II)

Performance Level		Standard		Help Item
DRAM Frequency	000	Auto		Options
Configure DRAW Timing by Over-clocking Function: Auto Detect DIMM/PCI Clk Spread Spectrum CPU Voltage NB Voltage DIMM Voltage CPU VTT Voltage	/ 5PD	Enabled Disabled Enabled Disabled Disabled Disabled Disabled 1.11V	Sta	andard hanced
Intel (R) Core (TM) 2 Qua Ratio Status: Unlocked (Min Ratio Actual Value: 8	ad CPU Q840 n: 06, Max: 08)	0 @ 2.66GHz		
Base CPU Frequency Base Memory Frequency CPU Core	: 333MHz : 800MHz : 1.200 V			
VNB VDIMM	: 1.072 V : 1.856 V			

t↓→ ← :Move Enter:Select +/-/: Value F10: Save ESC: Exit F1:General Help F9: Load Default Settings

Performance Level (Standard)

This item shows the performance level of the components, the options are: Standard and Enhanced.

DRAM Frequency (Auto)

This item enables users to adjust the DRAM frequency. The default setting is auto and we recommend users leave the setting unchanged. Modify it at will may cause the system to be unstable.

Configure DRAM Timing by SPD (Enabled)

When this item is set to enable, the DDR timing is configured using SPD. SPD (Serial Presence Detect) is located on the memory modules, BIOS reads information coded in SPD during system boot up.

Over-clocking Function (Disabled)

This item decides the CPU over-clocking function installed in yoursystem. If the over-clocking fails, please turn off the system power. And then, hold the PageUp key (similar to the Clear CMOS function) and turn on the power, the BIOS will recover the safe default.

Auto Detect DIMM/PCI Clk (Enabled)

When this item is enabled, BIOS will disable the clock signal of free DIMM/PCI slots.

Spread Spectrum (Enabled)

If you enable spread spectrum, it can significantly reduce the EMI (Electro-Magnetic Interference) generated by the system.



CPU Voltage (Disabled)

This item enable or disable users to adjust the CPU voltage.

NB Voltage (Disabled)

This item enable or disable users to adjust the North Bridge voltage.

DIMM Voltage (Disabled)

This item enable or disable users to adjust the DDR memory voltage.

CPU VTT Voltage (1.11V)

This item allows users to adjust the CPU VTT voltage.

Intel (R) Core (TM) 2 Quad CPU Q8400 @ 2.66GHz

This is display-only field and displays the information of the CPU installed in your computer.

Ratio Status/Ratio Actual Value (Unlocked/8)

These items show the locked/unlocked ratio status and the actual ratio of the CPU installed in your system.

Base CPU Frequency (333MHz)

This item indicates the current CPU frequency. Users can not make any change to this item. Please be noted that the frequency will be varied with different CPU.

Base Memory Frequency (800MHz)

This item displays the base memory frequency.

This item displays the current CPU voltage. **VNB (1.072 V)**

This item displays the NB Vcore.

VDIMM (1.856 V)

CPU Core (1.200 V)

This item displays theb current DIMM voltage.



Warning: Please pay attention that doing overvoltage may result in damage to hardware.

Press <Esc> to return to the main menu setting page.

Load Default Settings

This option opens a dialog box to ask if you are sure to install optimized defaults or not. You select [OK], and then press <Enter>, the Setup Utility loads all default values; or select [Cancel], and then press <Enter>, the Setup Utility does not load default values.

Load Non Disk

1. The default value of the item "Onboard LAN Boot ROM" is "Disabled" accordingly since the item "Load Non Disk" is set to "Disabled".



Onboard SATA Moc Onboard LAN Func Onboard LAN Boot Onboard AUDIO Fr Serial Port1 Addres USB Functions Legacy USB Suppo	le tion ROM unction is s	Enhanced Enabled Disabled Brabled 3F8&IRQ4 Enabled Enabled	Help Item Options Disabled Enabled
t↓→←:M	ove Enter:Select	t +/-/: Value F10: \$	Save ESC: Exit
F1	General Help	F9: Load Default Settir	

2. You may highlight this option and press <Enter> to Enable it.

CMOS Setup Utility -- Copyright (C) 1985-2008, American Megatrends, Inc.



3. Reboot.

4. Then the default value of the item "Onboard LAN Boot ROM" changed to "Enabled".

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc. Integrated Peripherals

Onboard SATA Mode Onboard LAN Function Onboard LAN Boot ROM Onboard AUDIO Functio Serial Port1 Address USB Functions Legacy USB Support	/ on	Enhanced Enabled Enabled 3F8&IRQ/ Enabled Enabled	4	Help Item Options Disabled Enabled
t↓→ ← :Move	Enter : Select	+/-/: Value	F10: Save	ESC: Exit

→ ← :Move Enter : Select +/-/: Value F10: Save ESC: Exit F1:General Help F9: Load Default Settings

5. And the default value of the item "1st Boot Device" changed to "Realtek Boot Agent" (LAN Boot First) automatically. It is convenient for users to boot from LAN or handle when there is no disk.

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc. Advanced Setup

Thermal Management TM Status Limit CPUID MaxVal Enhanced Halt (C1E) Intel XD Bit Intel IST Intel VT Quick Power on Self Test Boot Up Numlock Status APIC Mode 1st Boot Device	Enabled TM1/TM2 Disabled Enabled Enabled Enabled Enabled Enabled ON Enabled Realtek Boot Agent	Help Item For the processor its CPUII belows 0F41h. TM2 only can be enable ur der below setting. 1. Freq.>=3.6GHz FSB80 2. Freq.>=2.8GHz FSB53
2nd Boot Device 3rd Boot Device	CD/DVD Removable Dev	
Boot Other Device	Yes	

1↓→ ← :Move Enter: Select +//: Value F10: Save ESC: Exit F1:General Help F9: Load Default Settings

Press <Esc> to return to the main menu setting page.

Supervisor Password

This page helps you install or change a password.

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc. Supervisor Password

Supervisor Password :Insta	illed	Helpitem
Change Supervisor Password Security Check	Press Enter Setup	Install or Change the password.

↑↓→→→:Move Enter:Select +/-/:Value F10:Save ESC:Exit F1:General Help F9: Load Default Settings

Supervisor Password (Not Installed)

This item indicates whether a supervisor password has been set. If the password has been installed, *Installed* displays. If not, *Not Installed* displays.

Change Supervisor Password (Press Enter)

You can select this option and press <Enter> to access the sub menu. You can use the sub menu to change the supervisor password.

Security Check (Setup)

If you have installed password protection, this item defines if the password is required at system start up, or if it is only required when a user tries to enter the Setup Utility.

Press <Esc> to return to the main menu setting page.

User Password

This page helps you install or change a password.

CMOS Setup Utility - Copyright (C) 1985-2008, American Megatrends, Inc. User Password

User Password	: Not Installe	d	_		Help item
Change Supervisor Pass	word	Press Enter		Insta pass	II or Change the word.

.→ ← :Move Enter : Select +/-/: Value F10: Save ESC: F1:General Help F9: Load Default Settings

User Password (Not Installed)

This item indicates whether a user password has been set. If the password has been installed, *Installed* displays. If not, *Not Installed* displays.

Change Supervisor Password (Press Enter)

You can select this option and press <Enter> to access the sub menu. You can use thesub menu to change the supervisor password.

Press <Esc> to return to the main menu setting page.

Save & Exit Setup

Highlight this item and press <Enter> to save the changes that you have made in the Setup Utility and exit the Setup Utility. When the Save and Exit dialog box appears, select [OK] to save and exit, or select [Cancel] to return to the main menu.

Exit Without Saving

Highlight this item and press <Enter> to discard any changes that you have made in the Setup Utility and exit the Setup Utility. When the Exit Without Saving dialog box appears, select [OK] to discard changes and exit, or select [Cancel] to return to the main menu.



If you have made settings that you do not want to save, use the "Exit Without Saving" item and select [OK] to discard any changes you have made.

Using BIOS

42

Updating the BIOS

You can download and install updated BIOS for this motherboard from the manufacturer's Web site. New BIOS provides support for new peripherals, improvements in performance, or fixes for known bugs. Install new BIOS as follows:

- 1 If your motherboard has a BIOS protection jumper, change the setting to allow BIOS flashing.
- 2 If your motherboard has an item called Firmware Write Protect in Advanced BIOS features, disable it. (Firmware Write Protect prevents BIOS from being overwritten.)
- 3 Prepare a bootable device or create a bootable system disk. (Refer to Windows online help for information on creating a bootable system disk.)
- 4 Download the Flash Utility and new BIOS file from the manufacturer's Web site. Copy these files to the bootable device.
- 5 Turn off your computer and insert the bootable device in your computer. (You might need to run the Setup Utility and change the the boot priority items on the Advanced BIOS Features Setup page, to force your computer to boot from the bootable device first.)
- 6 At the C:\ or A:\ prompt, type the Flash Utility program name and the file name of the new BIOS and then press <Enter>. Example: AFUDOS.EXE 040706.ROM
- 7 When the installation is complete, remove the bootable device from the computer and restart your computer. If your motherboard has a Flash BIOS jumper, reset the jumper to protect the newly installed BIOS from being overwritten. The computer will restart automatically.

This concludes Chapter 3. Refer to the next chapter for information on the software supplied with the motherboard.

Memo

Using BIOS

44

Chapter 4

Using the Motherboard Software

About the Software CD-ROM

The support software CD-ROM that is included in the motherboard package contains all the drivers and utility programs needed to properly run the bundled products. Below you can find a brief description of each software program, and the location for your motherboard version. More information on some programs is available in a README file, located in the same directory as the software. Before installing any software, always inspect the folder for files named README.TXT, INSTALL.TXT, or something similar. These files may contain important information that is not included in this manual.



1. Never try to install all software from folder that is not specified for use with your motherboard.

2. The notice of Intel HD audio installation (optional): The Intel High Definition audio functionality unexpectedly quits working in Windows Server 2003 Service Pack 1 or Windows XP Professional x64 Edition. Users need to download and install the update packages from the Microsoft Download Center "before" installing HD audio driver bundled in the Driver CD. Please log on to http://support.microsoft.com/default.aspx?scid=kb;enus;901105#appliesto for more information.

Auto-installing under Windows XP/Vista

The Auto-install CD-ROM makes it easy for you to install the drivers and software for your motherboard.



The support software CD-ROM disc loads automatically under Windows XP/Vista. When you insert the CD-ROM disc in the CD-ROM drive, the autorun feature will automatically bring up the install screen. The screen has three buttons on it, Setup, Browse CD and Exit.





If the opening screen does not appear; double-click the file "setup.exe" in the root directory.

Using the Motherboard Software

Setup Tab

Setup	Click the Setup button to run the software installation program. Select from the menu which software you want to install.
Browse CD	The Browse CD button is the standard Windows command that allows you to open Windows Explorer and show the contents of the support CD.
	Before installing the software from Windows Explorer, look for a file named README.TXT, INSTALL.TXT or something simi- lar. This file may contain important information to help you install the software correctly.
	Some software is installed in separate folders for different operat- ing systems, such as Windows XP/Vista. Always go to the correct folder for the kind of OS you are using.
	In install the software, execute a file named SETUP.EXE or INSTALL.EXE by double-clicking the file and then following the instructions on the screen.
Exit	The EXIT button closes the Auto Setup window.

Application Tab

Lists the software utilities that are available on the CD.

Read Me Tab

Displays the path for all software and drivers available on the CD.

Running Setup

500

Follow these instructions to install device drivers and software for the motherboard:

1. Click Setup. The installation program begins:





The motherboard identification is located in the upper left-hand corner. Using the Motherboard Software

2. Click Next. The following screen appears:



3. Check the box next to the items you want to install. The default options are recom-

mended.

4. Click Next run the Installation Wizard. An item installation screen appears:



5. Follow the instructions on the screen to install the items.



1. Drivers and software are automatically installed in sequence. Follow the onscreen instructions, confirm commands and allow the computer to restart a few times to complete the installation.

2. During the Windows Vista Driver Auto Setup Procedure, users should use one of the following two methods to install the driver after the system restart.

Using the Motherboard Software

Method 1. Run Reboot Setup

Windows Vista will block startup programs by default when installing drivers after the system restart. You must select taskbar icon **Run Blocked Program** and run **Reboot Setup** to install the next driver, until you finish all drivers installation.



Method 2. Disable UAC (User Account Control)

* For administrator account only. Standard user account can only use Method 1.

Disable Vista UAC function before installing drivers, then use CD driver to install drivers, it will continue to install drivers after system restart without running blocked programs.

Follow these instructions to Disable Vista UAC function:

1. Go to Control Panel.



Using the Motherboard Software

48

2. Select Classic View.



3. Set User Account.



4. Select Turn User Account Control on or off and press Continue.



Using the Motherboard Software

5. Disable User Account Control (UAC) to help protect your computer item and press OK, then press Restart Now. Then you can restart your computer and continue to install drivers without running blocked programs.



Manual Installation

Insert the CD in the CD-ROM drive and locate the PATH.DOC file in the root directory. This file contains the information needed to locate the drivers for your motherboard.

Look for the chipset and motherboard model; then browse to the directory and path to begin installing the drivers. Most drivers have a setup program (SETUP.EXE) that automatically detects your operating system before installation. Other drivers have the setup program located in the operating system subfolder.

If the driver you want to install does not have a setup program, browse to the operating system subfolder and locate the readme text file (README.TXT or README.DOC) for information on installing the driver or software for your operating system.

Utility Software Reference

All the utility software available from this page is Windows compliant. They are provided only for the convenience of the customer. The following software is furnished under license and may only be used or copied in accordance with the terms of the license.



These software(s) are subject to change at anytime without prior notice. Please refer to the support CD for available software.

This concludes chapter 4.

Using the Motherboard Software