
Redstone Pentium II *System Board Manual*

MICRONICS

Document Number: 06-00335-01, Rev. 2A

April 1998

45365 Northport Loop West, Fremont, CA. 94538-6417

Copyright Notices

Copyright © 1998 Micronics Computers, Inc. The information contained in the Redstone PCI/ISA/AGP Pentium II system board manual has been carefully checked and is believed to be accurate. Micronics assumes no responsibility for any inaccuracies that may be contained in this document. Micronics makes no commitments to update or to keep the information in this manual at a current level when changes are made to the product.

Micronics reserves the right to make improvements to this document and/or product at any time and without notice. All Rights Reserved. No part of this document may be photocopied, reproduced, translated, or reduced to any medium or machine form without prior, written consent from Micronics.

Portions of the Manual

Portions of this manual were copied (with permission) from Phoenix Technologies, Ltd. All rights reserved.

Trademarks

IBM is a registered trademark of International Business Machines. Microsoft and Windows are registered trademarks of Microsoft Corporation. Intel, PCI and AGP are registered trademarks of Intel Corporation. All other product names mentioned herein are used for identification purposes only and may be the trademarks of their respective companies.

Table of Contents

Introduction	5
Features	6
Software Compatibility	7
Before You Begin	8
Chapter 1 - Quick Installation	9
Installing the Redstone	9
Chapter 2 - Configuring the Redstone	11
Static Electricity	11
Environment Considerations	11
Redstone System Board	12
Redstone Back Panel Connections	12
Jumper and Connector Settings	13
Chapter 3 - Installing the Redstone	17
Introduction	17
System Memory Support	17
Installing the Redstone	18
Tools Required	18
Equipment Required	18
System Memory	19
Adding Memory	19
Memory Configurations	20
CPU Installation	22
Installing the CPU Retention Mechanism	22
Installing a CPU	23
CPU Installation Overview	25
CPU Installation (Box version)	26
Installing DIMMs	27
Removing DIMMs	27

Installing a PCI Peripheral Card	28
Installing an ISA Peripheral Card	29
Installing an AGP Peripheral Card	30
Installing a CD-ROM Drive	31
Redstone Sound Option	32

Chapter 4 - The BIOS Setup Utility 35

Configuration	35
Initial Bootup	35
Setup	35
Running the Setup Procedure	36
Info Screen	37
Setting the CPU Speed	37
Setting the Main Screen	39
Setting the Advanced Screen	43
Setting the Chipset Screen	46
Setting the Features Screen	47
DMI Event Logging Submenu	49
Power Management Submenu	50
Security Submenu	52
Exit Screen	54

Chapter 5 - Installing Device Drivers 55

About Device Drivers	55
Installing the Sound Drivers	55

Chapter 6 - Special Features 57

Intel's 440BX AGPset	57
Accelerated Graphics Port (AGP)	57
SDRAM (Synchronous DRAM)	58
LM79 (Hardware Management)	58
Ultra DMA/33 IDE	59
Universal Serial Bus (USB)	59

Appendix A - Technical Information	61
Specifications	61
Environmental Specifications	63
Temperature Range	63
Relative Humidity	63
Battery Disposal	64
Support and Information Services	65
Technical Support	65
Appendix B - Post Messages	67
Appendix C - Beep and POST Codes	69
Appendix D - Updating the System BIOS	73
Appendix E - Warranties and Notices	75
Limited Warranty	75
Non-Warranty Service	76
FCC Statement	77
Glossary	78
Index	82

List of Figures

Figure 1.1: Power-Up Screen	10
Figure 2.1: Redstone System Board	12
Figure 2.2: Redstone Back Panel Connections	12
Figure 3.1: Installing a CPU	25
Figure 3.2: Installing a CPU (Boxed version)	26
Figure 3.3: Installing a 168-Pin DIMM	27
Figure 3.4: Installing a PCI Card	28
Figure 3.5: Installing an ISA Peripheral Card	29
Figure 3.6: Installing an AGP Peripheral Card	30
Figure 3.7: Connecting External Sound Devices	32
Figure 4.1: Power-Up Screen	36
Figure 4.2: Info Screen	37
Figure 4.3: CMOS Main Screen	39
Figure 4.4: IDE Device Submenu	41
Figure 4.5: Advanced Screen	43
Figure 4.6: Chipset Screen	46
Figure 4.7: Features Screen	47
Figure 4.8: DMI Event Logging Submenu	49
Figure 4.9: Power Management Submenu	50
Figure 4.10: Security Submenu	52
Figure 4.11: Exit Screen	54

List of Tables

Table 2.1: BIOS Configuration Setting	13
Table 2.2: Clear CMOS Settings	13
Table 2.3: Onboard Sound Selection	14
Table 2.4: Connector Settings and Functions	14
Table 3.1: Memory Configurations	20
Table A.1: Support and Information Services	66

Introduction

Thank you for choosing the Redstone system board. The Redstone is an advanced single processor solution for high-performance desktops and workstations.

Based on the highly acclaimed Intel 440BX AGPset, Redstone supports the next generation of the Pentium® II, which offers flexibility and the highest level of performance. It features support for 100MHz Front Side Bus (FSB) speeds and accepts PCI, ISA and AGP expansion cards.

Rich with features, Redstone provides Ultra DMA/33 IDE hard drive protocol (up to 33MBytes/sec transfer rate), PC100SDRAM memory support, jumperless CPU settings, optional LM79 microprocessor system hardware management support and optional Ensoniq ES1371 PCI audio, using the high-bandwidth PCI bus and an AC'97 codec to deliver advanced PC audio features.

Micronics builds all products to exacting standards, using the highest quality components available. We are proud to provide this system board and believe you will be pleased with your purchase.

Features

The Redstone includes the following features:

- ▲ Single Intel Slot 1® for:
 - Intel Pentium II® processors - 233/266/300/333MHz (66MHz FSB)
 - Intel Pentium II® processors - 350/400MHz (100MHz FSB)
- ▲ Integrated Voltage Regulator Module
- ▲ Jumperless CPU configuration via BIOS
- ▲ Intel 440BX AGPset
 - Intel PIIX 4e
 - SMC FDC37C675 Enhanced Super I/O chip
- ▲ Two 16-bit ISA slot
 - Four 32-bit PCI slots
 - (One is a shared PCI/ISA slot)
 - One AGP slot
- ▲ Bus Speed - 66 and 100MHz
- ▲ Three 3.3V unbuffered 64/72-bit 168-pin DIMM sockets
 - Maximum memory - 768MB for SDRAM (PC100 supported)
 - ECC support via chipset
- ▲ Ensoniq ES1371 PCI Audio (optional)
- ▲ LM79 Microprocessor System Hardware Management (optional)
 - LM75 CPU temperature sensor
- ▲ Ultra DMA/33 IDE protocol support
- ▲ Mini-ATX form factor

Software Compatibility

The Redstone system board has been thoroughly tested for compatibility with a variety of operating systems and environments, including:

- ▲ Microsoft -
 - DOS 6.2x
 - Windows 95
 - Windows NT 3.5x
 - Windows NT 4.0

- ▲ IBM -
 - OS/2 Warp 3.0
 - OS/2 Warp 4.0

- ▲ SCO -
 - UNIXWare 2.1.1
 - Open Server 5.02
 - UNIX 3.2.4.2

- ▲ Novell -
 - NetWare 3.12
 - NetWare 4.11

Before You Begin

This manual will familiarize you with the features, installation and use of your Redstone. There are several symbols and conventions used throughout this manual to help draw your attention to a feature or to focus on important information:



When you see the Magnifying Glass, it refers to something you should take a closer look at before proceeding further.



When you see the Exclamation Mark, it gives important information on avoiding damage.

Common Names

AGP	Accelerated Graphics Port
DIMM	Dual Inline Memory Module
DMI	Desktop Management Interface
DRAM	Dynamic Random Access Memory
ECC	Error Checking and Correction
FSB	Front Side Bus
IDE	Integrated Drive Electronics
PCI	Peripheral Component Interconnect
SDRAM	Synchronous DRAM
USB	Universal Serial Bus
VRM	Voltage Regulator Module

Chapter

1

Quick Installation

We know that many experienced people prefer to read as little of the documentation as possible. If this sounds like you, here's the short form to get up and running quickly.

Installing the Redstone



STATIC!

Before handling the Redstone, be properly grounded by using a special wrist or ankle strap, or touch a safely grounded object.

1. Make backup copies of your installation and configuration diskettes.
2. Ground yourself to prevent damaging static discharge.
3. Remove the Redstone from its packaging.
4. Configure the system board's jumper settings, if necessary (refer to Jumper Settings in Chapter 2).
5. Install the CPU and the system memory. Be sure to attach the Retention Mechanism as described in Chapter 3.
6. Install the system board in the chassis and make all necessary case connections.
7. Install any ISA, PCI and/or AGP add-on peripherals (refer to Chapter 2 for the location of the slots).
8. Connect any optional devices.
9. Configure the CPU speed. The CPU speed is selected through the BIOS. First you must place a jumper on pins 2-3 of jumper W1 (refer to Jumper and Connector Settings in Chapter 2).
10. Turn on your system. When the system is powered up it will go into Setup automatically.
11. The first selection on the Main screen will be CPU Speed. Select the correct speed.




Figure 1.1: Power-Up Screen

12. From the Main Menu screen, set the time and date. Adjust the BIOS settings to match your configuration. If installing an IDE drive, select the IDE device you wish to configure. Press ENTER with Type selected and the BIOS will automatically configure the drive for you (refer to Chapter 4).
13. Make any desired setting configurations in the other menus (refer to Chapter 4). When finished, press F10 (Save and Exit) to save your settings.
14. You will see a message indicating that the CPU speed setting has been saved.
15. Power down your system and remove the jumper off pins 2-3 of jumper W1 and place back on pins 1-2. The CPU speed selection will no longer appear in Setup.
16. After you have installed your operating system, you can install the sound device drivers (optional). Refer to Chapter 5.

Configuring the Redstone

Although the Redstone system board is packaged in materials that are designed to protect it from physical damage and static electricity, it is important to use care while unpacking the board and setting it up.

Static Electricity

The Redstone is shipped from the factory in an anti-static bag. To reduce the possibility of damage from static discharge, it is important to neutralize any static charges your body may have accumulated before handling the board.

The best way to do this is to ground yourself using a special anti-static wrist or ankle strap. If you do not have an anti-static strap available, touch both of your hands to a safely grounded object, such as the power supply or chassis of a computer that is connected to the power socket. After you have grounded yourself, ground the Redstone board via one of the solder pads that surround its mounting holes. When you remove the Redstone from its packaging, place it on top of the anti-static bag, and carefully inspect the board for damage which might have occurred during shipment.

Environment Considerations

Make sure the finished computer system is in an area with good ventilation. The system should not be in direct sunlight, near heaters, or exposed to moisture, dust, or dirt.

Redstone System Board




Figure 2-1: Redstone System Board Diagram

Back Panel Connections




Figure 2-2: Redstone Back Panel

Jumper and Connector Settings

This section provides jumper settings for the Redstone system board that may or may not need to be changed. Other configurations can be changed through the BIOS Setup, such as the CPU speed. *NOTE: For details on how to configure the CPU speed, see “Setting the CPU Speed” in Chapter 4.*

Table 2-1 lists the settings for the BIOS Configuration Setup. To select the CPU speed in the BIOS, you must place a jumper on pins 2-3. (Refer to Chapter 4 for details on setting the CPU speed).

Jumper	Function	Settings
W1	Normal (default)	1-2
	Invoke BIOS Setup to Change CPU speed	2-3

Table 2-1: BIOS Configuration Setting

Table 2-2 lists the settings to clear the CMOS. With your computer's power off, close pins 2-3, wait ten seconds and place the jumper back on pins 1-2. (The jumper must be placed back on pins 1-2 for the system to function properly.) *NOTE: This will reset all BIOS default settings. Any changes you have made will be lost.*

Jumper	Function	Settings
W4	Normal (default)	1-2
	Clear CMOS	2-3

Table 2-2: Clear CMOS Settings

Table 2-3 lists the connectors and their functions.

Connector	Function	Notes
J2	AGP Bus Expansion Slot	62 x 2-pin connector
J3-J5	DRAM (168-pin DIMM Sockets)	3.3 volt, unbuffered EDO and SDRAM DIMMs
J8, J9	Primary and Secondary IDE Port Connectors	Both support up to two IDE devices
J10	Floppy Drive Connector	Supports up to two floppy drives
J11	Add-In Drive Controller Hard Drive LED Connector	1 - External Hard Drive LED Input; 2 - No Connect
J12	USB Connector	Lower Level: USB Port 1 Upper Level: USB Port 0
J13	PS/2 Keyboard Connector PS/2 Mouse Connector	Lower Level Upper Level
J14	Parallel Port Connector	Upper Level
J15, J16	Serial Ports	COM 1 & COM 2
J17-J20	PCI Bus Expansion Slots	
J22 & J24	ISA Bus Expansion Slots	
J26	ATX Power Supply	20-pin
J27	Front Panel I/O Connector	
"	System Power On/Off	1 - Power On; 2 - Gnd
"	Drive Activity LED Note: IDE and Add-In Drive Controller share the same LED	13 or 16 - Positive; 15 - Negative
"	Power-On LED	18 - Gnd; 20 - Positive
"	System Reset Switch	22 - Gnd; 23 - Reset
"	External PC Speaker Note: To use the onboard PC Speaker, jumper pins 26 and 27 on J27	24 - +5V DC (signal return); 26 - Onboard PC Speaker Signal; 27- External PC Speaker Signal

Table 2-3: Connector Settings and Functions

Connector	Function	Notes
J29	CPU (U1) Cooling Fan Connector	1 - Ground; 2 - +12V Power; 3 - Fan Speed Monitor
J30	Chassis Cooling Fan	1 - Ground; 2 - +12V Power; 3 - Fan Speed Monitor
J31	I ² C Bus Connector (for External Temperature Sensor)	1 - I ² C Data; 2 - Ground; 3 - I ² C Clock; 4 - +5V Power; 5 - Temperature Alert
J32	Chassis Intrusion Sensor Connector	1 - Battery Power; 2 - Trigger Input
J38	Game Port/MIDI MIC In, Line In, Line Out	Upper Level Lower Level
J41	PC/PCI Sideband Signals Connector - Generic (for cards that use PC/PCI DMA and/or PCI serial IRQ's).	1 - PC/PCI DMA Grant; 2 - No Connect; 3 - Gnd; 4 - PC/PCI DMA Request; 5 - Gnd; 6 - PCI Serial IRQ's; 7 - ISA IRQ; 8 - Gnd; 9 - ISA IRQ7; 10 - ISA IRQ9; 11 - Gnd; 12 - ISA IRQ10; 13 - Gnd; 14 - ISA IRQ11
J42	PC/PCI Sideband Signals Connector - Intel (for cards that use PC/PCI DMA and/or PCI serial IRQ's).	1 - PC/PCI DMA Grant; 2 - Gnd; 3 - No Connect; 4 - PC/PCI DMA Request; 5 - Gnd; 6 - PCI Serial IRQ's
J44	Power Supply Connector	6-pin - Optional
J45	Audio Auxilliary Input (ATAPI Interface)	1 - Audio Auxilliary In Left Channel; 2 - Ground; 3 - Ground; 4 - Audio Auxilliary In Right Channel
J46	CD-ROM Audio (ATAPI Interface)	1 - CD-In Left Channel; 2 - Ground; 3 - Ground; 4 - CD-In Right Channel
J47	Video Audio Input (ATAPI Interface)	1 - Video Audio In Left Channel; 2 - Ground; 3 - Ground; 4 - Video Audio In Right Channel
J48	I ² S Bus Connector (for MPEG In)	1 - LR Clock; 2 - Bit Clock; 3 - Date In; 4 - Ground
J50	Phone In (Mono Out)	1 - Phone In; 2 - Ground; 3 - Ground; 4 - Mono Out
U1	Pentium II CPU	Primary

Table 2-3a: Connector Settings and Functions

Installing the Redstone

Introduction

This chapter explains how to install the Redstone system board, memory, CPU and peripherals.

WARNING: *Before installing or removing any peripherals or components, make sure you have a clear work space and that you adhere to all anti-static precautions described in Chapter 1. Micronics recommends that experienced technicians install and configure the system board.*

Damage which occurs to the board while adding or removing peripherals or components may void the warranty. If problems arise while installing peripherals, contact the computer dealer where you purchased the peripheral or Micronics' Technical Support Department.

System Memory Support

The flexibility of the Redstone is augmented by its support for standard SDRAM (66MHz) and PC100 SDRAM (100MHz) memory. The Redstone supports ECC (with 72-bit DIMMs) via the chipset.

SDRAM speed and synchronous operation have enabled the breakthrough in memory-systems design needed to meet the demands of fast high-performance processors. SDRAM improves bandwidth to main memory because all address, data and control signals are synchronized with the system clock. With all operations synchronized, system wait states are reduced, thus providing increased performance over conventional DRAM.

The new PC100 SDRAM memory has the same technology as standard SDRAM, but is faster due to its ability to support the new Intel BX chipset and system boards that support the 100MHz Front Side Bus speeds.

Installing the Redstone

Installation of the Redstone system board depends on the type of case you use. Redstone is designed for the mini-ATX form factor and must be installed in an ATX chassis. Install the system board into the chassis using the tools and equipment required and make all necessary case connections.

NOTE: If you are unfamiliar with installing a system board, Micronics highly recommends that you read the computer user's manual or contact your dealer's technical support department.

Tools Required

Micronics recommends using the following tools to install the Redstone:

- Small Phillips screwdriver
- Tweezers or a pair of needle-nose pliers
- Tray (to hold loose screws)

Equipment Required

Micronics recommends using the following equipment with the Redstone for a typical configuration:

- ATX chassis with standard hardware.
- A high-quality ATX power supply capable of providing continuous power within a 3 volt range. A power filter may be used with a noisy AC power source.
- PS/2 mouse and compatible keyboard.
- Eight ohm speaker.
- Standard ribbon cables for internal connections.
- Standard power cord (grounded).

System Memory

System memory is necessary to operate the Redstone system board. The Redstone has three 3.3V unbuffered 64/72-bit, 168-pin DIMM sockets for maximum memory of 768MB.

Support is provided for standard SDRAM (66MHz) and PC100 SDRAM (100MHz) memory. This section list the rules for adding memory to the Redstone, give some examples of common memory configurations and show how to physically install the memory.



For long term reliability, Micronics recommends using DIMMs with gold-plated contacts. The use of tin-plated contacts may conflict with the gold alloy on the DIMM socket.

Adding Memory

The following is a list of rules to follow when installing DIMMs. If you follow these rules, your upgrade should be trouble-free:

- Use 8ns or faster PC100 SDRAM DIMMs when using a 100MHz bus speed processor.
- Use 10ns or faster SDRAM DIMMs when using a 66MHz bus speed processor. NOTE: PC100 memory is backwards compatible to run at the 66MHz bus speed.
- Use only PC100MHz DIMM modules for the 100MHz Front Side Bus speeds (350 and 400). Due to the strict timing issues involved when operating at 100MHz, your system will not boot if non-compliant PC100 DIMM modules are used.



168-Pin DIMM

Memory Configurations

DIMM memory configuration is auto-banking and therefore does not need to be installed in any particular order. The following table lists the most common memory configurations.

Memory	Bank 0	Bank 1	Bank 2
8MB	1Mx64		
16MB	2Mx64		
16MB	1Mx64	1Mx64	
24MB	2Mx64	1Mx64	
24MB	1Mx64	1Mx64	1Mx64
32MB	2Mx64	2Mx64	
32MB	4Mx64		
40MB	2Mx64	2Mx64	1Mx64
40MB	4Mx64	1Mx64	
48MB	2Mx64	2Mx64	2Mx64
48MB	4Mx64	1Mx64	1Mx64
48MB	4Mx64	2Mx64	
56MB	4Mx64	2Mx64	1Mx64
64MB	4Mx64	4Mx64	
64MB	8Mx64		
80MB	8Mx64	2Mx64	
80MB	8Mx64	1Mx64	1Mx64

Table 3-1: Memory Configurations

Memory	Bank 0	Bank 1	Bank 2
96MB	4Mx64	4Mx64	4Mx64
112MB	8Mx64	4Mx64	2Mx64
128MB	16Mx64		
128MB	8Mx64	4Mx64	4Mx64
128MB	8Mx64	8Mx64	
160MB	16Mx64	4Mx64	
160MB	16Mx64	2Mx64	2Mx64
192MB	8Mx64	8Mx64	8Mx64
192MB	16Mx64	4Mx64	4Mx64
192MB	16Mx64	8Mx64	
224MB	16Mx64	8Mx64	4Mx64
256MB	16Mx64	16Mx64	
256MB	16Mx64	8Mx64	8Mx64
320MB	16Mx64	16Mx64	8Mx64
384MB	16Mx64	16Mx64	16Mx64
384MB	32Mx64	16Mx64	
384MB	32Mx64	8Mx64	8Mx64
448MB	32Mx64	16Mx64	8Mx64
512MB	32Mx64	32Mx64	
512MB	32Mx64	16Mx64	16Mx64
768MB	32Mx64	32Mx64	32Mx64

Table 3-1a: Memory Configurations

CPU Installation


The Redstone is designed to support single Pentium II processors. The Pentium II processor comes installed in a Single Edge Contact (SEC) cartridge that connects into "Slot 1" on the system board.

A Retention Mechanism is supplied to anchor the processor to the system board. Attach the Retention Mechanism before inserting the processor.

Installing the CPU Retention Mechanism


Before you begin, verify that your Retention Mechanism Kit contains the following items:

- Retention Base (black plastic module)
- Support Bridges with Studs (plastic mounts)




Follow the steps below to install the kit:


1. Locate the four Retention Base holes (near each end of the Slot 1 socket). Insert the two Support Bridges with studs (plastic mounts) from the bottom side of the Redstone toward the component side until they snap into place.



2. Place the Retention Base over the Slot 1 connector and insert it down into the Support Bridges with studs. Note the “Keyed” location of both Slot 1 and the Retention Base.



3. Using a screwdriver, tighten all four sides of the Retention Base.




Installing a CPU

Follow the steps below to install the Pentium II processor:

1. Locate the Slot 1 connector (refer to Figure 2-1).
2. If you are installing the boxed version of the Pentium II processor, follow the instructions in the section “CPU Installation (Boxed version).”
3. If you are installing the *optional* Heat Sink Support, continue to step 4; if not, go to step 5.

4. The Heatsink components consist of a top bar, base and two pins. Gently insert the Heatsink base into the holes next to the Slot 1 socket. Push down until the base snaps into place.



5. Gently insert the processor cartridge down into the Retention Module, making sure the connector on the processor cartridge and the Slot 1 connector are aligned (refer to the keyed location on the previous page).
6. Push the processor cartridge down until it snaps into place.
7. Lock the processor cartridge into place by pushing outward on the tabs located on both sides of the processor cartridge. The processor cartridge is locked when the tabs snap into the holes on the side of the Retention Mechanism.
8. After the processor cartridge is locked into place, connect the Heatsink's top bar to the base.
9. Lock the base into place by inserting a pin down into the base on both sides.
10. Make sure the CPU speed selection is set correctly.
NOTE: Leave the system case off until you have configured the CPU speed (refer to Chapter 4 - Setting the CPU Speed).

CPU Installation Overview

CPU Installation Overview

1. Mount the Retention Mechanism for the CPU.
2. Mount the (optional) heatsink support base onto the system board.
3. Slide the CPU into the Retention Mechanism.
4. Lock the CPU into the Retention mechanism using the tabs.
5. Slide in the Heat Sink Top Bar, then insert the pins to lock it in place.




Figure 3-1: Installing a CPU

CPU Installation (Boxed version)

A boxed version of the CPU is offered through Intel. This packaging uses an active cooling fan. The mounting hardware is described below. For detailed instructions, please refer to the documentation that is supplied with your CPU.

NOTE: Make sure the speed selection jumpers are set correctly (refer to Chapter 2 - Jumper Settings).




Figure 3-2: Installing a CPU (Boxed version)

Installing DIMMs

DIMM modules may be added one bank at a time. To install DIMMs, locate the memory banks on the system board and perform the following steps:

1. Hold the DIMM so that the notched edge is aligned with the notch on the DIMM socket (Figure 3-1).
2. Insert the DIMM at a 90 degree angle.
3. Gently push the DIMM straight down until it locks into place (past the release tabs).




Figure 3-3: Installing a 168-Pin DIMM

Removing DIMMs

To remove DIMMs, follow the steps below:

1. With both thumbs (or fingers), press the release tabs away from the socket.
2. With the DIMM free from the release tabs, lift the module up and place in an anti-static bag or package.

Installing a PCI Peripheral Card

Micronics PCI slots accommodate all PCI peripherals that meet the PCI 2.1 specifications. Follow the steps below to install a PCI card:

1. Turn the computer system off and remove its cover.
2. Choose an unused PCI slot and remove the slot cover.
3. Insert the card with the bottom edge level to the slot.
Never insert the card at an angle.
4. Carefully push the card straight down, making sure the card is fully inserted.
5. Replace the screw which holds the card in place.
6. Replace the computer cover.
7. Refer to the PCI card's documentation additional instructions regarding installation and software drivers.




Figure 3-4: Installing a PCI Card

Installing an ISA Peripheral Card

Micronics ISA slots accommodate all standard ISA peripherals. Follow the steps below to install an ISA card:

1. Turn the computer system off and remove its cover.
2. Choose an unused ISA slot and remove the slot cover.
3. Insert the card with the bottom edge level to the slot. *Never insert the card at an angle.*
4. Carefully push the card straight down, making sure the card is inserted fully.
5. Replace the screw that holds the card in place.
6. Replace the computer cover.
7. Refer to the ISA card's documentation for additional instructions regarding installation and software drivers.




Figure 3-5: Installing an ISA Peripheral Card

Installing an AGP Peripheral Card

Micronics AGP slot can accommodate all AGP peripherals that meet the Intel AGP bus specifications. Follow the steps below to install an AGP card:

1. Turn the computer system off and remove its cover.
2. Locate the AGP slot (J2) and remove the slot cover.
3. Insert the card with the bottom edge level to the slot. *Never insert the card at an angle.*
4. Carefully push the card straight down, making sure the card is fully inserted.
5. Replace the screw which holds the card in place.
6. Replace the computer cover.
7. Refer to the AGP card's documentation for additional instructions regarding installation and software drivers.




Figure 3-6: Installing an AGP Peripheral Card

Installing a CD-ROM Drive

The instructions below will help you with the installation, but also refer to the documentation that accompanied your CD-ROM drive.

Before starting the setup and installation, make sure your computer is off and the power cord is disconnected from the wall outlet. Your CD-ROM drive kit should contain the following items for a successful installation:

- CD-ROM Drive with installation hardware
 - Interface Cable
 - CD Audio Cable
1. Connect the ribbon cable as described in the CD-ROM's documentation, making sure the red stripe on the cable is aligned with pin 1 of the connectors.
 2. Connect the audio cable to the CD-ROM drive's audio connector.
 3. Connect the other end of the audio cable to the MPC-2 compatible CD-ROM audio connector on the Redstone system board (see Figures 2.1 and 2.2).
 4. Connect the power supply cable to the CD-ROM drive's power connector.
 5. Install the CD-ROM device drivers. CD-ROM drives require device drivers to access the drive and are generally provided by the manufacturer of the CD-ROM drive. Usually one device driver is added to the CONFIG.SYS file and one to the AUTOEXEC.BAT file.
 6. If you are using the CD-ROM drive in an MS-DOS environment, the utility MSCDEX.EXE must also be added to the AUTOEXEC.BAT file. Consult your DOS manual for more information.

Redstone Sound Option

You can connect external sound devices to your Redstone system board to take advantage of the optional sound support (refer to Figure 2.2). The sound option includes 16-bit stereo sound and a game and MIDI port. See Chapter 5 for information on installing sound device drivers.

Connecting Sound Devices




Figure 3-7: Connecting External Sound Devices

Game Port

You can use the Game Port connector to connect an IBM PC compatible joystick or MIDI instrument.

Line Out

The Line Out jack allows you to connect the audio output of the audio controller to your home stereo, VCR, or amplified speakers.

Line In

You may connect an external mono or stereo audio source to the audio controller, such as a tape player or radio. Use the appropriate converter cable to interface to your external equipment.

MIC In

The MIC In jack will accommodate a 600 ohm microphone.

Configuration

After the Redstone system board and all hardware is installed, the system is ready for configuration. Before turning on the computer, make sure all cables are correctly connected and all jumpers are correctly set.

We recommend that you keep the computer cover off the first time you boot the system. This makes it faster and easier to correct any difficulties that might arise.

Initial Boot Up

Power up the Redstone. If the system does not properly boot, check all your cables and peripherals for bad connections. You may also get beep codes or error messages. If this occurs, consult Appendix B for a guide to possible solutions.

After the system properly boots, it is ready to be configured. The following information explains the proper procedures for BIOS configuration.

Setup

The Setup program is used to configure the computer's BIOS (Basic Input/Output System). The computer's BIOS is responsible for configuring the system board, CPU and providing hardware information to the operating system. In order for the computer to run properly, run the Setup procedure after first installing the system board and whenever you make a hardware change to the system.

When the system is turned on, it performs a memory test, and a BIOS identification and system information screen is displayed on your monitor, as shown in Figure 4-1.




Figure 4-1: Power-Up Screen

When “Press <F2> to enter Setup” appears at the bottom of the screen, press the <F2> key to start the Setup program. Note that the Setup program can only be activated during the boot sequence.

Running the Setup Procedure

The Redstone system board has six primary configuration screens: Info, Main, Advanced, Chipset, Features and Exit. To toggle between the screens, press the right arrow <→> and the left arrow <←> keys.

Info Screen

The Info screen lists your system configuration information. This information is determined by your system configuration and cannot be manually changed.




Figure 4-2: Info Screen

Setting the CPU Speed

These instructions will assist you when installing a new CPU or changing the CPU speed. If you have not done so already, power down your system and remove the cover. Follow the steps below:

1. After you have removed the cover, place the jumper on pins 2-3 of jumper W1 (refer to the following table).

Jumper	Function	Settings
W1	Normal (default) Invoke BIOS Setup to Change CPU speed	1-2 2-3

2. Turn on your system. When the system is powered up it will go into Setup automatically.
3. The first selection on the Main screen will be CPU Speed. Select the correct speed and press F10 (Save and Exit) to save your setting.
4. You will see a message indicating that the CPU speed setting has been saved.
5. Power down your system and remove the jumper off pins 2-3 and place back on pins 1-2. The CPU speed selection will no longer appear in Setup.

NOTE:

- If you forget to change the configuration jumper after you save and exit, the process will simply repeat.

Setting the Main Screen

The CMOS Main screen is used to set the time and date, to set the floppy drive types, to configure IDE hard disks and other categories. This chapter explains how to configure each of these categories. To move between the categories, use the up and down arrow <↑/↓> keys.




Figure 4-3: CMOS Main Screen

System Time and Date

To set the Time, use the <-> key to decrease the number and the <+> key to increase the number. To move the prompt forward, use the <Tab> key; to move the prompt backward, use the <Shift-Tab> key. To set the Date, use the up and down arrows <↑/↓> to highlight the System Date and follow the same procedure used to set the Time.

Diskette A or B

To configure a floppy drive added to or removed from your computer, use the up and down arrow keys <↑/↓> to select the desired drive. Use the <+/-> keys to change the setting until it matches the floppy drive you installed. The BIOS supports 2.88MB, 1.44MB, 1.2MB, 720KB, and 360KB floppy drives.

Primary and Secondary IDE Devices

If you are setting up a SCSI hard disk, select None in the IDE Device parameters (see your SCSI card manual for more details). To install an IDE device, select the device to configure and press ENTER. An IDE Device submenu will appear (see Figure 4-4).

Large Disk Access Mode

If you are using a DOS operating system (MS-DOS, Novell DOS or PC-DOS), set to DOS (default). If you are using anything else, set to OTHER.




Figure 4-4: IDE Device Submenu

Type

This category selects the drive type installed in the system. The options are Auto (default), User and None. If Autotype Fixed Disk does not find your drive's parameters, fill this information in manually under the User category. This information may be in the manual which came with your system. If not, contact your dealer or the hard drive manufacturer to fill in this category. If you are using a SCSI hard drive, select None and refer to the documentation which came with the SCSI adapter.

Multiple-Sector Transfers

This category determines the number of sectors per block for multiple sector transfers. The options are Auto (default), Disabled, 2 Sectors, 4 Sectors, 6 Sectors, 8 Sectors and 16 Sectors.

LBA Mode Control

Enabling this selection causes LBA (Logical Block Addressing) to be used in place of Cylinders, Heads and Sectors. LBA Mode Control support drives larger than 500MB. The default setting is Enabled.

32-Bit I/O

This category allows you to enable the 32-bit I/O function of the PCI IDE controller. Select Disabled if your drive will not run at this speed. The default setting is Disabled.

Transfer Mode

This category sets the transfer speeds for IDE devices. The Fast PIO 1, Fast PIO 2, Fast PIO 3 and Fast PIO 4 (default setting) options are for higher speed devices.

Smart Monitoring

This feature will monitor your hard drive and report any problems detected. The default setting cannot be changed.

Setting the Advanced Screen

The Advanced screen is used to configure the system devices. To move to the Advanced screen, use the left and right arrow keys <<-/->> keys until you see the screen below.




Figure 4-5: Advanced Screen

Plug & Play O/S

This selection allows your system to work with a Plug and Play operating system such as Windows 95. The default setting is No. NOTE: This selection should be set to No when using Windows 3.1 or Windows NT.

Reset Configuration Data

Select Yes to reset Extended System Configuration Data (ESCD) when you exit Setup. This selection allows the PnP BIOS to re-detect your PCI and ISA PnP devices and reallocate resources to them. The default setting is No.

PCI Configuration

Use this selection for additional setup menus to configure IRQ's for legacy ISA devices.

PS/2 Mouse

When disabled, this selection prevents the PS/2 mouse from functioning and frees up IRQ12. Selecting Autodetect (default) allows the operating system to determine whether to enable or disable the mouse.

Legacy USB Support

Use this selection to provide BIOS support for USB devices to function in alternative operating systems. Your USB device must still have and load its own drivers for that particular operating system. Select Enabled when using DOS and Windows 95 operating systems. Select Disabled (default) when using Windows NT, OS/2 and Unix operating systems.

Keyboard Detection

Setting this to Enabled (default) activates the keyboard detection upon boot. When disabled, it allows the system to boot without a keyboard attached.

Integrated Ports

Use this selection for additional setup menus to configure peripheral devices. Press <Enter> and a submenu appears.

Integrated PCI IDE

Enables or disables the integrated PCI IDE adapter. The IDE controller may be set for Primary, Both (default) or Disabled.

Integrated LM79

Enable or disable the integrated LM79 microprocessor system hardware monitor. The LM79 can be used to monitor temperatures, power supply voltages and fan speeds.

Integrated Sound

Enables or disables the integrated sound interface. The default setting is Enabled.

Setting the Chipset Screen

The Chipset screen allows you to program the Intel 440BX AGP chipset features. To access the Chipset setup screen, highlight this option on the main menu screen and press <Enter>.




Figure 4-6: Chipset Setup Screen

Graphics Aperture

Select the size of the Graphics Aperture for the AGP video device. The aperture is a portion of the PCI memory address range dedicated for graphics memory address space.

DRAM Type

The DRAM type can be set for Non-Parity (default), Parity or ECC. Selecting ECC will detect the parity error and allow the system to correct the error, if ECC memory is in place on the system.

Setting the Features Screen

The Features Screen allows you to configure the boot configuration, power management functions and the security of the system. To move to the Features Screen, use the left and right arrow <←/→> keys until it appears.




Figure 4-7: Features Setup Screen

QuickBoot

This selection allows the system to skip certain tests while booting. This will decrease the time needed to boot up the system.

QuietBoot

When disabled, this selection displays the system diagnostics screen during boot up. When enabled, the system logo screen displays in place of the system diagnostics screen.

DMI Event Logging

Use this selection for additional setup menus to control the DMI (Desktop Management Interface) Event Logging functions of the system. This feature allows you to view and modify DMI Event logs. To enable the DMI Event Logging feature, press <Enter> and a submenu appears (see Figure 4-8).

Multiboot

Use this selection for additional setup menus to configure your boot devices. Press <Enter> and a submenu appears.

Power Management

Use this selection for additional setup menus to control the power management functions of the system. To enable the power management feature, press <Enter> and a submenu appears (see Figure 4-9).

Security

Use this selection for additional setup menus to control the security functions of the system. To enable the security feature, press <Enter> and a submenu appears (see Figure 4-10).




Figure 4-8: DMI Event Logging Submenu

Event Logging

When Enabled (default), this selection allows logging of DMI (Desktop Management Interface) events.

ECC Event Logging

When Enabled (default), this selection allows logging of ECC (Error Checking and Correction) events.

View DMI Event Log

Press <Enter> here to view contents of the DMI event log.

Mark Events As Read

After you have viewed the contents of the DMI event log, press <Enter> here to mark all DMI events as read.

Clear All DMI Event Logs

Selecting Yes will clear the DMI event log after the system reboots. The default setting is No.




Figure 4-9: Power Management Submenu

Power Savings

This selection allows you to change the system power management settings. Maximum Power Savings conserves the greatest amount of system power. Maximum Performance conserves power but allows greatest system performance. To alter these settings, choose Customize (disabled). To turn off power management, choose Disabled.

Standby Timeout

The Standby Time-out selection sets the amount of time that elapses for the system to enter Standby Mode. Standby Mode turns off various devices in the system, including the display screen, until you start using the system again. The options are Off (default), 1 min., 2 min., 4 min., 6 min., 8 min., 12 min. or 16 min.

Suspend Timeout

The Suspend Time-out selection sets the amount of time that elapses for the system to enter Suspend Mode. The

options are Off (default), 5 min., 10 min., 15 min., 20 min., 30 min., 40 min. or 60 min. Before making changes, "Customized" must be selected in the Power Management Mode selection.

Resume On Time

When this feature is turned On, the system counts down to zero and awakes from Standby or Suspend mode. Before making changes, "Customized" must be selected in the Power Management Mode category. The default setting is Off.




Figure 4-10: Security Submenu

Set Supervisor Password

This selection controls access to the Setup utility. Press the ENTER key to enter the Supervisor Password submenu. Type the password and press the ENTER key. Retype the password and press the ENTER key again. Write down the password somewhere safe so it will not be forgotten. The password may be disabled by setting the new password to nothing (pressing the ENTER key without first typing a password).

WARNING: If you forget the Supervisor Password, it cannot be disabled without discharging the CMOS.

Set User Password

This selection controls access to the Setup utility. Follow the same procedure used to set the Supervisor Password.

NOTE: After a password is entered, it is saved immediately. All other changes may still be discarded (see Exit Screen).

Password on Boot

When enabled, the system requires a password upon power up. Either the Supervisor or User Password may be entered. The default setting is Disabled.

Fixed Disk Boot Sector

This selection allows the boot sector of the fixed disk to be write protected. The default setting is Normal. When set for Write Protected, it serves as a form of virus protection. If the passwords are enabled, this option may only be changed by the Supervisor.

Exit Screen

After you complete configuring the BIOS, select the Exit screen. To move to the Exit Screen, use the left and right arrow <←/→> keys until it appears. To move between the categories, use the up and down arrow keys <↑/↓>.




Figure 4-11: Exit Screen

Choose “Save Changes and Exit” and reboot the computer.

Installing Device Drivers

This chapter explains how to install the software device drivers and utilities necessary to utilize the optional sound support. Other drivers and utilities are available through our online services.

About Device Drivers

Device drivers are necessary for the computer system to communicate with devices such as CD-ROM drives, sound controllers, graphics adapters or devices that are not natively supported by the system BIOS. Once started, device drivers remain active in the background of the computer system. Usually a device driver is added to the CONFIG.SYS file, the AUTOEXEC.BAT file or both.

Installing the Sound Drivers

Once you have connected your external sound devices, you can install the sound drivers. NOTE: If you are installing a CD-ROM drive, it is recommended you install it before setting up the sound devices. See Installing a CD-ROM Drive in Chapter 3.

1. Follow the instructions in Chapter 3 on connecting external sound devices.
2. If you previously installed another sound card, remove it and all associated files from your AUTOEXEC.BAT and CONFIG.SYS files. If you are using Windows 3.1x, you must also remove all associated files from the WIN.INI and SYSTEM.INI files. (For more information, please contact the sound driver manufacturer.)
3. Start your computer system.
4. Insert the sound driver disk into your floppy drive.

5. If you are using Windows 95, refer to the Windows 95 user's manual for instructions on how to install sound drivers.
6. If you are using Windows NT, refer to the Windows NT user's manual for instructions on how to install sound drivers.
7. Once the software is copied, the install program automatically updates the system files.

Special Features

The Redstone achieves high reliability, performance and scalability with numerous features.

Intel's 440BX AGPset

In the competitive world of system board chipsets, Intel's new 440BX places at the top with its support for the 100MHz Front Side Bus (FSB) technology. The 440BX is the infrastructure behind the 100MHz FSB technology. Along with PC100 memory and Intel's new versions of the Pentium II processor family, the 440BX AGPset adds a new data highway that should post a substantial increase in bus and memory access. The flexibility of the 440BX allows for support of the first generation Pentium II processors at 66MHz FSB speeds.



Accelerated Graphics Port (AGP)


With the introduction of the Pentium II and the 440LX AGPset, graphics took the next step onto the AGP freeway. The AGP bus is faster than the current 33MHz PCI bus. It provides a *direct* connection between the graphics subsystem and system memory. AGP, with dual 528MB/s data path, surpasses PCI's 132MB bottleneck.



SDRAM (Synchronous DRAM)

SDRAM is memory that can synchronize itself with the computer's clock. This synchronization reduces time delays and allows for fast consecutive read and write capability.

SDRAM can add as much as 10% to the



overall system performance.

Intel's release of the 440BX AGPset allows SDRAM to operate up to a new standard at 100MHz. At these speeds, a new standard of SDRAM or PC100 SDRAM is required. PC100MHz memory is backwards compatible to run at 66MHz, however, a non PC100 SDRAM may not be used on a 100MHz FSB system.

LM79 (Hardware Management)

A highly integrated Data Acquisition system for hardware monitoring of servers, Personal Computers, or



virtually any microprocessor based system. In a PC, the LM79 can be used to monitor power supply voltages, temperatures, and fan speeds. It provides the hardware support for remote management software, (i.e., Intel's

LANDesk) to keep maintenance costs to a minimum while providing real time remote management.

Ultra DMA/33 IDE

A hard drive interface protocol that increases the burst data transfer rate to 33MBytes per second. Prior to this protocol, Mode-4 protocol has been the fastest at 16.6MB per second. This new protocol is supported by Intel's 440LX and 440BX AGPsets.



Universal Serial Bus (USB)

The simple and flexible way to connect devices to your desktop or notebook PC. USB allows virtually unlimited PC expansion with no more hassles over add-in cards, dip



switches, jumper cables, software drivers, IRQ settings, DMA channels and I/O addresses. With USB,

you can attach and detach peripherals without opening the computer or even shutting it down.

Appendix

Specifications

A

Part Number: 09-00335-xx

Processor: Single Intel Slot 1® for:
Intel Pentium II® processors -
233/266/300/333MHz (66MHz FSB).
Intel Pentium II® processors -
350/400MHz (100MHz FSB).
Integrated VRM

CPU Clock: Support for 66 and 100MHz CPU bus

Chipset: Intel 440BX AGPset
Intel PIIX 4e
SMC FDC37C675 Enhanced Super I/O chip

Form Factor: Mini-ATX form factor - 12" x 8.3"
Four layer board
Stacked I/O connectors (Intel Venus
I/O Shield compatible).
20-pin ATX power connector

Expansion: Two 16-bit ISA slots
Four 32-bit PCI slots
(One is a shared PCI/ISA slot)
One AGP slot

BIOS: Phoenix 4.06 BIOS on 2MB Flash
Advanced Power Management 1.2
PCI auto configuration
Auto detection of memory size
Jumperless CPU configuration
Auto detection and display of SDRAM
memory.
Auto detection of IDE hard disk types
Soft Power Down
Quick Boot
Multiboot II
DMI 2.0/SMI/ACP

Appendix A: Technical Information

Keyboard/Mouse:	PS/2 style keyboard and mouse
Memory Capacity:	Three 3.3V unbuffered 64/72-bit DIMM sockets (PC100 100MHz SDRAM memory supported). Maximum memory - 768MB for SDRAM ECC supported via chipset when using 64/72-bit DIMMs.
Onboard Sound: (optional)	Ensoniq ES1371 PCI audio AK4540 AC'97 Codec Sound Blaster™ compatible 16-bit stereo PC/PCI ready (14 and 6-pin connectors) Line In, Line Out, MIC and Game/MIDI ports 4-pin CD-ROM audio header (ATAPI) 4-pin CD-ROM modem audio header (ATAPI) 4-pin Aux 2 (ATAPI) 4-pin Video Sound In header (ATAPI) 4-pin I2S header (ATAPI) Sound drivers
Hardware Management:	LM79 Microprocessor System Hardware Monitor (optional). LM75 CPU Temperature Sensor CPU Fan Speed Monitoring (3-pin header) Chassis Intrusion (2-pin header) Chassis Fan Speed Monitoring (3-pin header)
I/O Ports:	Two high speed serial ports (16550 compatible) One 25-pin Parallel Port (ECP and EPP) Two USB ports
Floppy Port:	Supports 360K - 2.88MB formats Auto detection of add-in floppy controllers
PCI IDE Ports:	Ultra DMA/33 IDE Two 40-pin IDE connectors (Primary and Secondary IDE). Multiple sector transfer support Auto detection of add-in IDE board Supports all ATAPI device

Environmental Specifications

The environment in which the Redstone is located is critical. Micronics recommends the following environmental specifications:

Temperature Range

Operating: 50 to 104 degrees Fahrenheit (10 to 40 degrees Celsius).

Non -Operating: 50 to 140 degrees Fahrenheit (10 to 60 degrees Celsius).


Shipping: -22 to 140 degrees Fahrenheit (-30 to 60 degrees Celsius).

Relative Humidity

Operating: 20% to 80%.

Non-Operating: 5% to 90%.

Battery Disposal



WARNING:

Please do not open battery, dispose of in fire, recharge, put in backwards or mix with used or other battery types. The battery may explode or leak and cause personal injury.

Support and Information Services

Micronics offers a variety of support and information services to help you get the most from your product. The following services are available:

- ▲ Technical Support
- ▲ Electronic Bulletin Board Service (BBS)
- ▲ Return Materials Authorization (RMA)
- ▲ Fax-On-Demand
- ▲ World Wide Web
- ▲ Customer Service

Refer to Table A-1 for details on these services.

Technical Support

If you need technical assistance, our Technical Support Engineers will be glad to help you. You can contact us via telephone, fax or BBS. Before calling Technical Support please have the following information ready:

- The model name, 09 part number and serial number of your Micronics product, which is silk screened on the face of the Redstone system board.
- Your computer information such as CPU type, operating system, amount of installed memory and other peripherals installed in your computer.
- Try to call from the location of your computer.

NOTE: For Return Material Authorization purposes, please keep a copy of your product receipt.

Appendix A: Technical Information

Service	Hours	Country	Telephone Number
Technical Support - Live phone help from Technical Support Engineers	M-F: 7:00am to 5:00pm (PST)	USA UK	(510) 661-3000 (510) 651-6982 (Fax) +44 (1256) 844899 +44 (1256) 364222 (Fax)
Electronic Bulletin Board Service (BBS) - Information on software upgrades, new releases and other helpful information	24 hours a day 7 days a week "	USA UK	(510) 651-6837 14400 baud rate, Parity=N, Data Bits=8, Stop Bits=1 YMODEM and ZMODEM (recommended file transfer protocols) +44 (1256) 363373
RMA (Return Materials Authorization) - Return products for repair	M-F: 8:00am to 4:45pm (PST)	USA	(510) 661-3030 (510) 683-0543 (Fax)
Fax-On-Demand - Automated system for product literature, technical bulletins and other helpful information	24 hours a day 7 days a week	USA	(510) 661-3199
World Wide Web - Product information, technical support, press releases and other helpful information	24 hours a day 7 days a week "	USA Europe	http://www.micronics.com
Customer Service - Order Micronics and Orchid products	M-F: 8:00am to 5:00pm	USA UK Taiwan	(800) 577-0977 (510) 651-3666 (Fax) +44 (1256) 479 898 +44 (1256) 364222 (Fax) +886 2 918 5005 +886 2 911 5472 (Fax)

Table A-1: Support and Information Services

Appendix

POST Messages**B**

The following table lists the Power On Self Test (POST) messages, possible causes and solutions.

Message	Possible Cause	Solution
DISKETTE DRIVE A FAILURE	Drive A failed or is missing.	Check Setup and cable connections.
DISKETTE DRIVE B FAILURE	Drive B failed or is missing.	Check Setup and cable connections.
EXTENDED RAM FAILED AT OFFSET: nnnn	Extended memory not working or configured properly.	Replace defective memory.
FAILING BITS: nnnn	Memory failure in System, Extended, or Shadow memory.	Replace defective memory.
FIXED DISK X FAILURE (where X =0 or 1)	The hard disk is not configured or working properly.	Rerun SETUP and check connections, or replace hard disk.
FIXED DISK CONTROLLER FAILURE	The controller card has failed.	Check configuration and connections, or replace controller card.
INCORRECT DRIVE A TYPE	Floppy drive A: not set correctly in Setup.	Run Setup.
INCORRECT DRIVE B TYPE	Floppy drive A: not set correctly in Setup.	Run Setup.
INVALID NVRAM MEDIA TYPE	NVRAM chip is bad.	Requires repair of system board.
KEYBOARD ERROR, or KEYBOARD CONTROLLER ERROR	The keyboard or keyboard controller failed.	Check connections. You may have to replace the keyboard or controller.
KEYBOARD ERROR nn	A key is jammed or was held down during boot.	Make sure the keys are not jammed or dirty.
KEYBOARD LOCKED	Keyswitch on the front of the case is locked.	Unlock the keyswitch.

Message	Possible Cause	Solution
MONITOR TYPE DOES NOT MATCH CMOS	Monitor type not correctly identified in Setup.	Run Setup and enter correct monitor type.
OPERATING SYSTEM NOT FOUND	Operating system cannot be located on Drive C: or Drive A:	Check Setup to see if Drive A: and C: are properly configured, or put a bootable disk in Drive A:
PARITY CHECK 1 nnnn	Parity error found in the system bus.	Check Setup. Board repair may be required.
PARITY CHECK 2 nnnn	Parity error found in the I/O bus.	Check Setup. Board repair may be required.
PREVIOUS BOOT INCOMPLETE - DEFAULT CONFIGURATION USED	Previous POST did not complete successfully.	Run Setup, load default BIOS settings, make any necessary adjustments, and save the changes
REAL TIME CLOCK ERROR	Real-time clock failed BIOS test.	May require battery replacement or board repair.
SHADOW RAM FAILED AT OFFSET	Shadow RAM failed.	May require repair of system board.
SYSTEM BATTERY IS DEAD	System battery died.	Replace the system battery and run Setup to reconfigure the system.
SYSTEM CACHE ERROR - CACHE DISABLED	External (L2) cache failed BIOS test.	System will still run, but slower. Replace cache at convenience.
SYSTEM CMOS CHECKSUM BAD - RUN SETUP	System CMOS has been corrupted or modified incorrectly.	Run Setup and reconfigure the system.
SYSTEM RAM FAILED AT OFFSET: nnnn	System RAM failed.	Replace defective RAM.
SYSTEM TIMER ERROR	Timer test failed.	Requires repair of system board.

Beep and POST Codes

C

Beep codes are a series of beeps sent through the speaker which indicate a problem during the Power On Self Test (POST). If text appears on the video screen, the Redstone has completed POST; any other tone from the speaker indicates something other than a POST error. These tones *are not* described in the tables on the following pages.

The beep error codes are a series of beeps. The duration of the beep tones are constant, but the length of the pauses between the beeps varies. For example: a 1-3-3 beep code will sound like one beep, a pause; three beeps consecutively, another pause and then three more beeps.

One beep code is often misunderstood. If a video card is not installed or is failing, the system board will generate a long-short-long-short beep code. This is often interpreted as a 1-2-1 beep code. But POST errors always vary in the length of the pause and not the duration of the beep tone.

Another way of identifying a POST error is to use a device called a POST card. This peripheral card is inserted into one of the ISA slots and has an LED (or LCD) read out showing the contents of port 80h.

The following tables list all beep codes and POST routines.

Appendix C: Beep and POST Codes

Code	Beeps	POST Routine Description
02		Verify Real Mode.
04		Get CPU type.
06		Initialize system hardware.
08		Initialize chipset registers with initial POST values.
09		Get in POST Reg.
0A		Initialize CPU registers.
0C		Initialize cache initial POST values.
0E		Initialize I/O.
0F		Initialize the localbus IDE.
10		Initialize Power Management.
11		Load alternate registers with initial POST values.
12		Jump to UserPatch0.
14		Initialize keyboard controller.
16	2-2-3	BIOS ROM checksum.
18		8254 timer initialization.
1A		8237 DMA controller initialization.
1C		Reset Programmable Interrupt Controller.
20	3-1-1	Test DRAM refresh.
22	3-1-3	Test 8742 Keyboard Controller.
24		Set ES segment register to 4 GB.
28		Autosize DRAM.
2A		Clear 512K base RAM.
2C	3-4-1	Test 512K base address lines.
2E	3-4-3	Test 512K base memory.
32		Test CPU bus-clock frequency.
34		Test CMOS RAM.
35		Initialize alternate chipset registers.
37		Reinitialize the chipset (MB only).
38		Shadow system BIOS ROM.
39		Reinitialize the cache (MB only).
3A		Autosize cache.
3C		Configure advanced chipset registers.
3D		Load alternate registers with CMOS values.
40		Set initial CPU speed.
42		Initialize interrupt vectors.
44		Initialize BIOS interrupts.
46	2-1-2-3	Check ROM copyright notice.
47		Initialize manager for PCI Option ROMs.
48		Check video configuration against CMOS.
49		Initialize PCI bus and devices.

Code	Beeps	POST Routine Description
4A		Initialize all video adapters in system.
4C		Shadow video BIOS ROM.
4E		Display copyright notice.
50		Display CPU type and speed.
51		Initialize EISA board.
52		Test keyboard.
54		Set key click if enabled.
56		Enable keyboard.
58	2-2-3-1	Test for unexpected interrupts.
5A		Display prompt "Press F2 to enter SETUP".
5C		Test RAM between 512 and 640k.
60		Test extended memory.
62		Test extended memory address lines.
64		Jump to UserPatch1.
66		Configure advanced cache registers.
68		Enable external and CPU caches.
6A		Display external cache size.
6C		Display shadow message.
6E		Display non-disposable segments.
70		Display error messages.
72		Check for configuration errors.
74		Test real-time clock.
76		Check for keyboard errors.
7C		Set up hardware interrupt vectors.
7E		Test coprocessor if present.
80		Disable onboard I/O ports.
82		Detect and install external RS232 ports.
84		Detect and install external parallel ports.
86		Re-initialize on-board I/O ports.
88		Initialize BIOSData Area.
8A		Initialize Extended BIOS Data Area.
8C		Initialize floppy controller.
90		Initialize hard-disk controller.
91		Initialize localbus hard-disk controller.
92		Jump to UserPatch2.
93		Build MPTABLE for multi-processor boards.
94		Disable A20 address line.
96		Clear huge ES segment register.
98		Search for option ROMs.
9A		Shadow option ROMs.

Code	Beeps	POST Routine Description
9C		Set up Power Management.
9E		Enable hardware interrupts.
A0		Set time of day.
A2		Check key lock.
A4		Initialize typematic rate.
A8		Erase F2 prompt.
AA		Scan for F2 keystroke.
AC		Enter SETUP.
AE		Clear in-POST flag.
B0		Check for errors.
B2		POST done - prepare to boot operating system.
B4		One beep.
B6		Check password (optional).
B8		Clear global descriptor table.
BC		Clear parity checkers.
BE		Clear screen (optional).
BF		Check virus and backup reminders.
C0		Try to boot with INT 19.
D0		Interrupt handler error.
D2		Unknown interrupt error.
D4		Pending Interrupt.
D6		Initialize option ROM error.
D8		Shutdown error.
DA		Extended Block Move.
DC		Shutdown 10 error.
		The following are for boot block in Flash ROM:
E2		Initialize the chipset.
E3		Initialize refresh counter.
E4		Check for Forced Flash.
E5		Check HW status of ROM.
E6		BIOS ROM is OK.
E7		Do a complete RAM test.
E8		Do OEM initialization.
E9		Initialize interrupt controller.
EA		Read in the bootstrap code.
EB		Initialize all vectors.
EC		Boot the Flash program.
ED		Initialize the boot device.
EE		Boot code was read OK.

Updating the System BIOS

D

The Micronics system boards are designed so that the BIOS can be reprogrammed using a BIOS file. You can easily FLASH a BIOS by following the steps below:

1. After downloading the appropriate BIOS file from our BBS or Website, extract it to a bootable MS-DOS 6.X diskette.
2. Reboot your system with the MS-DOS 6.X diskette in the A: drive. To make sure a clean DOS environment is loaded, press the F5 key while “Starting MS-DOS” is displayed. After the system has rebooted, the cursor will appear at the A:> prompt.
3. Now you can run the FLASH utility from the bootable floppy disk. Refer to the README.TXT file included with the BIOS update for detailed instructions.
4. After the update process has completed and the system reboots, verify that the new BIOS version appears on-screen. If you have problems during this process, or if you have questions about the procedure, please call Technical Support.



If you encounter any problems during this process, or if you have questions about the procedure, please call Technical Support.

NOTE: If you prefer to send your system board in for the upgrade, the RMA department offers this service free of charge if your system board is under warranty.

Appendix

Limited Warranty

E

Except as described below, Micronics warrants the products to be free from defects in material and workmanship in normal use for a period of one (1) year from date of purchase. Should any product fail to perform according to this warranty at any time during the warranty period, except as provided below, Micronics or its authorized service centers will, at Micronics' option, repair or replace the product at no additional charge.

The warranty does not cover loss or damage which occurs in shipment or which is due to: (1) improper installation or maintenance, misuse, neglect or any cause other than ordinary commercial application, including without limitation, accidents or acts of God; (2) adjustment, repair, or modification by other than a Micronics authorized service center; (3) improper environment, excessive or inadequate heating or air conditioning, or electrical power failures, surges or other irregularities; (4) any statement about the product other than those set forth in this warranty; or (5) nonconformity to models or samples shown to the purchaser. Any models or samples were for the sole purpose of suggesting the character of the product and are not intended to form the basis of the bargain.

A receipt or copy of the invoice with the date of purchase from a Micronics reseller is required before any warranty service can be rendered. Service can be obtained by calling Micronics for a Return Merchandise Authorization (RMA) Number.

The RMA Number should be prominently displayed on the outside of the shipping carton of the returned product. Returned product should be shipped prepaid or hand carried to Micronics. The purchaser assumes risk of loss or damage in transit, and unless otherwise agreed to in writing by Micronics, will pay inbound shipping charges.

The exclusive remedy of the purchaser under this warranty above will be repair or replace at Micronics' option,

but if for any reason that remedy should fail of its essential purpose, the exclusive remedy of the purchaser shall then be actual damages up to amounts paid for the defective product by the purchaser. This limited warranty shall be deemed to “fail of its essential purpose” if, after repeated efforts, Micronics is unable to make the product operate as warranted. Micronics’ liability for damages to the purchaser for any cause whatsoever; regardless of the form of action and whether in contract or in tort, shall be limited to the purchase price in effect when the cause of action arose for the product that is the basis of the claim.

Micronics will not be liable for any lost profits or any indirect, special incidental or consequential damages in connection with the product, even if Micronics has been advised of the possibility of such damages.

Micronics makes no warranties or representations as to performance of products or as to service to distributor or to any person, except as set forth in Micronics; limited warranty accompanying delivery of product.

Micronics disclaims all other warranties whether oral, written, expressed, or implied, including without limitation, the warranties of design, merchantability, or fitness for a particular purpose, if applicable, or arising from a course of dealing, usage or trade practice.

Non-Warranty Service

After the one year warranty service is no longer in effect, repair service is still available for Micronics products. For more information, contact Micronics’ RMA department at (510) 661-3030. The RMA department is open between 8:30 A.M. and 4:45P.M. Pacific Standard Time.

FCC Statement

This equipment has been tested and found to comply within the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not used in accordance with the instructions, may cause harmful interference to radio communications. Interference to radio or television reception can be determined by turning the equipment off and on. You are encouraged to try to correct the interference by one or more of the following measures:

- ▲ Reorient the receiving antenna.
- ▲ Increase the separation between the equipment and the receiver.
- ▲ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▲ Consult your dealer or an experienced radio/TV technician for help.

To meet FCC requirements, shielded cables are required.

NOTE: Changes or modifications not expressly approved by Micronics could void your authority to operate the equipment.

Glossary

16550 UART - A high speed chip for controlling serial ports. Although unnecessary for a mouse, it is required for modems that are 14,400 baud or faster.

AGP - Accelerated Graphics Port. A faster bus than the current 33MHz PCI bus, which will connect the graphics controller to system memory through the chipset.

Asynchronous - Operations that do not require the clocks of communicating devices to be coordinated. See Synchronous.

ATX - A system board size measuring approximately 12" x 9.6".

Bidirectional Parallel Port - A type of parallel port that can send and receive information.

BIOS - An Acronym for Basic Input/Output System. Configures the system board and provides hardware information to the operating system.

Bit - A contraction of Binary digit. The smallest unit of information in a binary number system. A bit represents a choice between either zero or one.

Boot - To start up the computer and load the operating system software. See cold boot and warm boot.

Buffered DIMMs - The 168-pin buffered DIMM modules use buffer logic chips on their control lines to reduce loading on the system board. This buffering action increases the maximum

number of modules on the same system board. The buffered DIMMs come with standard DRAM chips for either 5V or 3.3V operation.

Bus - A group of electronic paths used to send data between parts of the system. On a system board, the bus connects the peripheral cards with the microprocessor via the expansion slots.

Bus Mastering - The ability of a peripheral card to control the bus without requiring intervention of the CPU.

Byte - A group of adjacent bits treated as a unit. Eight bits are typically considered one byte. Also called a character.

Cache - A process where information is copied from the slower memory (DRAM) to the faster memory (SRAM). Information that is likely to be read or edited is stored in the cache providing significant performance increases.

Cache Hit - The percentage of request for data from memory that can be served from the cache.

Cache Miss - A memory access which cannot be supplied from cache.

Cold Boot - Starting the computer by turning on the power or pressing the RESET button. A cold boot makes the processor execute all of the diagnostics. See boot and warm boot.

CPU - An acronym for Central Processing Unit. A CPU performs arithmetic calculations, makes logical decisions, and directs the operation of the computer in conjunction with the operating system.

DIMM - An acronym for Dual Inline Memory Module. A small printed circuit board containing memory chips.

Disk Drive - A hardware device which provides for the storage of data on diskettes or hard metal disks that have a magnetic coating. A disk drive functions by spinning at high speed while moving a device called the read/write head across the disk's surface in order to read or write data in magnetic code.

DMI - An acronym for Desktop Management Interface. DMI makes hardware inventory easier. It defines a format of a management agent for desktop systems. Its layered-model architecture allows a wide range of software and hardware components to pass information about themselves to an asset management system.

DRAM - An acronym for Dynamic Random Access Memory. A type of memory chip that only keeps its memory if supplied with regular clock pulses and a chance to regularly refresh its data. It is slower and more cost effective than SRAM. See SRAM.

ECC - An acronym for Error Checking and Correction. ECC is logic designed to correct memory errors. The number of errors that can be corrected depends upon the algorithms used, and the number of error correction bits (non-data bits) present.

ECP - An acronym for Expanded Capabilities Port. A standard set by Hewlett Packard and Microsoft Corporation to expand the capabilities of the parallel port.

EDO Memory - An acronym for Extended Data Out. A DRAM performance feature that permits multiple bit of data in a single row to be accessed quickly.

EPP - An acronym for Enhanced Parallel Port. A standard which increases the capabilities of the parallel port.

EPROM - Acronym for Erasable Programmable Read Only Memory. A type of ROM chip that can be programmed with relatively simple tools that will retain its data until erased. It can only be erased by exposing the circuitry in the chip to ultraviolet light. See also Flash ROM.

Flash ROM - A type of ROM chip that will retain its data until erased. It can be erased or reprogrammed by supplying it with +12V of voltage. See ROM and EPROM.

Gigabyte - A disk storage capacity measurement. Approximately one thousand megabytes or 1,073,741,824 bytes.

IDE - An acronym for Integrated Device Electronics. A standard for communicating between a hard drive and a computer.

Internal Cache - Cache which is built into the CPU. See Cache.

ISA - An acronym for Industry Standard Architecture. A well-established bus standard that originated with the IBM AT. See *PCI and VESA Local Bus*.

LM75 - The LM75 is a temperature sensor. The host can query the LM75 at any time to read the temperature. Its 3.0V to 5.5V supply voltage range, low supply current and I²C interface, make it ideal for a wide range of applications.

LM79 - The LM79 is a highly integrated Data Acquisition system for hardware monitoring of servers, personal computers or virtually any microprocessor based system. In a PC, the LM79 can be used to monitor temperatures, power supply voltages and fan speeds.

NS - An acronym for Nanosecond. One billionth of a second. Measure of the access time of RAM.

Parallel Port - A connection for a printer or similar peripheral. Generally, parallel ports are output only. See *Bi-directional Parallel Port* and *ECP*.

Parity - Logic that detects the presence of an error in memory. Generally, a single parity bit is used for each byte (8 bits) of data. The most commonly used forms of parity are even parity, odd parity and checksums.

PC100 SDRAM - Intel's latest BX chipset and associated system boards increase the memory bus speed from 66 to 100MHz. Completely new SDRAM DIMM modules are necessary to meet the enhanced speed requirement.

These are called PC100 modules. The PC100 specification defines very stringent design rules for these 100MHz modules. Only DIMM's designed to meet this requirement will work correctly in 100MHz system boards.

PCI - An acronym for Peripheral Component Interconnect. A high performance 32-bit or 64-bit bus developed by Intel Corporation. PCI is designed to be independent of the hardware architecture to ensure compatibility with future computer systems. See *VESA Local Bus and ISA*.

Pentium - A high performance 64-bit CISC processor designed and manufactured by Intel Corporation.

Pipeline - In DRAMs and SRAMs, a method for increasing the performance using multistage circuitry to stack or save data while new data is being accessed.

Plug and Play - A standard developed to ensure easy installation of peripherals. Theoretically, a newly installed card will automatically configure itself and work properly without requiring jumper configuration or device drivers.

POST - An acronym for Power On Self Test. A diagnostic program that is run whenever the system is cold booted.

RAM - An acronym for Random Access Memory. A type of memory that is used as the "working memory" of a computer system. See *DRAM* and *SRAM*.

ROM - An acronym for Read Only Memory. A type of memory that retains its data without requiring power. Once written, it cannot be modified. See EPROM and Flash ROM.

SCSI - Small Computer System Interface. A bus interface standard that defines physical and electrical characteristics for hardware devices. SCSI provides a standard interface that enables many different kinds of devices, such as disk drives and CD-ROM drives to interface with the host computer.

SDRAM - An acronym for Synchronous Dynamic Random Access Memory or Synchronous DRAM. A DRAM designed to deliver bursts of data at very high speed using automatic addressing, multiple page interleaving and a synchronous (or clocked) interface.

Serial Port - A communications port used to connect peripherals such as modems and mice.

Setup - A program that allows you to make changes to the system configuration.

SIMM - An acronym for Standard Inline Memory Module. A small printed circuit board containing memory chips.

Small Computer System Interface - See SCSI.

Synchronous Cache - A type of cache that uses a clock signal to latch the inputs and the data output. This structure spreads the cache access across two

or three cycles while maintaining a bandwidth of one access per cycle. Improves performance by 5-10%.

Unbuffered DIMMs - The unbuffered DIMM modules do not use any buffer logic chips, thus achieving faster operation due to the elimination of the propagation delay of the logic buffer. This increase in speed comes at the cost of reducing the maximum number of modules on the same system board.

USB - Universal Serial Bus. The simple and flexible way to connect devices to your desktop or notebook PC. USB allows virtually unlimited PC expansion with no more hassles over add-in cards, dip switches, jumper cables, software drivers, IRQ settings, DMA channels and I/O addresses. With USB, you can attach and detach peripherals without opening the computer or even shutting it down.

VESA - An acronym for Video Electronics and Standards Association.

VESA Local Bus (VL-Bus) - A high performance bus designed by VESA. A 32-bit version of the ISA bus which operates at the speed of the computer's CPU. See *PCI and ISA*.

VRM - Voltage Regulator Module. Supplies CPU specific voltages for the Secondary CPU.

Write-Back Cache - Upon a cache hit, the cache is updated and the main memory is not affected. Upon a cache miss, only the main memory is updated.

Index

B

- Battery Disposal - 64
- POST Messages - 67
- BIOS
 - Configuration - 39
 - Setup - 39
- Bulletin Board System (BBS) - 66

C

- Configuring the Redstone- 11
- CPU
 - Box Version - 31
 - Installation - 26
 - Overview 30
 - Retention Mechanism - 26

D

- Diagram (Redstone) - 12

E

- Environmental Specifications - 63
- Error Checking (ECC) - 19, 21

H

- Help
 - Bulletin Board System (BBS) - 66
 - Telephone Numbers - 66
 - Troubleshooting - 67, 69

I

Installation

- AGP Peripheral Card - 34
- CPU - 26
- Installing the Redstone - 19
- ISA Peripheral Card - 33
- PCI Peripheral Card - 32
- Quick Installation - 9

J

- Jumper Settings - 13

M

- Redstone System Board Diagram - 12

Memory

- Configurations - 22
- Installing - 25
- Removing - 25
- Supported - 19, 21

O

- Online Services - 66

P

- PC100 SDRAM Memory - 19, 21
- POST Messages - 67

S

- Specifications - 61
- Synchronous DRAM Memory - 19, 21
- System BIOS - 35, 73

T

- Technical Specifications - 61
- Technical Support - 65
- Troubleshooting - 67, 69

U

- Updating the System BIOS - 73
- Utility Programs
 - Advanced Screen - 43
 - BIOS Setup - 39
 - Chipset Screen - 46
 - Exit Screen - 52
 - Features Screen - 47
 - Info Screen - 37
 - Main Screen - 39

W

- Warranties - 75
- World Wide Web - 66