

S755TWIN

USER'S MANUAL

***M/B For Socket 754 AMD Athlon64
Processor***

NO. G03-S755T8

Rev:1.0

Release date: April 2003

Trademark:

* Specifications and Information contained in this documentation are furnished for information use only, and are subject to change at any time without notice, and should not be construed as a commitment by manufacturer.

TABLE OF CONTENT

| | |
|--|----|
| USER'S NOTICE | ii |
| MANUAL REVISION INFORMATION | ii |
| COOLING SOLUTIONS..... | ii |
| CHAPTER 1 INTRODUCTION OF S755TWIN MOTHERBOARD | |
| 1-1 FEATURE OF MOTHERBOARD | 1 |
| 1-2 SPECIFICATION | 2 |
| 1-3 PERFORMANCE LIST | 3 |
| 1-4 LAYOUT DIAGRAM & JUMPER SETTING..... | 4 |
| CHAPTER 2 HARDWARE INSTALLATION | |
| 2-1 HARDWARE INSTALLATION STEPS..... | 6 |
| 2-2 CHECKING MOTHERBOARD'S JUMPER SETTING | 6 |
| 2-3 INSTALL CPU | 7 |
| 2-3-1 GLOSSARY | 7 |
| 2-3-2 ABOUT INTEL AMD K8 754-PIN CPU..... | 8 |
| 2-4 INSTALL MEMORY | 8 |
| 2-5 EXPANSION CARD | 9 |
| 2-5-1 PROCEDURE FOR EXPANSION CARD INSTALLATION..... | 9 |
| 2-5-2 ASSIGNING IRQ FOR EXPANSION CARD..... | 9 |
| 2-5-3 INTERRUPT REQUEST TABLE FOR THIS MOTHERBOARD | 10 |
| 2-5-4 AGP SLOT | 10 |
| 2-6 CONNECTORS, HEADERS | 11 |
| 2-6-1 CONNECTORS | 11 |
| 2-6-2 HEADERS..... | 14 |
| 2-7 STARTING UP YOUR COMPUTER..... | 18 |
| CHAPTER 3 INTRODUCING BIOS | |
| 3-1 ENTERING SETUP | 19 |
| 3-2 GETTING HELP | 19 |
| 3-3 THE MAIN MENU..... | 20 |
| 3-4 STANDARD CMOS FEATURES..... | 21 |
| 3-5 ADVANCED BIOS FEATURES..... | 22 |
| 3-6 ADVANCED CHIPSET FEATURES..... | 24 |
| 3-6-1 DRAM TIMING SETTINGS | 25 |
| 3-7 INTEGRATED PERIPHERALS | 26 |
| 3-7-1 ONBOARD IDE FUNCTION | 26 |
| 3-7-2 ONBOARD DEVICE FUNCTION..... | 27 |
| 3-7-3 ONBOARD SUPER IO FUNCTION | 28 |
| 3-8 POWER MANAGEMENT SETUP | 29 |
| 3-8-1 PM TIMER RELOAD EVENTS | 30 |
| 3-9 PNP/PCI CONFIGURATION SETUP | 30 |
| 3-9-1 IRQ RESOURCES..... | 31 |
| 3-10 PC HEALTH STATUS | 32 |
| 3-11 MISCELLANEOUS CONTROL..... | 32 |
| 3-12 LOAD STANDARD/OPTIMIZED DEFAULTS..... | 33 |
| 3-13 SET SUPERVISOR/USER PASSWORD..... | 34 |
| CHAPTER 4 DRIVER & FREE PROGRAM INSTALLATION | |
| MAGIC INSTALL SUPPORTS WINDOWS 98SE/ME/NT4.0/2000/XP | 35 |
| 4-1 AGPVXD INSTALL SIS AGPVXD DRIVER | 36 |
| 4-2 IDE INSTALL SIS MINI IDE DRIVER..... | 37 |
| 4-3 SOUND INSTALL ALC AUDIO CODEC DRIVER..... | 37 |
| 4-4 LAN INSTALL LAN CONTROLLER DRIVER | 38 |
| 4-5 PC-HEALTH INSTALLS SMART GUARDIAN SOFTWARE FOR HARDWARE MONITORING DEVICE | 39 |
| 4-6 PC-CILLIN INSTALL PC-CILLIN2002 ANTI-VIRUS PROGRAM | 40 |
| 4-7 USB2.0 INSTALL SIS USB2.0 DEVICE DRIVER..... | 41 |
| 4-8 RAID INSTALL SIS 180 RAID DRIVER AND UTILITY | 42 |
| 4-9 HOW TO DISABLE ON-BOARD SOUND | 43 |
| 4-10 HOW TO UPDATE BIOS..... | 43 |

USER'S NOTICE

COPYRIGHT OF THIS MANUAL BELONGS TO THE MANUFACTURER. NO PART OF THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT MAY BE REPRODUCED, TRANSMITTED OR TRANSLATED INTO ANY LANGUAGE IN ANY FORM OR BY ANY MEANS WITHOUT WRITTEN PERMISSION OF THE MANUFACTURER.

THIS MANUAL CONTAINS ALL INFORMATION REQUIRED TO USE S755TWIN MOTHER-BOARD AND WE DO ASSURE THIS MANUAL MEETS USER'S REQUIREMENT BUT WILL CHANGE, CORRECT ANY TIME WITHOUT NOTICE. MANUFACTURER PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, AND WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFIT, LOSS OF BUSINESS, LOSS OF USE OF DATA, INTERRUPTION OF BUSINESS AND THE LIKE).

PRODUCTS AND CORPORATE NAMES APPEARING IN THIS MANUAL MAY OR MAY NOT BE REGISTERED TRADEMARKS OR COPYRIGHTS OF THEIR RESPECTIVE COMPANIES, AND THEY ARE USED ONLY FOR IDENTIFICATION OR EXPLANATION AND TO THE OWNER'S BENEFIT, WITHOUT INTENT TO INFRINGE.

Manual Revision Information

| Reversion | Revision History | Date |
|-----------|------------------|------------|
| 1.0 | First Release | April 2003 |

Item Checklist

- S755TWIN Motherboard
- Cable for IDE/Floppy
- CD for motherboard utilities
- Cable for USB Port 3/4 (Option)
- Cable for Serial ATA IDE Port
- SPDIF-IN/SPDIF-OUT Adaptor
- S755TWIN User's Manual

AMD K8 Processor Family Cooling Solutions

As processor technology pushes to faster speeds and higher performance with increasing operation clock, thermal management becomes increasingly crucial while building computer systems. Maintaining the proper computing environment without thermal increasing is the key to reliable, stable, and 24 hours system operation. The overall goal is keeping the processor below its specified maximum case temperature. Heatsinks induce improved processor heat dissipation through increasing surface area and concentrated airflow from attached active cooling fans. In addition, interface materials allow effective transfers of heat from the processor to the heatsink. For optimum heat transfer, AMD recommends the use of thermal grease and mounting clips to attach the heatsink to the processor.

Please refer to the website below for collection of heatsinks evaluated and recommended for Socket-A processors by AMD. In addition, this collection is not intended to be a comprehensive listing of all heatsinks that support Socket-754 processors.

For vendor list of heatsinks and Active cooling fans, please visit :

http://www.amd.com/us-en/Processors/DevelopWithAMD/0,,30_2252_869_9460^9515,00.html

Introduction

MagicTwin is a 2-User-System solution built on this special designed motherboard with a dual headed AGP graphic card, two PS/2 keyboard and mouse Y-cables and one piece of software (Driver and Tools). It allows you to add one additional station simultaneously running Windows XP Home or XP-Professional (Service Pack 1).

System Requirement

Jetway MagicTwin Motherboard:

- 2 x PS/2 Y-cable
- Install CD (Driver and MagicTwin)
- Serial Number and Activation Key

Purchased Separately from Dealer:

- >=1.2 GHz Processor
- Min 256MB DRAM
- NVIDIA Dual Head AGP Graphic Card
- Windows XP Home, Prof. w/ SP1
- 2 x PS/2 Keyboards
- 2 x PS/2 Mice
- 2 x Monitors

Necessary Components to Configure 2-User-System


- one special designed Motherboard with connectivity hardware onboard
- one dual head AGP graphic card (purchased separately from your dealer)
- two Y-cables for two PS/2 Keyboards and two PS/2 Mice
- MAGIC INSTALL CD (incl. all DRIVERS you need and some TOOLS to enable the 2-User function of the motherboard). In addition this CD includes an auto detect software, which detects, installs and assigns the related 2nd video display and the 2nd PS/2 keyboard and PS/2 mouse.
- one serial number and activation key (printed on the sticker label on top of the CD package folding seal)
- two monitors
- two speaker systems (optional)

Recommendations

- CPU: >1GHz
- minimum 256 MB RAM for two Stations, running simultaneously
- two Standard PS/2 Keyboards, -Mice and two Monitors (Sound: optional)
- Hard disk and CD-ROM drive

Installation of MagicTwin

- We recommend to install Windows XP and all related drivers from the scratch
- Switch off your PC and open the computer case
- Remove the AGP slot bracket and insert a dual headed AGP Video Card purchased separately from your dealer into the AGP-slot. If the delivered motherboard comes with dual VGA port onboard, please skip this step.



Dual Port AGP VGA Card

- As well attach the delivered Y-cables to the “green” port (former PS/2 Mouse port) and into the “violet” port (former PS/2 Keyboard port) at the rear side of the motherboard.
- Connect the 1st and 2nd mouse to the Y-cable, which is also linked to the “green” PS/2 connector and the 1st and 2nd keyboard to the other Y-cable, which is also connected to the “violet” port. The additional monitor MUST be attached otherwise windows will not detect and enable the 2nd monitor. Make sure the additional keyboards and mice work; they should affect the host console.
- Start your PC. Windows will automatically detect the new AGP Video device as a standard VGA-card. Please install first all drivers before installing “MagicTwin” of the MAGIC INSTALL CD. Insert the CD, wait for the automatic start and run the Installation of all other drivers beside the MagicTwin from the Magic Install CD. If the CD does not run automatically, please click to Start-> Run-> CD-Drive-> SETUP.EXE.


- After all other drivers have been installed, lastly install the MagicTwin as follow:



Click "MagicTwin" when the MAGIC INSTALL MENU appears. The Installation-routine will start...



Welcome- Mask, click "Next"



Option: Change destination path or click "Next"



Password and Network Console, click "Next"



Type in the Serial and Address, click "Next"



Installation in process, please wait...



Afterwards "Reboot your PC".

- Windows is restarting and loading the new installed drivers. The MagicTwin will be activated and assign automatically the 2nd Station to the 2nd monitor, -PS/2-keyboard and PS/2 mouse.
- Please login in to Windows and add one or more additional users under the control panel.

Dual Head AGP-card

The NVIDIA MX 440-8X, MX-4000, FX 5200 and FX5600 dual-head graphic cards are supported under MagicTwin. One display can be used by the host and the second by the MagicTwin station. Contact your dealer for purchasing of the validated NVIDIA dual head AGP VGA card. Among them are:

- | | | |
|-----------------------|------------------------|------------------------|
| 1. Jetway NV18-A2-64B | 2. Jetway NV34-AD-128B | 3. Jetway N31X-AD-128B |
| 4. Asustek V9520 | 5. Leadtek A340 | 6. Leadtek A180 |
| 7. MSI FX5600-TD128 | 8. MSI FX5200-TD128 | |

Einführung

Dieses Barebone-System ist eine Multi-User-Plattform, welche die Verbindung zweier Benutzer zum System ermöglicht. Mit einer Anschlusshardware onboard und einer innovativen Software, erlaubt das MagicTwin® Series Barebone System zwei Benutzern verbunden zu sein und simultan eine Windows – Session zu betreiben. Jeder der zwei Benutzer hat dabei das Gefühl, seinen eigenen Windows-XP Rechner zu haben. Jeder Benutzer benötigt seine eigene Tastatur, seine eigene Maus, Soundkarte und seinen eigenen Monitor. Die übrige PC Hardware wird geteilt, sogar die IP. Alles was Sie brauchen ist ein einzelnes MiniQ MagicTwin System mit minimal einem 1.0 GHz oder einem höherem Prozessor, 256M RAM - Speicher (128MB pro Arbeitsstation/ Benutzer) und einem zweifachen VGA-Port. Sie können sofort dem einzelnen PC eine zusätzliche Benutzerstation hinzufügen und aus eins zwei machen!

Systemvoraussetzungen bzw. Empfehlungen

MiniQ MagicTwin Series Barebone System

- 2 x Oktopus- Kabel for PS/2 keyboard and PS/2 mouse
- 1 x MagicTwin Installation CD (driver and digital description)
- 1 x Serien- Nummer mit Authorisationscodes und Lizenzvereinbarung

Purchased Parts


- >= 1.2GHz Prozessor
- 256MB Systemspeicher
- Windows XP Home oder Professional, sowie das installierte Service Pack 1
- Dual- Head- VGA- AGP Grafikkarte von Ihrem Händler beziehen
- 2 x PS/2 Tastatur (Kabel oder Kabellos)
- 2 x PS/2 Maus (Kabel oder Kabellos)
- 2 x SVGA Standard Monitor (CRT Monitor oder TFT Flachbildschirm)

Installation der MagicTwin

Wir weisen ausdrücklich darauf hin, das Ihr Gerät alle Systemvoraussetzungen für die MagicTwin Technologie gegeben sind. Jedes MagicTwin System benoetigt zwei VGA- Ports. Sie können eine Dual- Head- VGA- AGP Grafikkarte von Ihrem Händler beziehen. Bereiten Sie die Installation vor, in dem Sie sicherstellen, das Sie in Ihrem Barebone- Pcs Prepare eine der folgenden Komponenten benutzen: a). hinzugefügt Dual Head AGP VGA Karte (2 VGA Ports) b). Dual Port VGA- Grafik onboard

Überprüfen Sie das Mainboard und die Barebone- Verpackung und folgen Sie der Installation für die Bereitstellung des 2. VGA- Ports.

Schalten Sie Ihren PC aus und öffnen Sie das Gehäuse. Entfernen Sie das Slotblech für den VGA- Port und setzen Sie an dieser Stelle eine Dual Head AGP Grafikkarte, welche Sie separat erworben haben, in den AGP-Slot. Wenn Ihr geliefertes Mainboard mit zwei VGA- Ports onboard geliefert wurde, überspringen Sie bitte diesen Schritt.




Nun schliessen Sie die zwei mitgelieferten Oktopus Kabel auf der Rückseite des Mainboards an, eines an den "gruenen" Port (normalerweise PS/2 Maus Port) und den Anderen an den "violetten" Port (normalerweise PS/2 Tastatur Port). Verbinden Sie nun die erste und zweite Maus mit dem Oktopus Kabel, welches bereits mit dem "gruenen" PS/2 Anschluss, und die erste und zweite Tastatur, welches bereits mit dem "violetten" Port verbunden ist. Der zusätzliche Monitor muss angeschlossen sein, da Windows den 2. Monitor sonst nicht erkennt und aktiviert. Starten Sie nun Ihren Computer neu.

Software Installation

Starten Sie Ihren Computer neu. Windows erkennt automatisch die neue AGP Grafikkarte als eine standard VGA- Grafikkarte. Bitte installieren Sie zunächst alle anderen aktuellen Treiber und erst danach den Treiber "MagicTwin" der MAGIC INSTALL CD. Legen Sie die CD ein, und warten auf den automatischen Start und starten die Installation der MagicTwin- Software von der Magic Install CD. Falls die CD nicht automatisch startet, klicken Sie bitte auf Start-> Ausführen-> CD-Laufwerk-> SETUP.EXE.



Klicken Sie auf "MagicTwin" wenn das MAGIC INSTALL MENUE erscheint. The Installationsroutine startet



Willkommensbildschirm, klicken Sie auf "Next"



Option: Ändern Sie den Zielpfad oder klicken auf "Next"



Passwort und Netzwerk- Konsole, klicken Sie "Next"



Geben Sie Seriennummer und Adresse ein, auf "Next"



Die Installation wird ausgeführt, bitte warten...



Danach "Starten Sie Ihren Computer neu".

Windows startet neu und lädt die neu installierten Treiber. MagicTwin ist nun aktiv und weist automatisch die 2. Arbeitsstation dem zweiten Monitor, -PS/2-Tastatur und PS/2 Maus zu.

Bitte loggen Sie sich nun bei Windows ein, und fügen Sie ein oder mehrere Benutzerkonten in der Systemsteuerung hinzu.

Installation de MAGIC TWIN

Magic Twin est une solution « 2 postes en 1 », grâce à une carte mère conçue tout spécialement à cet effet, elle comporte 2 connecteurs vidéo, 2 ports pour les claviers et les souris, deux câbles en Y sont fournis afin de dupliquer les ports PS/2, ainsi que le logiciel nécessaire au bon fonctionnement de l'ensemble (driver et utilitaire).

Composants nécessaires à l'utilisation de deux systèmes

- Une carte mère de conception spéciale (tous les câbles inclus).
- Deux câbles Y pour deux claviers et deux souris PS/2.
- Le CD « Magic Install » En supplément dans ce CD un logiciel d'auto détection pour l'installation et l'assignation du second écran, du second clavier, de la seconde souris.
- Deux moniteurs.
- Deux haut-parleurs systèmes (option).
- CPU > 1Ghz.
- 256 Mo de RAM minimum pour les deux postes de travail fonctionnant simultanément.
- Deux claviers PS/2 standard, deux souris PS/2 standard et deux moniteurs. (Son en option).
- Disque dur et lecteur de cd-rom.

Installation de « Magic Twin »

- Dans un 1^{er} temps nous vous recommandons d'installer Windows XP ainsi que tous les drivers du matériel installé.
- Eteignez votre PC (débranchez le) et ouvrez votre boîtier.
- Connecter les deux moniteurs aux deux connecteurs VGA de la carte mère.
- Connecter les deux duplicateurs de ports PS/2.
 - Vert pour les souris.
 - Violet pour les claviers.

A l'arrière de la carte mère

- Puis connecter les claviers et les souris se rapportant aux duplicateurs de ports.
- -Après avoir connecté le second moniteur et vous être assuré que celui-ci était bien reconnu par Windows, assurez-vous que le second clavier influe bien sur le second bureau et affecte bien le bon poste de travail.
- Allumer votre pc, Windows détecte automatiquement le nouveau périphérique vidéo AGP relié à la carte vidéo.
- En 1ers lieux installer le driver « Magic Twin » situé sur le CD « Magic Install ».
- Placer le CD dans le lecteur et attendre le démarrage automatique de l'installation du logiciel « Magic Twin ».
- Si le CD ne démarre pas correctement, cliquer sur :
START > RUN > CD-DRIVE > SETUP.EXE

Lorsque le menu " Magic Install" apparaît, cliquer sur « Magic Twin ».

Puis suivre les indications données à l'écran. (En règle générale cliquer sur « NEXT »).



Cliquez sur "MagicTwin" à l'apparition du menu MAGIC INSTALL . La routine d'installation commence...



Message de bienvenue click Next”



Option: Changer de destination path ou cliquer “Next”



Mots de passe et cliquez “Next”



Taper le n°de Série et votre Adresse, cliquez “Next”



Installation en cour merci de patienter.



Installation terminée, rebooter votre PC.

- Après avoir installé les nouveaux drivers et relancé votre PC, « Magic Twin » est activé, et assigne automatiquement le second poste de travail au second moniteur, le second clavier et la seconde souris.
- Relancer à nouveau Windows et ajouter un ou plusieurs utilisateurs additionnels dans le panneau de configuration.

Introduzione

Il sistema barebone è una piattaforma multiutente che consente la connessione al sistema da parte di due utenti. Grazie all'hardware di connettività integrato e al software innovativo, il sistema barebone della serie Digybox MagicTwin® consente a 2 utenti di connettersi e di lavorare contemporaneamente su 2 stazioni con sessioni Windows separate. Ciascuno dei 2 utenti ha l'impressione di disporre di un proprio computer dotato di Windows XP. Ogni utente deve avere a disposizione tastiera, mouse, periferica audio e monitor propri. Il resto dell'hardware del PC è condiviso, incluso l'indirizzo IP. Tutto ciò che è necessario è un singolo sistema Digybox MagicTwin dotato almeno di un processore da 1,2 GHz o superiore, di 256 MB di RAM (128 MB per workstation/utente) e di una doppia porta VGA. La seconda stazione utente può essere aggiunta al sistema singolo in pochi istanti, trasformando di fatto un PC in due.

Requisiti hardware minimi con caratteristiche flessibili di espansibilità

sistema della serie MagicTwin

2 x cavo Octopus per tastiera PS/2 e mouse PS/2

1 x CD di installazione MagicTwin (driver e manuali digitali)

1 x numero di serie con Codice di autorizzazione e Contratto di licenza 1.

Purchased parts

>= 1 GHz Processore

256 MB di memoria di sistema

Windows XP Home oppure Professional, con Service Pack 1

2 x tastiera PS/2 (con cavo o wireless)

2 x mouse PS/2 (con cavo o wireless)


2 x monitor standard SVGA (monitor CRT o LCD TFT)

Installazione di MagicTwin


È molto importante che siano rispettati i requisiti di sistema indicati. Ogni sistema MagicTwin necessita di due porte VGA. È possibile acquistare separatamente la scheda AGP VGA Dual Head dal proprio rivenditore. Preparare l'installazione utilizzando una scheda madre o un sistema barebone con: a) una scheda AGP VGA Dual Head aggiuntiva (con 2 porte VGA) b) una doppia porta VGA integrata su scheda. Controllare la confezione della scheda madre e del sistema barebone, quindi procedere con l'installazione sulla base dello stato di una doppia porta VGA.

Spegner il PC e aprire il case del computer.

Rimuovere la staffa dello slot AGP e inserire nello slot una scheda video AGP Dual Head acquistata separatamente dal proprio rivenditore. Se la scheda madre è fornita con una doppia porta VGA integrata su scheda, ignorare questo passaggio.



Doppia porta VGA su scheda



Doppia porta AGP VGA V

Collegare i due cavi Octopus forniti, uno alla porta "verde" (prima porta del mouse PS/2) e l'altro alla porta "viola" (prima porta della tastiera PS/2) sul retro della scheda madre.

Collegare il primo e il secondo mouse al cavo Octopus collegato al connettore PS/2 "verde", quindi collegare la prima e la seconda tastiera all'altro cavo Octopus collegato alla porta "viola". Il monitor aggiuntivo DEVE essere collegato, altrimenti Windows non potrà rilevare e attivare il secondo monitor. A questo punto, riavviare il PC.

Installazione del software

Riavviare il PC. Windows riconosce automaticamente la nuova periferica video AGP come scheda VGA standard. Installare prima tutti gli altri driver presenti, quindi per ultimo il driver "MagicTwin" dal CD MAGIC INSTALL. Inserire il CD, attendere l'avvio automatico e avviare l'installazione di MagicTwin dal CD Magic Install. Se il CD non si avvia automaticamente, fare clic su Start, Esegui e digitare D:\SETUP.EXE (dove D: è la lettera dell'unità ottica).



Fare clic su "MagicTwin" per aprire il menu MAGIC INSTALL. Si avvia la procedura di installazione...



Alla schermata iniziale, fare clic su "Next"



Opzione: modificare il percorso di destinazione oppure fare subito clic su "Next"



Password e Network Console, fare clic



Digitare il numero di serie e l'indirizzo, quindi fare clic su "Next"



Installazione in corso, attendere...



Al termine dell'operazione, scegliere "Yes" alla richiesta di riavvio del PC.

Windows viene riavviato, caricando i nuovi driver installati. MagicTwin viene attivato assegnando automaticamente la seconda stazione al secondo monitor, alla seconda tastiera PS/2 e al secondo mouse PS/2. Accedere a Windows e aggiungere uno o più utenti dal Pannello di controllo.

Introducción

El sistema MagicTwin es una solución interconstruida en el especial diseño de las tarjetas madre (principal) que lo incorporan y que le permitirá la simultánea operación de 2 usuarios en el mismo computador, con una tarjeta de video AGP de doble salida, dos cables ' Y ' para teclado y ratón tipo PS/2 y un programa con manejadores y herramientas. Este sistema le permitirá agregar una estación de trabajo adicional corriendo Windows XP Home o Professional (Service Pack 1) simultáneamente .

Requerimientos del Sistema

Tarjeta Madre Jetway MagicTwin :

- 2 x PS/2 cable ' Y '
- CD de Instalación (Manejadores y sistema MagicTwin)
- Número de serie y Llave de Activación

Adquirido en forma independiente con su Distribuidor:

- Procesador con velocidad igual o mayor a 1.2 Ghz
- Mínimo de 256MB DRAM en memoria
- Tarjeta de video gráfica AGP NVIDIA con salida Doble o Dual
- Windows XP edición Home ó Professional, con el Service Pack 1
- 2 Teclados PS/2
- 2 Ratones PS/2
- 2 Monitores

Componentes necesarios para configurar 2 usuarios


- Una Tarjeta madre con diseño especial de conectividad interconstruida
- Una Tarjeta de video gráfica AGP con salida de video doble (Adquirida con su distribuidor)
- Dos cables en ' Y ' para conectar dos teclados y dos ratones tipo PS/2
- CD MAGIC INSTALL (incluyendo todos los manejadores necesarios y las herramientas para habilitar la función 2 Usuarios en la Tarjeta madre). Además, éste contiene un programa de autodetección el cual detecta, instala y configura el 2do. Monitor , y los 2dos. Teclado y Ratón tipo PS/2.
- Número de serie y Llave de activación (Impresa en la etiqueta del estuche donde se empaqueta el CD de instalación)
- Dos monitores
- Dos juegos de bocinas (opcional)

Recomendaciones

- Microprocesador o CPU: > 1.2 GHz
- Mínimo de 256 MB RAM para dos estaciones corriendo simultáneamente
- Dos teclados estándar y dos ratones tipo PS/2 así como dos Monitores (Sonido: opcional)
- Disco duro y lector CD-ROM

Instalación del Sistema MagicTwin

- Instale Windows XP y sus correspondientes manejadores
 - Apague su computador y destape el gabinete
 - Retire la tapa correspondiente al conector AGP e instale la tarjeta de video gráfica AGP con salida dual (que fue adquirida por separado) en el conector AGP.
- Si el modelo de su Tarjeta madre ya incluye el puerto de salida de video dual, por favor omita este paso.



Dual Port AGP VGA Card

- Retire la tapa correspondiente al conector AGP e instale la tarjeta de video gráfica AGP con salida dual (que fue adquirida por separado) en el conector AGP.
- Si el modelo de su Tarjeta madre ya incluye el puerto de salida de video dual, por favor omita este paso.
- Conecte los cables ' Y ' en los conectores tipo PS/2 que se encuentran en la parte trasera de su computador : color Verde para Ratón y color Violeta para Teclado
- Conecte el primer y segundo ratón al cable ' Y ' que conectó al puerto PS/2 color verde, de igual forma instale el primer y segundo teclado al cable ' Y ' instalado en el conector PS/2 color Violeta. Conecte los dos monitores a sus respectivas salidas, tenga en cuenta que el 2do monitor DEBE estar conectado, de otra forma, Windows no lo detectará y no lo habilitará . Asegúrese que los teclados y ratones conectados estén en condiciones de trabajo ya que de lo contrario, podría afectar el funcionamiento del computador.
- Arranque su Computador . Windows automáticamente detectará el nuevo dispositivo AGP de video como una tarjeta de video gráfica VGA estándar. **Instale los manejadores de la misma antes de instalar el sistema Magic Twin desde el CD incluido.** Inserte el CD Magic Install, espere a que este se autoejecute y empiece la instalación de los manejadores y programas de configuración de los dispositivos integrados en la Tarjeta Madre y que serán necesarios para la operación del sistema Magic Twin. Si al insertar el CD, éste no se autoejecuta, presione INICIO -> Ejecutar -> Unidad lector-CD : SETUP.EXE

はじめに

このベアボーンシステムは、マルチメディア対応のプラットフォームで 2 人のユーザー共有が可能です。最先端の機器とソフトウェアを駆使し、MagicTwin® シリーズベアボーンシステムは、2 ユーザーを共有環境に導き Windows 上で、選択が可能です。各 2 ユーザーは、独自の Windows-XP コンピューターを持っている環境となります。通常の PC ユーザーは、各自、キーボード、マウス、音響機器、モニターが必要になります。しかし、本製品の場合は、機器の共有が可能です、IP も同様です。但し、本製品のユーザーの必須 PC 環境は、CPU は、1.0 GHz 以上、メモリは、DDR 256MB (各ユーザーに対して 128MB)、デュアルの VGA ポートが必要です。つまり、1 つの PC が 2 台分の役目が可能となります。

システム必須環境

MiniQ MagicTwin シリーズベアボーンシステム

- 2 x PS/2 keyboard・PS/2 mouse 用 Y 字ケーブル
- 1 x MagicTwin インストール CD (driver and digital description)
- 1 x シリアルナンバー・authorization code、ライセンス同意書

購入して下さい


- 2 x PS/2 キーボード(ケーブル、または、無線)
- 2 x PS/2 マウス(ケーブル、または、無線)
- 2 x SVGA の標準のモニター (CRT モニタ、または、TFT モニタ)
- デュアルヘッド AGP VGA
- Service Pack1 がインストールされている Windows XP HOME または、Professional
- CPU は 1,2GHz
- メモリは 256MB 搭載

MagicTwinハードウェア


システム要求が満たしている事を推奨します。全ての Magic Twin システムは 2 VGA ポートが必要です。別売りでデュアルヘッド AGP VGA カードを購入して下さい。取り付ける為に以下のいずれかを準備して下さい: a). デュアルポートが付いている VGA b). デュアルオンボード VGA カード

パッケージを確認してお客様の必要なデュアルVGAポートをご用意下さい。

AGP スロットブラケットを取り外し、AGP スロットに準備した AGP VGA カードを挿入して下さい。 b) の場合はこのステップを飛ばして下さい。



Onboard Dual Port VGA



Dual Port AGP VGA Card

マウス用・キーボード用それぞれの Y 字ケーブルを PS/2 マウスポート (グリーン) ・ PS/2 キーボードポート (紫) に接続して下さい。2 セットのマウスとキーボードを必ず一つの Y 字ケーブルで接続して下さい。モニターも必ず 2 つ接続して下さい。

ソフトウェアのインストール


PC を起動して下さい。Windows は標準の VGA カードとして新しい AGP VGA デバイスを自動的に検出します。Magic Twin ドライバー以外のドライバーを先にインストールして下さい。最後に Magic Twin インストール CD の Magic Twin ドライバーをインストールして下さい。もし CD がオートラン (自動再生) しない場合は Start>Run>CD ドライブ>SETUP.EXE をクリックして下さい。



“MagicTwin”をクリックして下さい。



Welcome 画面で“Next”をクリックして下さい。



オプション：プログラムを保存したい場所を選択するか、“Next”をクリックして下さい。



Password と Network Console を入力し、“Next”をクリックして下さい。



シリアルと必要事項を入力し、“Next”をクリックして下さい。



インストールが始まります。



“Restart”ボタンをクリックして、再起動して下さい。

ウィンドウズは、新しいインストールされたドライバーをロードします。MagicTwin はアクティブになり、そして自動的にセカンドステーションにモニタ、PS/2 マウスを指定します。

産品紹介

MagicTwin 為建構於具備雙視訊輸出連接器之 AGP 顯示卡，雙 PS/2 介面滑鼠鍵盤 Y 型纜線，與一套軟體〈驅動程式與工具程式〉之特殊設計主機板之雙使用者解決方案。它允許您增加額外之工作站來模擬運行 Windows XP 家用或專業版(Service Pack 1)。

系統需求

捷波 MagicTwin 主機板

2 x PS/2 Y 型纜線

安裝光碟片〈驅動程式與工具程式〉

產品序號與啓動金鑰
需另行於經銷商處購入
>=1.2 GHz 中央處理器
最小 256MB 之系統記憶體
NVIDIA 雙視訊輸出連接器之顯示卡
Windows XP 家用或專業版(Service Pack 1)
2 x PS/2 介面滑鼠
2 x PS/2 介面鍵盤
2 x 顯示器

設定雙使用者系統的必要元件


- 一張具備內建連接認證晶片的特殊設計主機板
- 一張具備雙視訊輸出連接器之顯示卡 (需另行於經銷商處購入)
- 兩條 PS/2 介面滑鼠鍵盤 Y 型纜線
- **MAGIC** 安裝光碟片 (包括您所需要之全部驅動程式與部分工具程式用以驅動主機板之雙使用者功能)。此外此光碟包括一套用以偵測、安裝與指定相關第二顯示器及第二組 PS/2 介面滑鼠鍵盤之自動偵測軟件
- 一組產品序號與啓動金鑰 (印於黏貼在 CD 封套頂端之貼紙上)
- 兩台顯示器
- 兩組揚聲器 (選購)

建議之系統需求

- 中央處理器>1GHz
- 最小 256MB 之系統記憶體以供兩工作站同時模擬運行
- 兩組標準之 PS/2 介面滑鼠鍵盤與兩台顯示器
- 硬碟機與光碟機

MagicTwin 之安裝

- 建議您完全重新安裝您的 Windows XP 作業系統與其他相關之驅動程式
- 關閉您的電腦並將機箱打開
- 移除 AGP 匯流排之機箱隔板並且插入一片另行於經銷商處購入之雙視訊輸出連接器之顯示卡於 AGP 匯流排上。若您購買之主機板已經內建雙視訊輸出連接器，請跳過此一步驟。



雙視訊輸出連接器之顯示卡


- 將隨產品附贈之 Y 型纜線分別插入位於主機板後方之綠色連接埠 (亦即 PS/2 介面滑鼠連接埠) 與紫色連接埠 (亦即 PS/2 介面鍵盤連接埠)
- 連接第一組與第二組滑鼠於插入綠色 PS/2 介面連接埠 Y 型纜線及連接第一組與第二組鍵盤於插入綠色 PS/2 介面連接埠 Y 型纜線。第二台顯示器**務必安裝妥當**，否則視窗作業系統將無法偵測與驅動第二台顯示器。確定第二組滑鼠與鍵盤運作正常，他們將會影響主機之主控台。
- 啓動您的電腦，視窗作業系統將會自動偵測到新安裝之顯示裝置為標準之 VGA-card。請於安裝 **MAGIC INSTALL** 光碟 **MagicTwin** 軟體前先行安裝完所有之驅動程式。插入光碟片，等待其自動執行除了 **MagicTwin** 軟體外，依序自 **MAGIC INSTALL** 光碟中安裝所有之驅動程式。若光碟片沒有自動執行，請執行 開始-> 執行 -> 光碟機-> **SETUP.EXE**。
- 安裝完所有的驅動程式之後，最後一如下步驟開始安裝 **MagicTwin** 軟體：



當 MAGIC INSTALL MENU 出現時，請執行“MagicTwin”，安裝程序將會開始.....



歡迎頁，請點選“Next”〈下一步〉



選項：改變安裝目的資料夾或點選“Next”〈下一步〉



密碼與網路主控台，點選“Next”〈下一步〉



輸入產品序號與地址，點選“Next”〈下一步〉



安裝執行中，點選“Next”〈下一步〉



之後，請重新啓動您的電腦

- 視窗作業系統正在重新啓動並安裝新的驅動程式，啓動完成後之 MagicTwin 軟體將自動將工作站 2 指定給第二台顯示器與第二組之 PS/2 介面滑鼠鍵盤。
- 請登入視窗作業系統並於主控台中增加一個或多個使用者。

具備雙視訊輸出連接器之顯示卡

MagicTwin 系統支援 NVIDIA MX 440-8X, MX-4000, FX 5200 與 FX5600 雙視訊輸出連接器之顯示卡。連接之一台顯示器為主機使用，而另一台顯示器為 MagicTwin 工作站使用。請與您的經銷商聯繫並購買下列為 MagicTwin 系統支援之雙視訊輸出連接器 AGP 顯示卡：

1. 捷波 NV18-A2-64B
2. 捷波 NV34-AD-128B
3. 捷波 N31X-AD-128B
4. 華碩 V9520
5. 麗台 A340
6. 麗台 A180
7. 微星 FX5600-TD128
8. 微星 FX5200-TD128

产品介绍

MagicTwin 为建构于具备双视讯输出连接器之 AGP 显示卡，双 PS/2 接口鼠标键盘 Y 型缆线，与一套软件（驱动程序与工具程序）之特殊设计主机板的双使用者解决方案。它允许您增加额外之工作站来仿真运行 Windows XP 家用或专业版 (Service Pack 1)。

系统需求

捷波 MagicTwin 主机板
2 x PS/2 Y 型缆线
安装光盘片（驱动程序与工具程序）
产品序号与激活金钥
需另行于经销商处购入
>=1.2 GHz 中央处理器
最小 256MB 之系统内存
NVIDIA 双视讯输出连接器之显示卡
Windows XP 家用或专业版 (Service Pack 1)
2 x PS/2 接口鼠标
2 x PS/2 接口键盘
2 x 显示器

设定双使用者系统的必要组件


- 一张具备内建连接认证芯片的特殊设计主机板
- 一张具备双视讯输出连接器之显示卡（需另行于经销商处购入）
- 两条 PS/2 接口鼠标键盘 Y 型缆线
- MAGIC 安装光盘片（包括您所需要之全部驱动程序与部分工具程序用以驱动主机板之双使用者功能）。此外此光盘包括一套用以侦测、安装与指定相关第二显示器及第二组 PS/2 接口鼠标键盘之自动侦测软件
- 一组产品序号与激活金钥（印于黏贴在 CD 封套顶端之贴上）
- 两台显示器
- 两组扬声器（选购）

建议之系统需求

- 中央处理器 > 1GHz
- 最小 256MB 之系统内存以供两工作站同时仿真运行
- 两组标准之 PS/2 接口鼠标键盘与两台显示器
- 硬盘机与光驱

MagicTwin 之安装

- 建议您完全重新安装您的 Windows XP 操作系统与其它相关之驱动程序
- 关闭您的计算机并将机箱打开
- 移除 AGP 总线之机箱隔板并且插入一片另行于经销商处购入之双视讯输出连接器之显示卡于 AGP 总线上。若您购买之主机板已经内建双视讯输出连接器，请跳过此一步骤。



双视讯输出连接器之显示卡

- 将随产品附赠之 Y 型缆线分别插入位于主机板后方之绿色连接埠（亦即 PS/2 接口鼠标连接端口）与紫色连接埠（亦即 PS/2 接口键盘连接端口）
- 连接第一组与第二组鼠标于插入绿色 PS/2 接口连接端口 Y 型缆线及连接第一组与第二组键盘于插入绿色 PS/2 接口连接端口 Y 型缆线。第二台显示器**务必安装妥当**，否则窗口操作系统将无法侦测与驱动第二台显示器。确定第二组鼠标与键盘运作正常，他们将会影响主机之主控台。
- 激活您的计算机，窗口操作系统将会自动侦测到新安装之显示装置为标准之 VGA-card。请于安装 MAGIC INSTALL 光盘 MagicTwin 软件前先行安装完所有之驱动程序。插入光盘片，等待其自动执行除了 MagicTwin 软件外，依序自 MAGIC INSTALL 光盘中安装所有之驱动程序。若光盘片没有自动执行，请执行开始-> 执行 -> 光驱-> SETUP.EXE。
- 安装完所有的驱动程序之后，最后一如下步骤开始安装 MagicTwin 软件：




当 MAGIC INSTALL MENU 出现时，请执行“MagicTwin”，安装程序将会开始……。



欢迎页，请点选“Next”〈下一步〉



选项：改变安装目的资料夹或点选“Next”〈下一步〉



密码与网络主控台，点选“Next”〈下一步〉



输入产品序号与地址，点选“Next”〈下一步〉



安装执行中，点选“Next”〈下一步〉



之后，请重新激活您的计算机

- 窗口操作系统正在重新激活并安装新的驱动程序，激活完成后之 MagicTwin 软件将自动将工作站 2 指定给第二台显示器与第二组之 PS/2 接口鼠标键盘。
- 请登入窗口操作系统并于主控台中增加一个或多个使用者。

具备双视讯输出连接器之显示卡

MagicTwin 系统支持 NVIDIA MX 440-8X, MX-4000, FX 5200 与 FX5600 双视讯输出连接器之显示卡。连接之一台显示器为主机使用，而另一台显示器为 MagicTwin 工作站使用。请与您的经销商联系并购买下列为 MagicTwin 系统支持之双视讯输出连接器 AGP 显示卡：

- | | | |
|--------------------|--------------------|--------------------|
| 1. 捷波 NV18-A2-64B | 2. 捷波 NV34-AD-128B | 3. 捷波 N31X-AD-128B |
| 4. 华硕 V9520 | 5. 丽台 A340 | 6. 丽台 A180 |
| 7. 微星 FX5600-TD128 | 8. 微星 FX5200-TD128 | |

Chapter 1

Introduction

The special designed 2-user motherboard allows two users to share the computing power of a single PC system. With integrated connectivity hardware onboard, the motherboard comes with innovative software, the MagicTwin[®], allowing 2 users to be connected to it and runs up to two stations directly from it simultaneously. The unique and copyright-protected MagicTwin[®] technology makes each of the 2 users feel like having himself his own Windows-XP computer. Each user needs to have himself his own keyboard, mouse, sound device, and monitor. All remaining PC hardware are shared, even the IP.

Both users can operate on their own station concurrently just like the operation of a standard PC. There is no obvious delay because of the Time-slicing/Multiplexing technology built-in. Each user gets an exact and extremely short defined moment to access to the PC system, devices, applications and Windows itself. Resources are only claimed for nanoseconds at a time, usually from electronic memory, or cache. Both users get from Windows and the PC, what they really need when they need it! The MagicTwin solution turns the single PC into a cost-effective multi-user system.

The setup is intuitive and easy. In only a few minutes, users can install and start using their new workstation. No network administrator is needed as everything to network the workstations together is done automatically with the MagicTwin software. You can add immediately additional user station to the single system and turn one PC into two.

System Requirement

Jetway MagicTwin Motherboard:

- 2 x PS/2 Y-cable
- Install CD (Driver and MagicTwin)
- Serial Number and Activation Key

Purchased Separately from Dealer:

- \geq 1.2 GHz Processor
- Min 256MB DRAM
- NVIDIA Dual Head AGP Graphic Card
- Windows XP Home, Prof. w/ SP1
- 2 x PS/2 Keyboards
- 2 x PS/2 Mice
- 2 x Monitors

Introduction of S755TWIN Motherboard

1-1 Feature of motherboard

The S755TWIN motherboard is design for use 64bit AMD Athlon64 (K8) Processor in 754 Pin HyperTransport Processor with the SiS 755/963L Chipset delivers a high performance and professional desktop platform solution. Which utilize the Socket 754 design and the memory size expandable to 2.0GB.

The motherboard use the newest SiS 755 North bridge chipset supports 800MHz System Bus in data transfer rate, and provided 200/166/133MHz SDRAM clock frequency support DDR400/DDR333/DDR266 SDRAM. The motherboard embedded SiS 963L south bridge and offers two parallel ULTRA ATA **133** interface to provide speedier HDD throughout that boosts overall system performance.

The motherboard integrated SiS 180 Serial-ATA IDE controller provided two Serial-ATA port and one Parallel Ultra ATA port (two devices), supports Ultra ATA/Serial ATA, Ultra/Serial ATA RAID 0 or 1, Ultra/Serial ATA Raid 0+1 meet future IDE demand increase the data transfer rate.

For those wanting even greater graphic performance, an AGP slot is included on the board **(For 1.5V AGP card only. No for 3.3V or Universal AGP card)**. This AGP slot will support either a 4X/8X VGA card compliant to AGP specification 2.0/3.0

The motherboard including Fast Ethernet MAC and PHY chip support 10Mb/s, 100Mb/s Base transfer rate.

The motherboard also has an integrated PCI 6-channel Audio chip on board support 6-channel 3D surround positioning Audio which is fully compatible with Sound Blaster Pro® that gives you the best sound quality and compatibility. The motherboard provided SPDIF-In/ SPDIF-Out optical function support SPDIF device.

With USB control as well as capability of expanding to 6 USB2.0 function ports, these motherboards meet future USB demand also these motherboard have built-in hardware monitor function. This will monitor and protect your computer. These motherboards special design in hardware to protect BIOS from virus crash BIOS data.

These motherboards provide special function in BIOS Setup to setting CPU Host clock step by step increasing let users to approach over clocking.

These motherboards provided high performance & meet future specification demand. It is really wise choice for your computer.

1-2 Specification

| Spec | Description |
|--|--|
| Design | * ATX form factor 4 layers PCB size: 30.5x21.5cm |
| Chipset | * SiS 755 K8HT AGP/MuTIOL Bridge (North Bridge) Chipset * SiS 963L MuTIOL 1G Media I/O (South Bridge) chipset |
| CPU Socket (mPGA478B Socket) | * Support 64bit AMD Athlon64 754-Pin package utilizes Flip-Chip Pin Grid Array package processor * Support CPU Frequency 800MHz * Support up to 3200+, 3400+ processor * Reserves support for future AMD Athlon64 754-pin processors |
| Memory Socket | * 184-pin DDR SDRAM module socket x2 * Support Dual channel DDR266/DDR333/DDR400 DDR SDRAM * Expandable to 2.0GB |
| Expansion Slot & Headers | * AGP slot x1 for AGP 0.8V/1.5V standard only, support AGP 2.0/3.0 & 4X/8X mode * 32-bit PCI slot x 5 * CNR slot x1 |
| Integrate IDE | * Two IDE controllers support PCI Bus Mastering, ATA PIO/DMA and the ULTRA DMA 66/100/133 functions that deliver the data transfer rate up to 100/133 MB/s |
| Serial-ATA IDE | * SiS 180 Serial-ATA Controller provide two Serial ATA ports support 150Mb/s data transfer rate and one Parallel ATA133 port support 133Mb/s data transfer rate * Support Ultra Mode Function * Support RAID 0 or 1, RAID 0+1 function |
| LAN On Board | * Integrated LAN MAC with LAN PHYceiver * Supports 10/100 Mb/sec data transfer rate |
| Audio | * ALC AC97 [®] 2.2 Codec chip integrated * Support 6-channel 3D surround & Positioning Audio * SPDIF-In/ SPDIF-Out Optical support * Audio driver and utility included |
| BIOS | * Award 2MB Flash ROM |
| Multi I/O | * PS/2 keyboard and PS/2 mouse connectors * Floppy disk drive connector x1 * Parallel port x1, Serial port x2 * USB 2.0 connector x6, headers x2 (connecting cable option) * Audio connector Line-in, Line-out, MIC & Game Port Header |

1-3 Performance List



The following performance data list is the testing result of some popular benchmark testing programs. These data are just referred by users, and there is no responsibility for different testing data values gotten by users (the different Hardware & Software configuration will result in different benchmark testing results.)

Performance Test Report

CPU: AMD K8 –ATHLON 64 3200+
DRAM: 256MB DDR400 SDRAM x1 (Winbond)
VGA Card: ATi 9700 Pro (1024x768x32bit Color)
Hard Disk Driver: IBM IC35L040AVVN07-0 (ATA-100 7200RPM)
BIOS: Award Optimal default
OS: Win XP Professional (Service Pack 1)

| | | |
|-------------------------------|--------|-------------------|
| | | 200/200MHz |
| 3D Mark 2001SE | | 17751 |
| Win Mark 2003 | | 5144 |
| PC Mark 2002 | | |
| CPU/Memory/HDD | | 6555/8739/1259 |
| Business Winstone 2002 | | 41.8 |
| SISOFT Sandra 2003 : | | |
| Dhrystone ALU | MIPS | 7225 |
| Whetstone FPU/iSEE2 | MFLOPS | 3038/4059 |
| RAM Int Buffered iSSE2 | MB/S | 3011 |
| RAM Float Buffered iSSE2 | MB/S | 3013 |
| Integer SSE2 | IT/S | 8661 |
| Floating-Point SSE2 | IT/S | 11331 |
| SUPER-PI | | 45 |
| WCPUID System/CPU Clock | | 199.99/1999.94 |

1-4 Layout Diagram & Jumper Setting



Jumpers

| Jumper | Name | Description | Page |
|---------------|-----------------------------------|--------------------|-------------|
| JP9 | CMOS RAM Clear | 3-pin Block | P.6 |
| JP13 | Keyboard Power On Enable/Disabled | 3-pin Block | P.7 |
| JP11/JP12 | USB Power On Enable/Disabled | 3-pin Block | P.7 |

Connectors

| Connector | Name | Description | Page |
|------------------------|---------------------------------------|------------------------|-------------|
| PWR2 | ATX Power Connector | 20-pin Block | P.11 |
| PWR1 | ATX 12V Power Connector | 4-pin Block | P.11 |
| USB1/USB2 | USB Port Connector | 4-pin Connector | P.12 |
| LAN | LAN Connectors | RJ-45 Connector | P.12 |
| KBMS (PS2 KB/MOUSE) | PS/2 Mouse & PS/2 Keyboard Connector | 6-pin Female | P.12 |
| PRINT | Parallel Port Connector | 25-pin Female | P.12 |
| CN1 | Audio Line In/Out MIC Connector | 3 phone jack Connector | P.12 |
| COM1/COM2 | Serial Port COM1/COM2 Connector | 9-pin Connector | P.12 |
| FDC | Floppy Driver Connector | 34-pin Block | P.13 |
| IDE1/IDE2/IDE3 | Primary/Secondary/Third IDE Connector | 40-pin Block | P.13 |
| SATA1, SATA2 | Serial-ATA Port Connector | 7-pin Block | P.14 |

Headers

| Header | Name | Description | Page |
|---|---|--------------------|-------------|
| AUDIO | Line-Out, MIC Headers | 9-pin Block | P.14 |
| USB3 | USB Port Headers | 4-pin Block | P.15 |
| SPEAK | Speaker connector | 4-pin Block | P.15 |
| FP (Power LED/Reset/ IDE LED/ Power Button) | Front Panel Header (including Power LED/ IDE activity LED/ Reset switch / Power On Button lead) | 9-pin Block | P.15 |
| WOL | Wake On-LAN Headers | 3-pin Block | P.16 |
| SYSFAN, CPUFAN | FAN Speed Headers | 3-pin Block | P.16 |
| IR | IR infrared module Headers | 5-pin Block | P.16 |
| CDIN | CD Audio-In Headers | 4-pin Block | P.17 |
| GAME | Game Port Header | 15-pin Block | P.17 |
| SPDIF | Optical In/Out Header | 10-pin Block | P.17 |

Expansion Sockets

| Socket/Slot | Name | Description | Page |
|--------------------|---------------------|--|-------------|
| ZIF Socket 754 | CPU Socket | 754-pin mPGAB Athlon64 CPU Socket | P.8 |
| DIMM1, DIMM2 | DDR Module Socket | 184-pin DDR SDRAM Module Expansion Socket | P.8 |
| PCI1 ~ PCI5 | PCI Slot | 32-bit PCI Local Bus Expansion slots | P.9 |
| AGP | AGP 4X/8X Mode Slot | AGP Expansion Slot | P.10 |
| | | | |

Chapter 2

Hardware installation

2-1 Hardware installation Steps

Before using your computer, you had better complete the following steps:

1. Check motherboard jumper setting
2. Install CPU and Fan
3. Install System Memory (DIMM)
4. Install Expansion cards
5. Connect IDE and Floppy cables, Front Panel /Back Panel cable
6. Connect ATX Power cable
7. Power-On and Load Standard Default
8. Reboot
9. Install Operating System
10. Install Driver and Utility

2-2 Checking Motherboard's Jumper Setting

(1) CMOS RAM Clear (3-pin) : JP9


A battery must be used to retain the motherboard configuration in CMOS RAM short 2-3 pins of JP9 to store the CMOS data.

To clear the CMOS, follow the procedure below:

1. Turn off the system and unplug the AC power
2. Remove ATX power cable from ATX power connector
3. Locate JP9 and short pins 1-2 for a few seconds
4. Return JP9 to its normal setting by shorting pins 2-3
5. Connect ATX power cable back to ATX power connector


Note: When should clear CMOS

1. *Troubleshooting*
2. *Forget password*
3. *After over clocking system boot fail*



(2) Keyboard/USB Power On function Enabled/Disabled: JP13/JP11, JP12

When setting Enabled you can use keyboard by key in password/USB device to power on system.



2-3 Install CPU

2-3-1 Glossary

Chipset (or core logic) - two or more integrated circuits which control the interfaces between the system processor, RAM, I/O devices, and adapter cards.

Processor slot/socket - the slot or socket used to mount the system processor on the motherboard.

Slot (AGP, PCI, ISA, RAM) - the slots used to mount adapter cards and system RAM.

AGP - Accelerated Graphics Port - a high speed interface for video cards; runs at 1X (66MHz), 2X (133MHz), or 4X (266MHz).

PCI - Peripheral Component Interconnect - a high speed interface for video cards, sound cards, network interface cards, and modems; runs at 33MHz.

ISA - Industry Standard Architecture - a relatively low speed interface primarily used for sound cards and modems; runs at approx. 8MHz.

Serial Port - a low speed interface typically used for mouse and external modems.

Parallel Port - a low speed interface typically used for printers.

PS/2 - a low speed interface used for mouse and keyboards.

USB - Universal Serial Bus - a medium speed interface typically used for mouse, keyboards, scanners, and some digital cameras.

Sound (interface) - the interface between the sound card or integrated sound connectors and speakers, MIC, game controllers, and MIDI sound devices.

LAN (interface) - Local Area Network - the interface to your local area network.

BIOS (Basic Input/Output System) - the program logic used to boot up a computer and establish the relationship between the various components.

Driver - software, which defines the characteristics of a device for use by another device or other software.

Processor - the "central processing unit" (CPU); the principal integrated circuit used for doing the "computing" in "personal computer"

Front Side Bus Frequency - the working frequency of the motherboard, which is generated by the clock generator for CPU, DRAM and PCI BUS.

CPU L2 Cache - the flash memory inside the CPU, normally Athlon CPU has 256K or above, while Duron will have 64K.


2-3-2 About AMD Athlon64 754-pin CPU

This motherboard provides a 754-pin surface mount, Zero Insertion Force (ZIF) socket, referred to as the mPGA754 socket supports AMD Athlon64 processor in the 754 Pin package utilizes Flip-Chip Pin Grid Array package technology.

The CPU that comes with the motherboard should have a cooling FAN attached to prevent overheating. If this is not the case, then purchase a correct cooling FAN before you turn on your system.

WARNING! Be sure that there is sufficient air circulation across the processor's heatsink and CPU cooling FAN is working correctly, otherwise it may cause the processor and motherboard overheat and damage, you may install an auxiliary cooling FAN, if necessary.

To install a CPU, first turn off your system and remove its cover. Locate the ZIF socket and open it by first pulling the level sideways away from the socket then upward to a 90-degree angle. Insert the CPU with the correct orientation as shown below. The notched corner should point toward the end of the level. Because the CPU has a corner pin for two of the four corners, the CPU will only fit in the orientation as shown.



When you put the CPU into the ZIF socket. No force require to insert of the CPU, then press the level to Locate position slightly without any extra force.


2-4 Install Memory

This motherboard provides **two** 184-pin DUAL INLINE MEMORY MODULES (DIMM) sites for memory expansion available from minimum memory size of 64MB to maximum memory size of 2.0GB DDR SDRAM.

Valid Memory Configurations

| Bank | 184-Pin DIMM | PCS | Total Memory |
|-------------------|---|-----|--------------|
| Bank 0, 1 (DIMM1) | DDRDDR266/DDR333/DDR400 DDR SDRAM Module | X1 | 64MB~1.0GB |
| Bank 2, 3 (DIMM2) | DDRDDR266/DDR333/DDR400 DDR SDRAM Module | X1 | 64MB~1.0GB |
| Total | System Memory (Max. 2.0GB) | 2 | 64MB~2.0GB |

Generally, installing DDR SDRAM modules to your motherboard is very easy, you can refer to figure 2-4 to see what a 184-Pin DDR266/DDR333/DDR400 DDR SDRAM module looks like.



NOTE! When you install DIMM module fully into the DIMM socket the eject tab should be locked into the DIMM module very firmly and fit into its indentation on both sides.

WARNING! For the DDR SDRAM CLOCK is set at 200MHz, use only DDR400-compliant DDR Modules. When this motherboard operate at 200Mhz, most system will not even boot if non-compliant modules are used because of the strict timing issues, if your SDR Modules are not DDR266-compliant, set the DDR SDRAM clock to 133MHz to ensure system stability.

2-5 Expansion Cards

WARNING! Turn off your power when adding or removing expansion cards or other system components. Failure to do so may cause severe damage to both your motherboard and expansion cards.

2-5-1 Procedure For Expansion Card Installation

1. Read the documentation for your expansion card and make any necessary hardware or software setting for your expansion card such as jumpers.
2. Remove your computer's cover and the bracket plate on the slot you intend to use.
3. Align the card's connectors and press firmly.
4. Secure the card on the slot with the screen you remove above.
5. Replace the computer system's cover.
6. Set up the BIOS if necessary.
7. Install the necessary software driver for your expansion card.

2-5-2 Assigning IRQs For Expansion Card

Some expansion cards need an IRQ to operate. Generally, an IRQ must exclusively assign to one use. In a standard design, there are 16 IRQs available but most of them are already in use.

Standard Interrupt Assignments

| IRQ | Priority | Standard function |
|------|----------|-----------------------------|
| 0 | N/A | System Timer |
| 1 | N/A | Keyboard Controller |
| 2 | N/A | Programmable Interrupt |
| 3 * | 8 | Communications Port (COM2) |
| 4 * | 9 | Communications Port (COM1) |
| 5 * | 6 | Sound Card (sometimes LPT2) |
| 6 * | 11 | Floppy Disk Controller |
| 7 * | 7 | Printer Port (LPT1) |
| 8 | N/A | System CMOS/Real Time Clock |
| 9 * | 10 | ACPI Mode when enabled |
| 10 * | 3 | IRQ Holder for PCI Steering |
| 11 * | 2 | IRQ Holder for PCI Steering |
| 12 * | 4 | PS/2 Compatible Mouse Port |
| 13 | N/A | Numeric Data Processor |
| 14 * | 5 | Primary IDE Channel |
| 15 * | 1 | Secondary IDE Channel |

* These IRQs are usually available for ISA or PCI devices.

2-5-3 Interrupt Request Table For This Motherboard

Interrupt request are shared as shown the table below:

| | INT A | INT B | INT C | INT D | INT E | INT F | INT G | INT H |
|---------------|-------|-------|-------|-------|-------|-------|-------|-------|
| Slot 1 | | √ | | | | | | |
| Slot 2 | | | √ | | | | | |
| Slot 3 | | | | √ | | | | |
| Slot 4 | | | | | | √ | | |
| Slot 5 | | | | | | | √ | |
| Onboard LAN | | | | | √ | | | |
| Onboard USB 1 | | | | | | | | √ |
| Onboard USB 2 | | | | √ | | | | |
| Onboard USB 3 | | | √ | | | | | |
| Sound | | √ | | | | | | |

IMPORTANT! If using PCI cards on shared slots, make sure that the drivers support “Shared IRQ” or that the cards don’t need IRQ assignments. Conflicts will arise between the two PCI groups that will make the system unstable or cards inoperable.

2-5-4 AGP Slot

This motherboard provides an AGP Slot, only support the 1.5V 4X/0.8V 8X AGP VGA card. Do not use AGP 2X card (3.3V) in this motherboard. It will burn and damage the motherboard due to chipset can not support AGP 2X (3.3V).

IMPORTANT! Before you plug-in AGP card, please make sure the following notice is fully understood and practiced. If your AGP card has “AGP 4X notch (show below) please make sure your AGP card is AGP 4X/8X (1.5V/0.8V) not AGP 2X (3.3V)



Example 1: SiS 305 & ATi Rage 128 Pro AGP card those golden finger is compatible with 2X/4X mode AGP slot, but only can support 2X (3.3V) only. If you install these cards in Intel® 865 based motherboard it will burn and damage the motherboard.


Example 2: We also find Diamond Vipper V770 golden finger is design for 2X/4X mode AGP Slot. It can be adjusted the jumper for AGP 2X (3.3V) or AGP 4X (1.5V). But the factory default setting is 2X (3.3V). If you install this AGP card in motherboard without change the jumper setting to 4X (1.5V), it will burn the motherboard.

2-6 Connectors, Headers

2-6-1 Connectors


(1) Power Connector (20-pin block) : PWR2

ATX Power Supply connector. This is a new defined 20-pins connector that usually comes with ATX case. The ATX Power Supply allows to use soft power on momentary switch that connect from the front panel switch to 2-pins Power On jumper pole on the motherboard. When the power switch on the back of the ATX power supply turned on, the full power will not come into the system board until the front panel switch is momentarily pressed. Press this switch again will turn off the power to the system board.



(2) ATX 12V Power Connector (4-pin block) : PWR1

This is a new defined 4-pins connector that usually comes with ATX Power Supply. The ATX Power Supply which fully support Pentium 4 processor must including this connector for support extra 12V voltage to maintain system power consumption. Without this connector might cause system unstable because the power supply can not provide sufficient current for system.



(3) USB Port connector: USB1, USB2

The connectors are 4-pin connector that connect USB devices to the system board.

(4) LAN Port connector: LAN

This connector is standard RJ45 connector for Network connector.

(5) PS/2 Mouse & PS/2 Keyboard Connector: KBMS (PS2 KB/MOUSE)

The connectors for PS/2 keyboard and PS/2 Mouse.

(6) Parallel Port Connector (25-pin female): PRINT

Parallel Port connector is a 25-pin D-Subminiature Receptacle connector. The On-board Parallel Port can be disabled through the BIOS SETUP. Please refer to Chapter 3 “INTEGRATED PERIPHERALS SETUP” section for more detail information.

(7) Audio Line-In, Lin-Out, MIC Connector : CN1

This Connector are 3 phone Jack for LINE-OUT, LINE-IN, MIC


Line-out : Audio output to speaker

Line-in : Audio input to sound chip

MIC : Microphone Connector


(8) Serial Port COM1: COM1/COM2

COM1/COM2 is the 9-pin D-Subminiature mail connector. The On-board serial port can be disabled through BIOS SETUP. Please refer to Chapter 3 “INTEGRATED PERIPHERALS SETUP” section for more detail information.



(9) Floppy drive Connector (34-pin block): FDC

This connector supports the provided floppy drive ribbon cable. After connecting the single plug end to motherboard, connect the two plugs at other end to the floppy drives.




(10) Primary IDE Connector (40-pin block): IDE1

This connector supports the provided IDE hard disk ribbon cable. After connecting the single plug end to motherboard, connect the two plugs at other end to your hard disk(s). If you install two hard disks, you must configure the second drive to Slave mode by setting its jumpers accordingly. Please refer to the documentation of your hard disk for the jumper settings.

(11) Secondary IDE Connector (40-pin block): IDE2


This connector connects to the next set of Master and Slave hard disks. Follow the same procedure described for the primary IDE connector. You may also configure two hard disks to be both Masters using one ribbon cable on the primary IDE connector and another ribbon cable on the secondary IDE connector.



- Two hard disks can be connected to each connector. The first HDD is referred to as the “Master” and the second HDD is referred to as the “Slave”.
- For performance issues, we strongly suggest you don’t install a CD-ROM or DVD-ROM drive on the same IDE channel as a hard disk. Otherwise, the system performance on this channel may drop.


(12) Third IDE Connector (40-pin block): IDE3

This connector supports the provided IDE hard disk ribbon cable. After connecting the single plug end to motherboard, connect the two plugs at other end to your hard disk(s). Please refer to the documentation of your hard disk for the jumper settings.



(13) Serial-ATA Port connector: SATA1/SATA2


This connector support the provided Serial ATA IDE hard disk cable to connecting the motherboard and serial ATA hard disk.



2-6-2 Headers


(1) Line-Out, MIC Header (9-pin): AUDIO

This header connect to Front Panel Line-out, MIC connector with cable.



(2) USB Port Headers (9-pin) : USB3

The header is used for connecting the additional USB port plug. By attaching an option USB cable, your can be provided with two additional USB plugs affixed to the back panel.



USB Port Headers

(3) IDE Activity LED: IDE LED

This connector connects to the hard disk activity indicator light on the case.

(4) Reset switch lead: RESET

This 2-pin connector connects to the case-mounted reset switch for rebooting your computer without having to turn off your power switch. This is a preferred method of rebooting in order to prolong the life of the system's power supply. See the figure below.

(5) Speaker connector: SPEAK


This 4-pin connector connects to the case-mounted speaker. See the figure below.

(6) Power LED: PWR-LED

The Power LED is light on while the system power is on. Connect the Power LED from the system case to this pin.

(7) Power switch: PWR BTN

This 2-pin connector connects to the case-mounted power switch to power ON/OFF the system.




System Case Connections

(8) Wake On-LAN Headers (3-pin) : WOL



This connector connects to a LAN card with a WAKE ON-LAN output. This connector power up the system when a wake up signal is received through the LAN card.

NOTE: This feature requires that Wake On LAN or Ring In Wake up is enabled.




(9) FAN Speed Headers (3-pin) : SYSFAN, CPUFAN

These connectors support cooling fans of 350mA (4.2 Watts) or less, depending on the fan manufacturer, the wire and plug may be different. The red wire should be positive, while the black should be ground. Connect the fan's plug to the board taking into consideration the polarity of connector.



(10) IR infrared module Headers (5-pin) : IR

This connector supports the optional wireless transmitting and receiving infrared module. You must configure the setting through the BIOS setup to use the IR function.



(11) CD Audio-In Headers (4-pin) : CDIN

CDIN are the connectors for CD-Audio Input signal. Please connect it to CD-ROM CD-Audio output connector.

2-7 Starting Up Your Computer

1. After all connection are made, close your computer case cover.
2. Be sure all the switch are off, and check that the power supply input voltage is set to proper position, usually in-put voltage is 220V~240V or 110V~120V depending on your country's voltage used.
3. Connect the power supply cord into the power supply located on the back of your system case according to your system user's manual.
4. Turn on your peripheral as following order:
 - a. Your monitor.
 - b. Other external peripheral (Printer, Scanner, External Modem etc...)
 - c. Your system power. For ATX power supplies, you need to turn on the power supply and press the ATX power switch on the front side of the case.
5. The power LED on the front panel of the system case will light. The LED on the monitor may light up or switch between orange and green after the system is on. If it complies with green standards or if it is has a power standby feature. The system will then run power-on test. While the test are running, the BIOS will alarm beeps or additional message will appear on the screen.

If you do not see any thing within 30 seconds from the time you turn on the power. The system may have failed on power-on test. Recheck your jumper settings and connections or call your retailer for assistance.

| Beep | Meaning |
|---|---|
| One short beep when displaying logo | No error during POST |
| Long beeps in an endless loop | No DRAM install or detected |
| One long beep followed by three short beeps | Video card not found or video card memory bad |
| High frequency beeps when system is working | CPU overheated System running at a lower frequency |

6. During power-on, press <Delete> key to enter BIOS setup. Follow the instructions in BIOS SETUP.
7. **Power off your computer:** You must first exit or shut down your operating system before switch off the power switch. For ATX power supply, you can press ATX power switching after exiting or shutting down your operating system. If you use Windows 9X, click "**Start**" button, click "**Shut down**" and then click "**Shut down the computer?**" The power supply should turn off after windows shut down.

Chapter 3

Introducing BIOS

The BIOS is a program located on a Flash Memory on the motherboard. This program is a bridge between motherboard and operating system. When you start the computer, the BIOS program gain control. The BIOS first operates an auto-diagnostic test called POST (power on self test) for all the necessary hardware, it detects the entire hardware device and configures the parameters of the hardware synchronization. Only when these tasks are completed done it gives up control of the computer to operating system (OS). Since the BIOS is the only channel for hardware and software to communicate, it is the key factor for system stability, and in ensuring that your system performance as its best.

In the BIOS Setup main menu of Figure 3-1, you can see several options. We will explain these options step by step in the following pages of this chapter, but let us first see a short description of the function keys you may use here:

- Press <Esc> to quit the BIOS Setup.
- Press ↑↓←→ (up, down, left, right) to choose, in the main menu, the option you want to confirm or to modify.
- Press <F10> when you have completed the setup of BIOS parameters to save these parameters and to exit the BIOS Setup menu.
- Press Page Up/Page Down or +/- keys when you want to modify the BIOS parameters for the active option.

3-1 Entering Setup

Power on the computer and by pressing immediately allows you to enter Setup.

If the message disappears before your respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the “RESET” button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt> and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to

Press <F1> to continue, <Ctrl-Alt-Esc> or to enter Setup

3-2 Getting Help

Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Status Page Setup Menu/Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window, press <Esc>.

3-3 The Main Menu

Once you enter Award® BIOS CMOS Setup Utility, the Main Menu (Figure 3-1) will appear on the screen. The Main Menu allows you to select from fourteen setup functions and two exit choices. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.




Figure 3-1

Standard CMOS Features

Use this Menu for basic system configurations.

Advanced BIOS Features

Use this menu to set the Advanced Features available on your system.

Advanced Chipset Features

Use this menu to change the values in the chipset registers and optimize your system's performance.

Integrated Peripherals

Use this menu to specify your settings for integrated peripherals.

Power Management Setup

Use this menu to specify your settings for power management.

PnP/PCI configurations

This entry appears if your system supports PnP/PCI.

PC Health Status

This entry shows your PC health status.

Miscellaneous Control

Use this menu to specify your settings for Miscellaneous control.

Load Optimized Defaults

Use this menu to load the BIOS default values that are settings for optimal performances system operations.

Load Standard Defaults

Use this menu to load the BIOS default values that are factory settings for the stable performance system operation.

Set Supervisor/User Password

Use this menu to set User and Supervisor Passwords.

Save & Exit Setup

Save CMOS value changes to CMOS and exit setup.

Exit Without Saving

Abandon all CMOS value changes and exit setup.

3-4 Standard CMOS Features

The items in Standard CMOS Setup Menu are divided into several categories. Each category includes no, one or more than one setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

Standard CMOS Features

| | | |
|---|-------------------|--|
| Date (mm:dd:yy) | Mon, Oct, 20 2003 | Item Help |
| Time (hh:mm:ss) | 11 : 02 : 35 | |
| > IDE Primary Master | Press Enter None | Menu Level > |
| > IDE Primary Slave | Press Enter None | |
| > IDE Secondary Master | Press Enter None | Change the day, month, year and century |
| > IDE Secondary Slave | Press Enter None | |
| Drive A | 1.44M, 3.5 in. | |
| Drive B | None | |
| Video | EGA/VGA | |
| Halt On | All,But Keyboard | |
| Base Memory | 640K | |
| Extended Memory | 56320K | |
| Total Memory | 57344K | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | |

Date

The date format is <day><month><date><year>.

Day Day of the week, from Sun to Sat, determined by BIOS. Read-only.

Month The month from Jan. through Dec.

Date The date from 1 to 31 can be keyed by numeric function keys.

Year The year depends on the year of the BIOS.

Time

The time format is <hour><minute><second>.

Primary Master/Primary Slave

Secondary Master/Secondary Slave

Press PgUp/<+> or PgDn/<-> to select Manual, None, Auto type. Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category. If your hard disk drive type is not matched or listed, you can use Manual to define your own drive type manually.

If you select Manual, related information is asked to be entered to the following items. Enter the information directly from the keyboard. This information should be provided in the documentation from your hard disk vendor or the system manufacturer.

If the controller of HDD interface is SCSI, the selection shall be "None".

If the controller of HDD interface is CD-ROM, the selection shall be "None"

Access Mode The settings are Auto Normal, Large, and LBA.

Cylinder number of cylinders

Head number of heads

Precomp write precomp

Landing Zone landing zone

Sector number of sectors

3-5 Advanced BIOS Features

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

Advanced BIOS Features

| | | | |
|---|------------|--------------|--|
| Anti-Virus Protection | Disabled | Item Help | |
| Cooling Sprite | Disabled | | |
| CPU L1 & L2 Cache | Enabled | Menu Level > | |
| Quick Power On Self Test | Enabled | | |
| SiS-SATA, SCSI Boot Order | SATA, SCSI | | |
| First Boot Device | Floppy | | |
| Second Boot Device | HDD 0 | | |
| Third Boot Device | CDROM | | |
| Boot other Device | Enabled | | |
| Swap Floppy Drive | Disabled | | |
| Boot Up Floppy Seek | Enabled | | |
| Boot Up NumLock Status | On | | |
| Gate A20 Option | Fast | | |
| Typematic Rate Setting | Disabled | | |
| Typematic Rate (Chars/Sec) | 6 | | |
| Typematic Delay (Msec) | 250 | | |
| Security Option | Setup | | |
| APIC Mode | Disabled | | |
| MPS Version Control For OS | 1.4 | | |
| OS Select For DRAM > 64MB | Non-OS2 | | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | | |

Anti-Virus Protection

Allows you to choose the VIRUS Warning feature for IDE Hard Disk boot sector protection. If this function is enabled and someone attempts to write data into this area, BIOS will show a warning message on screen and alarm beep.

- Disabled** (default) No warning message to appear when anything attempts to access the boot sector or hard disk partition table.
- Enabled** Activates automatically when the system boots up causing a warning message to appear when anything attempts to access the boot sector of hard disk partition table.

CPU L1 Cache

The default value is Enabled.

- Enabled** (default) Enable cache
- Disabled** Disable cache

Note: The internal cache is built in the processor.

CPU L2 Cache

Choose Enabled or Disabled. This option enables the Level 2 cache memory.

Quick Power On Self Test

This category speeds up Power On Self Test (POST) after you power on the computer. If this is set to Enabled, BIOS will shorten or skip some check items during POST.

- Enabled** (default) Enable quick POST
- Disabled** Normal POST

First/Second/Third/Fourth Boot Device

The BIOS attempts to load the operating system from the devices in the sequence selected in these items. The settings are Floppy, LS/ZIP, HDD-0/HDD-1/HDD-3, SCSI, CDROM, LAD and Disabled.

Swap Floppy Drive

Switches the floppy disk drives between being designated as A and B. Default is Disabled.

Boot Up Floppy Seek

During POST, BIOS will determine if the floppy disk drive installed is 40 or 80 tracks. 360K type is 40 tracks while 760K, 1.2M and 1.44M are all 80 tracks.

Boot Up NumLock Status

The default value is On.

- On** (default) Keypad is numeric keys.
- Off** Keypad is arrow keys.

Gate A20 Option

- Normal** The A20 signal is controlled by keyboard controller or chipset hardware.
- Fast** (default) The A20 signal is controlled by port 92 or chipset specific method.

Typematic Rate Setting

Keystrokes repeat at a rate determined by the keyboard controller. When enabled, the typematic rate and typematic delay can be selected. The settings are: Enabled/Disabled.

Typematic Rate (Chars/Sec)

Sets the number of times a second to repeat a keystroke when you hold the key down. The settings are: 6, 8, 10, 12, 15, 20, 24, and 30.

Typematic Delay (Msec)

Sets the delay time after the key is held down before it begins to repeat the keystroke. The settings are 250, 500, 750, and 1000.

Security Option

This category allows you to limit access to the system and Setup, or just to Setup.

- System** The system will not boot and access to Setup will be denied if the correct password is not entered at the prompt.
- Setup (default)** The system will boot, but access to Setup will be denied if the correct password is not entered at the prompt.

OS Select For DRAM > 64MB

Allows OS2® to be used with >64MB or DRAM. Settings are Non-OS/2 (default) and OS2. Set to OS/2 if using more than 64MB and running OS/2.

3-6 Advanced Chipset Features

The Advanced Chipset Features Setup option is used to change the values of the chipset registers. These registers control most of the system options in the computer.

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software
Advanced Chipset Features

| | | |
|---|-------------|--------------|
| > DRAM Timing Settings | Press Enter | Item Help |
| AGP Aperture Size | 64MB | |
| AGP Fast Write Support | Disabled | |
| AGP Data Transfer Rate | Auto | Menu Level > |
| AGP Auto Calibration | Enabled | |
| System BIOS Cacheable | Enabled | |
| Memory Hole At 15M-16M | Disabled | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | |

DRAM Timing Settings

Please refer to section 3-6-1

System BIOS Cacheable

Selecting Enabled allows caching of the system BIOS ROM at F0000h-FFFFFh, resulting in better system performance. However, if any program writes to this memory area, a system error may result. The settings are: Enabled and Disabled.

Memory Hole At 15M-16M

You can reserve this area of system memory for ISA adapter ROM. When this area is reserved, it cannot be cached. The user information of peripherals that need to use this area of system memory usually discusses their memory requirements. The settings are: Enabled and Disabled.

AGP Data Transfer Rate

In this item you can select AGP transfer mode Auto/4X/8X the Default setting is Auto.

3-6-1 DRAM Timing Settings

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

DRAM Timing Settings

| | | |
|-------------------------------|-------------|---------------|
| HyperTransport Link Width Out | Auto | Item Help |
| HyperTransport Link Frequency | 800MHz | |
| Auto Configuration | By SPD | |
| X RAS Active Time (tRAS) | 6 Bus Clock | Menu Level >> |
| X RAS Precharge Time (tRP) | 3 Bus Clock | |
| X RAS to CAS Delay (tRCD) | 3 Bus Clock | |
| X CAS Latency | CL =2.5 | |

↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Optimized Defaults F7:Standard Defaults

CAS Latency

When synchronous DRAM is installed, the number of clock cycles of CAS latency depends on the DRAM timing. The settings are: 2T and 2.5T.

Note: Change these settings only if you are familiar with the chipset.

RAS to CAS Delay

This field let's you insert a timing delay between the CAS and RAS strobe signals, used when DRAM is written to, read from, or refreshed. *Fast* gives faster performance; and *Slow* gives more stable performance. This field applies only when synchronous DRAM is installed in the system. The settings are: 2T, 3T and 4T. (1T=1 Bus Clock)

RAS Precharge Time

If an insufficient number of cycles is allowed for the RAS to accumulate its charge before DRAM refresh, the refresh may be incomplete and the DRAM may fail to retain date. *Fast* gives faster performance; and *Slow* gives more stable performance. This field applies only when synchronous DRAM is installed in the system. The settings are: 2T, 3T and 4T.

3-7 Integrated Peripherals

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

Integrated Peripherals

| | |
|--|------------------------|
| > OnChip IDE Function Press Enter > OnChip Device Function Press Enter > OnChip Super IO Function Press Enter Init Display First PCI Slot | Item Help |
| | Menu Level > |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | |

OnChip IDE Function

Please refer to section 3-7-1

OnChip Device Function

Please refer to section 3-7-2

OnChip Super IO Function

Please refer to section 3-7-3

Init Display First

This item allows you to decide to activate whether PCI Slot or AGP VGA first. The settings are: PCI Slot, AGP Slot.

3-7-1 OnChip IDE Function

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

OnChip IDE Function

| | |
|---|----------------------------|
| Internal PCI/IDE Both IDE Primary Master PIO Auto IDE Primary Slave PIO Auto IDE Secondary Master PIO Auto IDE Secondary Slave PIO Auto Primary Master UltraDMA Auto Primary Slave UltraDMA Auto Secondary Master UltraDMA Auto Secondary Slave UltraDMA Auto IDE DMA Transfer Access Enabled IDE Burst Mode Enabled IDE Prefetch Mode Enabled IDE HDD Block Mode Enabled Delay For HDD (Secs) 0 | Item Help |
| | Menu Level >> |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | |

Internal PCI/IDE

The integrated peripheral controller contains an IDE interface with support for two IDE channels. Select *Both* to activate each channel separately. The settings are: Both, Primary, Secondary and Disabled.

IDE Primary/Secondary Master/Slave PIO

The four IDE PIO (Programmed Input/Output) fields let you set a PIO mode (0-4) for each of the four IDE devices that the onboard IDE interface supports. Modes 0 through 4 provide successively increased performance. In Auto mode, the system automatically determines the best mode for each device. The settings are: Auto, Mode 0, Mode 1, Mode 2, Mode 3, Mode 4.

Primary/Secondary Master/Slave UltraDMA

Ultra DMA/33 implementation is possible only if your IDE hard drive supports it and the operating environment includes a DMA driver (Windows 95 OSR2 or a third-party IDE bus master driver). If your hard drive and your system software both support Ultra DMA/33 and Ultra DMA/66, select Auto to enable BIOS support. The settings are: Auto, Disabled.

IDE HDD Block Mode

Block mode is also called block transfer, multiple commands, or multiple sector read/write. If your IDE hard drive supports block mode (most new drives do), select Enabled for automatic detection of the optimal number of block read/writes per sector the drive can support. The settings are: Enabled, Disabled.

3-7-2 OnChip Device Function

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

OnChip Device Function

| | | |
|---|-------------|---------------|
| AC97 Audio Device | Enabled | Item Help |
| Game Port Address | 201 | |
| Midi Port Address | | Menu Level >> |
| Midi Port IRQ | 10 | |
| AC97 Modem Device | Enabled | |
| USB Device Function | Enabled | |
| USB Keyboard Legacy Support | Disabled | |
| Onboard LAN Boot ROM | Disabled | |
| ETHERNET Address ID Input | Press Enter | |
| | | |
| SiS180 SATA Controller | Enabled | |
| | | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | |

AC97 Audio Device

This will determine which on Board AC97 Codec Function will use. The settings are: Enabled, Disabled.

Game Port Address/Midi Port Address

This will determine which Address the Game Port/Midi Port will use.

USB Device Function

Select *Enabled* if your system contains a Universal Serial Bus (USB) controller and you have a USB peripherals. The settings are: Enabled, Disabled.

USB Keyboard Legacy Support

Select *Enabled* if your system contains a Universal Serial Bus (USB) controller and you have a USB keyboard. The settings are: Enabled, Disabled.

SiS180 SATA Controller

The settings are: Enabled and Disabled

3-7-3 Onboard Super IO Function

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

Onboard Super IO Function

| | | |
|---|----------|---------------|
| Onboard FDC Controller | Enabled | Item Help |
| Onboard Serial Port 1 | 3F8/IRQ4 | |
| Onboard Serial Port 2 | 2F8/IRQ3 | Menu Level >> |
| UART Mode Select | Normal | |
| UR2 Duplex Mode | Half | |
| Onboard Parallel Port | 378/IRQ7 | |
| Parallel Mode | SPP | |
| ECP Mode Use DMA | 3 | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | |

Onboard FDC Controller

Select Enabled if your system has a floppy disk controller (FDD) installed on the system board and you wish to use it. If you install add-on FDC or the system has no floppy drive, select Disabled in this field. The settings are: Enabled and Disabled.

Onboard Serial Port 1/Port 2

Select an address and corresponding interrupt for the first and the second serial ports. The settings are: 3F8/IRQ4, 2E8/IRQ3, 3E8/IRQ4, 2F8/IRQ3, Disabled, Auto.

UART Mode Select

This item allows you to determine which InfraRed(IR) function of the onboard I/O chip, this functions uses.

Onboard Parallel Port

There is a built-in parallel port on the on-board Super I/O chipset that Provides Standard, ECP, and EPP features. It has the following option:

Disabled

(3BCH/IRQ7)/ Line Printer port 0

(278H/IRQ5)/ Line Printer port 2

(378H/IRQ7) Line Printer port 1

Parallel Port Mode

SPP : Standard Parallel Port

EPP : Enhanced Parallel Port

ECP : Extended Capability Port

SPP/EPP/ECP/ECP+EPP

To operate the onboard parallel port as Standard Parallel Port only, choose "SPP." To operate the onboard parallel port in the EPP modes simultaneously, choose "EPP." By choosing "ECP", the onboard parallel port will operate in ECP mode only. Choosing "ECP+EPP" will allow the onboard parallel port to support both the ECP and EPP modes simultaneously. The ECP mode has to use the DMA channel, so choose the onboard parallel port with the ECP feature. After selecting it, the following message will appear: "ECP Mode Use DMA" at this time, the user can choose between DMA channels 3 to 1. The onboard parallel port is EPP Spec. compliant, so after the user chooses the onboard parallel port with the EPP function, the following message will be displayed on the screen: "EPP Mode Select." At this time either EPP 1.7 spec. or EPP 1.9 spec. can be chosen.

3-8 Power Management Setup

The Power Management Setup allows you to configure your system to most effectively save energy saving while operating in a manner consistent with your own style of computer use.

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

Power Management Setup

| | | |
|---|----------------|--------------|
| ACPI Function | Enabled | Item Help |
| ACPI Suspend Type | S1 (POS) | |
| Video off Option | Always Off | |
| Video off Method | V/H SYNC+Blank | Menu Level > |
| Switch Function | Break/Wake | |
| MODEM Use IRQ | NA | |
| Power Button Function | Instant-off | |
| Power State Resume Control | Always Off | |
| > PW Wake Up Events | Press Enter | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | |

ACPI Function

This item allows you to Enabled/Disabled the Advanced Configuration and Power Management (ACPI). The settings are Enabled and Disabled.

ACPI Suspend Type

This item allows you to select ACPI Suspend Type.

The setting are: S1(POS), S3(STR)

Video Off Option

This determines the manner in which the monitor is blanked. The choice are Always Off → Video will off , and Always On→ Video always On.

Video Off Method

This determines the manner in which the monitor is blanked.

- DPMS (default)** Initial display power management signaling.
- Blank Screen** This option only writes blanks to the video buffer.
- V/H SYNC+Blank** This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.

Modem Use IRQ

This determines the IRQ in which the MODEM can use.

The settings are: 3, 4, 5, 7, 9, 10, 11, NA.

Power Button Function

Pressing the power button for more than 4 seconds forces the system to enter the Soft-Off state. The settings are: Delay 4 Sec, Instant-Off.

PM Wake Up Events

Please refer to section 3-8-1

3-8-1 PM Wake Up Events

PM Wake Up Events

| | | | |
|---|----------|---------------|--|
| IRQ [3-7,9-15], MNI | Enabled | Item Help | |
| IRQ 8 Break Suspend | Disabled | | |
| RING Power Up Control | Disabled | Menu Level >> | |
| MACPME Power Up Control | Disabled | | |
| PCIPME Power Up Control | Disabled | | |
| Power Up by Alarm | Disaled | | |
| X Date (of Month) | 0 | | |
| X Time (hh:mm:ss) | 0 : 0 :0 | | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | | |

RING/MACPME/PCIPME Power Up Control

During Disabled, the system will ignore any incoming call from the PCI card/modem/LAN. During Enabled, the system will boot up if there's an incoming call from the PCI card /modem/LAN.

Power Up by Alarm

This function is for setting date and time for your computer to boot up. During Disabled, you cannot use this function. During Enabled, choose the Date and Time Alarm:

Date(of month) Alarm

You can choose which month the system will boot up. Set to 0, to boot every day.

Time(hh:mm:ss) Alarm

You can choose what hour, minute and second the system will boot up.

Note: If you have change the setting, you must let the system boot up until it goes to the operating system, before this function will work

3-9 PnP/PCI Configuration Setup

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed the CPU itself uses when communicating with its own special components. This section covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.

PnP/PCI Configurations

| | | |
|---|-------------|--------------|
| Reset Configuration Data | Disabled | Item Help |
| Resources Controlled By | Manual | |
| x IRQ Resources | Press Enter | Menu Level > |
| PCI/VGA Palette Snoop | Disabled | |
| Assign IRQ For VGA | Enabled | |
| Assign IRQ For USB | Enabled | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | |

Reset Configuration Data

Normally, you leave this field Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the operating system can not boot. The settings are: Enabled and Disabled.

Resource Controlled By

The Award Plug and Play BIOS has the capacity to automatically configure all of the boot and Plug and Play compatible devices. However, this capability means absolutely nothing unless you are using a Plug and Play operating system such as Windows®95/98. If you set this field to “manual” choose specific resources by going into each of the sub menu that follows this field (a sub menu is preceded by a “>”).

The settings are: Auto(ESCD), Manual.

IRQ Resources

When resources are controlled manually, assign each system interrupt a type, depending on the type of device using the interrupt.

Please refer to section 3-9-1

PCI/VGA Palette Snoop

Leave this field at *Disabled*. The settings are Enabled, Disabled.

3-9-1 IRQ Resources

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

IRQ Resources

| | | | | |
|---|-------------|------------|---------------|--|
| IRQ-3 | assigned to | PCI Device | Item Help | |
| IRQ-4 | assigned to | PCI Device | | |
| IRQ-5 | assigned to | PCI Device | Menu Level >> | |
| IRQ-7 | assigned to | PCI Device | | |
| IRQ-9 | assigned to | PCI Device | | |
| IRQ-10 | assigned to | PCI Device | | |
| IRQ-11 | assigned to | PCI Device | | |
| IRQ-12 | assigned to | PCI Device | | |
| IRQ-14 | assigned to | PCI Device | | |
| IRQ-15 | assigned to | PCI Device | | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | | | |

3-10 PC Health Status

This section shows the Status of you CPU, Fan, Warning for overall system status. This is only available if there is Hardware Monitor onboard.

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

PC Health Status

| | | | |
|---|----------|--------------|--|
| Shutdown Temperature | Disabled | Item Help | |
| Show PC Health in Post | Enabled | | |
| Detect CPUFAN in Post | Enabled | Menu Level > | |
| Current System Temperature | 25°C | | |
| Current CPU Temperature | 38°C | | |
| Current CPUFAN Speed | 5000 rpm | | |
| Current SYSFAN Speed | 5000 rpm | | |
| Vcore | 1.71V | | |
| Vcc1.5 | 1.51V | | |
| Vcc3.3 | 3.31V | | |
| + 5V | 4.98V | | |
| +12V | 12.22V | | |
| -12V | -12.36V | | |
| - 5V | -4.99V | | |
| VBAT(V) | 3.21V | | |
| 5VSB(V) | 5.02V | | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | | |

Show PC Health in Post

During Enabled, it displays information list below. The choice is either Enabled or Disabled.

Shutdown Temperature

This item can let users setting the Shutdown temperature, when CPU temperature over this setting the system will auto shutdown to protect CPU.

Current CPU Temperature/Current System Temp/Current FAN1, FAN2 Speed/Vcore/Vdd/3.3V/+5V/+12V/-12V/VBAT(V)/5VSB(V)

This will show the CPU/FAN/System voltage chart and FAN Speed.

3-11 Miscellaneous Control

This section is for setting CPU Frequency/Voltage Control.

CMOS Setup Utility - Copyright(C) 1984-2003 Award Software

Miscellaneous Control

| | | |
|---|----------------|--------------|
| Auto Detect PCI Clk | Enabled | Item Help |
| Spread Spectrum | Disabled | |
| Clock Control | By Software | Menu Level > |
| ** Current Host Clock 200MHz ** | | |
| HOS Clock at Next Boot is | 200MHz | |
| ** Current DRAM Clock is 133MHz ** | | |
| DRAM Clock at Next Boot is | By SPD | |
| CPU Vcore Select | Default | |
| AGP VddQ Select | 1.50V(Default) | |
| VDIMM Select | 2.50V(Default) | |
| ↑↓→← Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults | | |

Auto Detect PCI Clk

This item allows you to enable/disable auto detect PCI Clock.
The settings are: Enabled, Disabled.

Spread Spectrum

This item allows you to set the CPU Host/PCI clock and Spread Spectrum.
The settings are: Enabled, Disabled.

Hos Clock at Next Boot

This item allows you to select CPU frequency step by step increasing.
The choice are: 200MHz~233MHz

DRAM Clock at Next Boot is

This item allows you select the DRAM Clock for DDR266/DDR333/DDR400. The setting are:
100MHz, 133MHz, 166MHz, 200MHz, By SPD

CPU Vcore Select

This item allows you select CPU Vcore Voltage by increase 0.025V step by step from
0.7000V to 1.8V the Default setting is Default (CPU manufacturer Default setting).

AGP VddQ Select

This item allows you to select 1.5V of the AGP VGA card. The choice are: Default, 1.5V,
1.6V, 1.7V, 1.8V.

VDIMM Select

This item allows you to select DRAM Voltage. The choice are: 2.50V/2.6V/2.7V/2.8V.

3-12 Load Standard/Optimized Defaults

Load Standard Defaults

When you press <Enter> on this item, you get confirmation dialog box with a message similar
to:

Load Standard Defaults (Y/N)? N

Pressing <Y> loads the BIOS default values for the most stable, minimal-performance system
operations.

Load Optimized Defaults

When you press <Enter> on this item, you get a confirmation dialog box with a message
similar to:

Load Optimized Defaults (Y/N)? N

Pressing <Y> loads the default values that are factory settings for optimal performance system
operations.

3-13 Set Supervisor/User Password

You can set either supervisor or user password, or both of them. The differences are:

Supervisor password: Can enter and change the options of the setup menus.

User password: Can only enter but do not have the right to change the options of the setup menus. When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

ENTER PASSWORD:

Type the password, up to eight characters in length, and press <Enter>. The password typed now will clear any previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable a password, just press <Enter> when you are prompted to enter the password. A message will confirm that the password will be disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

PASSWORD DISABLED.

When a password has been enabled, you will be prompted to enter it every time you try to enter Setup. This prevents an unauthorized person from changing any part of your system configuration.

Additionally, when a password is enabled, you can also require the BIOS to request a password every time your system is rebooted. This would prevent unauthorized use of your computer.

You determine when the password is required within the BIOS Features Setup Menu and its Security option. If the Security option is set to “System”, the password will be required both at boot and at entry to Setup. If set to “Setup”, prompting only occurs when trying to enter Setup.

Chapter 4

DRIVER & FREE PROGRAM INSTALLATION

Check your package and there is A MAGIC INSTALL CD included. This CD consists of all DRIVERS you need and some free application programs and utility programs. In addition, this CD also include an auto detect software which can tell you which hardware is installed, and which DRIVERS needed so that your system can function properly. We call this auto detect software MAGIC INSTALL.

MAGIC INSTALL Supports WINDOWS 95/98/98SE/ME/NT4.0/2000/XP

Insert CD into your CD-ROM drive and the MAGIC INSTALL Menu should appear as below. If the menu does not appear, double-click MY COMPUTER / double-click CD-ROM drive or click START / click RUN / type X:\SETUP.EXE (assuming X is your CD-ROM drive).



From MAGIC INSTALL MENU you may make 11 selections:

1. AGPVXD install AGPVXD file when use External AGP card
2. IDE install SiS MINI IDE driver
3. SOUND install ALC Audio driver
4. LAN install LAN controller driver
5. USB2.0 install USB 2.0 driver
6. RAID install SIS 180 RAID driver and Utility
7. DIRECTX9 install Microsoft DirectX 9 driver
8. PC-CILLIN install PC-CILLIN2002 anti-virus program
9. PC-HEALTH installs SMART GUARDIAN software for hardware monitoring device
10. BROWSE CD to browse the contents of the CD
11. EXIT to exit from MAGIC INSTALL menu

4-1 AGPVXD Install SiS AGPVXD Driver

The AGPVXD Driver is Only For AGP Slot VGA CARD User, before install AGP card driver please install this AGPVXD driver first.

The path of the file:

for WINDOWS 9X is X:\SIS755\AGPVXD\WIN9X\SETUP.EXE

(including WIN95/98/98SE/ME)

for WINDOWS 2000/XP is X:\SIS755\AGPVXD\WIN2K_XP\SETUP.EXE

For WINDOWS 95/98/98SE/ME/2000/XP




1. Click AGPVXD when Magic Install MENU appears



2. Click Next when SiS Acceleration Graphic Port appears



3. Click NEXT or choose BROWSE to change the path For the file to be stored



4. After Setup complete please select restart my computer now and click Finish to complete setup

4-2 IDE

Install SiS MINI IDE Driver



1. Click IDE when Magic Install main menu appear



2. Click NEXT when SIS IDE Driver Setup window appear



3. Select components and Click Next



4. Click FINISH and Restart Computer


4-3 SOUND Install ALC Audio Codec Driver




1. Click SOUND when MAGIC INSTALL MENU appears




2. Then auto detect operation system language edition, click OK, start to install DRIVER




3. Click Finish and Restart Windows



4. Click Start→Program→Avance Sound Manager→AvRack. Then AVRACK Windows appears



5. Sound Effect select and KaraOK Mode Function



6. Manual Sound Effect Setting

Note: The path of the file

For WIN98/NT4.0/WIN2K/XP is X:\CODEC\ALC\SETUP.EXE

4-4 LAN install LAN controller driver

The path of the file:

for WINDOWS 9X/2000 is X:\SIS755\LANDRV\SETUP.EXE

(Including WINDOWS 95/98/98SE/98ME/2000)

for WINDOWS NT4.0 is X:\SIS755\LANDRV\NT40

WINDOWS 95/98/98SE/98ME/2000 Setup



1. Click LAN when Magic Install Menu appears



2. Click NEXT when SiS PCI LAN Driver Setup appears




3. Choice restart my computer now to finish setting up LAN Card, click Finish to complete setup



4. After restart computer you can check in control Panel\System Device Manager\ Network adapters to make sure LAN card Driver setup completely Click NEXT when SiS PCI LAN Driver Setup appears


4-5 PC-HEALTH installs SMART GUARDIAN software for hardware monitoring device



1. Click PC-HEALTH when MAGIC INSTALL MENU appears



2. Click Install when SMART GUARDIAN INSTALL appears



3. Click OK after the software is installed



4. SMART GUARDIAN Utility

**NOTE: MAGIC INSTALL will auto detect file path X:\SIS755\HEALTH\SETUP.EXE
This driver supports WINDOWS 95/98/98SE/NT4.0/2000**

4-6 PC-CILLIN Install PC-CILLIN 2002 Anti-virus program



1. Click PC-CILLIN when MAGIC INSTALL MENU appear




2. (1) Click "Install PC-CILLIN" when PC-CILLIN 2002 main menu appears, and Click NEXT when "Install Shield Wizard For PC-CILLIN 2002"

(2) Click Open Manual. you can learn PC-CILLIN 2002 how to use




3. This is license agreement, select "I Accept the terms" and Click NEXT



4. Click NEXT and Enter your Customer Information, Click NEXT or choose Change to change the path for the file to be stored



5. Click INSTALL, Start to install the software



6. Setup Complete and click FINISH



7. After PC-CILLIN 2002 complete, Please register your information and get LICENSE KEY from TREND MICRO web site, enter your license key and click FINISH


8. finish register process, we recommend select update item to download newest engine code and virus code

Note : Please install ACROBAT READER, Before you read PC-CILLIN 2002 User Manual, the path at X:\acrobat\ar500eng.exe

4-7 USB2.0 Install SIS USB2.0 DEVICE DRIVER



1. Click USB2.0 when MAGIC INSTALL MENU Appear



2. When SIS USB Enhanced Host Controller Setup appears , Click YES



3. When Finish SIS USB Enhanced Host Controller Setup appears , Click YES and restart computer



4. Check device working properly in Device Manager


4-8 RAID Install SIS 180 RAID Driver and Utility




1. Click RAID in MAGIC INSTALL MENU appear



2. When "RAID application windows appear, please click NEXT



3. When the license agreement windows appear, please choose "I accept the terms of the license agreement" and click NEXT, then click INSTALL , start install SIS180 RAID Controller Driver



4. Please click FINISH and restart your computer

4-9 HOW TO DISABLE ON-BOARD SOUND

Enter BIOS SETUP choose INTEGRATE PERIPHERALS choose ON-CHIP DEVICE FUNCTION choose AC97 SOUND DEVICE

Disable on-board sound function by press PAGE DOWN KEY to Disable

4-10 HOW TO UPDATE BIOS

Before update BIOS users have to “Disable”, “Flash Part Write Protect” item which in “Miscellaneous Control” of BIOS SETUP. Otherwise the system will not allow you to upgrade BIOS by Award Flash Utility.

STEP 1. Prepare a boot disc. (you may make one by click START click RUN type SYS A: click OK)

STEP 2. Copy utility program to your boot disc. You may copy from DRIVER CD X:\FLASH\AWDFLASH.EXE or download from our web site.

STEP 3. Copy latest BIOS for S755TWIN from our web site to your boot disc.

STEP 4. Insert your boot disc into A:,
start the computer, type “Awdflash A:\S755TWINAxxx.BIN /SN/PY/CC/R”
S755TWINAxxx.BIN is the file name of latest BIOS it can be S755TWINA03.BIN
or S755TWINB02.BIN

SN means don't save existing BIOS data

PY means renew existing BIOS data

CC means clear existing CMOS data

R means restart computer

STEP 5. Push ENTER and the BIOS will be updated, computer will be restarted automatically.