

## **U8799**

---

---

### **FCC Information and Copyright**

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee that interference will not occur in a particular installation.

The vendor makes no representations or warranties with respect to the contents here of and specially disclaims any implied warranties of merchantability or fitness for any purpose. Further the vendor reserves the right to revise this publication and to make changes to the contents here of without obligation to notify any party beforehand. Duplication of this publication, in part or in whole, is not allowed without first obtaining the vendor's approval in writing.

The content of this user's manual is subject to be changed without notice and we will not be responsible for any mistakes found in this user's manual. All the brand and product names are trademarks of their respective companies.

**Content**


---

---

<b>LAYOUT OF U8799 FOR VERSION 3.1 &amp; BELOW .....</b>	<b>1</b>
<b>LAYOUT OF U8799 VERSION 3.2.....</b>	<b>2</b>
<b>ENGLISH.....</b>	<b>3</b>
U8799 Features.....	3
Package contents.....	4
How to setup Jumper .....	5
CPU Installation.....	5
DDR DIMM Modules: DIMM1/ DIMM2.....	6
Jumpers, Headers, Connectors & Slots.....	7
<b>FRANÇAIS .....</b>	<b>14</b>
Caractéristique de U8799.....	14
<b>WARPSPEEDER.....</b>	<b>16</b>
Introduction.....	16
System Requirement.....	16
Installation .....	17
Usage.....	18
<b>TROUBLE SHOOTING.....</b>	<b>26</b>



## Layout of U8799 Version 3.2



※ NOTE: ● represents the first pin.

---

---

## English

### U8799 Features

#### A. Hardware

##### CPU

- Provides Socket 478
- Supports Intel® Pentium® 4 processor up to 3.06 GHz.
- Supports Hyper-Threading Technology.
- Front Side Bus at 400/533 MHz.

##### Chipset

- North Bridge: VIA P4X400.
- South Bridge: VIA VT8235.

##### Main Memory

- Supports up to 2 DDR devices.
- Supports 200/266/333/400 MHz DDR devices.
- Maximum memory size of 2GB.

##### Super I/O

- Chip: ITE IT8705.

##### Slots

- Three 32-bit PCI bus master slots.
- One AGP 4X/ 8X slot. (AGP 4X only supports 1.5v AGP electricals)
- One CNR slot.

##### On Board IDE

- Supports four IDE disk drives
- Supports PIO Mode 0~4, Ultra DMA 33/66/100/133 Bus Master Mode.

##### LAN

- Chip: VIA VT6103.
- Supports 10 Mb/s and 100 Mb/s auto-negotiation
- Half / Full duplex capability.

##### On Board AC'97 Sound Codec

- Chip: CMI9739A/CMI9761A (for v3.2 & above)
- Compliant with AC'97 specification.
- AC99 2.2 interface or CMI9739A/ AC99 2.3 interface for CMI9761A .
- Supports 6 channels.
- Supports stereo microphone. (for CMI9761A)

---

---

## **On Board Peripherals**

### ***a. Rearside***

- 2 serial ports.
- 1 parallel port. (SPP/EPP/ECP mode)
- Audio ports in vertical position.
- 1 LAN jack
- PS/2 mouse and PS/2 keyboard.
- 2 USB2.0 ports. (4 USB2.0 ports for v3.2)
- 1 vertical audio port

### ***b. FrontSide***

- 1 floppy port supports 2 FDDs with 360K, 720K, 1.2M, 1.44M and 2.88Mbytes.
- 4 USB2.0 ports
- 1 front audio header.

### **Dimensions**

- Micro ATX Form Factor: 24.5 X 22.5cm (W X L)

## **B. BIOS & Software**

### **BIOS**

- Award legal Bios.
- APM1.2.
- ACPI.
- USB Function.

### **Software**

- Supports Warpspeeder™, 9th Touch™, FLASHER™, WinFlasher™.
- Offers the highest performance for Windows 98 SE, Windows 2000, Windows Me, Windows XP, SCO UNIX etc.

## **Package contents**

- HDD Cable X 1
- FDD Cable X 1
- User's Manual X 1
- USB Cable X 1 (optional)
- Rear I/O Panel or Micro ATX Case X 1 (optional)
- Fully Setup Driver CD X1

---

---

## How to setup Jumper


The illustration shows how jumpers are setup. When the Jumper cap is placed on pins, the jumper is "**close**". If no jumper cap is placed on the pins, the jumper is "**open**". The illustration shows a 3-pin jumper whose pin 1 and 2 are "**close**" when jumper cap is placed on these 2 pins.



Jumper close



Jumper open



Pin 1-2 close

## CPU Installation

**Step1:** Pull the lever sideways away from the socket and then raise the lever up to a 90-degree angle.

**Step2:** Look for the white dot/cut edge. The white dot/cut edge should point towards the lever pivot. The CPU will fit only in the correct orientation.

**Step3:** Hold the CPU down firmly, and then close the lever.

**Step4:** Put the CPU fan on the CPU and buckle it. Connect the CPU fan power cable to the JCFAN1. This completes the installation.



Step1



Step2




Step3



Step4

### CPU Fan Header: JCFAN1

 <b>JCFAN1</b>	Pin No.	Assignment
	1	Ground
	2	+12V
	3	FAN rpm Rate Sense

### System Fan Header: JSFAN1

 <b>JSFAN1</b>	Pin No.	Assignment
	1	Ground
	2	+12V
	3	FAN rpm Rate Sense

### DDR DIMM Modules: DIMM1/ DIMM2

DRAM Access Time: 2.5/ Unbuffered DDR 200/266/333/400 MHz Type required.

DRAM Type: 64MB/ 128MB/ 256MB/ 512MB/ 1GB DIMM Module (184 pin)

#### Total Memory Size with Unbuffered DIMMs

DIMM Socket Location	DDR Module	Total Memory Size (MB)
DIMMB1	64MB/128MB/256MB/512MB/1GB *1	Max is 2 GB
DIMMB2	64MB/128MB/256MB/512MB/1GB *1	

\*\*\*Only for reference\*\*\*

### Installing DDR Module

1. Unlock a DIMM slot by pressing the retaining clips outward. Align a DIMM on the slot in the way that the notch on the DIMM matches the break on the slot.
2. Insert the DIMM firmly and vertically into the slot until the retaining chip snap back in place and the Dimm is properly seated.



---

---

## Jumpers, Headers, Connectors & Slots

### Floppy Disk Connector: FDD1

The motherboard provides a standard floppy disk connector that supports 360K, 720K, 1.2M, 1.44M and 2.88M floppy disk types. This connector supports the provided floppy drive ribbon cables.

### Hard Disk Connectors: IDE1/ IDE2

The motherboard has a 32-bit Enhanced PCI IDE Controller that provides PIO Mode 0-4, Bus Master, and Ultra DMA 33/ 66/ 100/ 133 functionality. It has two HDD connectors IDE1 (primary) and IDE2 (secondary).

The IDE connectors can connect a master and a slave drive, so you can connect up to four hard disk drives. The first hard drive should always be connected to IDE1.

### Peripheral Component Interconnect Slots: PCI 1-3

This motherboard is equipped with 3 standard PCI slots. PCI stands for Peripheral Component Interconnect, and it is a bus standard for expansion cards. This PCI slot is designated as 32 bits.


### Accelerated Graphics Port Slot: AGP1

Your monitor will attach directly to that video card. This motherboard supports video cards for PCI slots, but it is also equipped with an Accelerated Graphics Port (AGP). An AGP card will take advantage of AGP technology for improved video efficiency and performance, especially with 3D graphics.

### Communication Network Riser Slot: CNR1

The CNR specification is an open Industry Standard Architecture, and it defines a hardware scalable riser card interface, which supports modem only.


### Front USB Header: JUSB3/ JUSB4

 JUSB3/4	Pin	Assignment	Pin	Assignment
	1	+5V(fused)	2	+5V(fused)
	3	USBP4-	4	USBP5-
	5	USBP4+	6	USBP5+
	7	Ground	8	Ground
	9	KEY	10	NA


### Wake On LAN Header: JWOL1

 JWOL1	Pin	Assignment
	1	+5V Standby
	2	Ground
	3	Wake up

### Front Panel Connector: JPANEL1



### Power Connectors: JATXPWR1/ JATXPWR2



 <b>JATXPWR2</b>	<b>PIN</b>	<b>Assignment</b>	<b>PIN</b>	<b>Assignment</b>
	1	+12V	3	Ground
	2	+12V	4	Ground

**Power Source Selection for Keyboard and Mouse: JKBV1**

<b>JKBV1</b>	<b>Assignment</b>	<b>Description</b>
 Pin 1-2 close	+5V	+5V for key board and mouse
 Pin 2-3 close	+5V Standby Voltage	PS/2 Mouse and PS/2 Key board are powered with +5V standby voltage

*Note: In order to support this function "Power-on the system via keyboard and mouse, "JKBV1" jumper cap should be placed on pin 2-3.*

**Case Open Connector: JC1**

 <b>JC1</b>	<b>Pin</b>	<b>Assignment</b>
	1	Case Open Signal
	2	Ground

**Power Source Selection for USB: JUSBV1 /JUSBV2/ JUSBV3**

<b>JUSBV2/ JUSBV3</b>	<b>Assignment</b>	<b>Description</b>
 Pin 1-2 close	+5V	JUSBV2: 5V for USB located at the JUSBLAN1 port JUSBV3: 5V for USB located at the JUSB3/4 ports
 Pin 2-3 close	+5V Standby Voltage	JUSBV2: JUSBLAN1 port powered with standby voltage of 5V JUSBV3: JUSB3/4 ports powered with standby voltage of 5V

*Note: In order to support this function "Power-on the system via USB device", "JUSBV2/JUSBV3" jumper cap should be placed on pin 2-3 respectively.*

### Clear CMOS Jumper: JCMOS1

JCMOS1	Assignment
 <p>Pin 1-2 Close</p>	Normal Operation (default)
 <p>Pin 2-3 Close</p>	Clear CMOS Data




The following procedures are for resetting the BIOS password. It is important to follow these instructions closely.


※ **Clear CMOS Procedures :**

1. Remove AC power line.
2. Set the jumper to "Pin 2-3 close".
3. Wait for five seconds.
4. Set the jumper to "Pin 1-2 close".
5. Power on AC.
6. Reset your desired password or clear the CMOS data.

### CD-ROM Audio-In Header: JCDIN1/JCDIN2 (optional)

 <p>JCDIN1/ 2</p>	<b>Pin</b>	<b>Assignment</b>
	1	Left Channel Input
	2	Ground
	3	Ground
	4	Right Channel Input

### Front Panel Audio Header: JAUDIO1

			
Pin	Assignment	Pin	Assignment
1	Mic In/ Center	2	Ground
3	Mic Power/ Bass	4	Audio Power
5	Right Line Out/ Right Speaker Out	6	Right Line Out/ Right Speaker Out
7	Reserved	8	Key
9	Left Line Out/ Left Speaker Out	10	Left Line Out/ Left Speaker Out
11	Right Line In/ Right Rear Speaker	12	Right Line In/ Right Rear Speaker
13	Left Line In/ Left Rear Speaker	14	Left Line In/ Left Rear Speaker


### Front Panel Audio Header: JAUDIO1 (optional)

			
Pin	Assignment	Pin	Assignment
1	Mic In/ Center	2	Ground
3	Mic Power/ Bass	4	Audio Power
5	Right Line Out/ Right Speaker Out	6	Right Line Out/ Right Speaker Out
7	Reserved	8	Key
9	Left Line Out/ Left Speaker Out	10	Left Line Out/ Left Speaker Out
11	Surrender Right	12	Surrender Left
13	Center	14	Subwoof
15	Ground	16	Key

### Digital Audio Connector: JSPDIF\_OUT1/JSPDIF\_IN1: optional


 <p><b>JSPDIF_OUT1/ (JSPDIF_IN1)</b></p>	Pin	Assignment
	1	+5V
	2	SPDIF_OUT
	3	Ground

### Game Port Header: JGAME1




Pin	Assignment	Pin	Assignment
1	+5V	2	+5V
3	Joy stick B Buton 1	4	Joy stick AButton 1
5	Joy stick B Coordinate X	6	Joy stick A Coordinate X
7	MDI Output	8	Ground
9	Joy stick B Coordinate Y	10	Ground
11	Joy stick B Buton 2	12	Joy stick A Coordinate Y
13	MDI Input	14	Joy stick AButton 2
15	NA	16	+5V


### AUDIO DJ Connector: JDJ1



PIN	Assignment	PIN	Assignment
1	SMBDATA	3	INT_B
2	SMBCLK	4	Key
5	ATX_PWROK		

### Back Panel Connectors





---

---

## Français

### Caractéristique de U8799

#### A. Matériel

##### Processeur

- Socket 478.
- Supporte processeur Intel® Pentium® 4.
- Supporte la technologie Hyper-Threading.
- FSB 400/ 533/ 800 MHz.

##### Jeu des Puces

- North Bridge: VIA P4X400.
- South Bridge: VIA VT8235.

##### Mémoire principale

- Prise en charge de deux périphériques 2 DDR.
- Prise en charge des périphériques DDR 200/266/333/400 MHz.
- Taille maximale de la mémoire :2Go.

##### Super E/S

- Puce: ITE IT8705.
- Interface de Comptage de Broche Faible.
- Offre la fonctionnalité Super E/S héritée la plus couramment utilisée.
- Initiatives de Contrôle d'Environnement,
  - Moniteur H/W
  - Fonction "Smart Guardian" de ITE

##### Slots

- Trois slots de maîtrise de bus PCI 32 bits.
- Un slot CNR.
- Un slot compatible AGP 4X/ 8X.

##### IDE intégré

- Supporte quatre lecteurs de disque IDE.
- Supporte PIO Mode 0-4 et Ultra DMA 33/66/100/ 133 Bus Master Mode.

##### LAN

- Puce: VIA VT6103.
- Supporte le fonctionnement en auto-négociation 10 Mb/s et 100 Mb/s.
- Capacité Half/ Full duplex.

##### Codec Son AC'97 intégré (seulement pour version au-dessous de 3.1)

- Puce: CM19739A.
- Conforme aux spécifications AC'97.

- 
- 
- Supporte 6 canaux.

**Codec Son AC'97 intégré (seulement pour version au-dessus de 3.2)**

- Puce: CMI9761A.
- Conforme aux spécifications Intel® AC'97 Rev 2.3.
- Répond aux exigences de Microsoft® PC2001.
- Supporte 6 canaux.
- Supporte le microphone stéréo.
- Gestion d'alimentation avancée et capacités d'économie d'énergie.

**Périphériques intégré**

**a. Côté arrière**

- 2 ports série.
- 1 port parallèle. (mode SPP/EPP/ECP)
- 1 port audio en position verticale.
- 1 port LAN.
- 1 souris PS/2.
- 1 clavier PS/2.
- 4 ports USB2.0.

**b. Côté frontal**

- 1 port disquette prenant en charge 2 FDD avec 360K, 720K, 1.2M, 1.44M et 2.88 Mo.
- 4 ports USB2.0.
- 1 connecteur front audio.

**Dimensions**

- Facteur de Forme Micro ATX 24.5 X 22.5cm (Larg X L)

## **B. BIOS & Software**

**BIOS**

- Award legal Bios.
- APM1.2.
- ACPI.
- Fonction USB.

**Logiciel**

- Supporte Warpspeed™, 9th Touch™, FLASHER™, WinFlasher™.
- Offrant la meilleure performance pour Windows 98 SE, Windows 2000, Windows Me, Windows XP, UNIX series, etc.

---

---

## WarpSpeeder



### Introduction

[ WarpSpeeder™ ], a new powerful control utility, features three user-friendly functions including Overclock Manager, Overvoltage Manager, and Hardware Monitor.

With the Overclock Manager, users can easily adjust the frequency they prefer or they can get the best CPU performance with just one click. The Overvoltage Manager, on the other hand, helps to power up CPU core voltage and Memory voltage. The cool Hardware Monitor smartly indicates the temperatures, voltage and CPU fan speed as well as the chipset information. Also, in the About panel, you can get detail descriptions about BIOS model and chipsets. In addition, the frequency status of CPU, memory, AGP and PCI along with the CPU speed are synchronically shown on our main panel.

Moreover, to protect users' computer systems if the setting is not appropriate when testing and results in system fail or hang, [ WarpSpeeder™ ] technology assures the system stability by automatically rebooting the computer and then restart to a speed that is either the original system speed or a suitable one.

### System Requirement

OS Support: Windows 98 SE, Windows Me, Windows 2000, Windows XP


DirectX: DirectX 8.1 or above. (The Windows XP operating system includes DirectX 8.1. If you use Windows XP, you do not need to install DirectX 8.1.)

---

---

## Installation

1. Execute the setup execution file, and then the following dialog will pop up. Please click "Next" button and follow the default procedure to install.



2. When you see the following dialog in setup procedure, it means setup is completed. If the "Launch the WarpSpeeder Tray Utility" checkbox is checked, the Tray Icon utility and [WarpSpeeder™] utility will be automatically and immediately launched after you click "Finish" button.




## Usage

*The following figures are just only for reference, the screen printed in this user manual will change according to your motherboard on hand.*

[WarpSpeeder™] includes 1 tray icon and 5 panels:

1. Tray Icon:

Whenever the Tray Icon utility is launched, it will display a little tray icon on the right side of Windows Taskbar.



---

---

This utility is responsible for conveniently invoking [WarpSpeeder™] Utility. You can use the mouse by clicking the left button in order to invoke [WarpSpeeder™] directly from the little tray icon or you can right-click the little tray icon to pop up a popup menu as following figure. The "Launch Utility" item in the popup menu has the same function as mouse left-click on tray icon and "Exit" item will close Tray Icon utility if selected.



## 2. Main Panel

If you click the tray icon, [WarpSpeeder™] utility will be invoked. Please refer to the following figure; the utility's first window you will see is Main Panel.


Main Panel contains features as follows:

- a. Display the CPU Speed, CPU external clock, Memory clock, AGP clock, and PCI clock information.
- b. Contains About, Voltage, Overclock, and Hardware Monitor Buttons for invoking respective panels.
- c. With a user-friendly Status Animation, it can represent 3 overclock percentage stages:

Duck walking => overclock percentage from 100% ~ 110%

Duck running => overclock percentage from 110% ~ 120%

Duck burning => overclock percentage from 120% ~ above



### 3. Voltage Panel

Click the Voltage button in Main Panel, the button will be highlighted and the Voltage Panel will slide out to up as the following figure.

In this panel, you can decide to increase CPU core voltage and Memory voltage or not. The default setting is "No". If you want to get the best performance of overclocking, we recommend you click the option "Yes".



#### 4. Overclock Panel

Click the Overclock button in Main Panel, the button will be highlighted and the Overclock Panel will slide out to left as the following figure.




Overclock Panel contains these features:

- a. “-3MHz button”, “-1MHz button”, “+1MHz button”, and “+3MHz button”: provide user the ability to do real-time overclock adjustment.

*Warning: Manually overlock is potentially dangerous, especially when the overlocking percentage is over 110 %. We strongly recommend you verify every speed you overlock by click the Verify button. Or, you can just click Auto overclock button and let [ WarpSpeeder™ ] automatically gets the best result for you.*

- b. “Recovery Dialog button”: Pop up the following dialog. Let user select a restoring way if system need to do a fail-safe reboot.



- c. "Auto-overclock button": User can click this button and [ WarpSpeeder™ ] will set the best and stable performance and frequency automatically. [ WarpSpeeder™ ] utility will execute a series of testing until system fail. Then system will do fail-safe reboot by using Watchdog function. After reboot, the [ WarpSpeeder™ ] utility will restore to the hardware default setting or load the verified best and stable frequency according to the Recovery Dialog's setting.
- d. "Verify button": User can click this button and [ WarpSpeeder™ ] will proceed a testing for current frequency. If the testing is ok, then the current frequency will be saved into system registry. If the testing fail, system will do a fail-safe rebooting. After reboot, the [ WarpSpeeder™ ] utility will restore to the hardware default setting or load the verified best and stable frequency according to the Recovery Dialog's setting.

*Note: Because the testing programs, invoked in Auto-overclock and Verify, include DirectDraw, Direct3D and DirectShow tests, the DirectX 8.1 or newer runtime library is required. And please make sure your display card's color depth is High color (16 bit) or True color (24/32 bit) that is required for Direct3D rendering.*


---

---

## 5. Hardware Monitor Panel

Click the Hardware Monitor button in Main Panel, the button will be highlighted and the Hardware Monitor panel will slide out to left as the following figure.


In this panel, you can get the real-time status information of your system. The information will be refreshed every 1 second.



## 6. About Panel

Click the About button in Main Panel, the button will be highlighted and the About Panel will slide out to up as the following figure.

In this panel, you can get model name and detail information in hints of all the chipset that are related to overclocking. You can also get the mainboard's BIOS model and the Version number of [WarpSpeeder™] utility.



*Note: Because the overclock, overvoltage, and hardware monitor features are controlled by several separate chipset, [ WarpSpeeder™ ] divide these features to separate panels. If one chipset is not on board, the correlative button in Main panel will be disabled, but will not interfere other panels' functions. This property can make [ WarpSpeeder™ ] utility more robust.*

---



---

## Trouble Shooting

PROBABLE	SOLUTION
No power to the system at all. Power light don't illuminate, fan inside power supply does not turn on. Indicator light on keyboard does not turn on.	<ul style="list-style-type: none"> <li>* Make sure power cable is securely plugged in.</li> <li>* Replace cable</li> <li>* Contact technical support</li> </ul>
System inoperative. Keyboard lights are on, power indicator lights are lit, hard drive is spinning.	<ul style="list-style-type: none"> <li>* Using even pressure on both ends of the DIMM, press down firmly until the module snaps into place.</li> </ul>
System does not boot from hard disk drive, can be booted from CD-ROM drive.	<ul style="list-style-type: none"> <li>* Check cable running from disk to disk controller board. Make sure both ends are securely plugged in; check the drive type in the standard CMOS setup.</li> <li>* Backing up the hard drive is extremely important. All hard disks are capable of breaking down at any time.</li> </ul>
System only boots from CD-ROM. Hard disk can be read and applications can be used but booting from hard disk is impossible.	<ul style="list-style-type: none"> <li>* Back up data and applications files. Reformat the hard drive. Re-install applications and data using backup disks.</li> </ul>
Screen message says "Invalid Configuration" or "CMOS Failure."	<ul style="list-style-type: none"> <li>* Review system's equipment. Make sure correct information is in setup.</li> </ul>
Cannot boot system after installing second hard drive.	<ul style="list-style-type: none"> <li>* Set master/slave jumpers correctly.</li> <li>* Run SETUP program and select correct drive types. Call drive manufacturers for compatibility with other drives.</li> </ul>

---

---

03/03/2003

# ***U8799 BIOS Setup***

---

<b>BIOS Setup</b> .....	<b>1</b>
1 Main Menu.....	3
2 Standard CMOS Features .....	6
3 Advanced BIOS Features.....	9
4 Advanced Chipset Features.....	12
5 Integrated Peripherals .....	16
6 Power Management Setup .....	20
7 PnP/PCI Configurations .....	25
8 PC Health Status .....	28
9 Frequency Control .....	30

# **U8799 BIOS Setup**

---

## **BIOS Setup**

### **Introduction**

This manual discussed Award™ Setup program built into the ROM BIOS. The Setup program allows users to modify the basic system configuration. This special information is then stored in battery-backed RAM so that it retains the Setup information when the power is turned off.

The Award BIOS™ installed in your computer system's ROM (Read Only Memory) is a custom version of an industry standard BIOS. This means that it supports Intel Pentium® 4 processor input/output system. The BIOS provides critical low-level support for standard devices such as disk drives and serial and parallel ports.

Adding important has customized the Award BIOS™, but nonstandard, features such as virus and password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

The rest of this manual is intended to guide you through the process of configuring your system using Setup.

### **Plug and Play Support**

These AWARD BIOS supports the Plug and Play Version 1.0A specification. ESCD (Extended System Configuration Data) write is supported.

### **EPA Green PC Support**

This AWARD BIOS supports Version 1.03 of the EPA Green PC specification.

### **APM Support**

These AWARD BIOS supports Version 1.1&1.2 of the Advanced Power Management (APM) specification. Power management features are implemented via the System Management Interrupt (SMI). Sleep and Suspend power management modes are supported. This AWARD BIOS can manage power to the hard disk drives and video monitors .

### **ACPI Support**

Award ACPI BIOS support Version 1.0 of Advanced Configuration and Power interface specification (ACPI). It provides ASL code for power management and device configuration capabilities as defined in the ACPI specification, developed by Microsoft, Intel and Toshiba.

# U8799 BIOS Setup

---

## PCI Bus Support

This AWARD BIOS also supports Version 2.1 of the Intel PCI (Peripheral Component Interconnect) local bus specification.

## DRAM Support

DDR DRAM (Double Data Rate Synchronous DRAM) are supported.

## Supported CPUs

This AWARD BIOS supports the Intel Pentium® 4 CPU.

## Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the <PgUp> and <PgDn> keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program by using the keyboard.

Keystroke	Function
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left (menu bar)
Right arrow	Move to the item on the right (menu bar)
Move Enter	Move to the item you desired
PgUp key	Increase the numeric value or make changes
PgDn key	Decrease the numeric value or make changes
+ Key	Increase the numeric value or make changes
- Key	Decrease the numeric value or make changes
Esc key	Main Menu – Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu – Exit Current page and return to Main Menu
F1 key	General help on Setup navigation keys
F5 key	Load previous values from CMOS
F7 key	Load the optimized defaults
F10 key	Save all the CMOS changes and exit

# U8799 BIOS Setup


## 1 Main Menu

Once you enter Award BIOS™ CMOS Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

### ⚠WARNING

The information about BIOS defaults on manual (Figure 1,2,3,4,5,6,7,8,9) is just for reference, please refer to the BIOS installed on board, for update information.

■ Figure 1. Main Menu



### Standard CMOS Features

This submenu contains industry standard configurable options.

### Advanced BIOS Features

This submenu allows you to configure enhanced features of the BIOS.

### Advanced Chipset Features

This submenu allows you to configure special chipset features.

# U8799 BIOS Setup

---

## Integrated Peripherals

This submenu allows you to configure certain IDE hard drive options and Programmed Input/ Output features.

## Power Management Setup

This submenu allows you to configure the power management features.

## PnP/PCI Configurations

This submenu allows you to configure certain “Plug and Play” and PCI options.

## PC Health Status

This submenu allows you to monitor the hardware of your system.

## Frequency Control

This submenu allows you to change CPU Vcore Voltage and CPU/PCI clock. **(However, this function is strongly recommended not to use. Not properly change the voltage and clock may cause CPU or M/B damage!)**

## Load Optimized Defaults

This selection allows you to reload the BIOS when the system is having problems particularly with the boot sequence. These configurations are factory settings optimized for this system. A confirmation message will be displayed before defaults are set.



Load Optimized Defaults (Y/N)? N

## Set Supervisor Password

Setting the supervisor password will prohibit everyone except the supervisor from making changes using the CMOS Setup Utility. You will be prompted with to enter a password.



Enter Password:

## Set User Password

If the Supervisor Password is not set, then the User Password will function in the same way as the Supervisor Password. If the Supervisor Password is set and the User Password is set, the “User” will only be able to view configurations but will not be able to change them.



Enter Password:

# **U8799 BIOS Setup**

---

## **Save & Exit Setup**

Save all configuration changes to CMOS(memory) and exit setup. Confirmation message will be displayed before proceeding

```
SAVE to CMOS and EXIT (Y/N)? Y
```

## **Exit Without Saving**

Abandon all changes made during the current session and exit setup. Confirmation message will be displayed before proceeding

```
Quit Without Saving (Y/N)? N
```

## **Upgrade BIOS**

This submenu allows you to upgrade bios.


```
BIOS UPDATE UTILITY (Y/N)? N
```

# U8799 BIOS Setup

## 2 Standard CMOS Features

The items in Standard CMOS Setup Menu are divided into 10 categories. Each category includes no, one or more than one setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

■ **Figure 2. Standard CMOS Setup**



# U8799 BIOS Setup

---

## Main Menu Selections

This table shows the selections that you can make on the Main Menu.

<b>Item</b>	<b>Options</b>	<b>Description</b>
Date	mm : dd : yy	Set the system date. Note that the 'Day' automatically changes when you set the date.
Time	hh : mm : ss	Set the system internal clock.
IDE Primary Master	Options are in its sub menu.	Press <Enter> to enter the sub menu of detailed options
IDE Primary Slave	Options are in its sub menu.	Press <Enter> to enter the sub menu of detailed options.
IDE Secondary Master	Options are in its sub menu.	Press <Enter> to enter the sub menu of detailed options.
IDE Secondary Slave	Options are in its sub menu.	Press <Enter> to enter the sub menu of detailed options.
Drive A Drive B	360K, 5.25 in 1.2M, 5.25 in 720K, 3.5 in 1.44M, 3.5 in 2.88M, 3.5 in None	Select the type of floppy disk drive installed in your system.
Video	EGA/VGA CGA 40 CGA 80 MONO	Select the default video device.

## ***U8799 BIOS Setup***

---

<b>Item</b>	<b>Options</b>	<b>Description</b>
Halt On	All Errors No Errors All, but Keyboard All, but Diskette All, but Disk/ Key	Select the situation in which you want the BIOS to stop the POST process and notify you.
Base Memory	N/A	Displays the amount of conventional memory detected during boot up.
Extended Memory	N/A	Displays the amount of extended memory detected during boot up.
Total Memory	N/A	Displays the total memory available in the system.

# U8799 BIOS Setup

## 3 Advanced BIOS Features

■ Figure 3. Advanced BIOS Setup

Phoenix - AwardBIOS CMOS Setup Utility Advanced BIOS Features		Item Help
Virus Warning	Disabled	
CPU L1 & L2 Cache	Enabled	
CPU L2 Cache ECC Checking	Enabled	
Quick Power On Self Test	Enabled	Menu Level ▶
First Boot Device	Floppy	Show summary screen
Second Boot Device	HDD-0	
Third Boot Device	LS120	
Boot Other Device	Enabled	
Swap Floppy Drive	Disabled	
Boot Up Floppy Seek	Enabled	
Boot Up NumLock Status	On	
Typematic Rate Setting	Disabled	
x Typematic Rate (Chars/Sec)	6	
x Typematic Delay (Msec)	250	
Security Option	Setup	
OS Select For DRAM > 64MB	Non-OS2	
Video BIOS Shadow	Enabled	
Summary Screen Show	Disabled	

↑↓←→: Move    Enter: Select    +/-/PU/PD: Value    F10: Save    ESC: Exit    F1: General Help  
F5: Previous Values    F7: Optimized Defaults

### Virus Warning

This option allows you to choose the VIRUS Warning feature that is used to protect the IDE Hard Disk boot sector. If this function is enabled and an attempt is made to write to the boot sector, BIOS will display a warning message on the screen and sound an alarm beep.

**Disabled** (default)    Virus protection is disabled.  
**Enabled**    Virus protection is activated.

### CPU L1 & L2 Cache

Depending on the CPU/chipset in use, you may be able to increase memory access time with this option.

**Enabled** (default)    Enable cache.  
**Disabled**    Disable cache.

### CPU L2 Cache ECC Checking

This item allows you to enable/disable CPU L2 Cache ECC Checking

**The Choices:** **Enabled** (default), **Disabled**.

### Quick Power On Self Test

Enabling this option will cause an abridged version of the Power On Self-Test (POST) to execute after you power up the computer.

# U8799 BIOS Setup

---

Disabled	Normal POST.
<b>Enabled</b> (default)	Enable quick POST.

## **First /Second/Third/ Boot Other Device**

These BIOS attempts to load the operating system from the devices in the sequence selected in these items.

**The Choices:** Floppy, LS120, HDD-0, SCSI, CDROM, HDD-1, HDD-2, HDD-3, ZIP100, LAN, Enabled, Disabled.

## **Swap Floppy Drive**

For systems with two floppy drives, this option allows you to swap logical drive assignments.

**The Choices:** Enabled, **Disabled** (default).

## **Boot Up Floppy Seek**

Enabling this option will test the floppy drives to determine if they have 40 or 80 tracks. Disabling this option reduces the time it takes to boot-up.

**The Choices:** **Enabled** (default), Disabled.

## **Boot Up NumLock Status**

Selects the NumLock. State after power on.

<b>On</b> (default)	Numpad is number keys.
Off	Numpad is arrow keys.

## **Typematic Rate Setting**

When a key is held down, the keystroke will repeat at a rate determined by the keyboard controller. When enabled, the typematic rate and typematic delay can be configured.

**The Choices:** **Disabled** (default), Enabled.

## **Typematic Rate (Chars/Sec)**

Sets the rate at which a keystroke is repeated when you hold the key down.

**The Choices:** **6** (default), 8, 10, 12, 15, 20, 24, 30.

## **Typematic Delay (Msec)**

Sets the delay time after the key is held down before it begins to repeat the keystroke.

**The Choices:** **250** (default), 500, 750, 1000.

## **Security Option**

This option will enable only individuals with passwords to bring the system online and/or to use the CMOS Setup Utility.

**System:** A password is required for the system to boot and is also required to access the Setup Utility.

**Setup** (default): A password is required to access the Setup Utility only.

*This will only apply if passwords are set from the Setup main menu.*

# ***U8799 BIOS Setup***

---

## **OS Select For DRAM > 64MB**

A choice other than Non-OS2 is only used for OS2 systems with memory exceeding 64MB.  
**The Choices:** **Non-OS2** (default), OS2.

## **Video BIOS Shadow**

Determines whether video BIOS will be copied to RAM for faster execution.

<b>Enabled</b> (default)	Optional ROM is enabled.
Disabled	Optional ROM is disabled.

## **Summary Screen Show**

This item allows you to enable/disable the summary screen. Summary screen means system configuration and PCI device listing.


**The Choices:** Enabled, **Disabled** (default).

# U8799 BIOS Setup

## 4 Advanced Chipset Features

This submenu allows you to configure the specific features of the chipset installed on your system. This chipset manage bus speeds and access to system memory resources, such as DRAM. It also coordinates communications with the PCI bus. The default settings that came with your system have been optimized and therefore should not be changed unless you are suspicious that the settings have been changed incorrectly.

### ■ Figure 4. Advanced Chipset Setup



### **DRAM Clock/ Drive Control**

To control the Clock. If you highlight the literal “Press Enter” next to the “DRAM Clock” label and then press the enter key, it will take you to a submenu with the following options:

#### **DRAM Clock**

This item determines DRAM clock following 100MHz, 133MHz or By SPD.

**The Choices:** 100MHz, 133MHz, **By SPD** (default).

#### **DRAM Timing**

This item determines DRAM clock/ timing follow SPD or not.

**The Choices:** **By SPD** (default), Manual.

#### **SDRAM CAS Latency**

When DRAM is installed, the number of clock cycles of CAS latency depends on the DRAM timing.

**The Choices:** 2.5, **2** (default).

# **U8799 BIOS Setup**

---

## **Bank Interleave**

This item allows you to enable or disable the bank interleave feature.

**The Choices:** Disabled (default).

## **Precharge to Active (Trp)**

This item allows you to specify the delay from precharge command to activate command.

**The Choices:** 2T, 3T (default).

## **Active to Precharge (Tras)**

This item allows you to specify the minimum bank active time.

**The Choices:** 7T (default), 6T.

## **Active to CMD (Tred)**

Use this item to specify the delay from the activation of a bank to the time that a read or write command is accepted.

**The Choices:** 2T, 3T (default).

## **DRAM Command Rate**

This item controls clock cycle that must occur between the last valid write operation and the next command.

**The Choices:** 1T Command (default), 2T Command.

## **DRAM Burst Len**

**The Choices:** 4 (default), 8.

## **Write Recovery Time**

**The Choices:** 3T (default), 2T.

## **AGP & P2P Bridge Control**

If you highlight the literal "Press Enter" next to the "AGP & P2P Bridge Control" label and then press the enter key, it will take you a submenu with the following options:

### **AGP Aperture Size**

Select the size of the Accelerated Graphics Port (AGP) aperture. The aperture is a portion of the PCI memory address range dedicated for graphics memory address space. Host cycles that hit the aperture range are forwarded to the AGP without any translation.

**The Choices:** 64M (default), 256M, 128M, 32M, 16M, 8M, 4M.

### **AGP Mode**

This item allows you to select the AGP Mode.

**The Choices:** 4X (default), 2X, 1X.

### **AGP Driving Control**

By choosing "Auto" the system BIOS will the AGP output Buffer Drive strength P Ctrl by AGP Card. By choosing "Manual", it allows user to set AGP output

## **U8799 BIOS Setup**

---

Buffer Drive strength P Ctrl by manual.

**The Choices:** Auto (default), Manual.

### **AGP Driving Value**

While AGP driving control item set to “Manual”, it allows user to set AGP driving.

**The Choices:** DA (default).

### **AGP Fast Write**

**The Choices:** Enabled, Disabled (default).

### **AGP Master 1 WS Write**

When Enabled, writes to the AGP (Accelerated Graphics Port) are executed with one wait states.

**The Choices:** Disabled (default), Enabled.

### **AGP Master 1 WS Read**

When Enabled, read to the AGP (Accelerated Graphics Port) are executed with one wait states.

**The Choices:** Disabled (default), Enabled.

### **DBI Output for AGP Trans.**

**The Choices:** Disabled (default), Enabled.

## **CPU & PCI Bus Control**

If you highlight the literal “Press Enter” next to the “CPU & PCI Bus Control” label and then press the enter key, it will take you a submenu with the following options:

### **CPU to PCI Write Buffer**

When enabled, up to four Dwords of data. Can be written to the PCI bus without interrupting the CPU. When disabled, a write buffer is not used and the CPU read cycle will not be completed until the PCI bus signals that it is ready to receive the data.

**The Choices:** Enabled (default), Disabled.

### **PCI Master 0 WS Write**

When Enabled, writes to the PCI bus are executed with zero-wait states.

**The Choices:** Enabled (default), Disabled.

### **PCI Delay Transaction**

The chipset has an embedded 32-bit posted write buffer to support delay transactions cycles. Select Enabled to support compliance with PCI specification.

**The Choices:** Disabled, Enabled (default).

### **VLink 8X Support**

**The Choices:** Disabled (Default), Enabled.

# ***U8799 BIOS Setup***

---

## **Memory Hole At 15M-16M**

You can reserve this area of system memory for ISA adapter ROM. When this area is reserved it cannot be cached. The user information of peripherals that need to use this area of system memory usually<sup>2</sup> discussed their memory requirements.

**The Choices:** **Disabled** (default), Enabled.

## **System BIOS Cacheable**

Selecting the “Enabled” option allows caching of the system BIOS ROM at F0000h-FFFFFh which can improve system performance. However, any programs writing to this area of memory will cause conflicts and result in system errors.

**The Choices:** Enabled, **Disabled** (default).

## **Delay Prior to Thermal**

Set this item to enable the CPU Thermal function to engage after the specified time.

**The Choices:** **16Min** (default), 4Min, 8Min, 32Min.

## **NB Power Management**


This item allows you to enable or disable NB Power Management.

**The Choices:** Disabled, **Enabled** (Default).

# U8799 BIOS Setup

## 5 Integrated Peripherals

### ■ Figure 5. Integrated Peripherals



### VIA OnChip IDE Device

If you highlight the literal “Press Enter” next to the “VIA OnChip IDE Device” label and then press the enter key, it will take you a submenu with the following options:

#### **IDE DMA Transfer Access**

**The Choices:** Enabled (default), Disabled.

#### **OnChip IDE Channel 0/1**

The motherboard chipset contains a PCI IDE interface with support for two IDE channels. Select “Enabled” to activate the first and/or second IDE interface. Select “Disabled” to deactivate an interface if you are going to install a primary and/or secondary add-in IDE interface.

**The Choices:** Enabled (default), Disabled.

#### **IDE Prefetch Mode**

The “onboard” IDE drive interfaces supports IDE prefetching for faster drive access. If the interface does not support prefetching. If you install a primary and/or secondary add-in IDE interface, set this option to “Disabled”.

**The Choices:** Enabled (default), Disabled.

#### **Primary / Secondary / Master / Slave PIO**

The IDE PIO (Programmed Input / Output) fields let you set a PIO mode (0-4) for each of the IDE devices that the onboard IDE interface

## **U8799 BIOS Setup**

---

supports. Modes 0 to 4 will increased performance progressively. In Auto mode, the system automatically determines the best mode for each device.

**The Choices:** Auto (default), Mode0, Mode1, Mode2, Mode3, Mode4.

### **Primary / Secondary /Master / Slave UDMA**

Ultra DMA/100 functionality can be implemented if it is supported by the IDE hard drives in your system. As well, your operating environment requires a DMA driver (Windows 95 OSR2 or a third party IDE bus master driver). If your hard drive and your system software both support Ultra DMA/100, select Auto to enable BIOS support.

**The Choices:** Auto (default), Disabled.

### **VIA OnChip PCI Device**

If you highlight the literal "Press Enter" next to the "VIA OnChip PCI Device" label and then press the enter key, it will take you a submenu with the following options:

#### **VIA-3058 AC97 Audio**

This option allows you to control the onboard AC97 audio.

**The Choices:** Auto (default), Disabled.

#### **Onboard Codec**

This option allows you to enable or disable the onboard Codec.

**The Choices:** Enabled (Default), Disabled.

#### **Onboard CMI Audio**

This item allows you to enable or disable the onboard CMI 8738 Audio Chip.

**The Choices:** Enabled (Default), Disabled.

#### **VIA-3068 MC97 Modem**

This option allows you to control the onboard MC97 modem.

**The Choices:** Auto (default), Disabled.

#### **VIA-3043 OnChip LAN**

This option allows you to control the onboard LAN.

**The Choices:** Enabled, Disabled (default).

#### **Onboard LAN Boot ROM**

This item allows you to enable or disable Onboard LAN Boot ROM.

**The Choices:** Disabled (default), Enabled.

### **Super IO Device**

Press Enter to configure the Super I/O Device.

#### **Onboard FDC Controller**

Select Enabled if your system has a floppy disk controller (FDC) installed on the system board and you wish to use it. If install and FDC or the system has no

# U8799 BIOS Setup

---

floppy drive, select Disabled in this field.  
**The Choices:** Enabled (default), Disabled.

## Onboard Serial Port 1

Select an address and corresponding interrupt for the first and second serial ports.  
**The Choices:** 3F8/IRQ4 (default), Disabled, Auto, 2F8/IRQ3, 3E8/IRQ4, 2E8/IRQ3.

## Onboard Serial Port 2

Select an address and corresponding interrupt for the first and second serial ports  
**The Choices:** 2F8/IRQ3 (default), Disabled, Auto, 3F8/IRQ4 , 3E8/IRQ4, 2E8/IRQ3.

## UART Mode Select

This item allows you to determine which Infrared (IR) function of onboard I/O chip.

**The Choices:** Normal(default), ASKIR, IrDA, SCR .

## UR2 Duplex Mode

Select the value required by the IR device connected to the IR port. Full-duplex mode permits simultaneous two-direction transmission. Half-duplex mode permits transmission in one direction only at a time.

**The Choices:** Half (default), Full.

## Onboard Parallel Port

This item allows you to determine access onboard parallel port controller with which I/O Address.

**The Choices:** 378/IRQ7 (default), 278/IRQ5, 3BC/IRQ7, Disabled.

## Parallel Port Mode

The default value is SPP.

### The Choices:

SPP (Default)	Using Parallel Port as Standard Printer Port.
EPP	Using Parallel Port as Enhanced Parallel Port.
ECP	Using Parallel Port as Extended Capabilities Port.
ECP+EPP	Using Parallel Port as ECP & EPP mode.

## ECP Mode Use DMA

Select a DMA Channel for the port.

**The Choices:** 3 (default), 1.

## Game Port Address

Game Port I/O Address.

**The Choices:** 201 (default), 209, Disabled.

## Midi Port Address

Midi Port Base I/O Address.

# **U8799 BIOS Setup**

---

**The Choices:** 330 (default), 300, Disabled.

## **Midi Port IRQ**

This determines the IRQ in which the Midi Port can use.

**The Choices:** 10 (default), 5.

## **Init Display First**

With systems that have multiple video cards, this option determines whether the primary display uses a PCI Slot or an AGP Slot.

**The Choices:** PCI Slot (default), AGP.

## **OnChip USB Controller**

This option should be enabled if your system has a USB installed on the system board. You will need to disable this feature if you add a higher performance controller.

**The Choices:** All Enabled (default), All Disabled.

## **USB Keyboard Support**

Enables support for USB attached keyboards.

**The Choices:** Disabled (default), Enabled.

## **IDE HDD Block Mode**

Block mode is otherwise known as block transfer, multiple commands, or multiple sector read/write. Select the "Enabled" option if your IDE hard drive supports block mode (most new drives do). The system will automatically determine the optimal number of blocks to read and write per sector.


**The Choices:** Enabled (default), Disabled.

# U8799 BIOS Setup

## 6 Power Management Setup

The Power Management Setup Menu allows you to configure your system to utilize energy conservation and power up/power down features.

### ■ Figure 6. Power Management Setup



### ACPI Function

This item displays the status of the Advanced Configuration and Power Management (ACPI).

**The Choices:** Enabled (default), Disabled.

### ACPI Suspend Type

The item allows you to select the suspend type under the ACPI operating system.

**The Choices:** S1 (POS) (default) Power on Suspend  
S3 (STR) Suspend to RAM  
S1 & S3 POS+STR

### Power Management

This category allows you to select the type (or degree) of power saving and is directly related to the following modes:

- 1.HDD Power Down.
- 2.Doze Mode.
- 3.Suspend Mode.

# U8799 BIOS Setup

---

There are four options of Power Management, three of which have fixed mode settings

## Min. Saving

Minimum power management.

Doze Mode = 1 hr.

Standby Mode = 1 hr

Suspend Mode = 1 hr.

HDD Power Down = 15 min

## Max Saving

Maximum power management only available for sl CPU's.

Doze Mode = 1 min

Standby Mode = 1 min.

Suspend Mode = 1 min.

HDD Power Down = 1 min.

## User Defined (default)

Allows you to set each mode individually.

When not disabled, each of the ranges are from 1 min. to 1 hr. except for HDD Power Down which ranges from 1 min. to 15 min. and disable.

## HDD Power Down

When enabled and after the set time of system inactivity , the hard disk drive will be powered down while all other devices remain active.

**The Choices: Disabled** (default), 1Min, 2Min, 3Min, 4Min, 5Min, 6Min, 7Min, 8Min, 9Min, 10Min, 11Min, 12Min, 13Min, 14Min, 15Min.

## Suspend Mode

When enabled and after the set time of system inactivity, all devices except the CPU will be shut off.

**The Choices: Disabled** (default), 1Min, 2Min, 4Min, 8Min, 12Min, 20Min, 30Min, 40Min, 1Hour.

## Video Off Option

This field determines when to activate the video off feature for monitor power management.

**The Choices: Suspend**→**Off** (default), Always on.

## Video Off Method

This option determines the manner in which the monitor is goes blank.

**V/H SYNC+Blank** (default)

This selection will cause the system to turn off the vertical and horizontal

# U8799 BIOS Setup

---

synchronization ports and write blanks to the video buffer.

## Blank Screen

This option only writes blanks to the video buffer.

## DPMS

Initial display power management signaling.

## MODEM Use IRQ

This determines the IRQ, which can be applied in MODEM use.

**The Choices:** 3 (default) / 4 / 5 / 7 / 9 / 10 / 11 / NA

## Soft-Off by PWR-BTTN

Pressing the power button for more than 4 seconds forces the system to enter the Soft-Off state when the system has “hung.”

**The Choices:** Delay 4 Sec, **Instant-Off** (default).

## Run VGABIOS if S3 Resume

Choosing Enabled will make BIOS run VGA BIOS to initialize the VGA card when system wakes up from S3 state . The system time is shortened if you disable the function , but system will need AGP driver to initialize the card . So , if the AGP driver of the VGA card does not support the initialization feature , the display may work abnormally or not function after S3 .

**The Choices:**Auto (default), Yes, No.

## PWRON After PWR-Fail

This field determines the action the system will automatically take when power is restored to a system that had lost power previously without any subsequent manual intervention. There are 3 sources that provide current to the CMOS area that retains these Power-On instructions; the motherboard battery (3V), the Power Supply (5VSB), and the Power Supply (3.3V). While AC is not supplying power, the motherboard uses the motherboard battery (3V). If AC power is supplied and the Power Supply is not turned on, 5VSB from the Power Supply is used. When the Power Supply is eventually turned on 3.3V from the Power Supply will be used.

There are 3 options: “Former-Sts”, “On”, “Off”.

**“Off”** (default) Means always set CMOS to the “Off” status when AC power is lost.

**“On”** Means always set CMOS to the “On” status when AC power is lost

**“Former-Sts”** Means to maintain the last status of the CMOS when AC power is lost.

For example: If set to “Former-Sts” and AC power is lost when system is live, then after AC power is restored, the system will automatically power on. If AC power is lost when system is not live, system will remain powered off.

# U8799 BIOS Setup

---

## IRQ/Event Activity Detect

If you highlight the literal "Press Enter" next to the "IRQ/Event Activity Detect" label and then press the enter key, it will take you a submenu with the following options:

### VGA

When set to **On**, any event occurring at a VGA Port will awaken a system which has been powered down.

**The Choices:** **Off** (default), **On**.

### LPT & COM

When this option is set to **On**, any event occurring at a COM(serial)/LPT (printer) port will awaken a system which has been powered down.

**The Choices:** **LPT/COM** (default), **COM**, **LPT**, **NONE**.

### HDD & FDD

When this option is set to **On**, any event occurring on a hard drive or a floppy drive will awaken a system which has been powered down.

**The Choices:** **On** (default), **Off**.

### PCI Master

When set to **On**, you need a LAN add-on card which supports the power function. It should also support the wake-up on LAN jump.

**The Choices:** **Off** (default), **On**.

### PowerOn by PCI Card

When you select **Enabled**, a PME signal from PCI card returns the system to Full ON state.

**The Choices:** **Disabled** (default), **Enabled**.

### Modem Ring Resume

**The Choices:** **Disabled** (Default), **Enabled**.

### RTC Alarm Resume

When "Enabled", you can set the date and time at which the RTC (real-time clock) alarm awakens the system from Suspend mode.

**The Choices:** **Enabled**, **Disabled** (default).

### Date (of Month)

You can choose which month the system will boot up. This field is only configurable when "RTC Resume" is set to "Enabled".

### Resume Time (hh:mm:ss)

You can choose the hour, minute and second the system will boot up. This field is only configurable when "RTC Resume" is set to "Enabled".

### IRQs Activity Monitoring

**Press Enter** to access another sub menu used to configure the different wake up events (i.e. wake on LPT & COMM activity).

Primary INTR	On
IRQ3 (COM2)	Disabled

## ***U8799 BIOS Setup***

---


IRQ4 (COM1)	Enabled
IRQ5 (LPT2)	Enabled
IRQ6 (Floppy Disk)	Enabled
IRQ7 (LPT1)	Enabled
IRQ8 (RTC Alarm)	Disabled
IRQ9 (IRQ2 Redir)	Disabled
IRQ10 (Reserved)	Disabled
IRQ11 (Reserved)	Disabled
IRQ12 (PS/2 Mouse)	Enabled
IRQ13 (Coprocessor)	Enabled
IRQ14 (Hard Disk)	Enabled
IRQ15 (Reserved)	Disabled

# U8799 BIOS Setup

## 7 PnP/PCI Configurations

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed of the CPU itself uses when communicating with its own special components. This section covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.

### ■ Figure 7. PnP/PCI Configurations



#### **PNP OS Installed**

When set to YES, BIOS will only initialize the PnP cards used for the boot sequence (VGA, IDE, SCSI). The rest of the cards will be initialized by the PnP operating system like Window™ 95. When set to NO, BIOS will initialize all the PnP cards. For non-PnP operating systems (DOS, Netware™), this option must set to NO.

**The Choices:** No (default), Yes.

#### **Reset Configuration Data**

The system BIOS supports the PnP feature which requires the system to record which resources are assigned and protects resources from conflict. Every peripheral device has a node, which is called ESCD. This node records which resources are assigned to it. The system needs to record and update ESCD to the memory locations. These locations (4K) are reserved in the system BIOS. If the Disabled (default) option is chosen, the system's ESCD will update only when the new configuration varies from the last one. If the Enabled option is chosen, the system is forced to update ESCDs and then is automatically set to the "Disabled" mode.

## **U8799 BIOS Setup**

---

The above settings will be shown on the screen only if “Manual” is chosen for the resources controlled by function.

Legacy is the term, which signifies that a resource is assigned to the ISA Bus and provides non-PnP ISA add-on cards. PCI / ISA PnP signifies that a resource is assigned to the PCI Bus or provides for ISA PnP add-on cards and peripherals.

**The Choices:** Disabled (default), Enabled.

### **Resources Controlled By**

By Choosing “**Auto(ESCD)**” (default), the system BIOS will detect the system resources and automatically assign the relative IRQ and DMA channel for each peripheral. By Choosing “Manual”, the user will need to assign IRQ & DMA for add-on cards. Be sure that there are no IRQ/DMA and I/O port conflicts.

### **IRQ Resources**

This submenu will allow you to assign each system interrupt a type, depending on the type of device using the interrupt. When you press the “Press Enter” tag, you will be directed to a submenu that will allow you to configure the system interrupts. This is only configurable when “Resources Controlled By” is set to “Manual”.

IRQ-3	assigned to	PCI Device
IRQ-4	assigned to	PCI Device
IRQ-5	assigned to	PCI Device
IRQ-7	assigned to	PCI Device
IRQ-9	assigned to	PCI Device
IRQ-10	assigned to	PCI Device
IRQ-11	assigned to	PCI Device
IRQ-12	assigned to	PCI Device
IRQ-14	assigned to	PCI Device
IRQ-15	assigned to	PCI Device

### **PCI / VGA Palette Snoop**

Choose Disabled or Enabled. Some graphic controllers which are not VGA compatible take the output from a VGA controller and map it to their display as a way to provide boot information and VGA compatibility.

However, the color information coming from the VGA controller is drawn from the palette table inside the VGA controller to generate the proper colors, and the graphic controller needs to know what is in the palette of the VGA controller. To do this, the non-VGA graphic controller watches for the Write access to the VGA palette and registers the snoop data. In PCI based systems, where the VGA controller is on the PCI bus and a non-VGA graphic controller is on an ISA bus, the Write Access to the palette will not show up on the ISA bus if the PCI VGA controller responds to the Write.

In this case, the PCI VGA controller should not respond to the Write, it should only snoop the data and permit the access to be forwarded to the ISA bus. The non-VGA ISA graphic

## ***U8799 BIOS Setup***

---

controller can then snoop the data on the ISA bus. Unless you have the above situation, you should disable this option.

<b>Disabled</b> (default)	Disables the function.
Enabled	Enables the function.

### **Assign IRQ For VGA**

This item allows the users to choose which IRQ to assign for the VGA.

**The Choices:** **Enabled** (default), Disabled.

### **Assign IRQ For USB**


This item allows the users to choose which IRQ to assign for the USB.

**The Choices:** **Enabled** (default), Disabled.

# U8799 BIOS Setup

## 8 PC Health Status

■ Figure 8. PC Health Status



### Shutdown Temperature

This item allows you to set the shutdown temperature of the CPU in order not to be damaged by the overheated temperature. When this function is enabled, the system will automatically shutdown if the CPU temperature reaches the shutdown temperature. This function only works under Windows 98 ACPI mode.

**The Choices:** Disabled (default), 60°C/140°F, 65°C/149°F, 70°C/158°F, 75°C/167°F.

### CPU Vcore/+3.3V/ +5.0V/ +12V/ -12V/ -5V/ 5V(SB)/ Voltage Battery

Detect the system's voltage status automatically.

### Current CPU Temperature

Show you the current CPU temperature.

### Current CPUFAN Speed

This field displays the current CPUFAN speed.

### Current SYSEAN Speed

This field displays the current speed SYSTEM fan.

# ***U8799 BIOS Setup***

---

## **Show H/W Monitor in POST**


If your computer contains a monitoring system, it will show PC health status during POST stage. The item offers several delay times to select the one you want.

**The Choices:** Enabled (default), Disabled .

# U8799 BIOS Setup

## 9 Frequency Control

■ Figure 9. Frequency Control



### CPU Clock Ratio

**The Choices:** 8 X (default), 9X, 10X, 11X, 12X, 13X, 14 X, 15X, 16X, 17X, 18X, 19X, 20 X, 21 X, 22 X, 23 X.

### CPU Voltage

This item allows you to select CPU Voltage Regulator.

**The Choices:** Default (default), +1.7%, +3.4%, +5.1%.

### DDR Voltage

This item allows you to select DDR Voltage Regulator.

**The Choices:** 2.5V (Default), 2.6V, 2.7V, 2.8V.

### Auto Detect PCI/ DIMM Clk

This item allows you to enable / disable auto Detect PCI Clock.

**The Choices:** Enabled (default), Disabled.

### Spread Spectrum

This item allows you to enable/disable the Spread Spectrum function.

**The Choices:** Enabled (default), Disabled.

## **U8799 BIOS Setup**

---

### **CPU Clock**

This item allows you to select CPU Host Clock.

**The Choices:** 100MHz (Min) (default) ~ 132MHz (Max).

*If unfortunately, the system's frequency that you are selected is not functioning, there are two methods of booting-up the system.*

*Method 1: Clear the CMOS data by setting the JCMOS1 ((2-3) closed)) as "ON" status. All the CMOS data will be loaded as defaults setting.*

*Method 2: Press the <Insert> key and Power button simultaneously, after that keep-on pressing the <Insert> key until the power-on screen showed. This action will boot-up the system according to FSB of the processor.*