


## Chapter 5: Jumper Settings

### D-LINK

### DFE - 500TX

<b>NIC Type</b>	Ethernet
<b>Transfer Rate</b>	10Mbps 100Mbps 2 x 10/100Mbps
<b>Data Bus</b>	PCI
<b>Topology</b>	Star
<b>Wiring Type</b>	Unshielded twisted pair
<b>Boot ROM</b>	Not available



N0882

DIAGNOSTIC LED(S)			
LED	Color	Status	Condition
LED1	Green	On	100Mbps selected
LED1	Green	Off	10Mbps selected
LED2	Green	On	Power on
LED2	Green	Blinking	Data is being transmitted
LED2	Green	Off	Power off
LED3	Yellow	On	Network connection is good
LED3	Yellow	Blinking	Data is being received
LED3	Yellow	Off	Network connection is broken
LED4	Yellow	Blinking	Collision detected on network