**Chapter 5: Jumper Settings**

# D-LINK
# DF-400UT

| | |
|---|---|
| **NIC Type** | FDDI |
| **Transfer Rate** | 100Mbps |
| **Data Bus** | 32-bit EISA |
| **Topology** | Ring |
| **Wiring Type** | Unshielded twisted pair |
| **Boot ROM** | Not available |

N0884

| DIAGNOSTIC LED(S) | | | |
|---|---|---|---|
| LED | Color | Status | Condition |
| LED1 | Green | On | Station management program downloaded |
| LED1 | Green | Off | Station management program not downloaded |
| LED2 | Amber | On | Network connection is broken |
| LED2 | Amber | Off | Network connection is good |