
## **Chapter 5: Jumper Settings**

D-LINK

DE-220TP

Ethernet 10Mbps 16-bit ISA Linear Bus/Star AUI transceiver via DB-15 port Unshielded twisted pair Available NIC Type Transfer Rate Data Bus Topology Wiring Type

**Boot ROM** 



N0892

| DIAGNOSTIC LED(S) |        |          |  |
|-------------------|--------|----------|--|
| LED               | Color  | Status   | Condition  |
| LED1              | Green  | On       | Power on   |
| LED1              | Green  | Blinking | Data is being transmitted/received (UTP only)      |
| LED1              | Green  | Off      | Power off  |
| LED2              | Green  | On       | Network connection is good                         |
| LED2              | Green  | Blinking | Data is being transmitted/received (UTP only)      |
| LED2              | Green  | Off      | Network connection is broken                       |
| LED3              | Yellow | On       | Collision detected on network                      |
| LED3              | Yellow | Off      | No collision detected on network                   |
| LED4              | Yellow | On       | Network connection is broken (BNC only)            |
| LED4              | Yellow | Blinking | Card is transmitting for an extended time (jabber) |
| LED4              | Yellow | Off      | Normal operation                                   |