
## STB SYSTEMS, INC. EGA MULTI RES

Card Type Chip Set Maximum Onboard Memory I/O Options Data Bus

Multi-I/O card Unidentified 256KB EGA video port, light pen, parallel port 8-bit ISA



	CONNECTIONS				
Function	Label	Function	Label		
Battery connector	J1	Parallel port	P4		
Light pen connector	J5	Clock generator socket	U5		
9-pin digital video connector	P3				

USER CONFIGURABLE SETTINGS					
Function Label Position					
í EGA monitor connected to Multi Res adapter	J2	Pins 1 & 2 closed			
CGA/Monochrome monitor connected to Multi Res adapter	J2	Pins 2 & 3 closed			
í Factory configured - do not alter	J4	Pins 2 & 3 closed			
Note: Jumper J4 configures the adapter for all display types. Alternate settings are unidentified.					

DISPLAY CONFIGURATION						
Display	Mode	SW1/1	SW1/2	SW1/3	SW1/4	
Monochrome	Monochrome	Off	Off	On	Off	
CGA	40x25	On	Off	Off	On	
CGA	80x25	Off	Off	Off	On	
EGA	8x8 text	On	On	On	Off	
EGA 8x14 text Off On On Off						
Note: These settings are for systems where the EGA Multi Res is the sole adapter in the system.						

Continued on next page. . .

## STB SYSTEMS, INC. EGA MULTI RES

....continued from previous page

DISPLAY CONFIGURATION						
Primary Display/Mode	Secondary Display/Mode	SW1/1	SW1/2	SW1/3	SW1/4	
CGA/40x80	Monochrome/Monochrome	On	Off	Off	On	
CGA/80x25 Monochrome/Monochrome Off Off Off On					On	
EGA/8x8 text	Monochrome/Monochrome	On	On	On	Off	
EGA/8x14 text Monochrome/Monochrome Off On On Off						
Note: These settings are for systems where the EGA Multi Res is the primary adapter in the system and a monochrome/printer card is the secondary adapter.						

## DISPLAY CONFIGURATION

Primary Display/Mode	Secondary Display/Mode	SW1/1	SW1/2	SW1/3	SW1/4
Monochrome/Monochrome	CGA/40x25	On	On	On	On
Monochrome/Monochrome	CGA/80x25	Off	On	On	On
Monochrome/Monochrome	EGA/8x8 text	On	Off	On	On
Monochrome/Monochrome	EGA/8x14 text	Off	Off	On	On
Note: These settings are for systems where the EGA Multi Res is the secondary adapter in the system					
and a monochrome/printer card is the primary adapter.					

DISPLAY CONFIGURATION					
Primary Display/Mode	Secondary Display/Mode	SW1/1	SW1/2	SW1/3	SW1/4
Monochrome/Monochrome	CGA/40x25	On	Off	On	Off
Monochrome/Monochrome	CGA/80x25	Off	Off	On	Off
Note: These settings are for systems where the EGA Multi Res is the primary adapter in the system and a					
CGA card is the secondary adapter.					

	DISPLAY CONFIGURATION					
ſ	Primary Display/Mode	Secondary Display/Mode	SW1/1	SW1/2	SW1/3	SW1/4
Ī	CGA/40x25	Monochrome/Monochrome	On	On	Off	On
I	CGA/80x25	Monochrome/Monochrome	Off	On	Off	On
Ī	Note: These settings are for systems where the EGA Multi Res is the secondary adapter in the system					
	and a CGA card is the primary adapter.					

EGA MONITOR CONFIGURATION					
Setting SW1/7 SW1/8					
í Normal 25KHz monitors	Off	On			
Dyneer 140HI Off Off					

PARALLEL PORT ADDRESS SELECTION				
Setting SW1/5 SW1/6				
LPT1	On	On		
LPT2	On	Off		
LPT3	Off	On		
Disabled	Off	Off		