


CREATIVE LABS, INC. SOUNDBLASTER 16 SONY ASP (CT2230S), SOUNDBLASTER 16 SONY (CT2239S)

Card Type	Sound card
Chip Set	Unidentified
Maximum Onboard Memory	None
I/O Options	Game/MIDI port, CD-ROM interface, speaker out, line out, line in, microphone in, CD-ROM audio in, PC speaker connector
Data Bus	16-bit ISA



CONNECTIONS			
Function	Label	Function	Label
Game/MIDI port	CN1	Audio in - CD-ROM	CN7
Speaker out	CN2	CD-ROM interface - Sony	J1
Line out	CN3	PC speaker connector	J2
Microphone in	CN4	Unidentified	J3
Line in	CN5	Audio connector	JP17

USER CONFIGURABLE SETTINGS			
Function	Label	Position	
í Joystick enabled	JYEN	Closed	
Joystick disabled	JYEN	Open	
í Speaker enabled	JP16	Closed	
Speaker disabled	JP16	Open	
í Factory default - do not alter	J4	Closed	
í MPU-401 port enabled	MPUE N	Closed	
MPU-401 port disabled	MPUE N	Open	

AUDIO I/O ADDRESS SELECTION			
Address	IOS0	IOS1	
í 220h	Closed	Closed	
240h	Open	Closed	
260h	Closed	Open	
280h	Open	Open	

Continued on next page . . .

CREATIVE LABS, INC.
SOUNDBLASTER 16 SONY ASP (CT2230S),
SOUNDBLASTER 16 SONY (CT2239S)

. . . continued from previous page

MPU-401 I/O ADDRESS SELECTION	
Address	MSEL
300h	Open
í 330h	Closed

CSP CHIP SELECTION		
	IFSD	APSD
í Disabled	Closed	Closed
Enabled	Open	Open
Note: The IFSD and APDS jumpers are enabled on the CT2230S and are disabled on the CT2239s		