


CREATIVE LABS, INC. SOUNDBLASTER AWE32 (CT2760)

Card Type	Sound card
Chip Set	Creative Technology
Maximum Onboard Memory	Unidentified
I/O Options	CD-ROM interfaces (3), microphone connector, line in connector, line out connector, speaker out connector, game/MIDI port, PC internal speaker, CD-ROM audio in connector, feature connector
Data Bus	16-bit ISA



CONNECTIONS			
Function	Label	Function	Label
Line in connector	CN1	Feature connector	CN7
Microphone connector	CN2	Panasonic CD-ROM interface	CN9
Line out connector	CN3	Sony CD-ROM interface	CN10
Speaker out connector	CN4	Mitsumi CD-ROM interface	CN11
Game/MIDI port	CN5	PC internal speaker	JP15
CD-ROM audio in connector	CN6		

USER CONFIGURABLE SETTINGS		
Function	Label	Position
í Factory configured – do not alter	CN8	Unidentified
í Factory configured – do not alter (volume)	JP9	Unidentified
í Joystick enabled	JYEN	Closed
Joystick disabled	JYEN	Open
í MP-401 enabled	MPUEN	Closed
MP-401 disabled	MPUEN	Open
í MP-401 I/O address select 330	MSEL	Closed
MP-401 I/O address select 300	MSEL	Open
í Factory configured – do not alter	SPDIF	Unidentified

Continued on next page . . .

CREATIVE LABS, INC. SOUNDBLASTER AWE32 (CT2760)

... continued from previous page

DRAM CONFIGURATION

Note: Board is factory installed with 512KB memory. The maximum amount of onboard memory is unidentified.

DRAM JUMPER CONFIGURATION

Setting	JP2
Memory upgrade disabled	Pins 2 & 3 closed
Memory upgrade enabled	Pins 1 & 2 closed

CD-ROM SELECTION

Type	J1	J2	J3	J4
Creative	Open	Open	Open	Closed
Sony	Open	Open	Closed	Open
Mitsumi	Open	Closed	Open	Open
Other	Closed	Open	Open	Open

AUDIO I/O ADDRESS SELECTION

Address	IOS0	IOS1
220	Closed	Closed
240	Open	Closed
260	Closed	Open
280	Open	Open

MITSUMI CD-ROM PORT ADDRESS SELECTION

Address	CD0	CD1
310	Closed	Closed
320	Open	Closed
340	Closed	Open
350	Open	Open

MITSUMI CD-ROM DMA CHANNEL SELECTION

Channel	DRQ6	DRQ7
6	Closed	Open
7	Open	Closed

CSP CHIP SELECTION

Setting	APSD	IFSD
Enabled	Open	Open
Disabled	Closed	Closed

MITSUMI CD-ROM INTERRUPT SELECTION

IRQ	IRQ3	IRQ10	IRQ11
3	Closed	Open	Open
10	Open	Closed	Open
11	Open	Open	Closed