

Continued on next page. . .

... continued from previous page

CONNECTIONS					
Purpose Location Purpose Location					
Network connector	CN2				

USER CONFIGURABLE SETTINGS						
Function Label Position						
í Factory configured - do not alter	W1/3	Unidentified				
í Factory configured - do not alter W1/4 Unidentified						
Internal Network Data Bus enabled W12 Closed						
Internal Network Data Bus disabled W12 Open						
Note: The number of jumpers that comprise W12 are unidentified.						

DRAM CONFIGURATION					
Size	Bank 0	Bank 1			
256KB(A)	(18) 4164	(18) 4164			
256KB(B)	(18) 41256	None			
640KB	(18) 41256	(18) 4164			
1MB (18) 41256 (18) 41256					
Note: The location of banks 0 & 1 are unidentified.					

DRAM SWITCH CONFIGURATION					
Size	W1/1	W1/2			
256KB(A)	On	On			
256KB(B)	On	Off			
640KB	Off	On			
1MB	Off	Off			

DMA CHANNEL SELECTION					
Channel	W6	W7			
0	Pins 1 & 2 closed	Pins 1 & 2 closed			
í 1	Pins 3 & 4 closed	Pins 3 & 4 closed			
2	Pins 5 & 6 closed	Pins 5 & 6 closed			
3	Pins 7 & 8 closed	Pins 7 & 8 closed			

IRQ SELECTION (TXD/RXD)				
IRQ	W8			
í 2	Pins 1 & 2 closed			
3	Pins 3 & 4 closed			
4	Pins 5 & 6 closed			
5	Pins 7 & 8 closed			

Continued on next page...

... continued from previous page

IRQ SELECTION (TIMEOUT)				
IRQ W11				
2	Pins 1 & 2 closed			
í 3	Pins 3 & 4 closed			
4	Pins 5 & 6 closed			
5	Pins 7 & 8 closed			

PORT ADDRESS SELECTION					
Setting	W9	W10			
2XXh	Pins 2 & 3 closed	N/A			
í 3XXh	Pins 1 & 2 closed	N/A			
í X8Fh	N/A	Pins 1 & 2 closed			
X9Fh	N/A	Pins 2 & 3 closed			

	NETWORK ID SELECTION							
ID	U189/1	U189/2	U189/3	U189/4	U189/5	U189/6	U189/7	U189/8
0011	Off	Off	Off	Off	Off	Off	Off	Off
0012	Off	Off	Off	Off	Off	Off	Off	Off
0013	Off	Off	Off	Off	Off	Off	Off	Off
0014	Off	Off	Off	Off	Off	Off	Off	Off
0015	Off	Off	Off	Off	Off	Off	Off	Off
0016	Off	Off	Off	Off	Off	Off	Off	Off
0017	Off	Off	Off	Off	Off	Off	Off	Off
0018	Off	Off	Off	Off	Off	Off	Off	Off

	NETWORK ID SELECTION (CON'T)							
ID	U192/1	U192/2	U192/3	U192/4	U192/5	U192/6	U192/7	U192/8
0011	Off	Off	Off	On	Off	Off	Off	On
0012	Off	Off	Off	On	Off	Off	On	Off
0013	Off	Off	Off	On	Off	Off	On	On
0014	Off	Off	Off	On	Off	On	Off	Off
0015	Off	Off	Off	On	Off	On	Off	On
0016	Off	Off	Off	On	Off	On	On	Off
0017	Off	Off	Off	On	Off	On	On	On
0018	Off	Off	Off	On	On	Off	Off	Off

	BIOS SELECTION					
Туре	W2/1	W2/2	W2/3	W2/4		
27128	On	On	Off	Off		
27256	Off	Off	On	On		

SERIAL PORT INTERRUPT SELECTION					
IRQ W4/1 W4/2 W4/3 W4/4					
Serial port 1 IRQ4	On	On	Off	Off	
Serial port 2 IRQ3	Off	Off	On	On	

Copyright © 1995, 1996, Micro House International (303) 443-3388. All rights reserved. Including the right of reproduction in any form.

Continued on next page. . .

... continued from previous page

PARALLEL PORT INTERRUPT SELECTION				
IRQ	W4/5	W4/6	W4/7	W4/8
Parallel port 1 IRQ7	On	On	Off	Off
Parallel port 2 IRQ5	Off	Off	On	On