

IBM CORPORATION
APTIVA 2136

... continued from previous page

CONNECTIONS			
Purpose	Location	Purpose	Location
Floppy drive interface	FD1	Software shutdown connector	CN14
Chassis fan power	FN1	Power LED & keylock	CN17/pins 3 - 5
VGA port	CN1	IDE interface LED	CN20
Fax/modem/voice connector	CN3	Power switch	CN21
Audio in connector	CN4	Serial port	CM1
Line in	CN5	Serial port	CM2
VGA feature connector	CN7	Green PC connector	JP19
CD-ROM audio in	CN8	Parallel port	LP1
Wavetable connector	CN10	PS/2 mouse port	MS1
IDE interface 1	CN11	Riser slot	SL1
IDE interface 2	CN12		

USER CONFIGURABLE SETTINGS		
Function	Label	Position
í On board video enabled	JP1	Pins 2 & 3 closed
On board video disabled	JP1	Pins 1 & 2 closed
í Factory configured - do not alter	JP3	Pins 1 & 2 closed
í Password enabled	JP4	Pins 1 & 2 closed
Password disabled	JP4	Pins 2 & 3 closed
í BIOS select flash BIOS	JP7	Pins 2 & 3 closed
BIOS select block ROM	JP7	Pins 1 & 2 closed
í LED select IDE & floppy LEDs	JP18	Pins 1 & 2 closed
LED select IDE LED only	JP18	Pins 2 & 3 closed
í Factory configured - Software shut down enabled	JP20	Pins 1 & 2, 4 & 5 closed
í Flash BIOS write protect disabled	JP3001	Pins 2 & 3 closed
Flash BIOS write protect enabled	JP3001	Pins 1 & 2 closed

DRAM CONFIGURATION		
Size	Bank 0	Bank 1
8MB	(2) 1M x 32	None
16MB	(2) 2M x 32	None
16MB	(2) 1M x 32	(2) 1M x 32
24MB	(2) 2M x 32	(2) 1M x 32
32MB	(2) 4M x 32	None
32MB	(2) 2M x 32	(2) 2M x 32
40MB	(2) 4M x 32	(2) 1M x 32
48MB	(2) 4M x 32	(2) 2M x 32
64MB	(2) 8M x 32	None
64MB	(2) 4M x 32	(2) 4M x 32
72MB	(2) 8M x 32	(2) 1M x 32
80MB	(2) 8M x 32	(2) 2M x 32
96MB	(2) 8M x 32	(2) 4M x 32
128MB	(2) 8M x 32	(2) 8M x 32

Note: Board accepts EDO memory. Banks are interchangeable.

Continued on next page. . .

IBM CORPORATION
 APTIVA 2136

... continued from previous page

CACHE CONFIGURATION	
Size	Bank 0
256KB	(2) 32K x 32
512KB	(2) 64K x 32

Note: The location of the cache is unidentified.

CACHE JUMPER CONFIGURATION	
Size	JP6
256KB	Pins 1 & 2 closed
512KB	Pins 2 & 3 closed

CACHE OPERATION CONFIGURATION	
Type	JP16
í Interleave burst	Pins 1 & 2 closed
Linear burst	Pins 2 & 3 closed

VIDEO MEMORY CONFIGURATION
Note: 1MB video memory is factory installed and is not configurable. The location is unidentified.

CPU SPEED SELECTION (CYRIX)					
CPU speed	Clock speed	Multiplier	JP8	JP15	JP17
120MHz	50MHz	2x	1 & 4	1 & 2	2 & 3
150MHz	60MHz	2x	2 & 5	1 & 2	2 & 3
166MHz	66MHz	2x	3 & 6	1 & 2	2 & 3

Note: Pins designated should be in the closed position.

CPU SPEED SELECTION (IBM)					
CPU speed	Clock speed	Multiplier	JP8	JP15	JP17
120MHz	50MHz	2x	1 & 4	1 & 2	2 & 3
150MHz	60MHz	2x	2 & 5	1 & 2	2 & 3
166MHz	66MHz	2x	3 & 6	1 & 2	2 & 3

Note: Pins designated should be in the closed position.

CPU SPEED SELECTION (INTEL)					
CPU speed	Clock speed	Multiplier	JP8	JP15	JP17
100MHz	66MHz	1.5x	3 & 6	1 & 2	1 & 2
120MHz	60MHz	2x	2 & 5	1 & 2	2 & 3
133MHz	66MHz	2x	3 & 6	1 & 2	2 & 3
150MHz	60MHz	2.5x	2 & 5	2 & 3	2 & 3
166MHz	66MHz	2.5x	3 & 6	2 & 3	2 & 3
200MHz	66MHz	3x	3 & 6	2 & 3	1 & 2

Note: Pins designated should be in the closed position.

Continued on next page...

IBM CORPORATION
 APTIVA 2136

... continued from previous page

CPU VOLTAGE SELECTION	
Type	JP9
Single	Pins 1 & 2, 3 & 4, 5 & 6, 7 & 8 closed
Dual	Open

CPU VOLTAGE SELECTION (SINGLE)	
Voltage	JP14
3.35v	Pins 2 & 3 closed
3.5v	Pins 1 & 2 closed

CPU VOLTAGE SELECTION (DUAL)			
Voltage	V core	JP13	JP14
3.35v	2.5v	Pins 2 & 3 closed	Pins 2 & 3 closed
3.35v	2.8v	Pins 1 & 2 closed	Pins 2 & 3 closed
3.5v	2.5v	Pins 2 & 3 closed	Pins 1 & 2 closed
3.5v	2.8v	Pins 1 & 2 closed	Pins 1 & 2 closed