COMPAQ COMPUTER CORPORATION

PROLIANT 5500 (PENTIUM II)

Device TypeMainboardProcessorPentium II Xeon

Processor Speed 400MHz
Chip Set Unidentified
Video Chip Set Unidentified
Maximum Onboard Memory 4GB


Maximum Video Memory Unidentified

Cache 256/512KB (located on the Pentium II CPU)

BIOS Unidentified

I/O Options 32-bit PCI slots (7), SCSI interfaces (4), parallel port, PS/2 mouse port, serial ports (2), VGA

port, floppy drive interface



CONNECTIONS			
Purpose	Location	Purpose	Location

Power connector	CN1	Processor power module connector	CN8
Power connector	CN2	Diskette power connector	CN9
IDE interface	CN3	Floppy drive interface	CN10
Memory board slot	CN4	Processor power module connector	CN11
Power supply signal connector	CN5	Processor power module connector	CN12
Peripheral board slot	CN6	PCI slots	PC1 - PC7
Processor power module connector	CN7		

DIMM CONFIGURATION

Note: All memory is installed on a memory expansion board.


CACHE CONFIGURATION

Note: 256KB/512KB cache is located on the Pentium II CPU.

CPU SPEED SELECTION					
Speed	SW1/1	SW1/2	SW1/3	SW1/4	
400MHz	On	On	Off	On	
450MHz	Off	On	Off	On	
500MHz	On	On	Off	Off	


DIAGNOSTIC LED(S)				
LED Color Status Condition				
LED1	LED1 Unidentified On General interlock fault has occurred			
LED1	Unidentified	Off	No fault has been detected	

DIAGNOSTIC LED(S) (CONT)							
LED2	LED3	LED4	LED5	LED6	LED7	Condition	
On	On	On	On	On	On	Fault in memory board detected	
On	On	On	On	On	Off	Fault in processor 4 detected	
On	On	On	On	Off	Off	Fault in processor 3 detected	
On	On	On	Off	Off	Off	Fault in processor 2 detected	
On	On	Off	Off	Off	Off	Fault in processor 1 detected	
On	Off	Off	Off	Off	Off	Fault in peripheral board detected	
Off	Off	Off	Off	Off	Off	f No fault has been detected	



BACKPLANE BOARD

CONNECTIONS				
Purpose Location Purpose Location				
Power connector	CN1	Power connector for removable media	CN3	
SCSI connector	CN2			



PERIPHERAL BOARD

CONNECTIONS				
Purpose Location		Purpose	Location	
SCSI port	CN1	Integrated management display connector	CN8	
VGA port	CN2	SCSI port 2 connector	CN10	
Keyboard connector	CN3	SCSI port 1 connector	CN11	
Parallel port	CN4	Power switch connector	CN15	
Serial port	CN5	Fan cable assembly connector	CN16	
PS/2 mouse port	CN6	External battery connector	CN17	
Serial port interface	CN7			

	USER CONFIGURABLE SETTINGS					
	Function	Label	Position			
»	Factroy configured - do not alter	JP1	Unidentified			
»	Factory configured - do not alter	JP2	Unidentified			
	Internal battery enabled	JP3	Closed			
	External battery enabled	JP3	Open			
»	Factory configured - do not alter	JP4	Unidentified			
»	Integrated video enabled	SW1/1	Off			

	Integrated video disabled	SW1/1	On
»	Factory configured - do not alter	SW1/2	Off
»	Board in installed in tower case	SW1/3	Off
	Board is installed in rack mount case	SW1/3	On
»	Boot from diskette is controlled by configuration	SW1/4	Off
	Boot from diskette is enabled reguardless of configuration	SW1/4	On
»	Password at power on is enabled	SW1/5	Off
	Password at power on is disabled	SW1/5	On
»	Validate NVRAM	SW1/6	Off
	Invalidate and clear NVRAM	SW1/6	On
	Invalidate and clear NVRAM	SW1/6	On