

## NEED HELP?













 [Email Us](#)













 [Find service locations](#)

The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)













CPU	Validated since PCB	Validated since BIOS	Note
Celeron 450(2.2GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	1002 <a href="#">GO</a>	
Celeron Dual Core E1500(revM0,2.2GHz,800 FSB,L2: 512K)	ALL	0402 <a href="#">GO</a>	
Celeron Dual Core E3200(revR0,2.4GHz,800 FSB,L2: 1M)	ALL	1301 <a href="#">GO</a>	
Celeron Dual Core E3300(revR0,2.5GHz,800 FSB,L2: 1M)	ALL	1301 <a href="#">GO</a>	
Celeron Dual Core E3400(revR0,2.6GHz,800 FSB,L2: 1M)	ALL	1402 <a href="#">GO</a>	
Celeron Dual Core E3500(revR0,2.7GHz,800 FSB,L2: 1M)	ALL	1402 <a href="#">GO</a>	
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0402 <a href="#">GO</a>	
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0402 <a href="#">GO</a>	
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0402 <a href="#">GO</a>	
Core 2 Duo E4500 (2.2GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0402 <a href="#">GO</a>	
Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0402	










		<a href="#">GO</a>
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,revG0)	ALL	0402 <a href="#">GO</a>
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.B2)	ALL	0402 <a href="#">GO</a>
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0402 <a href="#">GO</a>
Core 2 Duo E6320 (1.86GHz,1066FSB,L2:4MB,rev.B2)	ALL	0402 <a href="#">GO</a>
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.B2)	ALL	0402 <a href="#">GO</a>
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.L2)	ALL	0402 <a href="#">GO</a>
Core 2 Duo E6420 (2.13GHz,1066FSB,L2:4MB,rev.B2)	ALL	0402 <a href="#">GO</a>
Core 2 Duo E6550 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0402 <a href="#">GO</a>
Core 2 Duo E6600 (2.40GHz,1066FSB,L2:4MB,rev.B2)	ALL	0402 <a href="#">GO</a>
Core 2 Duo E6700 (2.66GHz,1066FSB,L2:4MB,rev.B2)	ALL	0402 <a href="#">GO</a>
Core 2 Duo E6750 (2.66GHz,1333FSB,L2:4MB,rev.G0)	ALL	0402 <a href="#">GO</a>












Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.G0)	ALL	0402 
Core 2 Duo E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)	ALL	0512 
Core 2 Duo E7300(2.66GHz,1066FSB,L2:3MB,rev.M0)	ALL	0512 
Core 2 Duo E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)	ALL	1104 
Core 2 Duo E7500(2.93GHz,1066FSB,L2:3MB,rev.R0)	ALL	1104 
Core 2 Duo E7600(3.06GHz,1066FSB,L2:3MB,rev.R0)	ALL	1104 
Core 2 Duo E8200 (2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0402 
Core 2 Duo E8300 (2.83GHz,1333FSB,L2:6MB,rev.C0)	ALL	0508 
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	1001 
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,rev.C0)	ALL	0402 
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	1001 
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,rev.C0)	ALL	0402 

Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	1001 
Core 2 Extreme QX6700(revB3,2.66GHz,1066FSB,L2:2X4MB)	ALL	0402 
Core 2 Extreme QX6800(revB3,2.93GHz,1066FSB,L2:2X4MB)	ALL	0402 
Core 2 Extreme QX6850(revG0,3.00GHz,1333FSB,L2:2X4MB)	ALL	0402 
Core 2 Extreme QX9650 (rev.C1,3.00GHz,1333FSB,L2:2X6MB,4 cores)	ALL	0402 
Core 2 Extreme QX9650(revC0,3.00GHz,1333FSB,L2:2X6MB)	ALL	0402 
Core 2 Extreme QX9770(revC1,3.2GHz,1600FSB,L2:2X6MB)	ALL	0402 
Core 2 Extreme X6800(2.93GHz,1066FSB,L2:4MB,revB2)	ALL	0402 
Core 2 Quad Q6400 (2.13GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0402 
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0402 
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0402 
Core 2 Quad Q6700 (2.66GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0402 











Core 2 Quad Q8200 (rev.M1,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1002 
Core 2 Quad Q8200 (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1104 
Core 2 Quad Q8200S (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1104 
Core 2 Quad Q8300 (rev.R0,2.50GHz,1333FSB,L2:4MB,4 cores)	ALL	1104 
Core 2 Quad Q8400 (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	1104 
Core 2 Quad Q8400S (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	1104 
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6 MB,rev.M1,4 cores)	ALL	0402 
Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	1001 
Core 2 Quad Q9400S (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	1104 
Core 2 Quad Q9450 (2.66GHz,1333FSB,L2:12MB,rev.C1)	ALL	0402 
Core 2 Quad Q9500 (2.83GHz,1333FSB,L2:6MB,rev.R0)	ALL	1301 
Core 2 Quad Q9505(rev.R0,2.83GHz,1333FSB,L2:6MB)	ALL	1203 













Core 2 Quad Q9550(2.83GHz,1333FSB,L2:12MB,rev.C1)	ALL	0402 
Core 2 Quad Q9550(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	1001 
Core 2 Quad Q9550S(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	1104 
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	1001 
P4-3.20F GHz (EM64T)	ALL	0402 
P4-3.40F GHz (EM64T)	ALL	0402 
P4-3.40GHz(FSB800, revR0)	ALL	0402 
P4-3.60F GHz (EM64T)	ALL	0402 
P4-3.80F GHz (EM64T)	ALL	0402 
P4-3.80GHz(FSB800, revR0)	ALL	0402 
P4-520/520J (2.8E GHz) (800 FSB) (D0)	ALL	0402 
P4-520/520J (2.8E GHz) (800 FSB) (E0)	ALL	0402 













P4-521(2.8GHz, 800 FSB,HT, L2 1MB)(D0,E0)	ALL	0402 
P4-530/530J (3E GHz) (800 FSB) (D0,E0)	ALL	0402 
P4-531(3GHz, 800 FSB, L2 1MB)(D0,E0)	ALL	0402 
P4-540/540J (3.2E GHz) (800 FSB) (E0,D0)	ALL	0402 
P4-541(3.2GHz, 800 FSB, L2 1MB)(E0,D0)	ALL	0402 
P4-550/550J (3.4E GHz) (800 FSB) (D0,E0)	ALL	0402 
P4-551(3.4GHz, 800 FSB, L2 1MB,D0,E0)	ALL	0402 
P4-560/560J (3.6 GHz) (800 FSB) (D0,E0)	ALL	0402 
P4-561(3.6GHz, 800 FSB, L2 1MB)	ALL	0402 
P4-570J (3.8 GHz) (800 FSB) (D0,E0)	ALL	0402 
P4-571(3.8GHz, 800 FSB, L2 1MB V E0)	ALL	0402 
P4-630 (3.0E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0402 












P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revB1)	ALL	0402 
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revC1)	ALL	0402 
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revD0)	ALL	0402 
P4-640 (3.2E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0402 
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revB1)	ALL	0402 
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revC1)	ALL	0402 
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revD0)	ALL	0402 
P4-650 (3.4E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0402 
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revB1)	ALL	0402 
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revC1)	ALL	0402 
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revD0)	ALL	0402 
P4-660 (3.6E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0402 



P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revB1)	ALL	0402 
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revC1)	ALL	0402 
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revD0)	ALL	0402 
P4-662 (3.6 GHz, 800 FSB, L2:2MB, EM64T, HT, revR0)	ALL	0402 
P4-670 (3.8 GHz, 800 FSB, L2:2MB,NO)	ALL	0402 
P4-672 (3.8 GHz, 800 FSB, L2:2MB, revR0)	ALL	0402 
Pentium D 820 (2.8 GHz, 800 FSB, revA0)	ALL	0402 
Pentium D 820 (2.8 GHz, 800 FSB, revB0)	ALL	0402 
Pentium D 830 (3.0 GHz, 800 FSB, revA0)	ALL	0402 
Pentium D 830 (3.0 GHz, 800 FSB, revB0)	ALL	0402 
Pentium D 840 (3.2 GHz, 800 FSB, revA0)	ALL	0402 
Pentium D 840 (3.2 GHz, 800 FSB, revB0)	ALL	0402 

Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0402 
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0402 
Pentium D 920(2.8GHz, 800 FSB, L2 4MB, revB1)	ALL	0402 
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0402 
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0402 
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revB1)	ALL	0402 
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revC1)	ALL	0402 
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revB1)	ALL	0402 
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revC1)	ALL	0402 
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0402 
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0402 
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revB1)	ALL	0402 

Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revC1)	ALL	0402 
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revD0)	ALL	0402 
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revC1)	ALL	0402 
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revD0)	ALL	0402 
Pentium Dual Core E2160(1.8GHz, 800FSB, L2 1MB,L2)	ALL	0402 
Pentium Dual Core E2160(1.8GHz,800FSB,L2 1MB,M0)	ALL	0402 
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0402 
Pentium Dual Core E2200(2.2GHz,800FSB,L2 1MB,M0)	ALL	0402 
Pentium Dual Core E2210(2.2GHz,800FSB,L2 1MB,R0)	ALL	1301 
Pentium Dual Core E2220(2.4GHz,800FSB,L2 1MB,M0)	ALL	0402 
Pentium Dual Core E5000 (3.4GHz,800FSB,L2:2MB,rev.R0)	ALL	1402 
Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL	1002 

Pentium Dual Core E5200(2.50GHz,800FSB,L2:2MB,rev.R0)	ALL	1203 
Pentium Dual Core E5300 (2.60GHz,800FSB,L2:2MB,rev.R0)	ALL	1104 
Pentium Dual Core E5400 (2.70GHz,800FSB,L2:2MB,rev.R0)	ALL	1104 
Pentium Dual Core E5500 (2.8GHz,800FSB,L2:2MB,rev.R0)	ALL	1402 
Pentium Dual Core E5700 (3.0GHz,800FSB,L2:2MB,rev.R0)	ALL	1402 
Pentium Dual Core E5800 (3.2GHz,800FSB,L2:2MB,rev.R0)	ALL	1402 
Pentium Dual Core E6300 (2.8GHz,1066FSB,L2:2MB,rev.R0)	ALL	1104 
Pentium Dual Core E6500 (2.93GHz,1066FSB,L2:2MB,rev.R0)	ALL	1203 
Pentium Dual Core E6600 (3.06GHz,1066FSB,L2:2MB,rev.R0)	ALL	1203 
Pentium Dual Core E6700 (3.2GHz,1066FSB,L2:2MB,rev.R0)	ALL	1402 
Pentium Dual Core E6800 (3.3GHz,1066FSB,L2:2MB,rev.R0)	ALL	1402 
Pentium Extreme Ed-840 (3.2 GHz, 800 FSB, revA0)	ALL	0402 

Pentium Extreme Ed-840 (3.2 GHz, 800 FSB, revB0)	ALL	0402 <a href="#">GO</a>
Pentium Extreme ED-955(3.46GHz, rev A0,B1)	ALL	0402 <a href="#">GO</a>
Pentium Extreme ED-965(3.73GHz, rev C1)	ALL	0402 <a href="#">GO</a>

### Shop and Learn

#### Mobile

Phones

Accessories

#### Laptops

For Home

For Work

For Creators

For Students

For Gaming

Accessories

#### Displays / Desktops

Monitors

Projectors

All-in-One PCs

Tower PCs

Gaming Tower PCs

Mini PCs

Workstations

Accessories

#### Motherboards / Components

Motherboards

Graphics Cards

Gaming Cases

Cooling

Power Supply Units

Sound Cards

Optical Drives

Data Storage

External Graphics Docks

#### Networking / IoT / Servers

WiFi 7

WiFi 6

WiFi Routers

Wired Networking

Intelligent Robots

AIoT & Industrial Solutions

Servers

Smart Home

#### Accessories

Keyboards

Mice and Mouse Pads

Headsets and Audio

Streaming Kits

Apparel Bags and Gear

Cases and Protection

Adapters and Chargers

Docks Dongles and Cable

Power Banks

Controller

Gimbal

### Learn More

Asus Design Center

ASUSPRO

Automotive Solutions

AVC Licensing Notice

ASUS Blog

### Support

Check Repair Status

Find Service Locations

Product Registration

Email Us

Call Us

Security Advisory

ASUS Support Videos

MyASUS