

# P3B-1394



ProArt

ASUS IoT

Gaming

Business

Mobile

Laptops

Displays /  
Desktops

Motherboards /  
Components

Networking /  
IoT / Servers

Accessories

Support



Product Support For

## P3B-1394

[Find Another Model >](#)

By registering your device, you can easily manage your product warranty, get technical support and keep track of your repair status.

[Register Product](#)

CPU / Memory  
Support

Driver & Utility

FAQ

Manual &  
Document

# CPU SUPPORT

CPU Support

Memory / Device Support

## NEED HELP?

The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)

[Email Us](#)

[Find service locations](#)

CPU	Validated since PCB	Validated since BIOS	Note
Celeron 1000 (socket370 with S370-DL)	ALL	2004.001 GO	

# P3B-1394

Celeron 300 (socket370 with S370-DL)	ALL	GO
Celeron 266	ALL	ALL GO
Celeron 300	ALL	ALL GO
Celeron 300A	ALL	ALL GO
Celeron 333	ALL	ALL GO
Celeron 366	ALL	ALL GO
Celeron 400	ALL	ALL GO
Celeron 433	ALL	ALL GO
Celeron 466	ALL	ALL GO
Celeron 500	ALL	ALL GO
Celeron 533	ALL	ALL GO
Celeron 533A (socket370 with S370-DL)	ALL	2004.001 GO
Celeron 566 (socket370 with S370-DL)	ALL	2004.001 GO
Celeron 600 (socket370 with S370-DL)	ALL	2004.001 GO

## P3B-1394

Celeron 667 (socket370 with S370-DL)	ALL	GO
Celeron 667 (socket370 with S370-DL)	ALL	2004.001 GO
Celeron 700 (socket370 with S370-DL)	ALL	2004.001 GO
Celeron 733 (socket370 with S370-DL)	ALL	2004.001 GO
Celeron 766 (socket370 with S370-DL)	ALL	2004.001 GO
Celeron 800 (socket370 with S370-DL)	ALL	2004.001 GO
Celeron 850 (socket370 with S370-DL)	ALL	2004.001 GO
Celeron 900 (socket370 with S370-DL)	ALL	2004.001 GO
Celeron 950 (socket370 with S370-DL)	ALL	2004.001 GO
P2-233 MHz	ALL	ALL GO
P2-266 MHz	ALL	ALL GO
P2-300 MHz	ALL	ALL GO
P2-333 MHz	ALL	ALL GO
P2-350 MHz	ALL	ALL GO

## P3B-1394

P2-400 MHz	ALL	GO
P2-450 MHz	ALL	ALL GO
P3-1.0 GHz(slot1)	ALL	2004.001 GO
P3-450 MHz(slot1)	ALL	ALL GO
P3-500 MHz(slot1)	ALL	ALL GO
P3-550 MHz(slot1)	ALL	ALL GO
P3-550E MHz(slot1)	ALL	2002.003 GO
P3-550E MHz(socket370 with S370-DL)	ALL	2002.003 GO
P3-600 MHz(slot1)	ALL	ALL GO
P3-600 MHz(socket370 with S370-DL)	ALL	ALL GO
P3-600E MHz(slot1)	ALL	2004.001 GO
P3-600E MHz(socket370 with S370-DL)	ALL	2004.001 GO
P3-650 MHz(slot1)	ALL	2004.001 GO
P3-650 MHz(socket370 with S370-DL)	ALL	2004.001 GO

# P3B-1394

P3-700 MHz(slot1)	ALL	GO
P3-700 MHz(socket370 with S370-DL)	ALL	2004.001 GO
P3-750 MHz(slot1)	ALL	2004.001 GO
P3-750 MHz(socket370 with S370-DL)	ALL	2004.001 GO
P3-800 MHz(slot1)	ALL	2004.001 GO
P3-800 MHz(socket370 with S370-DL)	ALL	2004.001 GO
P3-850 MHz(slot1)	ALL	2004.001 GO
P3-900 MHz(slot1)	ALL	2004.001 GO



## Shop and Learn

- Mobile
- Phones
- Accessories
- Accessories
- Laptops
- For Home
- For Work
- For Creators
- For Students
- For Gaming
- Accessories
- Workstations
- Accessories
- Motherboards / Components**
- Motherboards
- Graphics Cards
- Gaming Cases
- Cooling
- Power Supply Units
- Sound Cards
- Wired Networking
- Intelligent Robots
- AIoT & Industrial Solutions
- Servers
- Smart Home
- Accessories**
- Keyboards
- Mice and Mouse Pads
- Headsets and Audio


## Learn More

- Asus Design Center
- ASUSPRO
- Automotive Solutions
- AVC Licensing Notice
- Support**
- Check Repair Status
- Find Service Locations

## About Us

- About ASUS
- News
- Investor Relations
- About CSR for global
- Press Room
- ASUSTOR Inc.
- ASUS Cloud Corporation
- UniMax Electronics Inc.

## Community



# P3B-1394

	<a href="#">Networking / IoT / Servers</a>	<a href="#">Protection</a>	<a href="#">Security Advisory</a>
<a href="#">All-in-One PCs</a>	<a href="#">WiFi Routers</a>	<a href="#">Adapters and Chargers</a>	<a href="#">ASUS Support Videos</a>
<a href="#">Tower PCs</a>	<a href="#">Whole Home Mesh WiFi System</a>	<a href="#">Docks Dongles and Cable</a>	<a href="#">MyASUS</a>
<a href="#">Gaming Tower PCs</a>		<a href="#">Power Banks</a>	
<a href="#">Mini PCs</a>		<a href="#">Controller</a>	
		<a href="#">Gimbal</a>	