



Product Support For

P5KPL SE

[Find Another Model >](#)

Get Product Support

[Register Product](#)

CPU / Memory
Support

Driver & Utility

FAQ

Manual &
Document

CPU SUPPORT

CPU Support

Memory / Device Support

NEED HELP?














[Email Us](#)

[Find service locations](#)

The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)

CPU	Validated since PCB	Validated since BIOS	Not

P5KPL SE

SIZE, LGA/FS, revA1)		
		
Celeron 450(2.2GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0307 
Celeron Dual Core E1200(revM0,1.6GHz,800 FSB,L2:512K)	ALL	0307 
Celeron Dual Core E3200(revR0,2.4GHz,800 FSB,L2: 1M)	2.01G	0507 
Celeron Dual Core E3300(revR0,2.5GHz,800 FSB,L2: 1M)	2.01G	0507 
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0307 
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0307 
Core 2 Duo E4500 (2.2GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0307 
Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0307 
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,revG0)	ALL	0307 
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.B2)	ALL	0307 
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0307 
Core 2 Duo E6320 (1.86GHz,1066FSB,L2:4MB,rev.B2)	ALL	0307 

P5KPL SE

(2.13GHz,1066FSB,L2:2MB,rev.L2)



Core 2 Duo E6420
(2.13GHz,1066FSB,L2:4MB,rev.B2)

ALL

0307



Core 2 Duo E6540
(2.33GHz,1333FSB,L2:4MB,rev.G0)

ALL

0307



Core 2 Duo E6550
(2.33GHz,1333FSB,L2:4MB,rev.G0)

ALL

0307



Core 2 Duo E6600
(2.40GHz,1066FSB,L2:4MB,rev.B2)

ALL

0307



Core 2 Duo E6700
(2.66GHz,1066FSB,L2:4MB,rev.B2)

ALL

0307



Core 2 Duo E6750
(2.66GHz,1333FSB,L2:4MB,rev.G0)

ALL

0307



Core 2 Duo E6850
(3.00GHz,1333FSB,L2:4MB,rev.G0)

ALL

0307



Core 2 Duo
E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)

ALL

0307



Core 2 Duo
E7300(2.66GHz,1066FSB,L2:3MB,rev.M0)

ALL

0307



Core 2 Duo
E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)

ALL

0404



Core 2 Duo
E7500(2.93GHz,1066FSB,L2:3MB,rev.R0)

ALL

0404



Core 2 Duo
E7600(3.06GHz,1066FSB,L2:3MB,rev.R0)














2.01G

0504



0307

P5KPL SE

(2.00GHz,1333FSB,L2:6MB,rev.C0)			
Core 2 Duo E8300 (2.83GHz,1333FSB,L2:6MB,rev.C0)	ALL	0307	
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0307	
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,rev.C0)	ALL	0307	
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0307	
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,rev.C0)	ALL	0307	
Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0307	
Core 2 Extreme QX6700(revB3,2.66GHz,1066FSB,L2:2X4MB)	ALL	0307	
Core 2 Extreme QX6800(revB3,2.93GHz,1066FSB,L2:2X4MB)	ALL	0307	
Core 2 Extreme QX9650 (rev.C1,3.00GHz,1333FSB,L2:2X6MB,4 cores)	ALL	0307	
Core 2 Extreme QX9770(revC1,3.2GHz,1600FSB,L2:2X6MB)	ALL	0307	
Core 2 Extreme X6800(2.93GHz,1066FSB,L2:4MB,revB2)	ALL	0307	
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0307	

P5KPL SE

(rev.M11,2.33GHz,1333FSB,L2:4MB,4 cores)		
Core 2 Quad Q8200 (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	2.01G	0504 GO
Core 2 Quad Q8200S (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0406 GO
Core 2 Quad Q8400 (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	2.01G	0504 GO
Core 2 Quad Q8400S (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	2.01G	0504 GO
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M1,4 cores)	ALL	0307 GO
Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0307 GO
Core 2 Quad Q9400S (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0406 GO
Core 2 Quad Q9500 (2.83GHz,1333FSB,L2:6MB,rev.R0)	ALL	0509 GO
Core 2 Quad Q9505(rev.R0,2.83GHz,1333FSB,L2:6MB)	2.01G	0507 GO
Core 2 Quad Q9550(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0307 GO
Core 2 Quad Q9550S(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0406 GO
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	0307 GO

P5KPL SE

P4-521 (2.8GHz, 800 FSB,HT, L2 1MB) (D0,E0)	ALL	0307	GO
P4-531 (3GHz, 800 FSB, L2 1MB)(D0,E0)	ALL	0307	GO
P4-540/540J (3.2E GHz) (800 FSB) (E0,D0)	ALL	0307	GO
P4-551 (3.4GHz, 800 FSB, L2 1MB,D0,E0)	ALL	0307	GO
P4-551 (3.4GHz, 800 FSB, L2 1MB,G1)	ALL	0307	GO
P4-570 (3.8 GHz) (800 FSB) (E0)	ALL	0307	GO
P4-630 (3.0E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0307	GO
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revB1)	ALL	0307	GO
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revD0)	ALL	0307	GO
P4-640 (3.2E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0307	GO
P4-650 (3.4E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0307	GO
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revB1)	ALL	0307	GO









P5KPL SE

			0307
Pentium D 820 (2.8 GHz, 800 FSB, revA0)	ALL		0307 GO
Pentium D 830 (3.0 GHz, 800 FSB, revA0)	ALL		0307 GO
Pentium D 830 (3.0 GHz, 800 FSB, revB0)	ALL		0307 GO
Pentium D 840 (3.2 GHz, 800 FSB, revA0)	ALL		0307 GO
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL		0307 GO
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revD0,without VT function)	ALL		0307 GO
Pentium D 920(2.8GHz, 800 FSB, L2 4MB, revB1)	ALL		0307 GO
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL		0307 GO
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL		0307 GO
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revB1)	ALL		0307 GO
Pentium D 935(3.2GHz, 800 FSB, L2 4MB, 95W, revD0)	ALL		0307 GO
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revC1)	ALL		0307 GO

P5KPL SE

revD0, without v i function)			
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revC1)	ALL	0307	GO
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revD0)	ALL	0307	GO
Pentium Dual Core E2140(1.6GHz, 800FSB, L2 1MB,L2)	ALL	0307	GO
Pentium Dual Core E2160(1.8GHz,800FSB,L2 1MB,M0)	ALL		GO
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0307	GO
Pentium Dual Core E2200(2.2GHz,800FSB,L2 1MB,M0)	ALL	0307	GO
Pentium Dual Core E2210(2.2GHz,800FSB,L2 1MB,R0)	ALL	0602	GO
Pentium Dual Core E2220(2.4GHz,800FSB,L2 1MB,M0)	ALL	0307	GO
Pentium Dual Core E5000 (3.4GHz,800FSB,L2:2MB,rev.R0)	ALL	0602	GO
Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL	0307	GO
Pentium Dual Core E5200(2.50GHz,800FSB,L2:2MB,rev.R0)	2.01G	0504	GO
Pentium Dual Core E5300 (2.60GHz,800FSB,L2:2MB,rev.R0)	ALL	0404	GO

P5KPL SE

(2.8GHz,800FSB,L2:2MB,rev.R0)			
Pentium Dual Core E5700 (3.0GHz,800FSB,L2:2MB,rev.R0)	ALL	0602	
Pentium Dual Core E6300 (2.8GHz,1066FSB,L2:2MB,rev.R0)	2.01G	0504	
Pentium Dual Core E6500 (2.93GHz,1066FSB,L2:2MB,rev.R0)	2.01G	0507	
Pentium Dual Core E6500K (2.93GHz,1066FSB,L2:2MB,rev.R0)	2.01G	0507	
Pentium Dual Core E6600 (3.06GHz,1066FSB,L2:2MB,rev.R0)	ALL	0511	
Pentium Dual Core E6700 (3.2GHz,1066FSB,L2:2MB,rev.R0)	ALL	0602	
Pentium Dual Core E6800 (3.3GHz,1066FSB,L2:2MB,rev.R0)	ALL	0602	

Shop and Learn

- Mobile
- Phones
- Accessories
- Motherboards / Components
- Motherboards
- Graphics Cards
- Gaming Cases
- Cooling
- Workstations
- Accessories

- Wired Networking
- Intelligent Robots
- AIoT & Industrial Solutions
- Servers
- Smart Home
- Accessories
- Keyboards


Learn More

- Asus Design Center
- ASUSPRO
- Automotive Solutions
- Support
- Check Repair Status
- Find Service

About Us

- About ASUS
- News
- Investor Relations
- About CSR for global
- Press Room
- ASUSTOR Inc.
- ASUS Cloud Corporation

Community



P5KPL SE

Desktops	Data Storage	Apparels Bags and Gears	Call Us
Monitors	External Graphics Docks	Cases and Protection	Security Advisory
Projectors	Networking / IoT / Servers	Adapters and Chargers	ASUS Support Videos
All-in-One PCs	WiFi Routers	Docks Dongles and Cable	MyASUS
Tower PCs	Whole Home Mesh WiFi System	Power Banks	
Gaming Tower PCs		Controller	
Mini PCs		Gimbal	
		Display Accessories	