

P5P41TD



ProArt

Gaming

Business

Mobile

Laptops

Displays /
Desktops

Motherboards /
Components

Networking /
IoT / Servers

Accessories

Support



Product Support For

P5P41TD

[Find Another Model](#) >

Get Product Support

Register Product

CPU / Memory
Support

Driver & Utility

FAQ

Manual &
Document

CPU SUPPORT

CPU Support

Memory / Device Support

NEED HELP?

The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)

[Email Us](#)

[Find service locations](#)

CPU

Celeron 420(1.60GHz,800 FSB,L2 512KB,LGA775,revA1)

Validated since PCB

ALL

Validated since BIOS

0206

GO

P5P41TD

Celeron 430(1.80GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0206	GO
Celeron 450(2.2GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0206	GO
Celeron Dual Core E1200(revM0,1.6GHz,800 FSB,L2:512K)	ALL	0206	GO
Celeron Dual Core E1400 (revM0,2.0GHz, 800 FSB, L2: 512K)	ALL	0206	GO
Celeron Dual Core E1600(revM0,2.4GHz,800 FSB,L2: 512K)	ALL	0206	GO
Celeron Dual Core E3200(revR0,2.4GHz,800 FSB,L2: 1M)	ALL	0206	GO
Celeron Dual Core E3300(revR0,2.5GHz,800 FSB,L2: 1M)	ALL	0206	GO
Celeron Dual Core E3400(revR0,2.6GHz,800 FSB,L2: 1M)	ALL	0505	GO
Celeron Dual Core E3500(revR0,2.7GHz,800 FSB,L2: 1M)	ALL	0505	GO
Core 2 Duo E2160 (1.80GHz,800FSB,L2:1MB,65W,rev.L2)	ALL	0206	GO
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0206	GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0206	GO
Core 2 Duo E4500 (2.2GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0206	GO

P5P41TD

Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,rev.M0)	ALL	0206	GO
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,rev.G0)	ALL	0206	GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0206	GO
Core 2 Duo E6320 (1.86GHz,1066FSB,L2:4MB,rev.B2)	ALL	0206	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.L2)	ALL	0206	GO
Core 2 Duo E6540 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0206	GO
Core 2 Duo E6550 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0206	GO
Core 2 Duo E6750 (2.66GHz,1333FSB,L2:4MB,rev.G0)	ALL	0206	GO
Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.G0)	ALL	0206	GO
Core 2 Duo E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)	ALL	0206	GO
Core 2 Duo E7300(2.66GHz,1066FSB,L2:3MB,rev.M0)	ALL	0206	GO
Core 2 Duo E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)	ALL	0206	GO
Core 2 Duo E7500(2.93GHz,1066FSB,L2:3MB,rev.R0)	ALL	0206	GO

P5P41TD

Core 2 Duo E7600(3.06GHz,1066FSB,L2:3MB,rev.R0)	ALL	0206	GO
Core 2 Duo E8190(2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0206	GO
Core 2 Duo E8200 (2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0206	GO
Core 2 Duo E8300 (2.83GHz,1333FSB,L2:6MB,rev.C0)	ALL	0206	GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0206	GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,rev.C0)	ALL	0206	GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0206	GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,rev.C0)	ALL	0206	GO
Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0206	GO
Core 2 Extreme QX6800 (rev.G0,2.93GHz,1066FSB,L2:2X4MB,4 cores)	ALL	0206	GO
Core 2 Extreme QX6850(revG0,3.00GHz,1333FSB,L2:2X4MB)	ALL	0206	GO
Core 2 Extreme QX9650 (rev.C1,3.00GHz,1333FSB,L2:2X6MB,4 cores)	ALL	0206	GO
Core 2 Extreme QX9650(revC0,3.00GHz,1333FSB,L2:2X6MB)	ALL	0206	GO

P5P41TD


Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL		GO
Core 2 Quad Q6700 (2.66GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0206	GO
Core 2 Quad Q8200 (rev.M1,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0206	GO
Core 2 Quad Q8200 (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0206	GO
Core 2 Quad Q8200S (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0206	GO
Core 2 Quad Q8300 (rev.E0,2.50GHz,1333FSB,L2:4MB,4 cores)	ALL	0206	GO
Core 2 Quad Q8300 (rev.R0,2.50GHz,1333FSB,L2:4MB,4 cores)	ALL	0206	GO
Core 2 Quad Q8400 (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	0206	GO
Core 2 Quad Q8400S (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	0206	GO
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M0,4 cores)	ALL	0206	GO
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M1,4 cores)	ALL	0206	GO
Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0206	GO
Core 2 Quad Q9400S (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0206	GO

P5P41TD

Core 2 Quad Q9450 (2.66GHz,1333FSB,L2:12MB,rev.C1)	ALL	0206	GO
Core 2 Quad Q9505(rev.R0,2.83GHz,1333FSB,L2:6MB)	ALL	0206	GO
Core 2 Quad Q9550(2.83GHz,1333FSB,L2:12MB,rev.C1)	ALL	0206	GO
Core 2 Quad Q9550(rev.C0,2.83GHz,1333FSB,L2:12MB)	ALL	0206	GO
Core 2 Quad Q9550(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0206	GO
Core 2 Quad Q9550S(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0206	GO
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	0206	GO
Pentium Dual Core E2140(1.6GHz,800FSB,L2 1MB,M0)	ALL	0206	GO
Pentium Dual Core E2160(1.8GHz, 800FSB, L2 1MB,L2)	ALL	0206	GO
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0206	GO
Pentium Dual Core E2200(2.2GHz,800FSB,L2 1MB,M0)	ALL	0206	GO
Pentium Dual Core E2220(2.4GHz,800FSB,L2 1MB,M0)	ALL	0206	GO
Pentium Dual Core E5000 (3.4GHz,800FSB,L2:2MB,rev.R0)	ALL	0501	GO

P5P41TD

Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL	GO
Pentium Dual Core E5300 (2.60GHz,800FSB,L2:2MB,rev.R0)	ALL	0206 GO
Pentium Dual Core E5400 (2.70GHz,800FSB,L2:2MB,rev.R0)	ALL	0206 GO
Pentium Dual Core E5500 (2.8GHz,800FSB,L2:2MB,rev.R0)	ALL	0501 GO
Pentium Dual Core E5700 (3.0GHz,800FSB,L2:2MB,rev.R0)	ALL	0501 GO
Pentium Dual Core E6300 (2.8GHz,1066FSB,L2:2MB,rev.R0)	ALL	0206 GO
Pentium Dual Core E6500 (2.93GHz,1066FSB,L2:2MB,rev.R0)	ALL	0206 GO
Pentium Dual Core E6500K (2.93GHz,1066FSB,L2:2MB,rev.R0)	ALL	0206 GO
Pentium Dual Core E6600 (3.06GHz,1066FSB,L2:2MB,rev.R0)	ALL	0215 GO
Pentium Dual Core E6700 (3.2GHz,1066FSB,L2:2MB,rev.R0)	ALL	0501 GO
Pentium Dual Core E6800 (3.3GHz,1066FSB,L2:2MB,rev.R0)	ALL	0501 GO



Shop and Learn

- Mobile
- Workstations
- Phones
- Accessories

Learn More

- Wired Networking
- Intelligent Robots
- Asus Design Center
- ASUSPRO

About Us

- About ASUS
- News

Community



P5P41TD

For Work			Support	ASUSTOR Inc.
For Creators	Gaming Cases	Accessories	Check Repair Status	ASUS Cloud Corporation
For Students	Cooling	Keyboards	Find Service Locations	UniMax Electronics Inc.
For Gaming	Power Supply Units	Mice and Mouse Pads	Product Registration	
Accessories	Sound Cards	Headsets and Audio	Email Us	
Displays / Desktops	Optical Drives	Streaming Kits	Call Us	
Monitors	Data Storage	Apparel Bags and Gear	Security Advisory	
Projectors	External Graphics Docks	Cases and Protection	ASUS Support Videos	
All-in-One PCs	Networking / IoT / Servers	Adapters and Chargers	MyASUS	
Tower PCs	WiFi Routers	Docks Dongles and Cable		
Gaming Tower PCs	Whole Home Mesh WiFi System	Power Banks		
Mini PCs		Controller		
		Gimbal		