



## Jumpers

Jumper	Configuration
BAT1 - Clear CMOS	<b>1-2</b> : Normal operation (default) <b>2-3</b> : Clear CMOS settings (keep system unplugged for five seconds)
JP14 - Clear BIOS Password	<b>ON</b> : Keep password (default) <b>OFF</b> : Password is cleared
JUSB - Front USB	<b>1-4, 2-5</b> : Front USB enabled (upper back USB 'C' disabled) <b>2-5, 3-6</b> : Upper Back USB 'C' enabled (front USB disabled)

### SW1 - Four 2-pin jumpers to set multiplier:

Multiplier	1	2	3	4
x3.5	ON	OFF	OFF	ON
x4	ON	OFF	ON	OFF
x4.5	ON	ON	OFF	OFF
x5	ON	ON	OFF	OFF
x5.5	ON	OFF	OFF	OFF
x6	OFF	ON	ON	ON
x6.5	OFF	OFF	ON	ON