

PB5400D JUMPER SETTING AND CONNECTOR R02

1. JUMPER SETTING:

JP3	1-2: DRQ1	JP4	1-2: DACK1	
	2-3: DRQ3 **		2-3: DACK3 **	====> FOR ECP/EPP
JP6	1-2: NORMAL **			
	2-3: PROGRAMMING FLASH EPROM			
JP7	1-2: 50MHZ			
	3-4: 60MHZ **			
	1-2,5-6 : 66.6 MHZ			
JP8	OPEN : 2/3 RATIO **			
	3-4 : 1/2 RATIO			
	1-2 : 1/3 RATIO			
	1-2,3-4 : 2/5 RATIO			
JP9	OPEN : 256KB CACHE **			
	1-2 : 512KB CACHE			
	1-2,3-4: 1024KB CACHE			

CACHE SIZE	U25	U26-29,34-37
256KB	32K*8-15	32K*8-15 (MIX MODE)
512KB	32K*8-15	64K*8-15 (MIX MODE)
1024KB	32K*8-15	128K*8-15 (MIX MODE)



2. CONNECTOR:

CN1 : KEYBOARD CONN.
 CN3 : COM1
 CN4 : COM2
 CN5 : PRINT PORT
 CN6 : FDC CONN.

CN7 : SECONDARY IDE
CN8 : PRIMARY IDE
CN9 : KEYLOCK AND POWER LED CONN.
JP12: TURBO INPUT
JP10 : SPEAKER CONN.
JP11 : RESET S.W
LE2 : TURBO LED
LE1 : HDD LED
PS1 : POWER CONN.

□