

# Hardware JUMPER LIST

## Installation For PCI400

CPU	JP6	JP14	JP15	JP3	JP10	JP9	JP11	JP7	JP17
DX120	2-3	1-2, 3-4	1-2	1-2	1-2	X	2-3	1-2	1-2, 5-6
DX100	2-3	1-2, 3-4	1-2	1-2	1-2	X	2-3	1-2	1-2
DX66	2-3	1-2, 3-4	1-2	1-2	1-2	X	2-3	1-2	1-2, 5-6

JP27: CPU VOLTAGE.  
 2-3: 3.3V (DEFAULT)  
 1-2: 3.15V  
 OPEN: 3.45V (MUST SHORT JP30)

JP20/JP21: CACHE SIZE:  
 1-2/3-4 SHORT: 256K (DEFAULT)  
 1-2/1-2 SHORT: 128K

J6: RTC CLEAR  
 2-3: NORMAL OPERATION  
 3-4: CLEAR CMOS RAM (MUST ON POWER-OFF OPERATION)

JP4: FLASH BIOS WRITE ENABLE, JP4: 1-2.  
 FLASH BIOS READ ONLY: JP4: 2-3 (DEFAULT)

JP19: CPU BUS CLOCK  
 1- 2 OPEN : FOR 120MHZ CPU  
 1-2,3-4,5-6 SHORT: FOR 100/66MHZ CPU

JP18: PCI BUS CLOCK  
 1- 2: AYSNC  
 2- 3: SYNC (DEFAULT)

JP23: I/O DEVICE ENABLE  
 1- 2SHORT: ENABLE (DEFAULT)

JP28: OPEN FOR 3.3V CPU (DEFAULT)