

GND = Ground NC = Not Connected * = Active Low Signal

Printer - DB-25 Female:

1	Strobe*	14	Auto Feed*
2	Data 0	15	Fault*
3	Data 1	16	Initialize*
4	Data 2	17	Select In*
5	Data 3	18	GND
6	Data 4	19	GND
7	Data 5	20	GND
8	Data 6	21	GND
9	Data 7	22	GND
10	Acknowledge*	23	GND
11	Busy	24	GND
12	Paper Out	25	GND
13	Select		

Floppy - 34 pin card socket:

1	GND	2	RWC*
3	GND	4	NC
5	GND	6	NC
7	GND	8	Index*
9	GND	10	Motor Enable 1*
11	GND	12	Drive Select 2*
13	GND	14	Drive Select 1*
15	GND	16	Motor Enable 2*
17	GND	18	Direction*
19	GND	20	Step*
21	GND	22	Write Data*
23	GND	24	Write Enable*
25	GND	26	Track 0*
27	GND	28	Write Protect*
29	GND	30	Read Data*
31	GND	32	Side Select*
33	GND	34	Disk Change*

Keyboard - 5 pin DIN:

1	Keyboard Clock
2	Keyboard Data
3	NC
4	GND
5	+5V

Battery - 4 pin header:

1	+Voltage	2	NC
3	GND	4	GND

Speaker - 4 pin header:

1	Sound	2	NC
3	GND	4	+5V

*RWC = Reduced Write Current

Serial Port - DB-9 Male:

1	Carrier Detect
2	Receive Data
3	Transmit Data
4	Data Terminal Ready
5	Signal Ground
6	Data Set Ready
7	Request to Send
8	Clear to Send
9	Ring Indicator

Power Connector (3):

1	+12V (violet)
2	GND (black)
3	GND (black)
4	+5V (red)

(/tmc-05/01/95)

[Privacy Policy](#)