

NAVIGATOR

- Data Sheet
- BIOS Upgrades
- Driver Upgrades
- Jumper Settings
- Online Manual
- FAQs

PRODUCTS

HOME



Jumper Settings

- [J4, J8, J14, J21: CPU Voltage Select](#)
- [J5, J6, J7, J9: CPU Frequency Select](#)
- [J11: AT Bus Clock Select](#)
- [J12: SMI Select](#)

J4, J8, J14, J21: CPU Voltage Select

J4	J8	J14	J21	CPU Type
SHORT	SHORT	SHORT	SHORT	P54C
OPEN	OPEN	OPEN	OPEN	P55C

[Go to Top of Page](#)

J5, J6, J7, J9: CPU Frequency Select

J5	J6	J7	J9	CPU External Clock	CPU Speed
OPEN	OPEN	SHORT	SHORT	50MHz	Pentium 75
OPEN	OPEN	OPEN	SHORT	60MHz	Pentium 90
OPEN	OPEN	SHORT	OPEN	66MHz	Pentium 100
SHORT	OPEN	OPEN	SHORT	60MHz	Pentium 120
SHORT	OPEN	SHORT	OPEN	66MHz	Pentium 133
SHORT	SHORT	OPEN	SHORT	60MHz	Pentium 150
SHORT	SHORT	SHORT	OPEN	66MHz	Pentium 166
OPEN	SHORT	SHORT	OPEN	66MHz	Pentium 200

Please note that these settings apply to Intel Pentium processors only. Cyrix 6x86 and AMD K5 processors have SLIC (Super Low-cost Interrupt Controller) that is not compatible APIC.

[Go to Top of Page](#)

J11: AT Bus Clock Select

J11	AT Clock
OPEN	PCI Clock/3
SHORT	PCI Clock/4

[Go to Top of Page](#)

J12: SMI Select

J12	Function
Short 1-2	Single Pentium processor operation
Short 2-3	Dual Pentium processor operation

[Go to Top of Page](#)

Copyright 1996 Taiwan Mycomp Co, Ltd. All Rights Reserved. Pentium and Pentium Pro are registered trademarks of Intel Corp. All other product and brand names are trademarks and/or registered trademarks of their respective companies.