












CPU Internal Frequency	JP1	Freq.-Ratio	SW1			
			1	2	3	4
233/350MHz	66/100MHz	x 3.5	O	X	X	O
266/400MHz	66/100MHz	x 4.0	X	O	O	O
300/450MHz	66/100MHz	x 4.5	X	O	X	O
333/500MHz	66/100MHz	x 5.0	X	X	O	O
366/550MHz	66/100MHz	x 5.5	X	X	X	O
400/600MHz	66/100MHz	x 6.0	O	O	O	X
433/650MHz	66/100MHz	x 6.5	O	O	X	X
466/700MHz	66/100MHz	x 7.0	O	X	O	X
500/750MHz	66/100MHz	x 7.5	O	X	X	X
533/800MHz	66/100MHz	x 8.0	X	O	O	X

O: ON
X: OFF



SW1

-  : 233/350MHz
-  : 266/400MHz
-  : 300/450MHz
-  : 333/500MHz
-  : 366/550MHz
-  : 400/600MHz
-  : 433/650MHz
-  : 466/700MHz
-  : 500/750MHz
-  : 533/800MHz

TS-ABX CPU Freq.-Ratio DIP Switch Setting