

MAIN BOARD
User's Guide
(VER : 5V-1A)

User's Manual

The information presented in this publication has been carefully for reliability; however no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

TRADEMARKS

IBM registered trademark of International Business Machines Corp.
Intel/Pentium® registered trademark of Intel Corp.
Award registered trademark of Award Software Inc.

All other trademarks mentioned in this manual are registered property of the respective owners.

COPYRIGHT

This manual may not in whole or in part, be photocopied, reproduced transcribed translated or transmitted in whatsoever from without the written consent of the manufacturer except for Copies retained by the purchaser for personnel archival purposes.

Table of Contents

Chapter 1 Introduction.....	4
1-1 Main Features.....	5
Chapter 2	
2-1 Motherboard layout.....	6
2-2 Connectors.....	7
2-3 Jumper setting.....	9
2-4 DRAM configuration.....	12
2-5 Cache memory configuration.....	12
Chapter 3 BIOS setup.....	13
3-1 Standard CMOS setup.....	14
3-2 BIOS Features setup.....	15
3-3 Chipset Features setup.....	18
3-4 Power Management setup.....	20
3-5 PNP/PCI Configuration.....	22
3-6 Load BIOS defaults.....	23
3-7 Load Setup defaults.....	23
3-8 Integrated Peripherals.....	24
3-9 Password Setting.....	25
3-10 IDE HDD auto detection.....	26
3-11 Save & Exit Setup.....	27
3-12 Exit without Saving.....	27

Chapter 1 Introduction

The VT82C580VPX mainboard combines the advanced capabilities of the VIA Apollo VPX chipset with a high performance concurrent PCI local bus architecture to provide the ideal platform for unleashing the unsurpassed speed and power of the Intel Pentium® processor, Cyrix® 6x86 and AMD® K5/K6 processors, and can be easily upgraded for 321 pin ZIF socket.

The processor's advanced performance is complemented by a second level write back PB-SRAM up to 512KB and main memory up to 512MB RAM. The main memory is initialed using the board's two 72-pin SIMM sockets and two 168-pin DIMM sockets that accept either the new high performance EDO, BEDO, or Fast Page mode DRAM.

The VT82C580VPX integrates a full set of I/O features on board, including two 16550 UART compatible serial ports, one EPP/ECP capable port, one floppy disk controller, and one infrared communication controller. On chip built in Enhanced IDE controller provides convenient, high speed PCI bus Master connection capable of four IDE devices, including Hard disk and CD-ROM.

VIA builds all products to exacting standards, using the highest quality components available. We are proud to provide this system board and hope it brings you years of reliable service.

1-1 Main Features

- * Supports

Intel Pentium® (P54C) CPU speed 75/90/100/120/133/150/166/200/233MHZ processors in a 321 pin ZIF socket, upgradable to P54C series/P54CT/P55C (optional by splitting the voltage regulator). Cyrix®6x86/6x86L/6X86MX/MII processors AMD® K5/K6/K6-2 processors.

- *VIA Apollo VPX chipset includes a CPU interface controller, advanced cache controller, intergrated DRAM controller, asynchronous/ synchronous PCI local bus interface, intergraded power management unit, internal keyboard controller, real-time clock.

- * Support on board 256K/512K synchronous PBSRAM.

- * Support synchronous DRAM using 168-pin DIMM modules of 8,16, 32. (OPTIONAL).

- * Take up to 256MB RAM in one bank using 72-pin SIMM modules of 1, 2, 4, 8, 16, 32, 64 or 128MB with supports for EDO,BEDO or Fast Page mode memory.

- * Three 16-bit ISA expansion slots and three 32-bit PCI expansion slots.

- * Integrated Enhanced PCI local bus IDE controller with two connectors support up to four IDE devices such as Hard disk, CD-ROM.


- * Integrated ITE IT8661F/RF multi I/O chipset that offers two 16550 UART compatible serial ports, one EPP/ECP capable port, one IR port, and one Floppy Disk Drive connector.

- * Supports 128KB Flash ROM


- * PCB size : 22 x 22.5 cm.

Chapter 2


2-1 Motherboard Layout



VER. 2.2 A



VER.2.2



2-2 Connectors

CN3 - Keyboard connector

Pin	Description
1	Keyboard Clock
2	Keyboard Data
3	N.C.
4	Ground
5	+5 Vcc

CN4 - External PS/2 Mouse connector

CN5,CN6 - USB Connector (OPTIONAL)

CN7 - Power Supply Connector

Pin	Description	Pin	Description
1	Power Good	7	Ground
2	+5V DC	8	Ground
3	+12V DC	9	-5V DC
4	-12V DC	10	+5V DC
5	Ground	11	+5V DC
6	Ground	12	+5V DC

IDE1 - Primary IDE Connector

IDE2 - Secondary IDE Connector

CN9 - Floppy Disk Connector

COM1,2 - Serial Ports Connector

CN8 - Printer Port Connector

CN1 - Infrared Connector : IR

Pin	Signal Name
1	IRRX
2	Ground
3	IRTX
4	VCC
5	IRRXH
6	VCC
7	GND

2-3 Jumper Setting(5V-1A)

Intel® Pentium® Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
P54C 75 MHZ 3.3V	50 MHZ	2-3	2-3	2-3	1-2	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 90 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 100 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 120 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	2X
P54C 133 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	2X
P54C 150 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	2.5X
P54C 166 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	2.5X
P55C 166 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	7-8	1-2,3-4	1-2	2.5X
P54C 180 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	3X
P54C 200 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	3X
P55C 200 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	7-8	1-2,3-4	1-2	3X
P55C 233 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	7-8	1-2,3-4	1-2	3.5X

AMD® K5/K6/K6-2 Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
K5-PR 75 3.52V	50 MHZ	2-3	2-3	2-3	1-2	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR 90/PR120 3.52V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR100/PR133 3.52V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR166 3.52V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2.5X
K6-PR166 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	2.5X
K6-PR200 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	3X
K6-PR233 3.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	5-6,7-8	1-2,3-4	1-2	3.5X
K6-PR233 3.3V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	1-2,3-4	1-2	3.5X
K6-PR266 2.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	CLOSE	3-4	1-2,3-4	1-2	4X
K6-PR300 2.2V/3.45V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	CLOSE	3-4	1-2,3-4	2-3	4.5X
K6-2 266 2.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	CLOSE	3-4	1-2,3-4	1-2	4X
K6-2 300 2.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	CLOSE	3-4	1-2,3-4	1-2	4.5X

Cyrix® 6x86 Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
P120+ M1 3.52V	50 MHZ	2-3	2-3	2-3	1-2	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P133+ M1 3.52V	55 MHZ	2-3	2-3	1-2	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P150+ M1 3.52V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P166+ M1 3.52V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P133+ 2.8V/3.3V 6X68L	55 MHZ	2-3	2-3	1-2	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P150+ 2.8V/3.3V 6X68L	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P166+ 2.8V/3.3V 6X68L	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P200+ 2.8V/3.3V 6X68L	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
MX PR 166 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	2X
MX PR 200 2.9V/3.3V	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	2X
MX PR 233 2.9V/3.3V	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	2.5X
MII PR 300 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	3.5X

JCK1-4 - CPU Speed Selector

Jumper	50MHZ	55MHZ	60MHZ	66MHZ	75MHZ
JCK1	2-3	2-3	1-2	2-3	1-2
JCK2	2-3	2-3	2-3	1-2	2-3
JCK3	2-3	1-2	2-3	2-3	1-2
JCK4	1-2/2-3	1-2/2-3	1-2/2-3	1-2/2-3	1-2/2-3
PCICLK	25/32	7.5/32	30/32	33.3/32	37.5/32

NOTE: JCK4 is synchronous/asynchronous selection.

JPW1 , JV1, JV2- CPU Voltage Selector (FOR ONE REGULATOR)

Description	CPU Voltage	JPW1	JV1	JV2
1. P54C-STD,VR 2. AMD® K5-C,F 3. Cyrix® 6X86-016	Core: 3.3V IO: 3.3	1-2,5-6,7-8	OPEN	1-2
1. P54C-VRE 2. AMD® K5-B 3. Cyrix®6X86-028	Core: 3.4 ~ 3.6V IO: 3.4 ~ 3.6V	1-2,3-4,5-6,7-8	OPEN	1-2

(FOR TWO REGULATOR)

Description	CPU Voltage	JPW1	JV1	JV2
1. INTEL® P55C 2. AMD® K5-H,J 3. Cyrix® 6x86L	Core: 2.8V IO: 3.3V	7-8	1-2,3-4	1-2
1. AMD® K6 2. Cyrix® 6x86MX	Core: 2.9V IO: 3.3V	1-2,7-8	1-2,3-4	1-2
AMD® K6 233	Core: 3.2V IO: 3.3V	5-6,7-8	1-2,3-4	1-2
AMD® K6 300	Core: 2.2V IO: 3.45V	1-2, 7-8	1-2, 3-4	2-3

NOTE : INTEL® P55C MMX, AMD® K6 AND CYRIX® 6X86L ARE “DUAL VOLTAGE CPUs” , “6X86L” IS CYRIX® NEW LOW POWER CPU.

JBF0-JBF2 - CPU/BUS Ratio

Ratio	JBF0	JBF1	JBF2
1.5X	OPEN	OPEN	OPEN
2X	CLOSE	OPEN	OPEN
2.5X	CLOSE	CLOSE	OPEN
3X	OPEN	CLOSE	OPEN
3.5X	OPEN	OPEN	OPEN
4.0X	CLOSE	OPEN	CLOSE
4.5X	CLOSE	CLOSE	CLOSE

JBAT1 - CMOS Selector

Description	JBAT1
Normal (default)	1-2
Clear CMOS (clear password)	2-3

JROM1 - Flash ROM Voltage Selector

Description	JROM1
5V (SST,Winbond)	1-2
12V (Intel,MXIC)	2-3

JD1 - DIMM Voltage Selector

Description	JD1
5V DIMM	1-3,2-4
3.3V DIMM	5-7,6-8

2-4 DRAM Configuration

System memory RAM is comprised of industry standard 72-pin Single In-line Memory Modules (SIMMs). Burst Extended Data Out (BEDO) and Extended Data Out (EDO) memory are the latest DRAM chip designs that perform a lot better than the Fast Page mode DRAM type. With BEDO and EDO memory, CPU access to memory is 10 to 15% faster.

The VT82C580VP3 is able to support standard FPM (Fast Page Mode), EDO (Extended Data Out), or BEDO (Burst Extended Data Out); memory can be installed in a variety of cong., as show in the following table:

Total Memory	Bank 0/1 (DIMM1)	Bank 2/3 (DIMM2)	Bank4/5 (SIMM1,SIMM2)
8MB	8MB		
8MB			4MB & 4MB
12MB	8MB	4MB	
16MB	8MB	8MB	
16MB	16MB		
16MB			8MB & 8MB
24MB	16MB	8MB	
32MB	16MB	16MB	
32MB	32MB		
32MB			16MB & 16MB
40MB	32MB	8MB	
48MB	32MB	16MB	
64MB	32MB	32MB	
64MB	64MB		
64MB			32MB & 32MB
72MB	64MB	8MB	
80MB	64MB	16MB	
96MB	64MB	32MB	
128MB	64MB	64MB	
128MB			64MB & 64MB

2-5 Cache Memory Configuration

The VT82C580VP3 comes with onboard 256KB/512KB synchronous 3.3V Pipeline Burst SRAMs. Please note that for 256K secondary cache, U20 and U15 should be mounted with 32x32 PBSRAM, otherwise 64x32 PBSRAM can offer 512K secondary cache.

Chapter 3 BIOS setup

Award's ROM BIOS provides a built-in Setup program which allows user to modify the basic system configuration and hardware parameters. The modified data will be stored in a battery-backed CMOS ram so data will be retained even when the power is turned off. In general, the information saved in the CMOS ram stay unchanged unless there is config. change in the system, such as hard drive replacement or new equipment change.

It is possible that CMOS had a battery failure which cause data loss in CMOS ram. If so, re-enter system config. parameters become necessary.

TO ENTER SETUP PROGRAM

Power on the computer and press key immediately will bring you into BIOS CMOS SETUP UTILITY.

ROM PCI/ISA BIOS (2A5LXXXX) CMOS SETUP UTILITY AWARD SOFTWARE, INC.	
STANDARD CMOS SETUP	INTEGRATED PERIPHERALS
BIOS FEATURES SETUP	SUPERVISOR PASSWORD
CHIPSET FEATURES SETUP	USER PASSWORD
POWER MANAGEMENT SETUP	IDE HDD AUTO DETECTION
PNP/PCI CONFIGURATION	HDD LOW LEVEL FORMAT
LOAD SETUP DEFAULTS	SAVE & EXIT SETUP
	EXIT WITHOUT SAVING
ESC : Quit	<--> : Select Item
F10 : Save & Exit Setup	(Shift)F2 : Change Color

The menu displays all the major selection items and allows user to select any one of show item. The selection is made by moving cursor (press any direction key) to the item and press "enter" key. An on line help message is displayed at the bottom of the screen as cursor is moving to various items which provides user better understanding of each function. When a selection is made, the menu of selected item will appear so the user can modify associated configuration parameters.

3-1 Standard CMOS setup

ROM PCI/ISA BIOS (2A5LXXX)								
STANDARD CMOS SETUP								
AWARD SOFTWARE, INC.								
Date (mm:dd:yy) : Wed, Jan, 1 1997								
Time (hh:mm:ss) : 00:00:00								
HARD DISKS	TYPE	SIZE	CYLS	HEAD	PRECOMP	LANDZ	SECTOR	MODE
Primary Master :	Auto	0	0	0	0	0	0	Auto
Primary Slave :	Auto	0	0	0	0	0	0	Auto
Secondary Master :	Auto	0	0	0	0	0	0	Auto
Secondary Slave :	Auto	0	0	0	0	0	0	Auto
Driver A : 1.44M, 3.5 in								
Driver B : None		Base Memory		:		640K		
		Extended Memory		:		7168K		
Video : EGA/VGA		Other Memory		:		384K		
Halt On : All Errors		Total Memory		:		8192K		
ESC : Quit			<--> : Select Item			PU/PD/+/- : Modify		
F1 : Help			(shift)F2 : Change Color					

The Standard CMOS setup screen is displayed above, System BIOS automatically detects memory size, thus no changes are necessary, it has a few items for setting.

Each item may have one or more option settings. It allows you to change the system Date and Time, IDE hard disk, floppy disk drive types for drive A: and B: boot up video display mode, and POST error handling selection. Use the arrow keys to highlights the item and then use the <Pgup> or <Pgdn> keys to select the value you want in each item.

Hard Disk Configurations

TYPE :

Select from "1" to "45" to fill remaining fields with redefined values of disk drives. Select "User" to fill the remaining fields. Select "Auto" to detect the HDD type automatically.

SIZE :

The hard disk size. The unit is Mega Byte.

CYLS :

The cylinder number of the hard disk.

HEAD :

The read/write head number of hard disk. The range is from "1" to "16".

PRECOMP :

The cylinder number at which the disk drive changes the write timing.

LANDZ :

The cylinder number that the disk drive heads (read/write) are seated when The disk drive is parked.

SECTOR :

The sector number of each track defined on the hard disk. The range is from

"1" to "64".

Mode :

Select "AUTO" to detect the mode type automatically. If your hard disk supports the LBA mode, select "LBA" or "Large". However, if your hard disk cylinder is more than 1024 and does not support the LBA function, you have to set at "Large". Select "Normal" if your hard disk supporting cylinder is below 1024.

3-2 BIOS Features Setup

ROM PCI/ISA BIOS (2A5LXXXX)			
BIOS FEATURES SETUP			
AWARD SOFTWARE, INC.			
Virus warning	: Disabled	Video BIOS Shadow	: Enabled
CPU Internal Cache	: Enabled	C8000-CBFFF Shadow	: Disabled
External Cache	: Enabled	CC000-CFFFF Shadow	: Disabled
Quick Power On Self Test	: Disabled	D0000-D3FFF Shadow	: Disabled
Boot Sequence	: A,C,SCSI	D4000-D7FFF Shadow	: Disabled
Swap Floppy Drive	: Disabled	D8000-DBFFF Shadow	: Disabled
Boot Up Floppy Seek	: Enabled	DC000-DFFFF Shadow	: Disabled
Boot Up Numlock Status	: On		
Boot Up System Speed	: High		
Gate A20 Option	: Normal		
Typematic Rate Setting	: Disabled		
Typematic Rate (Chars/Sec)	: 6		
Typematic Delay (Msec)	: 250		
Security Option	: Setup		
IDE Second Channel Control	: Enabled		
PCI/VGA Palette Snoop	: Disabled	ESC : Quit	<--> : Select Item
OS Select for DRAM>64MB	: Non-OS2	F1 : Help	PU/PD/+/- : Modify
		F5 : Old Values	(Shift)F2 : Color
		F7 : Load Setup Defaults	

Selecting the "BIOS FEATURE SETUP" option in the CMOS setup utility menu allows user to change system related parameters in the display menu. This menu shows all of the manufacturer's default values of SV-P55V. Again, user can move the cursor by pressing direction keys and <PgDn> or <PgUp> key to modify the parameters. Pressing [F1] key to display help message of the selected item.

The setup program also provides 2 convenient ways to load the default parameter data from CMOS [F7] area if shown data is corrupted. This provides the system a capability to recover from any possible error.

Virus Warning:

When enabled, assigns the BIOS to monitor the master boot sector and the DOS boot sector of the first hard disk drive.

The options are: Enabled, Disabled (Default)

CPU Internal Cache:

When enabled, improves the system performance. Disable this item when testing or trouble-shooting.

The options are : Enabled (Default), Disabled

External Cache:

When enabled, supports an optional cache SRAM.

The options are : Enabled (Default), Disabled

Quick Power On Self Test:

When enabled, allows the BIOS to bypass the extensive memory test.

The options are : Enabled, Disabled (Default)

Boot Sequence:

Allows the system BIOS to first try to boot the operating system from the selected disk drive.

The options are : A,C,SCSI (Default); C,A,SCSI; C,CDROM,A; CDROM,C,A; D,A,SCSI; E,A,SCSI; F,A,SCSI; SCSI,A,C; SCSI,C,A; C only; LS/ZIP,C.

Swap Floppy Drive:

When enabled, allows you to switch the order in which the operating system accesses the floppy drives during boot up.

The options are : Enabled, Disabled (Default)

Boot Up Floppy Seek:

When enabled, assigns the BIOS to perform floppy diskette drive tests by issuing the time-consuming seek commands.

The options are : Enabled (Default), Disabled

Boot Up Numlock Status:

When set to On, allows the BIOS to automatically enable the Num Lock function when the system boots up.

The options are : On (Default), Off

Port 92H Fast A20G:

When enabled, allows the A20G bus line signal generated from the chipset 82C586 PC/AT to directly pass to port 92H, instead of the keyboard controller. It will speed up the system performance.

The options are : Fast, Normal(Default)

Typematic Rate Setting:

The term "typematic" means that when a keyboard key is held down, the character is repeatedly entered until the key is released. When this item is enabled, you may change the typematic repeat rate.

The options are : Disabled (Default), Enabled

Typematic Rate (Chars/Sec):

Sets the rate of a character repeat when the key is held down.

The options are : 6 (Default), 8, 10, 12, 15, 20, 24, 30

Typematic Delay (Msec):

Sets the delay time before a character is repeated.

The options are : 250 (Default), 500, 750, 1000 millisecond

Security Option:

Allows you to set the security level of the system.

The options are : Setup (Default), System

PCI/VGA Palette Snoop:

When enabled, allows you install an enhanced graphics adapter card. If your graphics adapter card does not support the Palette Snoop function, please set at Disable to avoid system malfunctions.

The options are : Enabled, Disabled (Default)

Video BIOS Shadow:

When enabled, allows the BIOS to copy the video ROM code of the add-on video cards to the system memory for faster access.

The options are : Enabled (Default), Disabled

C8000-CBFFF to DC000-DFFFF Shadow:

When enabled, allows the BIOS to copy the BIOS ROM code of the add-on card to system memory for faster access. It may improve the performance of the add-on card.

Some add-on cards will not function properly if it's BIOS ROM code is shadowed. To use these options correctly, you need to know the memory address range used by the BIOS ROM of each add-on card.

The options are : Enabled, Disabled (Default)

3-3 Chipset Features Setup

ROM PCI/ISA BIOS (2A5LXXXX) CHIPSET FEATURES SETUP AWARD SOFTWARE, INC.			
DRAM Auto Configuration	: Disabled	On Chip USB	: Disabled
DRAM Timing Control	: Normal		
SDRAM Cycle Length	: 3		
SDRAM Bank Interleave	: Disabled		
Sustained 3T write	: Disabled		
2 Bank PBSRAM	: 3-1-1-1		
Read Pipeline	: Disabled		
Write Pipeline	: Enabled		
Cache Timing	: Fast		
Linear Burst	: Disabled		
Video BIOS Cacheable	: Disabled		
System BIOS Cacheable	: Disabled		
Memory Hole At 15MB Addr.	: Disabled		
item		ESC : Quit	<--> : Select
Modify		F1 : Help	PU/PD/+/- :
Color		F5 : Old Values	(Shift)F2 :
		F7 : Load Setup Defaults	

Video BIOS Cacheable:

When enabled, allows the system to use the video BIOS codes C0000H-C7FFFH from cache, instead of the slower DRAMs or ROMs. Video BIOS must be shadowed first.

The options are : Enabled (Default), Disabled

System BIOS Cacheable:

When enabled, allows the ROM area E0000H-FFFFFH to be cacheable when cache controller is activated.

The options are : Enabled (Default), Disabled

Memory Hold At 15MB Addr.:

When enabled, the memory hole at the 15MB address will be relocated to the 15~16MB address range of the ISA cycle when the processor accesses the 15~16MB address area.

When disabled, the memory hole at the 15MB address will be treated as a DRAM cycle when the processor accesses the 15~16MB address.

The options are : Enabled, Disabled (Default)

Sustained 3T Write:

The cache architecture adopts Write Through. When Write Through is enabled, the performance is better under most application environment because the 580VP FIFO queue is deep.

The options are : Enabled, Disabled (Default)

Read/Write Pipeline:

Turn on Read/Write Pipeline operation to increase performance.

DRAM Timing Control:

Allows you to speed up the data access of 82C585M.

For example:	DRAM type	Turbo	Fast
	FP-7		V
	EDO-6	V	
	EDO-7		V

The options are : Turbo, Fast, Medium, Normal

3-4 Power Management Setup

ROM PCI/ISA BIOS (2A5LXXXX) POWER MANAGEMENT SETUP AWARD SOFTWARE, INC.			
Power Management	: User Defined	IRQ5 (LPT2)	: Primary
PM Control by APM	: Yes	IRQ6 (Floppy Disk)	: Primary
Video off Option	: Suspend->Off	IRQ7 (LPT1)	: Primary
Video off Method	: V/H SYNC+ Blank	IRQ8 (RTC Alarm)	: Disabled
Conserve Mode	: Disabled	IRQ9 (IRQ2 Redir)	: Secondary
Modem Use IRQ	: 3	IRQ10 (Reserved)	: Secondary
		IRQ11 (Reserved)	: Secondary
PM Timer		IRQ12 (PS/2 Mouse)	: Primary
HDD Power Down	: Disable	IRQ13 (Coprocessor)	: Primary
Doze Mode	: Disbale	IRQ14 (Hard Disk)	: Primary
Suspend Mode	: Disable	IRQ15 (Reserved)	: Disabled
PM Events			
VGA	: OFF		
LPT & COM	: LPT/COM		
HDD & FDD	: ON	ESC : Quit	<--> : Select Item
DMA/MASTER	: OFF	F1 : Help	PU/PD/+/- : Modify
Primary INTR	: ON	F5 : Old Values	(Shift) F2 : Color
IRQ3 (COM2)	: Primary	F7 : Load Setup Defaults	
IRQ4 (COM1)	: Primary		

Power Management:

When enable, allows you to use Power Management features.

PM Control by APM:

The option "**No**" allows the BIOS to ignore the APM (Advanced Power Management) specification. Selecting "**Yes**" will allow the BIOS wait for APM's prompt before it enters Doze mode, Standby mode, or Suspend mode. If the APM is installed, it will prompt the BIOS to set the system into the power saving mode after all tasks are done.

Video off Option:

This feature provides the selections of the video display power saving mode. The option "**Suspend -> Off**" allows the display blanks if the system enters Suspend mode. The option "**All modes -> Off**" allows the video display banks if the system enters Doze mode or Suspend mode. The option "**Always On**" allows the video display to stay in Standby mode even the system enters Doze or Suspend mode.

Video Off Method:

The option "**V/H SYNC+ Blank**" allows the BIOS to blank off screen display by turning off the V-Sync signals sent from add-on VGA card. "**DPMS Supported**" allows the BIOS to blank off screen display by your add-on VGA card which supports DPMS (Display Power Management Signaling function). "**Blank Screen**" allows the BIOS to blank screen display by turning off the red-green-blue signals.

Conserve Mode:

When the Doze Mode of the system being happened, the Doze Mode is handled by hardware not by SMI function.

Modem use IRQ:

When the system is in green function, modem wakes up the system through IRQ.

HDD Power Down:

Selecting "Disabled" will turn off the hard disk drive (HDD) motor.

Selecting "1Min ...15Min" allows you to define the HDD idle time before the HDD enters Power Saving mode.

The option "When Suspend" lets the BIOS turn the HDD motor off when the system is in Suspend mode. The options "1Min ... 15Min" and "When Suspend" will not work concurrently. When HDD is in Power Saving Mode, any access to the HDD will wake the HDD up.

Doze Mode:

When disabled, the system will not enter Doze mode. The specified time option define the idle time the system takes before it enters Doze mode.

Suspend Mode:

When disabled, the system will not enter Suspend mode. The specified time option defines the idle time the system takes before it enters Suspend mode.

VGA:

Selecting "ON" will enable the power management timers when a "no activity" events is detected in the VGA. Selecting "OFF" to disable the PM timer even if a "no activity" event is detected.

LPT & COM:

Selecting "LPT & COM" will enable the power management timers when a "no activity" event is detected in the LPT and COM ports. Selecting "LPT" ("COM") will enable the power management timers when a "no activity" event is detected in the LPT (COM) ports.

Selecting "NONE" to disable the PM timer even if a "no activity" event is detected.

HDD & FDD:

Selecting "ON" will enable the power management timers when a "no activity" event is detected in the hard disk drive and floppy disk drive. Selecting "OFF" to disable the PM timer event if a "no activity" event is detected.

DMA/Master:

When the master is working, the system will not have SMI signal until the master is finished.

Primary INTR:

When enabled, you can choose any IRQ#.

IRQ#:

When set at "Primary" the processor will power down only after the BIOS detects a "no IRQ activity" during the time specified by the Suspend time. If set at "Secondary event"

the system will distinguish whether an interrupt accesses an I/O address or not. If it does, the system enters the standby mode. If not, the system enters the dreaming mode; that is the system goes back full-on status but leaves the monitor blank. For instance, if the system connects to a LAN and receives an interrupt from its file server, the system will enter the dreaming mode to execute the corresponding calling routine.

3-5 PNP/PCI Configuration

ROM PCI/ISA BIOS (2A5LXXXX) PNP/PCI CONFIGURATION SETUP AWARD SOFTWARE, INC.			
PNP OS Installed	: No	CPU to PCI Write Buffer	: Enabled
Resources Controlled By	: Manual	PCI Dynamic Bursting	: Enabled
Reset Configuration Data	: Disabled	PCI Master 0 WS Write	: Enabled
		PCI Peer Concurrency	: Disabled
		PCI Delay Transaction	: Disabled
IRQ-3 assigned to	: Legacy ISA	PCI IRQ Activated By	: Edge
IRQ-4 assigned to	: Legacy ISA	PCI IDE IRQ Map To	: PCI-AUTO
IRQ-5 assigned to	: PCI/ISA PnP	Primary IDE INT#	: A
IRQ-7 assigned to	: Legacy ISA	Secondary IDE INT#	: B
IRQ-9 assigned to	: PCI/ISA PnP		
IRQ-10 assigned to	: PCI/ISA PnP		
IRQ-11 assigned to	: PCI/ISA PnP		
IRQ-12 assigned to	: PCI/ISA PnP		
IRQ-14 assigned to	: Legacy ISA		
IRQ-15 assigned to	: Legacy ISA		
DMA-0 assigned to	: PCI/ISA PnP	ESC : Quit	<--> : Select Item
DMA-1 assigned to	: PCI/ISA PnP	F1 : Help	PU/PD/+/- : Modify
DMA-3 assigned to	: PCI/ISA PnP	F5 : Old Valucs	(Shift) F2 : Color
DMA-5 assigned to	: PCI/ISA PnP	F7 : Load Setup Defaults	
DMA-6 assigned to	: PCI/ISA PnP		
DMA-7 assigned to	: PCI/ISA PnP		

PCI IRQ Activated By:

If your IDE cards is triggered by edge, set it at "Edge".

The options are : Level, Edge (Default)

PCI IDE IRQ Map To:

Set to auto to allow the system BIOS to automatically detect which interrupt is used by the PCI master drive.

The options are : PCI-AUTO (Default), PCI-SLOT1, PCI-SLOT2, PCI-SLOT3, PCI-SLOT4, ISA

CPU to PCI Write Buffer:

When enabled, allows data and address access to the internal buffer of 82C586A so the processor can be released from the waiting state.

The options are : Enabled (Default), Disabled

PCI Dynamic Bursting:

When enabled, the PCI controller allows Bursting PCI transfer if the consecutive PCI cycles come with the address falling in same 1KB space. This improves the PCI bus through put.

The options are : Enabled (Default), Disabled.

PCI Master 0 WS Write:

When enabled, allows a zero-wait-state-cycle delay when the PCI master drive writes data to DRAM.

The options are : Enabled, Disabled (Default)

3-6 Load BIOS Defaults

The BIOS defaults contain the most appropriate values of the system parameters that allows minimum system performance. The OEM manufacturer may change the defaults through MODBIN before the binary image burns into the ROM.

3-7 Load Setup Defaults

Selecting this field loads the factory defaults for BIOS and Chipset Features which the system automatically detects.

3-8 Integrated Peripherals

ROM PCI/ISA BIOS (2A5LXXXX) INTEGATED PERIPHEALS AWARD SOFTWARE, INC.			
OnChip IDE first channel	: Enabled	Parallel Port Mode	: SPP
Onchip IDE second channel	: Enabled		
IDE Prefetch Mode	: Enabled		
IDE HDD Block Mode	: Enabled		
IDE Primary Master PIO	: Auto		
IDE Primary Slave PIO	: Auto		
IDE Secondary Master PIO	: Auto		
IDE Secondary Slave PIO	: Auto		
IDE Primary Master UDMA	: Auto		
IDE Primary Slave UDMA	: Auto		
IDE Secondary Master UDMA	: Auto		
IDE Secondary Slave UDMA	: Auto		
Onboard FDC Controller	: Enabled		
Onboard Serial Port 1	: Auto		
Onboard Serial Port 2	: Auto	ESC : Quit	<--> : Select Item
IR Address Select	: Disable	F1 : Help	PU/PD/+/- : Modify (Shift)F2 : Color
		F5 : Old Values	
		F7 : Load Setup Default	
Onboard Parallel Port	: 378/IRQ7		

OnChip IDE First Channel:

When enabled, allows the IDE driver to use the first channel of the primary IDE.

OnChip IDE Second Channel:

When enabled, allows the IDE drive to use the second channel of the primary IDE.

IDE Prefetch Mode:

When enabled, allows the system BIOS to utilize the prefetch buffer of the onboard IDE controller to prefetch the next sequential data of the current access.

IDE Primary Slave PIO:

The default value is Auto.

Auto: BIOS will automatically detect the Onboard Primary Slave PCI IDE HDD accessing mode.

Mode 0-4 : Manually set the IDE accessing mode.

IDE Secondary Master PIO:

The default value is Auto.

Auto : BIOS will automatically detect the Onboard Secondary Master PCI IDE HDD accessing mode.

Mode 0-4 : Manually set the IDE accessing mode.

IDE Primary Master PIO:

The default value is Auto.

IDE Secondary Slave PIO:

The default value is Auto.

Onboard FDC Controller:

The default value is Enabled.

Enabled : Enabled the onboard I/O Chip's floppy drive interface controller.

Disabled : Disabled the onboard I/O Chip's floppy drive interface controller. When use on-card ISA FDC's controller.

Onboard Serial Port 1:

The field allows the user to select the serial port. The default value is AUTO.

COM1: Enable onboard serial port1 and address is COM1/3F8H

COM2: Enable onboard serial port1 and address is COM2/2F8H

COM3: Enable onboard serial port1 and address is COM3/3E8H

COM4: Enable onboard serial port1 and address is COM4/2E8H

Disabled: Disable onboard I/O Chip's Serial port 1.

AUTO : BIOS will automatically detect the Onboard Serial Port.

Onboard Serial Port 2:

The field allows the user to select the serial port. The default value is AUTO.

COM1: Enable onboard serial port1 and address is COM1/3F8H

COM2: Enable onboard serial port1 and address is COM2/2F8H

COM3: Enable onboard serial port1 and address is COM3/3E8H

COM4: Enable onboard serial port1 and address is COM4/2E8H

Disabled: Disable onboard I/O Chip's Serial port 1.

AUTO : BIOS will automatically detect the Onboard Serial Port.

Onboard Parallel Port:

The field allows the user to select the LPT port. The default value is 378H/IRQ7.

378H : Enable onboard LPT port and address is 378H and IRQ7

278H : Enable onboard LPT port and address is 278H and IRQ5

3BCH : Enable onboard LPT port and address is 3BCH and IRQ7

Disabled : Disable onboard I/O Chip's LPT port

3-9 Password Setting

1.If CMOS is corrupted or the option was not used, a default password stored in the ROM will be used. The screen will display the following message:

Enter Password

Press the [Enter] key to continue after proper password is given

2.If CMOS is corrupted or the option was used earlier and the user wish to change default password, the SETUP UTILITY will display a message and ask for a confirmation.

Confirm Password:

3.After pressing the [Enter] key (ROM password if the option was not used) or current password (user-defined password), the user can change the password and store new one in CMOS RAM. A maximum of 8 characters can be entered.

3-10 IDE HDD Auto Detection

The "**IDE HDD AUTO DETECTION**" utility is a very useful tool specially when you do not know which kind of hard disk type you are using. You can use this utility to detect the correct disk type installed in the system automatically. But now you can set HARD DISK TYPE to auto in the STANDARD CMOS SETUP. You don't need the "IDE HDD AUTO DETECTION" utility. The BIOS will Auto-detect the hard disk size and model on display during POST.

ROM PCI/ISA BIOS (2A5LXXXX) CMOS SETUP UTILITY AWARD SOFTWARE, INC.								
HARD DISK	TYPE	SIZE	CYLS	HEADS	PRECOMP	LANDZONE	SECTORS	MODE
Primary Master		343	665	16	65535	664	63	Normal
Primary Slave								
Secondary Master								
Secondary Slave								

Note: HDD modes

The Award BIOS supports 3 HDD modes : Normal, LBA&LARGE.

Normal mode:

Generic access mode in which either the BIOS or the IDE controller will make any transformations during accessing.

The maximum number of cylinders, head & sectors for Normal mode are 1024, 16 & 63.

no.Cylinder (1024)
 x no.Head (16)
 x no.Sector (63)
 x no.per sector (512)

 528 Megabytes

If user set in Normal mode, the maximum accessible HDD size will be 528 Megabyte even though its physical size may be greater than that !

LBA (Logical Block Addressing) mode:

A new HDD accessing method to overcome the 528 Megabyte bottleneck. The number of cylinders, head & sectors show in setup may not be the number physically contained in the HDD.

During HDD accessing, the IDE controller will transform the logic address described by sector, head & cylinder into its own physical address inside the HDD.

The maximum HDD size supported by LBA mode is 8.4 Gigabytes which is obtained by the following formula:

no.Cylinder (1024)
 x no.Head (255)
 x no.Sector (63)
 x bytes.per sector (512)

 8.4 Gigabytes

LARGE mode:

Extended HDD access mode supported by Award Software.

Some IDE HDDs contain more than 1024 cylinder without LBA support(in some cases, user do not want LBA). The Award BIOS provides another alternative to support these kinds of LARGE mode:

<u>CYLS.</u>	<u>HEADS</u>	<u>SECTOR</u>	<u>MODE</u>
1120	16	59	Normal
560	32	59	Large

BIOS tricks DOS (or other OS) that the number of cylinders is less than 1024 by dividing it by 2. At the same time, the number of heads is multiplied by 2. Averse transformation process will be made inside INT 12h in order to access the right HDD address the right HDD address !

```
no.Cylinder    (1024)
x no.Head      (32)
x no.Sector    (63)
x bytes.per sector (512)
-----
1 Gigabytes
```

Note:

To support LBA or LARGE mode of HDDs, there must be some softwares involved. All these softwares are located in the Award HDD Service Routine (INT 13h). It may be failed to access a HDD with LBA (LARGE) mode selected if you are runing under a operating system which replaces the whole INT 13h. UNIX operating systems do not support either or LARGE and must utilize the standard mode. UNIX can support drives large than 528MB.

3-11 Save & Exit Setup

After you have made changes under Setup, press <ESC> to return to the main menu. Move cursor to "Save and Exit Setup" or press "F10" and then press "Y" to change the CMOS setup. If you did not change anything, press <ESC> again or move cursor to "Exit Without Saving" and press "Y" to retain the Setup settings.

The following message will appear at the center of the screen to allow you to save data to CMOS and exit the setup utility.

SAVE to CMOS and EXIT (Y/N)?

3-12 Exit Without Saving

The "EXIT WITHOUT SAVING" option will bring you back to normal boot up procedure without saving any into CMOS RAM.

All of the old data in the CMOS will not be destroyed.

If you select this feature, the following message will appear at the center of the screen to allow you to exit the setup utility without saving CMOS modifications:

Quit Without Saving(Y/N)?

5V-1A-2

END

Addendum_(TEXT ERROR)

FOR PENTIUM 5V-2 MAIN BOARD (FOR ONE REGULATOR)

AMD® 5K86 Processor installation

CPU clock	SYS. clock	JCK1	JCK2	JCK3	JCK4	JBF1	JBF2	Ratio
K5-PR166	66 MHZ	2-3	1-2	2-3	1-2	close	close	2.5x

JPW1 - CPU Voltage Selector (FOR ONE REGULATOR)

Description	CPU Voltage	JPW1	JV1	JV2
3.3V (P54C-STD,VR, AMD® 5K86-C,F, Cyrix® 6X86-0	Core: 3.3V IO: 3.3	1-2	1-2,3-4	1-3,2-4
3.52V (P54C-VRE, AMD® 5K86-B, Cyrix® 6X86-028)	Core: 3.4 ~ 3.6V IO: 3.4 ~ 3.6V	3-4	1-2,3-4	1-3,2-4

FOR OLD VER JUMPER SETTING

Description	CPU Voltage	JPW1	JV1	JV2
3.3V (P54C-STD,VR, AMD® 5K86-C,F, Cyrix® 6X86-016)	Core: 3.3V IO: 3.3	1-2	1-2,3-4	1-2,3-4
3.52V (P54C-VRE, AMD® 5K86-B, Cyrix® 6X86-028)	Core: 3.4 ~ 3.6V IO: 3.4 ~ 3.6V	3-4	1-2,3-4	Open
2.8V (P55C, AMD® 5K86-H,J)	Core: 2.7 ~ 2.9V IO: 3.3V	5-6	1-2,3-4	Open
2.5V (P55C, AMD® 5K86-K)	Core: 2.5V IO: 3.3V	7-8	1-2,3-4	Open

Addendum (TEXT ERROR)

FOR PENTIUM 5V-2 MAIN BOARD (FOR TWO REGULATOR)

AMD® 5K86 Processor installation

CPU clock	SYS. clock	JCK1	JCK2	JCK3	JCK4	JBF1	JBF2	Ratio
K86-PR166	66 MHZ	2-3	1-2	2-3	1-2	close	close	2.5x

JCK1-4 - CPU Speed Selector

Jumper	50MHZ	55MHZ	60MHZ	66MHZ	75MHZ
JCK1	2-3	2-3	1-2	2-3	1-2
JCK2	2-3	2-3	2-3	1-2	2-3
JCK3	2-3	1-2	2-3	2-3	1-2
JCK4	1-2	1-2	1-2	1-2	1-2
PCICLK	25/32	27.5/32	30/32	33.3/32	37.5/32

JPW1 - CPU Voltage Selector (FOR TWO REGULATOR)

Description	CPU Voltage	JPW1	JV1	JV2
			Open	1-3,2-4
			X86-016)	
			Open	1-3,2-4
			28	
			1-2,3-4	Open
			1-2,3-4	Open

3.3V (P54C-STD,VR, AMD® 5K86-C,F, Cyrix® 6X86-016)	Core: 3.3V IO: 3.3	1-2	Open	1-3,2-4
3.52V (P54C-VRE, AMD® 5K86-B, Cyrix® 6X86-028)	Core: 3.4 ~ 3.6V IO: 3.4 ~ 3.6V	3-4	Open	1-3,2-4
2.8V (P55C, AMD® 5K86-H,J, Cyrix 6X86L)	Core: 2.8V IO: 3.3V	5-6	1-2,3-4	Open
2.5V (P55C, AMD® 5K86-K)	Core: 2.5V IO: 3.3V	7-8	1-2,3-4	Open

AMD® 5K86 Processor installation

CPU clock	SYS. clock	JCK1	JCK2	JCK3	JCK4	JBF1	JBF2	Ratio
K86-PR75	50 MHZ	2-3	2-3	2-3	1-2	open	open	1.5x
K86-PR90/PR120	60 MHZ	1-2	2-3	2-3	1-2	open	open	1.5x
K86-PR100/PR133	66 MHZ	2-3	1-2	2-3	1-2	open	open	1.5x
K86-PR166	66 MHZ	2-3	1-2	2-3	1-2	close	close	2.5x

JCK1-4 - CPU Speed Selector

Jumper	50MHZ	55MHZ	60MHZ	66MHZ	75MHZ
JCK1	2-3	2-3	1-2	2-3	1-2
JCK2	2-3	2-3	2-3	1-2	2-3
JCK3	2-3	1-2	2-3	2-3	1-2
JCK4	1-2	1-2	1-2	1-2	1-2
PCICLK	25/32	27.5/32	30/32	33.3/32	37.5/32

JPW1 - CPU Voltage Selector (FOR TWO REGULATOR)

Description	CPU Voltage	JPW1	JV1	JV2
			Open	1-3,2-4
				X86-016)
			Open	1-3,2-4

3.3V	Core: 3.3V IO: 3.3	1-2	Open	1-3,2-4
(P54C-STD,VR, AMD 5K86-C,F, Cyrix 6X86-016)				
3.52V	Core: 3.4 ~ 3.6V IO: 3.4 ~ 3.6V	3-4	Open	1-3,2-4
(P54C-VRE, 1 5K86-B, Cyrix 6X86-028)				
2.8V	Core: 2.8V IO: 3.3V	5-6	1-2,3-4	Open
(P55C, AMD 5K86-H,J)				
2.5V	Core: 2.5V IO: 3.3V	7-8	1-2,3-4	Open
(P55C, AMD 5K86-K)				

Addendum

FOR PENTIUM 5V-2 MAIN BOARD (FOR TWO REGULATOR)
PLEASE UPDATE MANUAL WITH FOLLOWING AMENDMENTS :

1. PAGE 6 : CHAPTER 2 2-1 MOTHERBOARD LAYOUT
JV2 SHOULD BE POSITIONED



2. PAGE 10 : AMD 5K86 PROCESSOR INSTALLATION

AMD 5K86 Processor installation

CPU clock	SYS. clock	JCK1	JCK2	JCK3	JCK4	JBF1	JBF2	Ratio
*K86-PR150	60 MHZ	1-2	2-3	2-3	1-2	close	close	2.5x
*K86-PR166	66 MHZ	2-3	1-2	2-3	1-2	close	close	2.5x

NOTE: " * " -- This CPU had not been tested when this manual was printed.

3. PAGE 10 : JPW1 - CPU VOLTAGE SELECTOR

JPW1 - CPU Voltage Selector (FOR TWO REGULATOR)

Description	CPU Voltage	JPW1	JV1	JV2
3.3V (P54C-STD,VR, AMD K5-C,F, Cyrix 6X86-016)	Core: 3.3V IO: 3.3	1-2	Open	1-2,3-4
3.52V (P54C-VRE, AMD K5-B, Cyrix 6X86-028)	Core: 3.4 ~ 3.6V IO: 3.4 ~ 3.6V	3-4	Open	1-2,3-4
2.8V (INTEL P55C, AMD K5-H,J, Cyrix 6x86L)	Core: 2.8V IO: 3.3V	5-6	1-2,3-4	Open
2.5V (INTEL P55C, AMD K5-K)	Core: 2.5V IO: 3.3V	7-8	1-2,3-4	Open

Addendum

FOR PENTIUM 5V-2 MAIN BOARD (FOR ONE REGULATOR)

PLEASE UPDATE MANUAL WITH FOLLWING AMENDMENTS :

1. PAGE 6 : CHAPTER 2 2-1 MOTHERBOARD LAYOUT
JV2 SHOULD BE POSITIONED



2. PAGE 10 : AMD 5K86 PROCESSOR INSTALLATION AMD 5K86
Processor installation

CPU clock	SYS. clock	JCK1	JCK2	JCK3	JCK4	JBF1	JBF2	Ratio
*K86-PR150	60 MHZ	1-2	2-3	2-3	1-2	close	close	2.5x
*K86-PR166	66 MHZ	2-3	1-2	2-3	1-2	close	close	2.5x

NOTE: " * " -- This CPU had not been tested when this manual was printed.

3. PAGE 10 : JPW1 - CPU VOLTAGE SELECTOR

JPW1 - CPU Voltage Selector (FOR ONE REGULATOR)



Description	CPU Voltage	JPW1	JV1	JV2
3.3V (P54C-STD, VR, AMD 5K86-C,F, Cyrix 6X86-016)	Core: 3.3V IO: 3.3	1-2	1-2,3-4	1-2,3-4
3.52V (P54C-VRE, AMD 5K86-B, Cyrix 6X86-028)	Core: 3.4 ~ 3.6V IO: 3.4 ~ 3.6V	3-4	1-2,3-4	1-2,3-4

Addendum

FOR PENTIUM 5V-2 MAIN BOARD (FOR TWO REGULATOR)
PLEASE UPDATE MANUAL WITH FOLLOWING AMENDMENTS :

- PAGE 6 : CHAPTER 2 2-1 MOTHERBOARD LAYOUT
JV2 SHOULD BE POSITIONED



- PAGE 10 : AMD 5K86 PROCESSOR INSTALLATION

Cyrix® 6x86 Processor installation

CPU clock	SYS. clock	JCK1	JCK2	JCK3	JCK4	JBF1	JBF2	Ratio
6X68L 133	55 MHZ	2-3	2-3	1-2	1-2	close	open	2x
6X86L 150	60 MHZ	1-2	2-3	2-3	1-2	close	open	2x
6X86L 166	66 MHZ	2-3	1-2	2-3	1-2	close	open	2x
6X86L 200	75 MHZ	1-2	2-3	1-2	1-2	close	open	2x

NOTE: " * " -- This CPU had not been tested when this manual was printed.

- PAGE 10 : JPW1 - CPU VOLTAGE SELECTOR

JPW1 - CPU Voltage Selector (FOR TWO REGULATOR)

Description	CPU Voltage	JPW1	JV1	JV2
			Open	1-2,3-4
			6-016)	
			Open	1-2,3-4
)	
			1-2,3-4	Open
			6L)	
			1-2,3-4	Open

3.3V	Core: 3.3V IO: 3.3	1-2	Open	1-3,2-4
(P54C-STD,VR, AMD K5-C,F, Cyrix 6X86-016)				
3.52V	Core: 3.4 ~ 3.6V IO: 3.4 ~ 3.6V	3-4	Open	1-3,2-4
(P54C-VRE, AMD K5-B, Cyrix 6X86-028)				
2.8V	Core: 2.8V IO: 3.3V	5-6	1-2,3-4	Open
(INTEL P55C, AMD K5-H,J, Cyrix 6x86l)				
2.5V	Core: 2.5V IO: 3.3V	7-8	1-2,3-4	Open
(INTEL P55C, AMD K5-K)				

Addendum

FOR PENTIUM 5V-2 MAIN BOARD (FOR TWO REGULATOR)
PLEASE UPDATE MANUAL WITH FOLLOWING AMENDMENTS :

AMD K5/K6 Processor installation

CPU clock	SYS. clock	JCK1	JCK2	JCK3	JCK4	JBF1	JBF2	Ratio
K6-PR166	66 MHZ	2-3	1-2	2-3	1-2	close	close	2.5x
K6-PR200	66 MHZ	2-3	1-2	2-3	1-2	open	close	3x
K6-PR233	66 MHZ	2-3	1-2	2-3	1-2	open	open	3.5x

3. PAGE 10 : JPW1 - CPU VOLTAGE SELECTOR

JPW1 - CPU Voltage Selector (FOR TWO REGULATOR)

Description	CPU Voltage	JPW1	JV1	JV2
			Open	1-2,3-4
				6-016)
			Open	1-2,3-4
)
			1-2,3-4	Open
				6L)
			1-2,3-4	Open

3.3V	Core: 3.3V IO: 3.3	1-2	Open	1-3,2-4
(P54C-STD,VR, AMD K5-C,F, Cyrix 6X86-016)				
3.52V	Core: 3.4 ~ 3.6V IO: 3.4 ~ 3.6V	3-4	Open	1-3,2-4
(P54C-VRE, AMD K5-B, Cyrix 6X86-028)				
2.8V	Core: 2.8V IO: 3.3V	5-6	1-2,3-4	Open
(INTEL P55C, AMD K5-H,J, Cyrix 6x86I)				
2.5V	Core: 2.5V IO: 3.3V	7-8	1-2,3-4	Open
(INTEL P55C, AMD K5-K)				

ADDENDUM(5V-1A VER.2.2)

PLEASE FIND THE BELOW UPDATE JUMPER SETTINGS FOR 5V-1A, VER2.2:

Intel® Pentium® Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
P54C 75 MHZ 3.3V	50 MHZ	2-3	2-3	2-3	1-2	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 90 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 100 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 120 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	2X
P54C 133 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	2X
P54C 150 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	2.5X
P54C 166 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	2.5X
P55C 166 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	7-8	1-2,3-4	1-2	2.5X
P54C 180 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	3X
P54C 200 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	3X
P55C 200 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	7-8	1-2,3-4	1-2	3X
P55C 233 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	7-8	1-2,3-4	1-2	3.5X

AMD® K5/K6 Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
K5-PR 75 3.52V	50 MHZ	2-3	2-3	2-3	1-2	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR 90/PR120 3.52V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR100/PR133 3.52V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR166 3.52V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2.5X
K6-PR166 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	2.5X
K6-PR200 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	3X
K6-PR233 3.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	5-6,7-8	1-2,3-4	1-2	3.5X
K6-PR233 3.3V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	1-2,3-4	1-2	3.5X
K6-PR266 2.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	CLOSE	3-4	1-2,3-4	1-2	4X
K6-PR300 2.2V/3.45V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	CLOSE	3-4	1-2,3-4	2-3	4.5X

Cyrix® 6x86 Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
P120+ M1 3.52V	50 MHZ	2-3	2-3	2-3	1-2	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P133+ M1 3.52V	55 MHZ	2-3	2-3	1-2	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P150+ M1 3.52V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P166+ M1 3.52V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P133+ 2.8V/3.3V 6X68L	55 MHZ	2-3	2-3	1-2	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P150+ 2.8V/3.3V 6X68L	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P166+ 2.8V/3.3V 6X68L	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P200+ 2.8V/3.3V 6X68L	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
MX PR 166 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	2X
MX PR 200 2.9V/3.3V	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	2X
MX PR 233 2.9V/3.3V	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	2.5X
MII PR 300 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	3.5X

5V-1A 2.2□ □□

□□□□ 5V-1A 2.2 □□□ □□□□□:

□□□(Intel ®)Pentium® □□□□□□□

CPU □□	□□	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	□□
P54C 75 MHZ 3.3V	50 MHZ	2-3	2-3	2-3	1-2	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 90 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 100 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 120 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	2X
P54C 133 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	2X
P54C 150 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	2.5X
P54C 166 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	2.5X
P55C 166 MHZ 2.8/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	7-8	1-2,3-4	1-2	2.5X
P54C 180 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	3X
P54C 200 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	3X
P55C 200 MHZ 2.8/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	7-8	1-2,3-4	1-2	3X
P55C 233 MHZ 2.8/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	7-8	1-2,3-4	1-2	3.5X

AMD® K5/K6 •••••••


CPU □□	□□	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	□□
K5-PR75 3.52V	50 MHZ	2-3	2-3	2-3	1-2	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR90/PR120 3.52V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR100/PR133 3.52V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR166 3.52V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2.5X
K6-PR166 2.9/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	2.5X
K6-PR200 2.9/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	3X
K6-PR233 3.2/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	5-6,7-8	1-2,3-4	1-2	3.5X
K6-PR233 3.3/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2, 5-6, 7-8	1-2, 3-4	1-2	3.5X
K6-PR266 2.2/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	CLOSE	3-4	1-2, 3-4	1-2	4X
K6-PR300 2.2/3.45V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	CLOSE	3-4	1-2, 3-4	2-3	4.5X

Cyrix® 6x86 / IBM/ SGS-Thomson •••••••

CPU □□	□□	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	□□
P120+ M1 3.52V	50 MHZ	2-3	2-3	2-3	1-2	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P133+ M1 3.52V	55 MHZ	2-3	2-3	1-2	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P150+ M1 3.52V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P166+ M1 3.52V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P133+ 2.8/3.3V 6X68L	55 MHZ	2-3	2-3	1-2	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P150+ 2.8/3.3V 6X68L	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P166+ 2.8/3.3V 6X68L	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P 200+ 2.8/3.3V 6X68L	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
MX PR 166 2.9/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	2X
MX PR 200 2.9/3.3V	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	2X
MX PR233 2.9/3.3V	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	2.5X
MII PR300 2.9/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2, 7-8	1-2, 3-4	1-2	3.5X

ADDENDUM(5V-1A VER.2.2A)

NOTE: ADD CN11 “TB-LED,” “CN10” & “CN4”



NOTE: DELETE “HDD LOW LEVEL FORMAT” IN BIOS SETUP

ADDENDUM FOR 5V-1A VER.2.2

Intel® Pentium® Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
P54C 75 MHZ 3.3V	50 MHZ	2-3	2-3	2-3	1-2	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 90 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 100 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 120 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	2X
P54C 133 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	2X
P54C 150 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	2.5X
P54C 166 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	2.5X
P55C 166 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	7-8	1-2,3-4	1-2	2.5X
P54C 180 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	3X
P54C 200 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	3X
P55C 200 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	7-8	1-2,3-4	1-2	3X
P55C 233 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	7-8	1-2,3-4	1-2	3.5X

AMD® K5/K6/K6-2 Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
K5-PR 75 3.52V	50 MHZ	2-3	2-3	2-3	1-2	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR 90/PR120 3.52V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR100/PR133 3.52V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR166 3.52V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2.5X
K6-PR166 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	2.5X
K6-PR200 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	3X
K6-PR233 3.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	5-6,7-8	1-2,3-4	1-2	3.5X
K6-PR233 3.3V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	1-2,3-4	1-2	3.5X
K6-PR266 2.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	CLOSE	3-4	1-2,3-4	1-2	4X
K6-PR300 2.2V/3.45V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	CLOSE	3-4	1-2,3-4	2-3	4.5X
K6-2 266 2.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	CLOSE	3-4	1-2,3-4	1-2	4X

Cyrix® 6x86 Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
P120+ M1 3.52V	50 MHZ	2-3	2-3	2-3	1-2	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P133+ M1 3.52V	55 MHZ	2-3	2-3	1-2	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P150+ M1 3.52V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P166+ M1 3.52V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P133+ 2.8V/3.3V 6X68L	55 MHZ	2-3	2-3	1-2	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P150+ 2.8V/3.3V 6X68L	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P166+ 2.8V/3.3V 6X68L	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P200+ 2.8V/3.3V 6X68L	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
MX PR 166 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	2X
MX PR 200 2.9V/3.3V	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	2X
MX PR 233 2.9V/3.3V	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	2.5X
MII PR 300 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	3.5X

Intel® Pentium® Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
P54C 75 MHZ 3.3V	50 MHZ	2-3	2-3	2-3	1-2	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 90 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 100 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	1.5X
P54C 120 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	2X
P54C 133 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,5-6,7-8	OPEN	1-2	2X
P54C 150 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	2.5X
P54C 166 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	2.5X
P55C 166 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	7-8	1-2,3-4	1-2	2.5X
P54C 180 MHZ 3.3V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	3X
P54C 200 MHZ 3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	1-2,5-6,7-8	OPEN	1-2	3X
P55C 200 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	7-8	1-2,3-4	1-2	3X
P55C 233 MHZ 2.8V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	7-8	1-2,3-4	1-2	3.5X

AMD® K5/K6/K6-2 Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
K5-PR 75 3.52V	50 MHZ	2-3	2-3	2-3	1-2	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR 90/PR120 3.52V	60 MHZ	1-2	2-3	2-3	2-3	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR100/PR133 3.52V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	1.5X
K5-PR166 3.52V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2.5X
K6-PR166 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	2.5X
K6-PR200 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	3X
K6-PR233 3.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	5-6,7-8	1-2,3-4	1-2	3.5X
K6-PR233 3.3V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,5-6,7-8	1-2,3-4	1-2	3.5X
K6-PR266 2.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	CLOSE	3-4	1-2,3-4	1-2	4X
K6-PR300 2.2V/3.45V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	CLOSE	3-4	1-2,3-4	2-3	4.5X
K6-2 266 2.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	CLOSE	3-4	1-2,3-4	1-2	4X


Cyrix® 6x86 Processor Installation

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO
P120+ M1 3.52V	50 MHZ	2-3	2-3	2-3	1-2	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P133+ M1 3.52V	55 MHZ	2-3	2-3	1-2	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P150+ M1 3.52V	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P166+ M1 3.52V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,3-4,5-6,7-8	OPEN	1-2	2X
P133+ 2.8V/3.3V 6X68L	55 MHZ	2-3	2-3	1-2	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P150+ 2.8V/3.3V 6X68L	60 MHZ	1-2	2-3	2-3	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P166+ 2.8V/3.3V 6X68L	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
P200+ 2.8V/3.3V 6X68L	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	OPEN	OPEN	7-8	1-2,3-4	1-2	2X
MX PR 166 2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	2X
MX PR 200 2.9V/3.3V	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	2X
MX PR 233 2.9V/3.3V	75 MHZ	1-2	2-3	1-2	2-3	CLOSE	CLOSE	OPEN	1-2,7-8	1-2,3-4	1-2	2.5X

MII PR 300	2.9V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	OPEN	OPEN	OPEN	1-2,7-8	1-2,3-4	1-2	3.5X
------------	-----------	--------	-----	-----	-----	-----	------	------	------	---------	---------	-----	------

ADDENDUM (5V-1A ver. 2.2A)

Reg: case connector




Reg: AMD® K6-2 300

CPU CLOCK	SYS. CLOCK	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	RATIO	
K6-2 300	2.2V/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	CLOSE	3-4	1-2,3-4	1-2	4.5X

□□ (5V-1A ver. 2.2A)

□: □□□□□□



□: AMD® K6-2 300 □□

CPU □□	□□	JCK1	JCK2	JCK3	JCK4	JBF0	JBF1	JBF2	JPW1	JV1	JV2	□□	
K6-2 300	2.2/3.3V	66 MHZ	2-3	1-2	2-3	2-3	CLOSE	CLOSE	CLOSE	3-4	1-2, 3-4	1-2	4.5X