

# Preface

## Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the material contained herein, may be reproduced without written consent of the author.

Version 1.0

## Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaim any implied warranties of merchantability or fitness for any particular purpose. The manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

## Trademark Recognition

Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corp.

MMX, Pentium, Pentium-II, Pentium-III, Celeron are registered trademarks of Intel Corporation.

Other product names used in this manual are the properties of their respective owners and are acknowledged.

## Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment onto an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interconnect cables and a shielded AC power cable must be employed with this equipment to ensure compliance with the pertinent RF emission limits governing this device. Changes or modifications not expressly approved by the system's manufacturer could void the user's authority to operate the equipment.

## Declaration of Conformity

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

## Canadian Department of Communications

This class B digital apparatus meets all requirements of the Canadian Interference-causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

## About the Manual

The manual consists of the following:

<b>Chapter 1</b> <b>Introducing the Motherboard</b>	Describes features of the motherboard, and provides a shipping checklist.  Go to ⇒ page 1
<b>Chapter 2</b> <b>Installing the Motherboard</b>	Describes installation of motherboard components.  Go to ⇒ page 7
<b>Chapter 3</b> <b>Using BIOS</b>	Provides information on using the BIOS Setup Utility.  Go to ⇒ page 24
<b>Chapter 4</b> <b>Using the Motherboard Software</b>	Describes the motherboard software.  Go to ⇒ page 46

## Features Translations

### Caractéristiques

<b>Processeur</b>	<p>La carte mère utilise un Socket micro PGA 478 broches présentant les caractéristiques suivantes :</p> <ul style="list-style-type: none"> <li>• Supporte un bus frontal (FSB) de 400/533 MHz</li> <li>• Accepte des processeurs Pentium 4 à 1.5G/1.6G/1.7G... 3.06G et plus</li> </ul>
<b>Chipset</b>	<p>Les chipsets <b>SiS650GX B0</b> Northbridge et <b>SiS962L</b> Southbridge sont basés sur une architecture novatrice et dimensionnable avec une fiabilité et des performances prouvées.</p> <ul style="list-style-type: none"> <li>• Supporte les CPU de la série Intel Pentium 4 avec des vitesses de transfert de 533/ 400MHz</li> <li>• Support de 12 transactions remarquables</li> <li>• Supporte les SDRAM DDR333/DDR266/200</li> <li>• Conforme AGP v2.0</li> <li>• Supporte la Taille de Fenêtre Graphique de 4Moctets à 256Moctets</li> <li>• Réalise une bande passante de 533Mo/s en mode 66MHz x 4</li> <li>• Intègre un moteur 3D de haute qualité</li> <li>• Conforme aux spécifications PCI 2.2</li> <li>• Supporte le mode PIO 0,1,2,3,4 et le mode DMA Multi-word 0,1,2</li> <li>• Supporte Ultra DMA 33/66/100/133</li> <li>• Trois contrôleurs d'hôte OHCI USB 1.1 indépendant et un contrôleur d'hôte EHCI USB 2.0, supporte jusqu'à six ports</li> <li>• Événements d'éveil système inclus : Bouton d'alimentation, mot de passe de clavier/touche de raccourci, alarme RTC, sonnerie Modem, LAN, Eveil AC 97 et éveil USB</li> </ul> <p>Les caractéristiques clé supplémentaires de la carte mère comprennent le support de six ports USB, une liaison AC' 97 pour audio et modem, surveillance matérielle, et gestion d'alimentation ACPI/OnNow.</p>
<b>Memory</b>	<p>La carte mère supporte une SDRAM DDR 266/333. It accommodates two unbuffered 2.5V 184-pin slots. Each slot supports up to 1 GB with a total maximum capacity of 2 GB.</p>
<b>Graphiques</b>	<p>La carte mère comprend un logement AGP qui offre quatre fois la bande passante des spécifications AGP d'origine. AGP technology provides a direct connection between the graphics sub-system and the processor so that the graphics do not have to compete for processor time with other devices on the PCI bus.</p>
<b>USB</b>	<p>The USB 2.0 Controller is compliant with Universal Serial Bus Specification Revision 2.0.</p> <p>The USB 2.0 supports data transfer rates up to 480MB/sec for high-speed devices and specifies a microframe that will be 1/8<sup>th</sup> of a 1msec frame. This allows the USB 2.0 devices to</p>

	<p>have small buffers even at high data rates.</p> <p>The USB 1.1 connectors and other full speed cables can support the higher speed of USB 2.0 without any changes.</p> <p>The chipset has the following advanced USB features:</p> <ul style="list-style-type: none"> <li>• Compliant with Enhanced Host Controller Interface (EHCI) Specification Revision 0.95 and Universal Host Controller Interface (UHCI) Specification Revision 1.1</li> <li>• PCI multi-function device consists of two UHCI Host Controllers for full/low-speed signaling and one EHCI Host Controller core for high-speed signaling</li> <li>• Supports PCI-Bus Power Management Interface Specification release 1.1</li> <li>• Legacy support for all downstream facing ports</li> </ul>
<b>AC' 97 Audio Codec</b>	<p>Le codec Audio AC' 97 est conforme aux spécifications AC 97 2.3 répondant aux exigences PC2001 et supportant Sortie S/PDIF. Il possède aussi une mémoire tampon intégrée et PLL interne. Les fonctionnalités comprennent le support du commutateur analogique pour sortie arrière (partagée), la prise de ligne d'entrée (partagée), centre basse (partagée), et prise MIC à la sortie audio 6 canaux.</p> <p><b>Remarque:</b> Contrôleur audio 4 canaux optionnel.</p>
<b>LAN Interne (optionnel)</b>	<p>Le VT6103 L est un périphérique à Couche Physique pour Ethernet 10BASE-T et 100BASE-TX utilisant des câbles Non blindés de catégorie 5, Blindés de Type 1, et à Fibres Optiques.</p> <ul style="list-style-type: none"> <li>• Double Vitesse – 100/10 Mbps</li> <li>• Half et Full Duplex</li> <li>• Interface MII vers Contrôleur Ethernet</li> <li>• Conforme à tous les Standards IEEE 802.3, 10Base-T et 100Base-Tx Applicables</li> </ul>
<b>Options d'Extensions</b>	<p>La carte mère est livrée avec les options d'extensions suivantes:</p> <ul style="list-style-type: none"> <li>• Deux logements PCI 32 bits</li> <li>• Un logement AGP</li> <li>• Un logement de Communications et Network Riser (CNR) (Interface AC97 seulement)</li> <li>• Deux canaux IDE et une interface de lecteur de disquette</li> </ul> <p>La carte mère supporte la maîtrise de bus Ultra DMA avec des vitesses de transfert de 33/66/100/133 Mo/sec.</p>
<b>E/S Intégrée</b>	<p>La carte mère possède un jeu complet de ports d'E/S et de connecteurs:</p> <ul style="list-style-type: none"> <li>• Deux ports PS/2 pour souris et clavier</li> <li>• Un port série</li> <li>• Un port VGA</li> <li>• Un port parallèle</li> <li>• Quatre ports USB</li> <li>• Un port LAN</li> <li>• Prises audio pour microphone, ligne d'entrée et ligne de sortie</li> </ul>
<b>Microprogramme BIOS</b>	<p>Cette carte mère utilise Award BIOS qui permet aux utilisateurs de configurer de nombreuses caractéristiques du système comprenant les suivantes:</p>

- |  |                                                                                                                                                                                 |
|--|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <ul style="list-style-type: none"><li>• Gestion d'alimentation</li><li>• Alarmes de réveil</li><li>• Paramètres de CPU</li><li>• Synchronisation de CPU et de mémoire</li></ul> |
|--|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Le microprogramme peut aussi être utilisé pour définir les paramètres pour les vitesses d'horloges de différents processeurs.



Certaines spécifications matérielles et éléments de logiciels peuvent être modifiés sans avertissement.

## Features

<b>Prozessor</b>	<p>Das Motherboard verwendet einen Mikro-PGA 478-Pin Sockel mit den folgenden Eigenschaften:</p> <ul style="list-style-type: none"> <li>• Unterstützt 400/533 MHz Frontsidebus (FSB)</li> <li>• Nimmt Pentium 4 Prozessoren mit 1.5G/1.6G/1.7G... 3.05G und darüber auf</li> </ul>
<b>Chipsatz</b>	<p>Die Chipsätze <b>SiS650GX B0</b> Northbridge und <b>SiS962L</b> Southbridge basieren auf einer innovativen und skalierbaren Architektur mit bewiesener Zuverlässigkeit und Leistung.</p> <ul style="list-style-type: none"> <li>• Unterstützt CPU der Intel Pentium 4 Serie mit Datentransferraten von 533/ 400MHz</li> <li>• Unterstützt 12 Outstanding-Transactions</li> <li>• Unterstützt DDR333/DDR266/200 SDRAM</li> <li>• Entspricht AGP v2.0</li> <li>• Unterstützt Graphic Window Size von 4Mbytes bis zu 256Mbytes</li> <li>• Leistung von 533MB/s Bandbreite im 66MHz x 4-Modus</li> <li>• Hochwertiger 3D-Engine integriert</li> <li>• Entspricht PCI 2.2 Spezifikation</li> <li>• Unterstützt PIO-Modus 0,1,2,3,4 und Multiword DMA-Modus 0,1,2</li> <li>• Unterstützt Ultra DMA 33/66/100/133</li> <li>• Drei unabhängige OHCI USB 1.1 Host-Controller und ein EHCI USB 2.0 Host-Controller unterstützen bis zu sechs Schnittstellen</li> <li>• System-Wake-up-Events umfassen: Netzschalter, Tastatur-Kennwort/Hotkey, RTC-Alarm, Modem-Anruf, LAN, AC 97-Wake-up und USB-Wake up</li> </ul> <p>Zusätzliche Schlüsseleigenschaften des Motherboards umfassen die Unterstützung für sechs USB-Anschlüsse, ein AC 97-Link für Audio und Modem, Hardwareüberwachung und ACPI/OnNow-Energieverwaltung.</p>
<b>Speicher</b>	<p>Das Motherboard unterstützt DDR 266/333 SDRAM. Es nimmt zwei ungepufferte 2.5V 184-Pin Steckplätze auf. Jeder Steckplatz unterstützt bis zu 1 GB, mit einer maximalen Kapazität von insgesamt 2 GB.</p>
<b>USB</b>	<p>Der USB 2.0 Controller entspricht der Universal Serial Bus Spezifikation Revision 2.0.</p> <p>USB 2.0 unterstützt Datentransferraten von bis zu 480MB/Sek. für Hochgeschwindigkeitsgeräte und spezifiziert einen Mikroframe, der 1/8 eines 1msek Frames darstellt. Dies erlaubt kleine Puffer für die USB 2.0-Geräte selbst bei hohen Datenraten.</p> <p>Die USB 1.1-Anschlüsse und andere Vollgeschwindigkeitskabel unterstützen die höhere Geschwindigkeit von USB 2.0 ohne Änderungen.</p> <p>Der Chipsatz verfügt über die folgenden erweiterten USB-Merkmale:</p> <ul style="list-style-type: none"> <li>• Entspricht Enhanced Host Controller Interface (EHCI) Spezifikation Revision 0.95 und Universal Host Controller Interface (UHCI) Spezifikation Revision 1.1</li> <li>• Multifunktions-PCI-Gerät besteht aus zwei UHCI Host-</li> </ul>

	<p>Controllern für Signalübertragung bei voller und niedriger Geschwindigkeit sowie einem EHCI-Host</p> <ul style="list-style-type: none"> <li>• Controllerkern für Hochgeschwindigkeits-Signalübertragung</li> <li>• Unterstützt PCI-Bus Power Management Interface Spezifikation Ausgabe 1.1</li> <li>• Legacy-Unterstützung für alle Downstream-Ports</li> </ul>
<b>Grafik</b>	<p>Das Motherboard enthält einen 4x AGP-Steckplatz mit der vierfachen Bandbreite der ursprünglichen AGP-Spezifikation. AGP-Technologie bietet eine direkte Verbindung zwischen dem Grafiksbus und dem Speicher, so dass die Grafik nicht mit anderen Geräten auf dem PCI-Bus um Prozessorzeit wetteifern muss.</p>
<b>AC' 97 Audio Codec</b>	<p>Der AC' 97 Audio-Codec ist kompatibel mit der AC' 97-Spezifikation für PC2001 und unterstützt S/PDIF Out. Weiterhin verfügt es über einen internen Puffer und PLL. Seine Funktionen umfassen Unterstützung für analogen Switch für den Hinterausgang (gemeinsam), die Line-in-Buchse (gemeinsam), Mitte/Bass (gemeinsam) und die MIC-Buchse für 6-Kanal-Audioausgang.</p> <p><b>Anmerkung:</b> Optionaler 4-Kanal Audiocontroller.</p>
<b>Integriertes LAN (optional)</b>	<p>Das VT6103L ist ein Physical-Layer-Gerät für Ethernet 10BASE-T und 100BASE-TX bei Benutzung von nicht abgeschirmten Kategorie 5-Kabeln, abgeschirmten Typ 1-Kabeln und Glasfaserkabeln.</p> <ul style="list-style-type: none"> <li>• Zwei Geschwindigkeiten – 100/10 MB/Sek.</li> <li>• Halb- und Vollduplex</li> <li>• MII Interface-zu-Ethernet Controller</li> <li>• Entspricht allen geltenden IEEE 802.3, 10Base-T und 100Base-Tx-Standards</li> </ul>
<b>Erweiterungsoptionen</b>	<p>Das Motherboard bietet die folgenden Erweiterungsoptionen:</p> <ul style="list-style-type: none"> <li>• Zwei 32-bit PCI-Steckplätze</li> <li>• Ein AGP-Steckplatz</li> <li>• Einen Steckplatz für Communications und Network Riser (CNR) (nur AC97 Interface)</li> <li>• Zwei IDE-Kanäle und eine Schnittstelle für ein Floppydiskettenlaufwerk</li> </ul> <p>Das Motherboard unterstützt Ultra DMA Bus-Mastering mit Übertragungsraten von 33/66/100/133 MB/s.</p>
<b>Integrierte I/O</b>	<p>Das Motherboard verfügt über einen kompletten Satz von I/O-Schnittstellen und Anschlüssen:</p> <ul style="list-style-type: none"> <li>• Zwei PS/2-Schnittstellen für Maus und Tastatur</li> <li>• Eine serielle Schnittstelle</li> <li>• Einen VGA-Anschluss</li> <li>• Eine parallele Schnittstelle</li> <li>• Vier USB-Schnittstellen</li> <li>• Eine LAN-Schnittstelle</li> <li>• Audiobuchsen für Mikrofon, Line-in und Line-out</li> </ul>
<b>BIOS Firmware</b>	<p>Dieses Motherboard setzt das Award BIOS ein, mit dem der Anwender viele Systemeigenschaften selbst konfigurieren kann, einschließlich der folgenden:</p> <ul style="list-style-type: none"> <li>• Energieverwaltung</li> <li>• Wake-up Alarm</li> </ul>

- |  |                                                                                                   |
|--|---------------------------------------------------------------------------------------------------|
|  | <ul style="list-style-type: none"><li>• CPU-Parameter</li><li>• CPU- und Speichertiming</li></ul> |
|--|---------------------------------------------------------------------------------------------------|

Mit der Firmware können auch die Parameter für verschiedene Prozessortaktgeschwindigkeiten eingestellt werden.



Bestimmte Hardwarespezifikationen und Teile der Softwareausstattung können ohne weitere Ankündigung abgeändert werden.



## Caratteristiche

<b>Processor</b>	<p>La scheda madre usa un socket micro PGA 478-pin con le seguenti caratteristiche:</p> <ul style="list-style-type: none"> <li>• Supporto per il bus di sistema frontside (FSB) 400/533 MHz</li> <li>• Alloggia processori Pentium 4 a 1,5G/1,6G/1,7G... 3,08G e superiore</li> </ul>
<b>Chipset</b>	<p>I chipset <b>SiS650GX B0</b> Northbridge e <b>SiS962L</b> Southbridge sono basati su un'architettura innovativa e scalabile di provata affidabilità e di eccellenti prestazioni.</p> <ul style="list-style-type: none"> <li>• Supporto per le CPU della serie Pentium 4 con velocità di trasferimento dati fino a 533/400MHz</li> <li>• Supporta 12 transazioni in esecuzione</li> <li>• Supporta DDR333/DDR266/200 SDRAM</li> <li>• AGP v2.0 Compatibile</li> <li>• Supporta una finestra grafica da 4MBytes a 256MBytes</li> <li>• Funzionamento a 533MB/s di larghezza di banda nella modalità 66MHz x 4</li> <li>• Motore 3D integrato di altissima qualità</li> <li>• Conforme alle specifiche PCI 2.2</li> <li>• Supporta le modalità PIO 0,1,2,3,4 e le modalità Multiword DMA 0,1,2</li> <li>• Supporta Ultra DMA 33/66/100/133</li> <li>• Tre interfacce OHCI USB 1.1 indipendenti e una interfaccia EHCI USB 2.0, con supporto fino a sei porte</li> <li>• Gli eventi wake-up del sistema includono: Pulsante di accensione, tasto rapido/password per la tastiera, allarme RTC, Modem ring-in, LAN, AC 97 wake-up e USB wake-up</li> </ul> <p>Caratteristiche aggiuntive includono il supporto per sei porte USB, un collegamento AC 97 per audio e modem, monitoraggio hardware e gestione energetica ACPI/OnNow.</p>
<b>Memoria</b>	<p>La scheda madre supporta DDR 266/333 SDRAM. Presenta due slot privi di memoria di tampone (184 pin) a 2,5V; ogni slot supporta fino a 1GB di memoria per un totale massimo di 2 GB</p>
<b>USB</b>	<p>Il controller USB 2.0 è compatibile con Universal Serial Bus Specification Revision 2.0.</p> <p>USB 2.0 supporta trasferimento dati fino a 480MB/sec per dispositivi ad alta velocità disponendo di un microframe pari a 1/8 di 1msec frame. Ciò permette ai dispositivi USB 2.0 di disporre di piccole memorie di tampone anche ad alte velocità di trasferimento dei dati.</p> <p>I connettori USB 1.1 e altri cavi a velocità completa possono supportare la maggiore velocità di USB 2.0 senza necessità di alcuna modifica.</p> <p>Il chipset è dotato delle seguenti funzioni USB avanzate:</p> <ul style="list-style-type: none"> <li>• Compatibile con Enhanced Host Controller Interface (EHCI) Specification Revision 0.95 e Universal Host Controller Interface (UHCI) Specification Revision 1.1</li> <li>• Il dispositivo PCI multifunzione consiste di due schede di controllo UHCI per la trasmissione segnali alta velocità/bassa velocità e una scheda di controllo EHCI</li> </ul>

	<p>per la trasmissione segnali ad alta velocità.</p> <ul style="list-style-type: none"> <li>• Supporto per interfaccia risparmio energia bus PCI specifiche release 1.1</li> <li>• Supporto per tutte le porte downstream precedenti</li> </ul>
<b>Grafica</b>	<p>La scheda madre include uno slot AGP che fornisce fino a quattro volte l'ampiezza di banda delle caratteristiche tecniche dell'AGP originale. La tecnologia AGP fornisce una connessione diretta tra il sottosistema grafico e la memoria in modo tale che non vi sia competizione tra i bus PCI e quelli grafici per l'utilizzo del processore.</p>
<b>AC' 97 Audio Codec</b>	<p>Il codec Audio AC'97 è conforme alla specifica AC 97 2.3 che soddisfa i requisiti PC2001 e supporta Uscita S/PDFI. Inoltre ha una memoria tampone interna e PLL interno. Le caratteristiche includono supporto per interruttore analogico sull'uscita posteriore (condivisa), il jack di ingresso linea (condiviso), centrale/bassi (condivisi), e jack MIC per fornire un'uscita a 6 canali audio.</p> <p><b>Nota:</b> Controller audio opzionale a 4 canali</p>
<b>LAN integrata (opzionale)</b>	<p>La scheda VT6103L è un dispositivo Physical Layer per Ethernet 10BASE-T e 100BASE-TX che usa cavi della categoria 5 non schermati, Tipo 1 schermati e ottici.</p> <ul style="list-style-type: none"> <li>• Dual Speed – 100/10 Mbps</li> <li>• Half e Full Duplex</li> <li>• Interfaccia MII su Ethernet Controller</li> <li>• Conforme a tutti gli standard applicabili IEEE 802.3, 10Base-T e 100Base-Tx</li> </ul>
<b>Opzioni di espansione</b>	<p>La scheda madre presenta le seguenti opzioni di espansione:</p> <ul style="list-style-type: none"> <li>• Due slot PCI 32 bit</li> <li>• Uno slot AGP</li> <li>• Una slot Communications e Network Riser (CNR) (solo interfaccia AC97)</li> <li>• Due canali IDE e un'interfaccia lettore disco floppy</li> </ul> <p>La scheda supporta il bus mastering Ultra DMA con transfer rate 33/66/100/133 MB/sec.</p>
<b>Inizializza I/O</b>	<p>La scheda madre è dotata da una serie completa di porte e connettori I/O:</p> <ul style="list-style-type: none"> <li>• Due porte PS/2 per tastiera e mouse</li> <li>• Una porta seriale</li> <li>• Una porta VGA</li> <li>• Una porta parallela</li> <li>• Quattro porte USB</li> <li>• Una porta LAN</li> <li>• Jack audio per microfono, ingresso linea e uscita linea</li> </ul>
<b>Firmware BIOS</b>	<p>Questa scheda madre adotta un BIOS Award che permette agli utenti di configurare le caratteristiche principali del sistema, inclusi:</p> <ul style="list-style-type: none"> <li>• Gestione energia</li> <li>• Allarmi wake up</li> <li>• Parametri CPU</li> <li>• Temporizzazione CPU e memoria</li> </ul> <p>Il firmware può anche essere usato per impostare i parametri per diverse velocità di clock.</p>



Alcune specifiche hardware ed elementi software sono soggetti a variazioni senza preavviso.

## Características

<b>Procesador</b>	<p>La placa principal usa un micro receptáculo PGA de 478 pines que tiene las siguientes características:</p> <ul style="list-style-type: none"> <li>• Soporta un bus frontal de 400/533 MHz (FSB)™</li> <li>• Acomoda procesadores Pentium 4 en 1.5G/1.6G/1.7G... 3.06G y por encima de estos</li> </ul>
<b>Chipset</b>	<p>Los chipsets Northbridge <b>SiS650GX B0</b> y Southbridge <b>SiS962L</b> están basados en una arquitectura innovadora y escalable con fiabilidad y rendimiento comprobados.</p> <p>La placa principal puede soportar ambos chipsets Northbridge y Southbridge mencionados arriba. Referencia abajo sobre combinación y respectivos detalles:</p> <ul style="list-style-type: none"> <li>• Permite Intel Pentium 4 series CPU con valor de transferencia de datos de 533/ 400MHz</li> <li>• Permite 12 transacciones excelentes</li> <li>• Permite DDR333/DDR266/200 SDRAM</li> <li>• AGP v2.0 Adaptable</li> <li>• Permite Tamaño de Ventana de Gráficos desde 4MBytes hasta 256Mbytes</li> <li>• Ejecuta 533MB/s de ancho de banda en 66MHz x modo 4</li> <li>• Procesador 3D de alta calidad incorporado</li> <li>• Especificación de conformidad PCI 2.2</li> <li>• Permite modo PIO 0,1,2,3,4 y DMA Compuesto modo 0,1,2</li> <li>• Permite DMA Ultra 33/66/100/133</li> <li>• Tres controladores de servidor independientes OHCI USB 1.1 y un controlador de servidor EHCI USB 2.0, permite hasta seis puertos</li> <li>• El sistema despertar eventos incluye: Botón de energía, Teclado contraseña/tecla atajo, alarma RTC, Modem anunciar, LAN, despertar AC 97 y despertar USB</li> </ul> <p>Características de las teclas adicionales de la placa principal incluyen el soporte para seis puertos USB, un enlace AC' 97 para audio y modem, monitorización de hardware, y administración de energía ACPI/Encendido ahora.</p>
<b>Memoria</b>	<p>La placa principal permite DDR 266/333 SDRAM. Acomoda ranuras 2.5V de 184 pines sin buffer. Cada ranura soporta hasta 1 GB con una capacidad total máxima de 2 GB.</p>
<b>USB</b>	<p>El Controlador USB 2.0 se conforma con la Especificación de Bus Serial Universal Revisión 2.0.</p> <p>El USB 2.0 soporta los índices de transferencia de datos hasta 480MB/seg. para los dispositivos de alta velocidad y especifica un micro marco que será 1/8<sup>th</sup> de un marco de 1mseg. Esto permite que los dispositivos USB 2.0 para que tengan buffers pequeños aun en los índices de datos altos.</p> <p>Los conectores USB 1.1 y otros cables de alta velocidad pueden soportar la velocidad superior de USB 2.0 sin cambios.</p> <p>El chipset tiene las siguientes características USB avanzadas:</p> <ul style="list-style-type: none"> <li>• Conforme con la Enhanced Host Controller Interface (EHCI) Specification Edición 0.95 y Universal Host Controller Interface (UHCI) Specification Edición 1.1</li> <li>• Dispositivo PCI multi-función de dos Controladores Anfitrión-</li> </ul>

	<p>nes UHCI para la señalización de velocidad completa/baja y un Anfitrión EHCI</p> <ul style="list-style-type: none"> <li>• Soporta PCI-BUS Interfaz de Administración de Energía Especificación edición 1.1</li> <li>• Soporte de legado para todos los puertos frontales inferiores</li> </ul>
<b>Gráficas</b>	<p>La placa principal incluye una ranura AGP que proporciona cinco veces el ancho de banda de la especificación AGP original. La tecnología AGP provee una conexión directa entre el subsistema de gráficos y el procesador así que el gráfico no tiene que competir por el tiempo de procesador con otros aparatos del bus del PCI.</p>
<b>Codec de Sonido AC 97</b>	<p>El codec de Sonido AC' 97 se conforma con la especificación AC 97 2.3 que satisface los requisitos PC2001 y soporta S/PDIF Out. También tiene un buffer incorporado y PLL interno. Las características incluyen soporte para interruptor analógico para la salida trasera (compartir), la clavija de entrada de línea (compartir), centro/bajo (compartir), y clavija MIC para exportar sonido de 6 canales.</p> <p><b>Nota: Controlador de sonido de 4 canales optativo.</b></p>
<b>LAN Abordo (optativo)</b>	<p>La VT6103L es un componente Estrato Físico para Ethernet 10BASE-T y 100BASE-TX usando categoría 5 no blindado, Tipo 1 Blindado, y cables de Fibra óptica.</p> <ul style="list-style-type: none"> <li>• Velocidad Doble – 100/10 Mbps</li> <li>• Bidireccional Total y Medio</li> <li>• Interfaz MII para el Controlador de Ethernet</li> <li>• Reúne Todo lo Apropiado IEEE 802.3, 10Base-T y 100Base-Tx Convencionales</li> </ul>
<b>Opciones de Expansión</b>	<p>La placa principal viene con las siguientes opciones de expansión:</p> <ul style="list-style-type: none"> <li>• Dos ranuras PCI de 32 bits</li> <li>• Una ranura AGP</li> <li>• Una ranura Riser de comunicaciones y Network (CNR) (sólo interfaz AC97)</li> <li>• Two IDE channels and a floppy disk drive interface</li> </ul> <p>La placa principal soporta al bus Ultra DMA dominando las velocidades de transferencia de 33/66/100/133 MB/sec.</p>
<b>I/O Integrado</b>	<p>La placa principal tiene un set completo de puertos I/O y conectores:</p> <ul style="list-style-type: none"> <li>• Dos puertos PS/2 para ratón y teclado</li> <li>• Un puerto de serie</li> <li>• Un puerto paralelo</li> <li>• Un puerto MIDI/juego</li> <li>• Cuatro puertos USB</li> <li>• Un puerto LAN</li> <li>• Clavijas de sonido para micrófono, en línea, fuera de línea</li> </ul>
<b>BIOS Firmware</b>	<p>La placa principal usa Award BIOS que habilita a los usuarios para que configuren muchas características del sistema incluyendo las siguientes:</p> <ul style="list-style-type: none"> <li>• Administración de alimentación</li> <li>• Alarmas despertadores</li> <li>• Parámetros de CPU</li> </ul>

	<ul style="list-style-type: none"><li>• Cronometraje de CPU y de memoria</li></ul> <p>También se puede usar el firmware para configurar los parámetros para diferentes velocidades de reloj del procesador.</p>
--	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



Algunas especificaciones de hardware e ítems de software son sujetos a cambio sin previo aviso.

## 製品特徴

<p>プロセッサ</p>	<p>本メインボードに搭載されているマイクロPGA478ピンソケットは、次の特徴があります。</p> <ul style="list-style-type: none"> <li>• 400/533MHzのシステムバス (FSB) をサポートします</li> <li>• 1.5G/1.6G/1.7G…2.5G以上でPentium 4プロセッサに対応しています</li> </ul>
<p>チップセット</p>	<p>搭載した <b>SiS650GX B0</b> Northbridgeおよび<b>SiS962L</b> South bridgeチップセットは最新且つ拡張性あるアーキテクチャを採用し、高い安定性およびパフォーマンスを兼ね備えたものです。</p> <ul style="list-style-type: none"> <li>• 533/400MHzのデータ通信速度でIntel Pentium 4シリーズCPUに対応</li> <li>• 12の優れた処理機能に対応</li> <li>• DDR333/DDR266/200 SDRAM対応</li> <li>• AGP v2.0対応</li> <li>• 4MB~256MBのグラフィック ウィンドウサイズ対応</li> <li>• 66MHz x 4モードで533MB/秒バンド幅を実現</li> <li>• 高品質3Dエンジン内蔵</li> <li>• PCI 2.2仕様準拠</li> <li>• PIOモード0、1、2、3、4及びマルチワードDMAモード0、1、2対応</li> <li>• Ultra DMA 33/66/100/133対応</li> <li>• 独立したOHCI USB 1.1 ホストコントローラ x 3とEHCI USB 2.0ホストコントローラ x 1 で最大6ポートまで対応</li> <li>• システム再開イベント: 電源ボタン、キーボードパスワード/ホットキー、RTCアラーム、モデム呼び出し音、LAN、AC 97ウェイクアップ、USBウェイクアップ、1394ウェイクアップ</li> </ul> <p>その他に、次の重要機能をサポートしています: 6つのUSBポートをサポート、オーディオおよびモデム向けのAC 97リンク、ハードウェアのモニタ、およびACPI/OnNow 電源管理。</p>
<p>メモリ</p>	<p>メインボードはDDR266/333 SDRAMをサポートします。メインボードに搭載された2つの非バッファ2.5V184ピン仕様のスロットが、各々1GB、トータルで2GBまでのメモリをサポートします。</p>
<p>USB</p>	<p>搭載しているUSB 2.0 コントローラはUniversal Serial Bus Specification Revision 2.0仕様に適合しています。</p> <p>USB 2.0仕様では最大480MB/秒までの転送速度をサポートし、1msフレームの1/8になるマイクロフレームで転送を制御する。これにより、より小さいバッファでの高速なデータ伝送が可能です。</p> <p>高速なUSB2.0のデータ伝送には、USB 1.1向けのコネクタおよびフルスピードケーブルを直接適用することが出来ます。</p> <p>このチップセットは次の先進なUSB機能を提供します:</p> <ul style="list-style-type: none"> <li>• EHCI (Enhanced Host Controller Interface) 0.95 仕様およびUHCI (Universal Host Controller Interface) 1.1仕様に適合しています</li> </ul>

	<ul style="list-style-type: none"> <li>● PCIマルチ機能デバイスは2つのフルスピード/ロースピード伝送用UHCIホストコントローラおよび1つのEHCIホストで構成されています</li> <li>● PCIバス電源管理インターフェース1.1仕様に適合</li> <li>● すべてのダウンストリームフェースポートをサポート</li> </ul>
<b>グラフィック</b>	搭載されているAGP スロットは、オリジナルのAGP仕様の4倍にもなる帯域幅をサポートします。AGP技術はグラフィックサブシステムをプロセッサに直接アクセスさせることにより、PCIバスにある他のデバイスと競合せずに、プロセッサによる高速なグラフィック処理を実現するものです。
<b>AC' 97 オーディオコーデック</b>	AC' 97 オーディオコーデックはAC' 97 2.3 仕様に適合したもので、PC2001要求を満たし、S/PDIF Outに対応しています。また、内蔵バッファ及び内部PLLを搭載しています。背面アナログスイッチ（共有）、ライン入力ジャック（共有）、中央/ベース（共有）、6チャンネルオーディオへのMIC出力ジャックなどの機能を含みます。 メモ： オプション4チャンネルオーディオコントローラ
<b>オンボードLAN機能 (オプション)</b>	VT6103L はカテゴリ5案シールド、Type 1 シールド、光ファイバケーブルを使ったEthernet 10BASE-Tと100BASE-TXのための物理レイヤーです。 <ul style="list-style-type: none"> <li>● デュアルスピード - 100/10 Mbpsに対応</li> <li>● 半/全二重をサポート</li> <li>● イーサネットコントローラのMIIインターフェースを搭載</li> <li>● すべてのIEEE 802.3、10Base-T、100Base-Tx標準に対応</li> </ul>
<b>拡張オプション</b>	メインボードには次に拡張オプションが搭載されています： <ul style="list-style-type: none"> <li>● 32ビットPCI スロット x 2</li> <li>● AGPスロット x 1</li> <li>● 通信ネットワークライザー(CNR)スロット(AC97仕様インターフェースのみ対応) x 1</li> <li>● IDEチャンネル x 2およびフロッピードライブインターフェース x 1</li> </ul> 本メインボードは転送レート33/66/100/133 MB/秒をサポートするUltra DMAバスマスタ機能をお届けします。
<b>統合I/O機能</b>	このメインボードにはフルセットのI/Oポートおよびコネクタが搭載しています。 <ul style="list-style-type: none"> <li>● マウスおよびキーボード用PS/2ポート x 2</li> <li>● シリアルポート x 1</li> <li>● VGAポート x 1</li> <li>● パラレルポート x 1</li> <li>● USBポート x 4</li> <li>● LANポート x 1</li> <li>● マイクロフォンやライン入力、ライン出力用のオーディオジャック</li> </ul>
<b>BIOS ファームウェア</b>	本メインボードは下記のシステム機能を含めた設定をすることができるAward BIOSを採用しています： <ul style="list-style-type: none"> <li>● 電源管理</li> <li>● Wake-up警告</li> </ul>



- |  |                                                                                                                            |
|--|----------------------------------------------------------------------------------------------------------------------------|
|  | <ul style="list-style-type: none"><li>• CPUパラメータ</li><li>• CPUおよびメモリのタイミング</li></ul> その他に、各種プロセッサクロック速度のパラメータを設定することができます。 |
|--|----------------------------------------------------------------------------------------------------------------------------|



一部のハードウェア仕様及びソフトウェアアイテムは予告なく変更されることがあります。

## 기능

<p><b>프로세서</b></p>	<p>본 메인보드는 micro PGA 478 핀 소켓을 사용하며 다음과 같은 특징을 지닌다:</p> <ul style="list-style-type: none"> <li>• 400/533 MHz frontside bus (FSB) 지원</li> <li>• 1.5G/1.6G/1.7G... 3.06G 이상의 Pentium 4 프로세서 사용 3.06G</li> </ul>
<p><b>칩셋</b></p>	<p><b>SiS650GX B0 Northbridge</b> 과 <b>SiS962L Southbridge</b> 칩셋은 혁신적이고 범용성을 지닌 아키텍처를 바탕으로 인정된 신뢰성과 성능을 지닌다.</p> <ul style="list-style-type: none"> <li>• 전송 속도 533/ 400MHz의 Intel Pentium 4 시리즈 CPU 지원</li> <li>• 12 우수한 정보 처리 지원</li> <li>• DDR333/DDR266/200 SDRAM 지원</li> <li>• AGP v2.0 호환</li> <li>• 4Mbytes ~ 256Mbytes의 그래픽 윈도우 사이즈 지원</li> <li>• 66MHz x 4 모드에서 533MB/s 대역폭</li> <li>• 고품질의 3D 엔진 내장</li> <li>• PCI 2.2 사양 호환</li> <li>• PIO 모드 0,1,2,3,4 및 Multiword DMA 모드 0,1,2 지원</li> <li>• Ultra DMA 33/66/100/133 지원</li> <li>• 3개의 독립 OHCI USB 1.1 호스트 컨트롤러 및 1개의 EHCI USB 2.0 호스트 컨트롤러가 최대 6개의 포트 지원</li> <li>• 시스템 wake-up의 경우: 전원 버튼, 키보드 암호/단축키, Power button, keyboard password/hot key, RTC 알람, 모뎀 ring-in, LAN, AC 97 wake-up, USB wake up 및 1394 wake up</li> </ul> <p>이외에도 본 메인보드의 주요 기능으로 USB 포트 6개, 오디오 및 모뎀용 AC' 97 링크 1개, 하드웨어 모니터링, ACPI/OnNow 전원 관리가 있다.</p>
<p><b>메모리</b></p>	<p>본 메인보드는 DDR 266/333 SDRAM을 지원한다. 2개의 unbuffered 2.5V 184 핀 슬롯이 제공되며 각 슬롯은 최대 1 GB 를 지원하여 총 최대 용량은 2 GB이다.</p>
<p><b>USB</b></p>	<p>USB 2.0 컨트롤러는 Universal Serial Bus 2.0 사양에 부합된다.</p> <p>USB 2.0은 고속 장치를 위해 데이터 전송 속도를 최대 480MB/sec 까지 지원하고 1msec 프레임의 8분의 1인 마이크로 프레임을 지원함으로써, USB 2.0 장치는 고속의 데이터 속도에도 작은 버퍼를 유지할 수 있다.</p> <p>USB 1.1 커넥터와 기타 전송 케이블은 다른 변경 없이 USB 2.0 의 고속을 지원할 수 있다.</p> <p>이 칩셋은 다음과 같은 고급의 USB 특징을 지닌다:</p> <ul style="list-style-type: none"> <li>• Enhanced Host Controller Interface (EHCI) 0.95 사양 및 Universal Host Controller Interface (UHCI) 1.1 사양 호환</li> <li>• 2개의 UHCI 호스트 컨트롤러 (전속/저속 시그널링 용) 과 1개의 EHCI 호스트 컨트롤러 코어 (고속 시그널링 용) 로 이루어진 PCI 다기능 장치</li> </ul>

	<ul style="list-style-type: none"> <li>• PCI-버스 전원 관리 인터페이스 1.1 사양 지원</li> <li>• 모든 다운스트림 페이싱 포트를 지원하는 Legacy</li> </ul>
<b>그래픽</b>	본 메인보드에는 기존 AGP 사양보다 4 배의 대역폭을 제공하는 4x AGP 슬롯이 포함되어 있다. AGP 기술은 그래픽 서버 시스템과 프로세서를 직접 연결함으로써 그래픽 프로세서 시간을 PCI 버스에 있는 다른 장치와 다룰 필요가 없다.
<b>AC' 97 오디오 코덱</b>	AC' 97 오디오 코덱은 AC 97 2.3 사양과 호환하여 PC2001 요구 사항에 부합하며 S/PDIF Out을 지원한다. 버퍼 및 PLL이 내장되어 있으며, 후면-출력 (공유), 라인 입력 잭 (공유), 중앙/베이스 (공유), 및 6 채널 오디오 출력 용 MIC 잭을 위한 아날로그 스위치를 포함한다. <b>노트:</b> 선택적 4 채널 오디오 컨트롤러가 있다.
<b>보드 내장 LAN (선택 사항)</b>	VT6103L 는 카테고리 5 Unshielded, 타입 1 Shielded, 유리 섬유 케이블을 사용한 Ethernet 10BASE-T와 100BASE-TX 를 위한 물리적 레이어 장치이다. <ul style="list-style-type: none"> <li>• 듀얼 속도 - 100/10 Mbps</li> <li>• Half 및 Full Duplex</li> <li>• MII 인터페이스 이더넷 컨트롤러</li> <li>• 모든 적용 가능한 IEEE 802.3, 10Base-T 및 100Base-Tx 표준 지원</li> </ul>
<b>확장 옵션</b>	본 메인보드에는 다음과 같은 확장 옵션이 있다: <ul style="list-style-type: none"> <li>• 32-bit PCI 슬롯2개</li> <li>• AGP 슬롯 1개</li> <li>• Communications and Network Riser (CNR) 슬롯1 개 (AC97 인터페이스의 경우에만)</li> <li>• IDE 채널 2 개 및 플로피 디스크 드라이브 인터페이스 1개</li> </ul> <p>본 메인보드는 전송 속도 33/66/100/133 MB/sec 의 Ultra DMA bus mastering 을 지원한다.</p>
<b>통합 I/O</b>	본 메인보드에는 풀 세트의 I/O 포트와 커넥터가 있다: <ul style="list-style-type: none"> <li>• 마우스 및 키보드용 PS/2 포트 2 개</li> <li>• 시리얼 포트 1 개</li> <li>• VGA 포트 1 개</li> <li>• 패러럴 포트 1 개</li> <li>• USB 포트 4 개</li> <li>• LAN 포트 1 개</li> <li>• 마이크 용 오디오 잭, 라인 입력과 라인 출력</li> </ul>

<b>BIOS 펌웨어</b>	본 메인보드는 Award BIOS 를 사용하여 사용자는 다음과 같은 시스템 기능을 구성할 수 있다: <ul style="list-style-type: none"><li>• 전원 관리</li><li>• Wake-up 알람</li><li>• CPU 파라미터</li><li>• CPU 및 메모리 타이밍</li></ul> 펌웨어는 다른 프로세서의 클럭 속도를 설정하는 데도 사용될 수 있다.
---------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



하드웨어 사양 및 소프트웨어 아이템은 사전 통보 없이 변경될 수 있음.

## 性能

中央處理器	<p>本主機板採用了具有下列功能之微PGA 478針插槽：</p> <ul style="list-style-type: none"> <li>• 支援400/533MHz的前側匯流排(FSB)</li> <li>• 支援1.5G/1.6G/1.7G/3.06G及以上之 Pentium 4 處理器</li> </ul>
晶片組	<p><b>SiS650GX B0</b> 北橋及 <b>SiS962L</b> 南橋晶片組，採用了獨創且具有擴充功能的架構，能夠發揮最佳的穩定性及功能。</p> <ul style="list-style-type: none"> <li>• 支援Intel Pentium 4系列CPU，位元傳輸速率高達533/400MHz</li> <li>• 支援12個未結束傳送 (outstanding transactions)</li> <li>• 支援DDR333/DDR266/200 SDRAM</li> <li>• 相容於AGP v2.0</li> <li>• 支援4到256 Mbytes之圖形視窗大小</li> <li>• 藉由66MHz x4模式，提供效能高達每秒533MB之頻寬</li> <li>• 內建高品質3D立體圖像處理引擎</li> <li>• 相容於PCI 2.2 規格</li> <li>• 支援PIO mode 0,1,2,3,4 和多字元DMA mode 0,1,2</li> <li>• 支援Ultra DMA 33/66/100/133</li> <li>• 3個獨立OHCI USB 1.1 主控制器和一個EHCI USB 2.0 主控制器，支援上至6埠</li> <li>• 系統喚醒事件包括: 電源按鈕、鍵盤密碼/熱鍵、RTC alarm、數據機鈴響、乙太網路、AC 97喚醒功能和USB喚醒功能</li> </ul> <p>其他重要功能包括：支援6個USB埠、音效及數據機連接用的 AC 97 link、硬體監視功能、及ACPI/OnNow 電源管理功能。</p>
記憶體	<p>本主機板支援DDR266/333 SDRAM。且，配備2個無緩衝2.5V 184針插槽，各插槽可支援1GB，即本主機共可支援高達2GB的記憶體容量。</p>
USB	<p>本USB 2.0控制器符合通用串列匯流排2.0版規格。</p> <p>USB 2.0可為高速週邊設備提供高達480MB/sec 的資料傳輸速度及1/8微秒框架，使得USB2.0設備僅需較小的緩衝記憶體區，便可進行高速資料傳輸。</p> <p>USB 1.1 連接器及其全速連接線可直接支援更高速的USB 2.0規格。</p> <p>本晶片組具有以下先進的USB功能：</p> <ul style="list-style-type: none"> <li>• 符合EHCI (Enhanced Host Controller Interface) 規格0.95版及UHCI (Universal Host Controller Interface) 規格1.1版</li> <li>• PCI 多功能設備係由2個全/低速信號處理用UHCI 主控制卡及1個EHCI 控制卡所組成</li> <li>• 支援 PCI-匯流排式 電源管理介面(Power Management Interface) 規格1.1版</li> <li>• 支援所有舊式的下行傳輸埠</li> </ul>
繪圖卡	<p>主機板配備有一個AGP插槽，能夠支援為原AGP規格4倍之頻寬。AGP技術，係使繪圖子系統與中央處理器直接連接，藉以使繪圖系統無需與PCI插槽上的設備，爭取處理器資源。</p>
AC' 97 音效解碼/編碼器	<p>配備之AC' 97 音效解碼/編碼器採用了AC' 97 2.3 規格，該規格符合PC2001規格要求並支援S/PDIF輸入/輸出。同</p>

	<p>時，本解碼/編碼器也具有內建緩衝器和內裝PLL。藉由對後聲道輸出(共用)端子、外部音源輸入(共用)端子、中低音(共用)端子、及麥克風端子的切換功能，提供6聲道的音效輸出。</p> <p><b>附註:</b> 可選購4聲道音響控制器。</p>
<b>機載LAN功能 (選購)</b>	<p>VT6103L係為乙太10BASE-T 和 100BASE-TX之實體層元件, 使用 Category 5(速率100 Mbps) 無遮蔽式雙絞線, Type 1屏蔽電纜以及光纖電纜。</p> <ul style="list-style-type: none"> <li>• 支援雙速 - 100/10 Mbps 傳輸速率</li> <li>• 支援半或全雙工運作模式</li> <li>• 提供乙太網路的MII介面</li> <li>• 適用於所有可用之IEEE 802.3, 10BaseT和100Base-Tx雙絞線, 等之標準</li> </ul>
<b>擴充選項</b>	<p>本主機板具有下列的擴充選擇：</p> <ul style="list-style-type: none"> <li>• 2個32位元 PCI插槽</li> <li>• 1個AGP槽</li> <li>• 1個CNR(Communications Network Riser) 槽，AC97專用介面</li> <li>• 2個IDE通道及1個軟碟介面</li> </ul> <p>本主機板具有之Ultra DMA 匯流排控制功能，能夠支援33/66/100/133 MB/秒的傳輸速度。</p>
<b>整合的輸入出功能</b>	<p>本主機板提供完整的輸出入埠及連接器：</p> <ul style="list-style-type: none"> <li>• 2個 PS/2 埠，分供滑鼠及鍵盤連接</li> <li>• 1個串列埠</li> <li>• 1個VGA埠</li> <li>• 1個平行埠</li> <li>• 4個USB埠</li> <li>• 1個LAN埠</li> <li>• 麥克風、音效輸入及音效輸出端子</li> </ul>
<b>BIOS 韌體</b>	<p>本主機板使用了Award BIOS，使用者可藉此對包括下列之系統功能進行設定：</p> <ul style="list-style-type: none"> <li>• 電源管理</li> <li>• 喚醒警示</li> <li>• CPU參數</li> <li>• CPU及記憶體定時</li> </ul> <p>本BIOS也可用以設定各種有關處理器頻率的參數。</p>



有些硬體規格以及軟體物件將視狀況適當調整，不予另行通知。

## 特性

<b>处理器</b>	主板使用一个 micro PGA 478-pin 插座，此插座具有以下特点： <ul style="list-style-type: none"> <li>• 支持 400/533 MHz 前端总线 (FSB)</li> <li>• 支持 1.5G/1.6G/1.7G/3.06G 或更高速度的 Pentium 4 处理器</li> </ul>
<b>芯片组</b>	<b>SiS650GX B0 北桥和SiS962L</b> 南桥芯片组是基于一种新型的、可扩展的架构，能提供已经证明的可靠性和高性能。 <ul style="list-style-type: none"> <li>• 支持 Intel Pentium 4 系列 CPU，数据传输速率可达 533MHz</li> <li>• 支持 12 个未完成的事务处理</li> <li>• 支持 DDR333/DDR266/200 SDRAM</li> <li>• AGP v2.0 兼容</li> <li>• 支持 4MB 到 256MB 图形窗口</li> <li>• 在 66MHz x 4 模式下可达 533MB/s 带宽</li> <li>• 内建高质量 3D 引擎</li> <li>• 符合 PCI 2.2 规格</li> <li>• 支持 PIO 模式 0、1、2、3、4 和多字节 DMA 模式 0、1、2</li> <li>• 支持 Ultra DMA 33/66/100/133</li> <li>• 3 个独立的 OHCI USB 1.1 主控器和 1 个 EHCI USB 2.0 主控器，可支持 6 个端口</li> <li>• 系统唤醒事件包括：电源按钮、键盘口令/热键、RTC 报警、调制解调器振铃、LAN、AC 97 唤醒和 USB 唤醒</li> </ul> 其它主要功能包括支持 6 个 USB 端口、用于音频和调制解调器的 AC 97 连接、硬件监测和 ACPI/OnNow 电源管理。
<b>内存</b>	主板支持 DDR 266/333 SDRAM。它有 2 个非缓冲 2.5V 184 pin 插槽，每个插槽支持 1 GB，总共最大可支持 2 GB。
<b>USB</b>	USB 2.0 控制器与通用串行总线规格 2.0 兼容。 USB 2.0 支持的高速设备数据传输速率可达 480MB/sec，并指定一个 microframe（即 1msec 帧的 1/8）。这就使 USB 2.0 设备在高速数据传输速率时能够保持较小的缓冲区。 USB 1.1 接口和其它全速电缆可支持更高速度的 USB2.0，不需要做任何修改。 此芯片组还具备以下增强 USB 功能： <ul style="list-style-type: none"> <li>• 与 0.95 版本的增强主控器接口 (EHCI) 规格和 1.1 版本的通用主控器接口 (UHCI) 规格兼容</li> <li>• PCI 多功能设备由 2 个用于全速/低速传输数据的 UHCI 主控器 和1 个用于高速传输数据的 EHCI 主控器组成</li> <li>• 支持 1.1 版本的 PCI 总线电源管理接口规格</li> <li>• 支持所有传统下行端口</li> </ul>
<b>图形</b>	此主板包括一个 4xAGP 插槽，可提供普通 AGP 规格 4 倍的带宽。AGP 技术能提供图像子系统和处理器之间的直接连接，这样图像就不需要与 PCI 总线上的其它设备争用处理器时间。

<b>AC' 97 Audio Codec</b>	AC' 97 音频编解码器符合 AC 97 2.3 PC2001 规格，支持 S/PDIF Out。它还带有一个内置的缓冲器和一个内部 PLL。功能包括支持后端模拟开关（共享）、线入插孔（共享）、中置/低音（共享）和 MIC 插孔以输出 6 声道音频。 <b>说明：</b> 可选 4-通道音频控制器
<b>Onboard LAN (可选)</b>	VT6103L 是一种物理层设备，可用于使用 5 类非屏蔽线、1 类屏蔽线和光缆的以太网 10BASE-T 和 100BASE-TX。 <ul style="list-style-type: none"> <li>• 双速 -100/10 Mbps</li> <li>• 半双工和全双工</li> <li>• 以太网控制器的 MII 接口</li> <li>• 符合所有相应的 IEEE 802.3、10Base-T 和 100Base-Tx 标准到</li> </ul>
<b>扩展选项</b>	此主板提供如下扩展选项： <ul style="list-style-type: none"> <li>• 2 个 32 位 PCI 扩展插槽</li> <li>• 1 个 AGP 插槽</li> <li>• 1 个通信网络转接 (CNR) 插槽（仅对于 AC97 接口）</li> <li>• 2 个 IDE 通道和一个软驱接口</li> </ul> 主板支持 Ultra DMA 总线控制，传输速率可达 33/66/100/133 MB/sec。
<b>集成 I/O</b>	此主板具有完整的 I/O 端口和插孔： <ul style="list-style-type: none"> <li>• 2 个用于鼠标和键盘的 PS/2 端口</li> <li>• 1 个串口</li> <li>• 1 个 VGA 端口</li> <li>• 1 个并口</li> <li>• 4 个 USB 端口</li> <li>• 1 个 LAN 端口</li> <li>• 麦克风、线入和线出声音插孔</li> </ul>
<b>BIOS</b>	此主板使用 Award BIOS，可以让用户自己配置以下系统功能： <ul style="list-style-type: none"> <li>• 电源管理</li> <li>• 唤醒报警</li> <li>• CPU 参数</li> <li>• CPU 和记忆定时</li> </ul> 还可用于设置不同处理器时钟速度的参数。



部分硬件规格和软件项目若有更改恕不另行通知。



---

## TABLE OF CONTENTS

---

<b>Preface</b>	<b>i</b>
<b>Features Translations</b>	<b>iii</b>
<b>CHAPTER 1</b>	<b>1</b>
<b>Introducing the Motherboard</b>	<b>1</b>
<i>Introduction</i> .....	1
<i>Features</i> .....	2
<i>Choosing a Computer Case</i> .....	4
<i>Motherboard Components</i> .....	5
<b>CHAPTER 2</b>	<b>7</b>
<b>Installing the Motherboard</b>	<b>7</b>
<i>Safety Precautions</i> .....	7
<i>Quick Guide</i> .....	7
<i>Installing the Motherboard in a Case</i> .....	8
<i>Checking Jumper Settings</i> .....	8
Setting Jumpers .....	8
Checking Jumper Settings .....	9
Jumper Settings .....	9
<i>Connecting Case Components</i> .....	10
Front Panel Connector .....	12
<i>Installing Hardware</i> .....	13
Installing the Processor .....	13
Installing Memory Modules .....	15
Installing a Hard Disk Drive/CD-ROM .....	16
Installing a Floppy Diskette Drive .....	18
Installing Add-on Cards .....	19
Connecting Optional Devices .....	21
<i>Connecting I/O Devices</i> .....	23
<b>CHAPTER 3</b>	<b>24</b>
<b>Using BIOS</b>	<b>24</b>
<i>About the Setup Utility</i> .....	24
The Standard Configuration .....	24
Starting Setup .....	25
Updating the BIOS .....	26
<i>Using BIOS</i> .....	27
Standard CMOS Features .....	27
Advanced BIOS Setup .....	29
Advanced Chipset Setup .....	32
Integrated Peripherals .....	33
Power Management Setup .....	37

PNP/PCI Configurations.....	41
PC Health Status.....	42
Frequency/Voltage Control.....	43
Load Fail-Safe Defaults Option.....	44
Load Optimized Defaults Option.....	44
Set Password.....	44
Save & Exit Setup Option .....	45
Exit Without Saving .....	45

**CHAPTER 4** **46**

<b>Using the Motherboard Software</b>	<b>46</b>
<i>About the Software CD-ROM</i> .....	46
<i>Auto-installing under Windows 98/ME/2000/XP</i> .....	46
Running Setup .....	47
<i>Manual Installation</i> .....	49
<i>Utility Software Reference</i> .....	49

## *Chapter 1*

# Introducing the Motherboard

---

## **Introduction**

Thank you for choosing the 651-M motherboard. This micro-ATX motherboard comes with the high performance SiS650GX B0 Northbridge and SiS962L Southbridge chipsets. It accommodates Intel Pentium 4 processors, which supports a front side bus (FSB) speeds up to 400/533 MHz.

The SiS650GX B0 Northbridge provides a high performance 2D/3D Graphic Engine, Video Accelerator and Advanced Hardware Acceleration MPEGI/MPEGII Video Decoder for the Intel Pentium 4 series based PC systems. It offers bandwidth up to 2.7GB/s under DDR333, 2GB/s under DDR266 and 1GB/s under PC 133 in order to sustain the bandwidth demand from host processor, as well as the multi I/O masters and AGP masters.

The SiS962L Southbridge integrates one Universal Serial Bus 2.0 Host Controllers, audio controller with AC 97 interface, Ethernet MAC controller with standard MII interface, three Universal Serial Bus 1.1 Host Controllers and the IDE Master/Slave controllers.

The motherboard has an advanced full set of I/O ports, such as dual channel IDE interfaces, a floppy controller, a high-speed serial port, a VGA port, an EPP/ECP capable bi-directional parallel port connector, four USB (Universal Serial Bus) connector, a PS/2 keyboard connector, mouse connector and audio jacks for microphone, line-in, line-out. One AGP slot, two PCI local bus slots and one communication and networking riser (CNR) slot provide expandability for add-on peripheral cards.

Featuring good stability and performance, and the advanced SiS chipset, the 651-M is an excellent Pentium 4 DDR motherboard for the budget-conscious consumer. It is the ideal solution for any home or workstation PC.

## Features

<b>Processor</b>	<p>The motherboard uses a micro PGA 478-pin socket that has the following features:</p> <ul style="list-style-type: none"> <li>• Supports 400/533 MHz frontside bus (FSB)</li> <li>• Accommodates Pentium 4 processors at 1.5G/1.6G/1.7G ...3.06G and above</li> </ul>
<b>Chipset</b>	<p>The <b>SiS650GX B0 Northbridge</b> and <b>SiS962L</b> Southbridge chipsets are based on an innovative and scalable architecture with proven reliability and performance.</p> <ul style="list-style-type: none"> <li>• Support Intel Pentium 4 series CPU with data transfer rate of 533/400MHz</li> <li>• Support 12 outstanding transactions</li> <li>• Supports DDR333/266/200 SDRAM</li> <li>• AGP v2.0 Compliant</li> <li>• Supports Graphic Window Size from 4MBytes to 256Mbytes</li> <li>• Perform 533MB/s bandwidth in 66MHz x 4 mode</li> <li>• Built-in a high quality 3D engine</li> <li>• PCI 2.2 specification compliance</li> <li>• Supports PIO mode 0,1,2,3,4 and Multiword DMA mode 0,1,2</li> <li>• Supports Ultra DMA 33/66/100/133</li> <li>• Three independent OHCI USB 1.1 host controllers and one EHCI USB 2.0 host controller, support up to six ports</li> <li>• System wake-up events include: Power button, keyboard password/hot key, RTC alarm, Modem ring-in, LAN, AC 97 wake-up, USB wake up and 1394 wake up</li> </ul> <p>Additional key features of the motherboard include support for six USB ports, an AC' 97 link for audio and modem, hardware monitoring, and ACPI/OnNow power management.</p>
<b>Memory</b>	<p>The motherboard supports DDR 266/333 SDRAM. It accommodates two unbuffered 2.5V 184-pin slots. Each slot supports up to 1 GB with a total maximum capacity of 2 GB.</p>
<b>Graphics</b>	<p>The motherboard includes an AGP slot that provides four times the bandwidth of the original AGP specification. AGP technology provides a direct connection between the graphics sub-system and the processor so that the graphics do not have to compete for processor time with other devices on the PCI bus.</p>
<b>USB</b>	<p>The USB 2.0 Controller is compliant with Universal Serial Bus Specification Revision 2.0.</p> <p>The USB 2.0 supports data transfer rates up to 480MB/sec for high-speed devices and specifies a microframe that will be 1/8<sup>th</sup> of a 1msec frame. This allows the USB 2.0 devices to have small buffers even at high data rates.</p> <p>The USB 1.1 connectors and other full speed cables can support the higher speed of USB 2.0 without any changes.</p> <p>The chipset has the following advanced USB features:</p> <ul style="list-style-type: none"> <li>• Compliant with Enhanced Host Controller Interface (EHCI) Specification Revision 0.95 and Universal Host Controller Interface (UHCI) Specification Revision 1.1</li> </ul>

	<ul style="list-style-type: none"> <li>• PCI multi-function device consists of two UHCI Host Controllers for full/low-speed signaling and one EHCI Host Controller core for high-speed signaling</li> <li>• Supports PCI-Bus Power Management Interface Specification release 1.1</li> <li>• Legacy support for all downstream facing ports</li> </ul>
<b>AC' 97 Audio Codec</b>	<p>The AC' 97 Audio codec is compliant with the AC 97 2.2 specification that meets the PC2001 requirements and supports S/PDIF Out. It also has a built-in buffer and internal PLL. Features include support for analog switch for rear-out (share), the line-in jack (share), center/bass (share), and MIC jack to output 6 channels audio.</p> <p><b>Note:</b> Optional 4-channel audio controller.</p>
<b>Onboard LAN (optional)</b>	<p>The VT6103L is a Physical Layer device for Ethernet 10BASE-T and 100BASE-TX using category 5 Unshielded, Type 1 Shielded, and Fiber Optic cables.</p> <ul style="list-style-type: none"> <li>• Dual Speed – 100/10 Mbps</li> <li>• Half And Full Duplex</li> <li>• MII interface to Ethernet Controller</li> <li>• Meet all applicable IEEE802.3, 10Base-T and 100Base-Tx standards</li> </ul>
<b>Expansion Options</b>	<p>The motherboard comes with the following expansion options:</p> <ul style="list-style-type: none"> <li>• Two 32-bit PCI slots</li> <li>• One AGP slot</li> <li>• A Communications and Network Riser (CNR) slot (AC97 interface only)</li> <li>• Two IDE channels and a floppy disk drive interface</li> </ul> <p>The motherboard supports Ultra DMA bus mastering with transfer rates of 33/66/100/133 MB/sec.</p>
<b>Integrated I/O</b>	<p>The motherboard has a full set of I/O ports and connectors:</p> <ul style="list-style-type: none"> <li>• Two PS/2 ports for mouse and keyboard</li> <li>• One serial port</li> <li>• One VGA port</li> <li>• One parallel port</li> <li>• Four USB ports</li> <li>• One LAN port</li> <li>• Audio jacks for microphone, line-in and line-out</li> </ul>
<b>BIOS Firmware</b>	<p>This motherboard uses Award BIOS that enables users to configure many system features including the following:</p> <ul style="list-style-type: none"> <li>• Power management</li> <li>• Wake-up alarms</li> <li>• CPU parameters</li> <li>• CPU and memory timing</li> </ul> <p>The firmware can also be used to set parameters for different processor clock speeds.</p>



Some hardware specifications and software items are subject to change without prior notice.

---


## **Choosing a Computer Case**

There are many types of computer cases on the market. The motherboard complies with the specifications for the Micro ATX system case. Some features on the motherboard are implemented by cabling connectors on the motherboard to indicators and switches on the system case. Ensure that your case supports all the features required. The motherboard can support one or two floppy diskette drives and four enhanced IDE drives. Ensure that your case has sufficient power and space for all the drives that you intend to install.

Most cases have a choice of I/O templates in the rear panel. Make sure that the I/O template in the case matches the I/O ports installed on the rear edge of the motherboard.

This motherboard has a Micro ATX form factor of 244 x 220 mm. Choose a case that accommodates this form factor.

## Motherboard Components



## Table of Motherboard Components

Label	Component
AGP1	Accelerated Graphics Port
ATX1	Auxiliary power connector for Pentium 4 CPUs
ATX2	Standard 20-pin ATX power connector
AUDIO1	Front audio connector
BAT1	Three volt realtime clock battery
CASFAN1	Case fan connector 1
CDIN1	Primary CD-in connector
CNR1	Communications Networking Riser slot
CPU SOCKET	Micro PGA 478-pin socket for Pentium 4 CPUs
CPUFAN1	Cooling fan for CPU
DIMM1 ~ DIMM2	Two 184-pin DDR SDRAM
FDD1	Floppy disk drive connector
IDE 1	Primary IDE channel
IDE 2	Secondary IDE channel
JP1	Clear CMOS jumper
JP2	BIOS protection jumper
LED1 <sup>1</sup>	Memory module LED (optional)
PANEL1	Connector for case front panel switches and LED indicators
PCI1 ~ PCI2	Two 32-bit add-on card slots
PWRFAN1*	Case fan connector 2
SJ1*	Single color LED header
SPDIF1*	SPDIF out header
SPEAKER1	Speaker connector
USB3	Front panel USB headers
USBCR1	USB Card Reader header

<sup>1</sup>Optional component

This concludes Chapter 1. The next chapter explains how to install the motherboard.

---

<sup>1</sup> The red indicator LED1 turns on if your system is still powered, at which time memory modules cannot be installed or uninstalled.



## Chapter 2

# Installing the Motherboard

---

### Safety Precautions

Follow these safety precautions when installing the motherboard:

- Wear a grounding strap attached to a grounded device to avoid damage from static electricity.
- Discharge static electricity by touching the metal case of a safely grounded object before working on the motherboard.
- Leave components in the static-proof bags they came in.
- Hold all circuit boards by the edges. Do not bend circuit boards.

---

### Quick Guide

This Quick Guide suggests the steps you can take to assemble your system with the motherboards.

The following table provides a reference for installing specific components:

<b>Locating Motherboard Components</b>	Go to page 5
<b>Installing the Motherboard in a Case</b>	Go to page 7
<b>Setting Jumpers</b>	Go to page 8
<b>Installing Case Components</b>	Go to page 10
<b>Installing the CPU</b>	Go to page 13
<b>Installing Memory</b>	Go to page 16
<b>Installing a HDD and CD-ROM Drive</b>	Go to page 17
<b>Installing an FDD</b>	Go to page 18
<b>Installing Add-on Cards</b>	Go to page 20
<b>Connecting Optional Devices</b>	Go to page 21
<b>Connecting Peripheral (I/O) Devices</b>	Go to page 24

---

## Installing the Motherboard in a Case


Refer to the following illustration and instructions for installing the motherboard in a case:

This illustration shows an example of a motherboard being installed in a tower-type case:

**Note:** Do not overtighten the screws as this can stress the motherboard.

Most system cases have mounting brackets installed in the case, which correspond to the holes in the motherboard. Place the motherboard over the mounting brackets and secure the motherboard onto the mounting brackets with screws.

2. Secure the mainboard with screws where appropriate.



Ensure that your case has an I/O template that supports the I/O ports and expansion slots on your motherboard.

---

## Checking Jumper Settings


This section explains how to set jumpers for correct configuration of the motherboard.

### Setting Jumpers


Use the motherboard jumpers to set system configuration options. Jumpers with more than one pin are numbered. When setting the jumpers, ensure that the jumper caps are placed on the correct pins.

The illustrations below show a 2-pin jumper. When the jumper cap is placed on both pins, the jumper is **SHORT**. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is **OPEN**.


This illustration shows a 3-pin jumper. Pins 1 and 2 are **SHORT**.



Short




Open





## Checking Jumper Settings

The following illustration shows the location of the motherboard jumpers. Pin 1 is labeled.



### Jumper Settings

Jumper	Type	Description	Setting (default)
JP1	3-pin	Clear CMOS	1-2: Normal 2-3: <i>Clear</i> Before clearing the CMOS, make sure to turn the system off. 
JP2	3-pin	BIOS protect	1-2: Write Enabled 2-3: <i>Write Disabled</i> 

## Connecting Case Components

After you have installed the motherboard into a case, you can begin connecting the motherboard components. Refer to the following:

<ol style="list-style-type: none"> <li>1. Connect the Pentium 4 processor auxiliary case power supply connector to <b>ATX1</b>.</li> <li>2. Connect the standard power supply connector to <b>ATX2</b>.</li> <li>3. Connect the CPU cooling fan cable to <b>CPUFAN1</b>.</li> <li>4. Connect the auxiliary power supply cooling fan connector to <b>PWRFAN1</b>.</li> <li>5. Connect the case cooling fan connector to <b>CASFAN1</b>.</li> <li>6. Connect the case speaker cable to <b>SPEAKER1</b>.</li> <li>7. Connect the case LED cable to <b>SJ1</b>.</li> </ol>	
<ol style="list-style-type: none"> <li>8. Connect the case switches and indicator to <b>PANEL1</b>.</li> </ol>	

### ATX2: ATX 20-pin Power Connector

Pin	Signal Name	Pin	Signal Name
1	+3.3V	11	+3.3V
2	+3.3V	12	-12V
3	Ground	13	Ground
4	+5V	14	PS ON#
5	Ground	15	Ground
6	+5V	16	Ground
7	Ground	17	Ground
8	PWRGD	18	-5V
9	+5VSB	19	+5V
10	+12V	20	+5V

### ATX1: ATX 12V Power Connector

Pin	Signal Name
1	+12V
2	+12V
3	Ground
4	Ground

**CPUFAN1/CASFAN1/PWRFAN1 (optional): FAN Power Connectors**

Pin	Signal Name	Function
1	GND	System Ground
2	+12V	Power +12V
3	Sense	Sensor


**SPEAKER1: Internal speaker**

Pin	Signal Name
1	Signal
2	Key
3	Ground
4	VCC

**SJ1: Single color LED header (optional)**


Pin	Signal Name	Function
1	ACPI LED	MSG LED (-) green
2	ACPI LED	MSG LED (-) green
3	SB5V	Power LED (+)

**ACPI LED function:**

	S0	S1	S3	S4/S5
	Light	Blinking	Blinking	Dark

## Front Panel Connector

The front panel connector (PANEL1) provides a standard set of switch and LED connectors commonly found on ATX or micro-ATX cases. Refer to the table below for information:



Pin	Signal	Function	Pin	Signal	Function
1	HD_LED_P	Hard disk LED (positive)	2	FP PWR/SLP	MSG LED [dual color or single color (+)]
3	HD_LED_N	Hard disk active LED (negative)	4	FP PWR/SLP	MSG LED [dual color or single color (-)]
5	RST_SW_N	Reset Switch	6	PWR_SW_P	Power Switch
7	RST_SW_P	Reset Switch	8	PWR_SW_N	Power Switch
9	RSVD	Reserved	10	Key	No pin

### **Hard Drive Activity LED**

Connecting pins 1 and 3 to a front panel mounted LED provides visual indication that data is being read from or written to the hard drive. For the LED to function properly, an IDE drive should be connected to the onboard IDE interface. The LED will also show activity for devices connected to the SCSI (hard drive activity LED) connector.

### **Power / Sleep / Message Waiting LED**

Connecting pins 2 and 4 to a single- or dual-color, front panel mounted LED provides power on/off, sleep, and message waiting indication.

### **Reset Switch**

Supporting the reset function requires connecting pins 5 and 7 to a momentary-contact switch that is normally open. When the switch is closed, the board resets and runs POST.

### **Power Switch**

Supporting the power on/off function requires connecting pins 6 and 8 to a momentary-contact switch that is normally open. The switch should maintain contact for at least 50 ms to signal the power supply to switch on or off. The time requirement is due to internal debounce circuitry. After receiving a power on/off signal, at least two seconds elapses before the power supply recognizes another on/off signal.

---

## Installing Hardware

### Installing the Processor

**Caution:** When installing a CPU heatsink and cooling fan make sure that you DO NOT scratch the motherboard or any of the surface-mount resistors with the clip of the cooling fan. If the clip of the cooling fan scrapes across the motherboard, you may cause serious damage to the motherboard or its components.

On most motherboards, there are small surface-mount resistors near the processor socket, which may be damaged if the cooling fan is carelessly installed.

Avoid using cooling fans with sharp edges on the fan casing and the clips. Also, install the cooling fan in a well-lit work area so that you can clearly see the motherboard and processor socket.

### Before installing the Processor


This motherboard automatically determines the CPU clock frequency and system bus frequency for the processor. You may be able to change these settings by making changes to jumpers on the motherboard, or changing the settings in the system Setup Utility. We strongly recommend that you do not overclock processors or other components to run faster than their rated speed.

**Warning:** Overclocking components can adversely affect the reliability of the system and introduce errors into your system. Overclocking can permanently damage the motherboard by generating excess heat in components that are run beyond the rated limits.

This motherboard has a Socket 478 processor socket. When choosing a processor, consider the performance requirements of the system. Performance is based on the processor design, the clock speed and system bus frequency of the processor, and the quantity of internal cache memory and external cache memory.

## CPU Installation Procedure

The following illustration shows CPU installation components:




---

**Note:** The pin-1 corner is marked with an arrow ▼

---

Follow these instructions to install the Retention Module and CPU:


1. Press the lever down.



2. Apply thermal grease on top of the CPU.




3. Put the CPU Fan down on the retention module and snap the four retention legs of the cooling fan into place.



4. Flip the levers over to lock the heat sink in place.

5. Connect the CPU Cooling Fan power cable to the CPUFAN1 connector. This completes the installation.



- Notes:**
- To achieve better airflow rates and heat dissipation, we suggest that you use a high quality fan with 4800 rpm at least.
  - CPU fan and heatsink installation procedures may vary with the type of CPU fan/heatsink supplied. The form and size of fan/heatsink may also vary.

## Installing Memory Modules

This motherboard accommodates 184-pin 2.5V unbuffered Double Data Rate (DDR) SDRAM memory modules. The memory chips must be standard or registered SDRAM (Synchronous Dynamic Random Access Memory). The memory bus runs at 166 MHz.

---

**Note:** SDRAM provides 800 MBps or 1 GBps data transfer depending on whether the bus is 100MHz or 133MHz. Double Data Rate SDRAM (DDR SDRAM) doubles the rate to 1.6 GBps and 2.1 GBps. DDR SDRAM uses additional power and ground lines and requires 184-pin DIMM modules rather than the 168-pin DIMMs used by SDRAM.

---

The motherboard accommodates two memory modules. You must install at least one module in any of the two slots. Each module can be installed with 32 MB to 1 GB of memory; total memory capacity is 2 GB.




Do not remove any memory module from its antistatic packaging until you are ready to install it on the motherboard. Handle the modules only by their edges. Do not touch the components or metal parts. Always wear a grounding strap when you handle the modules.


Refer to the following to install the memory modules.

1. This motherboard supports unbuffered DDR SDRAM only. Do not attempt

to insert any other type of DDR SDRAM into the slots.



2. Push the latches on each side of the DIMM slot down.
3. Align the memory module with the slot. The DIMM slots are keyed with notches and the DIMMs are keyed with cutouts so that they can only be installed correctly.



4. Check that the cutouts on the DIMM module edge connector match the notches in the DIMM slot.
5. Install the DIMM module into the slot and press it firmly down until it seats correctly. The slot latches are levered upwards and latch on to the edges of the DIMM.



6. Install any remaining DIMM modules.

## Installing a Hard Disk Drive/CD-ROM

This section describes how to install IDE devices such as a hard disk drive and a CD-ROM drive.

Your mainboard has a primary and secondary IDE channel interface (IDE1 and IDE2). An IDE ribbon cable supporting two IDE devices is bundled with the mainboard.


If you want to install more than two IDE devices, get a second IDE cable and you can add two more devices to the secondary IDE channel.



You must orient the cable connector so that the pin 1 (color) edge of the cable corresponds to the pin 1 of the I/O port connector.


### IDE1: Primary IDE Connector

The first hard drive should always be connected to IDE1.



### IDE2: Secondary IDE

The second drive on this controller must be set to slave mode. The configuration is the same as IDE1.



IDE devices have jumpers or switches that are used to set the IDE device as MASTER or SLAVE. Refer to the IDE device user's manual. When installing two IDE devices on one cable, ensure that one device is set to MASTER and the other device is set to SLAVE. The documentation of your IDE device explains how to do this.

### About UltraDMA

This mainboard supports UltraDMA 66/100/133. UDMA is a technology that accelerates the performance of devices in the IDE channel. To maximize performance, install IDE devices that support UDMA and use 80-pin IDE cables that support UDMA 66/100/133.

## Installing a Floppy Diskette Drive


The mainboard has a floppy diskette drive (FDD) interface and ships with a diskette drive ribbon cable that supports one or two floppy diskette drives. You can install a 5.25-inch drive and a 3.5-inch drive with various capacities. The floppy diskette drive cable has one type of connector for a 5.25-inch drive and another type of connector for a 3.5-inch drive.



You must orient the cable connector so that the pin 1 (color) edge of the cable corresponds to the pin 1 of the I/O port connector.


### FDD1: Floppy Disk Connector

This connector supports the provided floppy drive ribbon cable. After connecting the single end to the onboard floppy connector, connect the remaining plugs on the other end to the floppy drives correspondingly.



## Installing Add-on Cards

The slots in this motherboard are designed to hold expansion cards and connect them to the system bus. Expansion slots are a means of adding or enhancing the motherboard's features and capabilities. With these efficient facilities, you can increase the motherboard's capabilities by adding hardware which performs tasks that are not part of the basic system.




- PCI Slots** PCI slots are used to install expansion cards that have the 32-bit PCI interface.
- AGP Slot** The AGP slot is used to install a graphics adapter that supports the 4xAGP specification and has a 4xAGP edge connector.
- CNR Slot** This slot is used to insert CNR cards with Modem and Audio functionality.

---

**Note:** Before installing an add-on card, check the documentation for the card carefully. If the card is not Plug and Play, you may have to manually configure the card before installation.

---


Follow these instructions to install an add-on card:

1. Remove a blanking plate from the system case corresponding to the slot you are going to use.	
2. Install the edge connector of the add-on card into the expansion slot. Ensure that the edge connector is correctly seated in the slot.	
3. Secure the metal bracket of the card to the system case with a screw.	

**Note:** For some add-on cards, for example graphics adapters and network adapters, you have to install drivers and software before you can begin using the add-on card.

## Connecting Optional Devices

Refer to the following for information on connecting the motherboard's optional devices:



### AUDIO1: Front Panel Audio header

This header allows the user to install auxiliary front-oriented microphone and line-out ports for easier access.

Pin	Signal Name	Function
1	AUD_MIC	Front Panel Microphone input signal
2	AUD_GND	Ground used by Analog Audio Circuits
3	AUD_MIC_BIAS	Microphone Power
4	AUD_VCC	Filtered +5 V used by Analog Audio Circuits
5	AUD_FPOUT_R	Right Channel Audio signal to Front Panel
6	AUD_RET_R	Right Channel Audio signal to Return from Front Panel
7	HP_ON	Reserved for future use to control Head-phone Amplifier
8	KEY	No Pin
9	AUD_FPOUT_L	Left Channel Audio signal to Front Panel
10	AUD_RET_L	Left Channel Audio signal Return from Front Panel

## USB3: Front panel USB ports

The motherboard has two USB ports installed on the rear edge I/O port array. Additionally, some computer cases have USB ports at the front of the case. If you have this kind of case, use auxiliary USB connector USB3 to connect the front-mounted ports to the motherboard.

Pin	Signal Name	Function
1	VREG_FP_USBPWR0	Front Panel USB Power
2	VREG_FP_USBPWR0	Front Panel USB Power
3	USB_FP_P0-	USB Port 0 Negative Signal
4	USB_FP_P1-	USB Port 1 Negative Signal
5	USB_FP_P0+	USB Port 0 Positive Signal
6	USB_FP_P1+	USB Port 1 Positive Signal
7	GND	Ground
8	GND	Ground
9	KEY	No pin
10	USB_FP_OC0	Overcurrent signal

**Note:** Please make sure that the USB cable has the same pin assignment as indicated above. A different pin assignment may cause damage or system hang-up.

## USBCR1: USB Card Reader connector

This connector is for connecting internal USB card reader. You can use a card reader to read or transfer files and digital images to your computer.

Pin	Signal Name	Function
1	USBVCC2	+5V dual
2	USB2-	Data signal port 2-
3	USB2+	Data signal port 2+
4	GND	Ground
5	Key	No pin

**Note:** The USBCR1 is shared with one of the USB ports of the I/O back panel. See “Connecting I/O Devices” for more information.



Please check the pin assignment of the cable and the USB header on the motherboard. Make sure the pin assignment will match before plugging in. Any incorrect usage may cause unexpected damage to the system.



## SPDIF1: SPDIF out header (optional)


This is an optional header that provides an S/PDIF (Sony/Philips Digital Interface) output to digital multimedia device through optical fiber or coaxial connector.

Pin	Signal Name
1	SPDIF Out
2	VCC
3	KEY
4	GND

---

## Connecting I/O Devices

The backplane of the motherboard has the following I/O ports:



- PS/2 Mouse** Use the upper PS/2 port to connect a PS/2 pointing device.
- PS/2 Keyboard** Use the lower PS/2 port to connect a PS/2 keyboard.
- LPT1** Use LPT1 to connect printers or other parallel communications devices.
- COM1** Use the COM ports to connect serial devices such as mice or fax/modems. COM1 is identified by the system as COM1/3.
- VGA Port** Connect your monitor to the VGA port.
- Audio Ports** Use the three audio ports to connect audio devices. The first jack is for stereo line-in signal. The second jack is for stereo line-out signal. The third jack is for microphone.
- LAN Port** Connect an RJ-45 jack to the LAN port to connect your computer to the Network.
- USB Ports** Use the USB ports to connect USB devices.

This concludes Chapter 2. The next chapter covers the BIOS.

## *Chapter 3*

# Using BIOS

---

### **About the Setup Utility**

The computer uses the latest Award BIOS with support for Windows Plug and Play. The CMOS chip on the motherboard contains the ROM setup instructions for configuring the motherboard BIOS.

The BIOS (Basic Input and Output System) Setup Utility displays the system's configuration status and provides you with options to set system parameters. The parameters are stored in battery-backed-up CMOS RAM that saves this information when the power is turned off. When the system is turned back on, the system is configured with the values you stored in CMOS.

The BIOS Setup Utility enables you to configure:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

The settings made in the Setup Utility affect how the computer performs. Before using the Setup Utility, ensure that you understand the Setup Utility options.

This chapter provides explanations for Setup Utility options.

### **The Standard Configuration**

A standard configuration has already been set in the Setup Utility. However, we recommend that you read this chapter in case you need to make any changes in the future.

This Setup Utility should be used:

- when changing the system configuration
- when a configuration error is detected and you are prompted to make changes to the Setup Utility
- when trying to resolve IRQ conflicts
- when making changes to the Power Management configuration
- when changing the password or making other changes to the Security Setup

## Starting Setup

The BIOS is immediately activated when you first turn on the computer. The BIOS reads system configuration in CMOS RAM and begins the process of checking out the system and configuring it through the power-on self test (POST).

When these preliminaries are finished, the BIOS seeks an operating system on one of the data storage devices (hard drive, floppy drive, etc.). The BIOS launches the operating system and hands control of system operations to it.

During POST, you can start the Setup program in one on two ways:

1. By pressing Del immediately after switching the system on, or
2. By pressing Del or pressing Ctrl+Alt+Esc when the following message appears briefly at the bottom of the screen during POST:

TO ENTER SETUP BEFORE BOOT PRESS DEL KEY

*If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the RESET button on the system case. You may also restart by simultaneously pressing Ctrl+Alt+Del. If you do not press the keys at the correct time and the system does not boot, an error message appears and you are again asked to:*

PRESS F1 TO CONTINUE, DEL TO ENTER SETUP

Phoenix – AwardBIOS CMOS Setup Utility

▶ <b>Standard CMOS Features</b>	▶ Frequency/Voltage Control
▶ Advanced BIOS Features	Load Fail-Safe Defaults
▶ Advanced Chipset Features	Load Optimized Defaults
▶ Integrated Peripherals	Set Password
▶ Power Management Setup	Save & Exit Setup
▶ PnP/PCI Configurations	Exit Without Saving
▶ PC Health Status	
Esc : Quit	↑ ↓ → ← : Select Item
F10 : Save & Exit Setup	
Time, Date, Hard Disk Type . . .	

## BIOS Navigation Keys


The BIOS navigation keys are listed below:

Key	Function
Esc	Exits the current menu
←↑↓→	Scrolls through the items on a menu
+/-/PU/PD	Modifies the selected field's values
F10	Saves the current configuration and exits setup
F1	Displays a screen that describes all key functions
F5	Loads previously saved values to CMOS
F6	Loads a minimum configuration for troubleshooting.
F7	Loads an optimum set of values for peak performance

## Updating the BIOS

You can download and install updated BIOS for this motherboard from the manufacturer's Web site. New BIOS provides support for new peripherals, improvements in performance, or fixes for known bugs. Install new BIOS as follows:

1. If your motherboard has a BIOS protection jumper, change the setting to allow BIOS flashing.
2. If your motherboard has an item called Firmware Write Protect in Advanced BIOS features, disable it. (Firmware Write Protect prevents BIOS from being overwritten.)
3. Create a bootable system disk. (Refer to Windows online help for information on creating a bootable system disk.)
4. Download the Flash Utility and new BIOS file from the manufacturer's Web site. Copy these files to the system diskette you created in Step 3.
5. Turn off your computer and insert the system diskette in your computer's diskette drive. (You might need to run the Setup Utility and change the boot priority items on the Advanced BIOS Features Setup page, to force your computer to boot from the floppy diskette drive first.)
6. At the A:\ prompt, type the Flash Utility program name and press <Enter>. You see a screen similar to the following:



7. Type the filename of the new BIOS in the "File Name to Program" text box. Follow the onscreen directions to update the motherboard BIOS.

8. When the installation is complete, remove the floppy diskette from the diskette drive and restart your computer. If your motherboard has a Flash BIOS jumper, reset the jumper to protect the newly installed BIOS from being overwritten.

## Using BIOS

When you start the Setup Utility, the main menu appears. The main menu of the Setup Utility displays a list of the options that are available. A highlight indicates which option is currently selected. Use the cursor arrow keys to move the highlight to other options. When an option is highlighted, execute the option by pressing <Enter>.

Some options lead to pop-up dialog boxes that prompt you to verify that you wish to execute that option. Other options lead to dialog boxes that prompt you for information.

Some options (marked with a triangle ►) lead to submenus that enable you to change the values for the option. Use the cursor arrow keys to scroll through the items in the submenu.

In this manual, default values are enclosed in parenthesis. Submenu items are denoted by a triangle ►.

## Standard CMOS Features

*In the Standard CMOS menu you can set the system clock and calendar, record disk drive parameters and the video subsystem type, and select the type of errors that stop the BIOS POST.*

Phoenix – AwardBIOS CMOS Setup Utility  
Standard CMOS Features

Date (mm:dd:yy)	Tue, July 11 2001	Item Help
Time (hh:mm:ss)	12 : 8 : 59	Menu Level ►
► IDE Primary Master		Change the day, month, year and century.
► IDE Primary Slave		
► IDE Secondary Master		
► IDE Secondary Slave		
Drive A	[1.44M, 3.5 in.]	
Drive B	[None]	
Floppy 3 Mode Support	[Disabled]	
Video	[EGA/VGA]	
Halt On	[All Errors]	
Base Memory	640K	
Extended Memory	31744K	
Total Memory	32768K	

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

### Date and Time

The Date and Time items show the current date and time on the computer. If you are running a Windows OS, these items are automatically updated when-

ever you make changes to the Windows Date and Time Properties utility.

► **IDE Devices (None)**

Your computer has two IDE channels (Primary and Secondary) and each channel can be installed with one or two devices (Master and Slave). Use these items to configure each device on the IDE channel.

Press <Enter> to display the IDE submenu:

Phoenix – AwardBIOS CMOS Setup Utility  
IDE Primary Master

IDE HDD Auto-Detection	[Press Enter]	Item Help
IDE Primary Master	[Auto]	Menu Level ►► To auto-detect the HDD's size, head . . . on this channel
Access Mode	[Auto]	
Capacity	0 MB	
Cylinder	0	
Head	0	
Precomp	0	
Landing Zone	0	
Sector	0	

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

**IDE HDD Auto-Detection**

Press <Enter> while this item is highlighted to prompt the Setup Utility to automatically detect and configure an IDE device on the IDE channel.

**Note:** If you are setting up a new hard disk drive that supports LBA mode, more than one line will appear in the parameter box. Choose the line that lists LBA for an LBA drive.

**IDE Primary/Secondary Master/Slave (Auto)**

Leave this item at Auto to enable the system to automatically detect and configure IDE devices on the channel. If it fails to find a device, change the value to Manual and then manually configure the drive by entering the characteristics of the drive in the items described below.

Refer to your drive's documentation or look on the drive casing if you need to obtain this information. If no device is installed, change the value to None.

**Note:** Before attempting to configure a hard disk drive, ensure that you have the configuration information supplied by the manufacturer of your hard drive. Incorrect settings can result in your system not recognizing the installed hard disk.

**Access Mode**

This item defines ways that can be used to access IDE hard disks such as LBA (Large Block Addressing). Leave this value at Auto and the system will automatically decide the fastest way to access the hard disk drive.

Press <Esc> to return to the Standard CMOS Setup screen.

### Drive A/Drive B (1.44M, 3.5 in.)

These items define the characteristics of any diskette drive attached to the system. You can connect one or two diskette drives.

### Floppy 3 Mode Support (Disabled)

Floppy 3 mode refers to a 3.5-inch diskette with a capacity of 1.2 MB. Floppy 3 mode is sometimes used in Japan.

### Video (EGA/VGA)

This item defines the video mode of the system. This motherboard has a built-in VGA graphics system; you must leave this item at the default value.

### Halt On (All Errors)

This item defines the operation of the system POST (Power On Self Test) routine. You can use this item to select which types of errors in the POST are sufficient to halt the system.

### Base Memory, Extended Memory, and Total Memory

These items are automatically detected by the system at start up time. These are display-only fields. You cannot make changes to these fields.

## Advanced BIOS Setup

*This screen contains industry-standard options additional to the core PC AT BIOS.*

### Phoenix – AwardBIOS CMOS Setup Utility Advanced BIOS Setup

Virus Warning	[Disabled]		Item Help
CPU L1 & L2 Cache	[Enabled]		Menu Level ▶
Hyper-Threading Technology	[Enabled]		Allows you to choose the VIRUS warning feature for IDE Hard
Quick Power On Self Test	[Enabled]		Disk boot sector protection. If this function is enabled
First Boot Device	[Floppy]		and someone attempts to write data into this area, BIOS will show a warning message on screen and alarm beep
Second Boot Device	[HDD-0]		
Third Boot Device	[CDROM]		
Boot Other Device	[Enabled]		
Swap Floppy Drive	[Disabled]		
Boot Up Floppy Seek	[Disabled]		
Boot Up NumLock Status	[On]		
Gate A20 Option	[Fast]		
ATA 66/100 Cable MSG	[Enabled]		
Typematic Rate Setting	[Disabled]		
x Typematic Rate (Chars/Sec)	6		
x Typematic Delay (Msec)	250		
Security Option	[Setup]		
APIC Mode	[Enabled]		
OS Select For DRAM > 64MB	[Non-OS2]		
HDD S.M.A.R.T Capability	[Disabled]		

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

### **Virus Warning (Disabled)**

When enabled, this item provides protection against viruses that try to write to the boot sector and partition table of your hard disk drive. You need to disable this item when installing an operating system. We recommend that you enable this item as soon as you have installed an operating system.

---

**Note:** For complete protection against viruses, install virus software in your operating system and update the virus definitions regularly.

---

### **CPU L1 and L2 Cache (Enabled)**

All processors that can be installed in this motherboard use internal level 1 (L1) and external level 2 (L2) cache memory to improve performance. Leave this item at the default value for better performance.

### **Hyper-Threading Technology (Enabled)**

This item is only available when the chipset supports Hyper-Threading and you are using a Hyper-Threading CPU.

### **Quick Power On Self Test (Enabled)**

Enable this item to shorten the power on testing (POST) and have your system start up faster. You might like to enable this item after you are confident that your system hardware is operating smoothly.

### **First/Second/Third Boot Device (Floppy/HDD-0/CDROM)**

Use these three items to select the priority and order of the devices that your system searches for an operating system at start-up time.

### **Boot Other Device (Enabled)**

When enabled, the system searches all other possible locations for an operating system if it fails to find one in the devices specified under the First, Second, and Third boot devices.

### **Swap Floppy Drive (Disabled)**

If you have two floppy diskette drives in your system, this item allows you to swap the assigned drive letters so that drive A becomes drive B, and drive B becomes drive A.

### **Boot Up Floppy Seek (Disabled)**

If this item is enabled, it checks the size of the floppy disk drives at start-up time. You don't need to enable this item unless you have a legacy diskette drive with 360K capacity.

### **Boot Up NumLock Status (On)**

This item defines if the keyboard Num Lock key is active when your system is started.

### **Gate A20 Option (Fast)**

This item defines how the system handles legacy software that was written for an earlier generation of processors. Leave this item at the default value.



#### **ATA 66/100 Cable MSG (Enabled)**

This item enables or disables the display of the ATA 66/100 Cable MSG.

#### **Typematic Rate Setting (Disabled)**

If this item is enabled, you can use the following two items to set the typematic rate and the typematic delay settings for your keyboard.

- **Typematic Rate (Chars/Sec):** Use this item to define how many characters per second are generated by a held-down key.
- **Typematic Delay (Msec):** Use this item to define how many milliseconds must elapse before a held-down key begins generating repeat characters.

#### **Security Option (Setup)**

If you have installed password protection, this item defines if the password is required at system start up, or if it is only required when a user tries to enter the Setup Utility.

#### **APIC Mode (Enable)**

This option is used to enable or disable APIC (Advanced Programmable Interrupt Controller) functionality. The APIC is an Intel chip that provides symmetric multiprocessing (SMP) for its Pentium systems.

#### **OS Select For DRAM > 64 MB (Non-OS2)**

This item is only required if you have installed more than 64 MB of memory and you are running the OS/2 operating system. Otherwise, leave this item at the default.

#### **HDD S.M.A.R.T Capability (Disabled)**

The S.M.A.R.T. (Self-Monitoring, Analysis, and Reporting Technology) system is a diagnostics technology that monitors and predicts device performance. S.M.A.R.T. software resides on both the disk drive and the host computer.

The disk drive software monitors the internal performance of the motors, media, heads, and electronics of the drive. The host software monitors the overall reliability status of the drive. If a device failure is predicted, the host software, through the Client WORKS S.M.A.R.T applet, warns the user of the impending condition and advises appropriate action to protect the data.

#### **Report No FDD For WIN95 (Yes)**

If you are running a system with no floppy drive and using Windows 95, select Yes for this item to ensure compatibility with the Windows 95 logo certification. Otherwise, select No.

#### **Small Logo (EPA) Show (Disabled)**

Enables or disables the display of the EPA logo during boot.

## Advanced Chipset Setup

The parameters in this screen are for system designers, service personnel, and technically competent users only. Do not reset these values unless you understand the consequences of your changes.

Phoenix – AwardBIOS CMOS Setup Utility  
Advanced Chipset Setup

▶ Advanced DRAM Control 1 [Press Enter] Prefetch Caching [Disabled] AGP Aperture Size [128MB]	Item Help
	Menu Level ▶

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
 F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

### ▶ Advanced DRAM Control 1

Scroll to this item and press <Enter> to view the following screen:

CMOS Setup Utility – Copyright (C) 1984 – 2001 Award Software  
Advanced DRAM Control 1

System Performance [Normal Mode] CAS Latency Setting [2.5T] DRAM Addr/Cmd Rate [Auto Mode]	Item Help
	Menu Level ▶

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
 F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

#### **System Performance (Normal Mode)**

This is the DRAM auto configuration option, which can be set to Safe Mode, Normal Mode, Fast Mode or Ultra Mode.

#### **CAS Latency Setting (2.5T)**

Enables you to select the CAS latency time in HCLKs of 2, 2.5, or 3. The value is set at the factory depending on the DRAM installed. Do not change the values in this field unless you change specifications of the installed DRAM or the installed CPU.





► **SIS OnChip PCI Device**

Scroll to this item and press <Enter> to view the following screen:

Phoenix – AwardBIOS CMOS Setup Utility  
SIS OnChip PCI Device

SIS-7012 AC97Audio	[Enabled]	Item Help
SIS-7013 S/W Modem	[Enabled]	
SIS 10/100M Ethernet	[Enabled]	Menu Level ►►
Onboard LAN Boot ROM	[Disabled]	
System Share Memory Size	[32 MB]	

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

**SIS-7012 AC97 AUDIO (Enabled)**

Enables and disables the onboard AC 97 audio function. Disable this item if you are going to install a PCI audio add-on card.

**SIS-7013 S/W Modem (Enabled)**

Enables and disables the onboard modem. Disable this item if you are going to install an external modem.

**SIS 10/100M Ethernet (Enabled)**

Enables and disables the onboard LAN.

**Onboard LAN Boot ROM (Disabled)**

Use this item to enable and disable the booting from the onboard LAN or a network add-in card with a remote boot ROM installed.

**System Share Memory Size (32MB)**

This motherboard has a built-in graphics system that uses UMA (Unified Memory Architecture) so that the graphics reserves a part of main memory for video memory. Use this item to determine how much of the main memory can be used as video memory.

Press <Esc> to return to the Integrated Peripherals screen.

## ► Onboard SuperIO Device

Scroll to this item and press <Enter> to view the following screen:

Phoenix – AwardBIOS CMOS Setup Utility  
Onboard SuperIO Device

Onboard FDC Controller	[Enabled]	Item Help
Onboard Serial Port 1	[3F8/IRQ4]	
Onboard Parallel Port	[378/IRQ7]	Menu Level ►►
Parallel Port Mode	[ECP]	
ECP Mode Use DMA	[3]	

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

### **Onboard FDC Controller (Enabled)**

This option enables the onboard floppy disk drive controller.

### **Onboard Serial Port 1 (3F8/IRQ4)**

This option is used to assign the I/O address and interrupt request (IRQ) for onboard serial port 1 (COM1).

### **Onboard Parallel Port (378/IRQ7)**

This option is used to assign the I/O address and interrupt request (IRQ) for the onboard parallel port.

### **Parallel Port Mode (ECP)**

Enables you to set the data transfer protocol for your parallel port. There are four options: SPP (Standard Parallel Port), EPP (Enhanced Parallel Port), ECP (Extended Capabilities Port) and ECP+EPP.

SPP allows data output only. Extended Capabilities Port (ECP) and Enhanced Parallel Port (EPP) are bi-directional modes, allowing both data input and output. ECP and EPP modes are only supported with EPP- and ECP-aware peripherals.

### **ECP Mode Use DMA (3)**

When the onboard parallel port is set to ECP mode, the parallel port can use DMA 3 or DMA 1.

Press <Esc> to return to the Integrated Peripherals screen.

### **USB Controller (Enabled)**

Enable this item if you plan to use the Universal Serial Bus ports on this motherboard.

### **USB Keyboard Support (Disabled)**

Enable this item if you plan to use a keyboard connected through the USB port in a legacy operating system (such as DOS) that does not support Plug and Play.

### **Onboard LAN (Enabled)**

Use this item to enable and disable the onboard LAN function.

### **IDE HDD Block Mode (Enabled)**

Enable this field if your IDE hard drive supports block mode. Block mode enables BIOS to automatically detect the optimal number of block read and writes per sector that the drive can support. It also improves the speed of access to IDE devices.

### **Init Display First (PCI Slot)**

Use this item to specify whether your graphics adapter is installed in one of the PCI slots or is integrated on the motherboard.

### **AGP Auto Calibration (Enabled)**

This item allows you to enable or disable the AGP buffer strength auto calibration through the chipset.

### **IDECHO/IDECH1 ACCESS INTERFACE (EDB Bus)**

This item determines whether the IDE access interface is the PCI bus or the embedded bus.

### **USB0/USB1/USB2 ACCESS INTERFACE (EDB Bus)**

This option determines whether the USB0/USB1/USB2 access interface is the embedded bus or the PCI bus.

### **USB2.0 ACCESS INTERFACE (EDB BUS)**

This option determines whether the USB2.0 access interface is the embedded bus or a PCI bus.

### **Audio ACCESS INTERFACE (EDB BUS)**

This option determines whether the audio access interface is the embedded bus or a PCI bus.

## **Power Management Setup**

*The Power Management Setup Menu option is used to change the values of the chipset registers for system power management.*

### **Power Management Timeouts**

The power-saving modes can be controlled by timeouts. If the system is inactive for a time, the timeouts begin counting. If the inactivity continues so that the timeout period elapses, the system enters a power-saving mode. If any item in the list of Reload Global Timer Events is Enabled, then any activity on that item will reset the timeout counters to zero.

## Wake Up Calls

If the system is suspended, or has been powered down by software, it can be resumed by a wake up call that is generated by incoming traffic to a modem, a LAN card, a PCI card, or a fixed alarm on the system realtime clock.

### Phoenix – AwardBIOS CMOS Setup Utility Power Management Setup

		Item Help
	ACPI function	[Enabled]
x	ACPI Suspend Type	S1(POS)
	Video Off Option	[Susp, Stby --> Off]
	Video Off Method	[DPMS Supported]
	MODEM Use IRQ	[Auto]
	Hot Key Function as	[Power Off]
	HDD Off After	[Disabled]
	Power Button Override	[Instant-Off]
	Power State Resume Control	[Always Off]
▶	PM Wake Up Events	[Press Enter]
	Delay Prior to Thermal	[None]

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General  
Help    F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

### ACPI Function (Enabled)

This motherboard supports ACPI (Advanced Configuration and Power management Interface). Use this item to enable or disable the ACPI feature.

---

**Note:** ACPI is a power management specification that makes hardware status information available to the operating system. ACPI enables a PC to turn its peripherals on and off for improved power management. It also allows the PC to be turned on and off by external devices, so that mouse or keyboard activity wakes up the computer.

---

### ACPI Suspend Type (S1(POS))

Use this item to define how your system suspends. In the default, S1(POS), the suspend mode is equivalent to a software power down. If you select S3 (STR), the suspend mode is a suspend to RAM, i.e., the system shuts down with the exception of a refresh current to the system memory.

### Video Off Option (Susp, Stby --> Off)

This option defines if the video is powered down when the system is put into suspend mode.

### Video Off Method (DPMS Supported)

This item defines how the video is powered down to save power. This item is set to DPMS (Display Power Management Software) by default.

### MODEM Use IRQ (Auto)

If you want an incoming call on a modem to automatically resume the system from a power-saving mode, use this item to specify the interrupt request line





system to wake from a power saving mode.

**IRQ 8 Break Suspend (Disabled)**

Determines whether the system will monitor IRQ 8 activity and wake the system from a power saving mode when IRQ 8 is activated.

**Ring PowerUp Control (Disabled)**

Use this item to enable LAN or modem activity to wakeup the system from a power saving mode.

**PCIPME Power Up Control (Enabled)**

Use this item to enable PCI activity to wakeup the system from a power saving mode.

**Power Up by Alarm (Disabled)**

When set to Enabled, the following three fields become available: Month Alarm, Day of Month Alarm, and Time Alarm Upon arrival of the alarm time, it will instruct the system to wake up.

When set to 0 (zero) for the day of the month, the alarm will power on your system every day at the specified time.

**\*\* Reload Global Timer Events \*\***

Global Timer (power management) events are I/O events whose occurrence can prevent the system from entering a power saving mode or can awaken the system from such a mode. In effect, the system remains alert for anything that occurs to a device that is configured as Enabled, even when the system is in a power-down mode.

**Primary/Secondary IDE 1/0 (Disabled)**

When these items are enabled, the system will restart the power-saving timeout counters when any activity is detected on any of the drives or devices on the primary or secondary IDE channels.

**FDD, COM, LPT Port (Disabled)**

When this item is enabled, the system will restart the power-saving timeout counters when any activity is detected on the floppy disk drive, serial ports, or the parallel port.

**PCI PIRQ[A-D]# (Disabled)**

When disabled, any PCI device set as the Master will not power on the system.

**PWRON After PWR-Fail (Off)**

This item enables your computer to automatically restart or return to its last operating status after power returns from a power failure.

Press <Esc> to return to the Power Management screen.

## PNP/PCI Configurations

This section describes configuring the PCI bus system. PCI (Peripheral Component Interconnect) is a system, which allows I/O devices to operate at speeds nearing CPU's when they communicate with own special components.

All the options describes in this section are important and technical and it is strongly recommended that only experienced users should make any changes to the default settings.

### Phoenix – AwardBIOS CMOS Setup Utility PnP/PCI Configurations

		Item Help
Reset Configuration Data	[Disabled]	Menu Level ►  Default is Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the OS cannot boot
Resources Controlled by	[Auto(ESCD)]	
x IRQ Resources	Press Enter	
PCI/VGA Palette Snoop	[Disabled]	
INT Pin 1 Assignment	[Auto]	
INT Pin 2 Assignment	[Auto]	
INT Pin 3 Assignment	[Auto]	
INT Pin 4 Assignment	[Auto]	
INT Pin 5 Assignment	[Auto]	
INT Pin 6 Assignment	[Auto]	
INT Pin 7 Assignment	[Auto]	
INT Pin 8 Assignment	[Auto]	

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
 F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

### Reset Configuration Data (Disabled)

If you enable this item and restart the system, any Plug and Play configuration data stored in the BIOS Setup is cleared from memory.

### Resources Controlled By (Auto(ESCD))

You should leave this item at the default Auto(ESCD). Under this setting, the system dynamically allocates resources to Plug and Play devices as they are required.

If you cannot get a legacy ISA (Industry Standard Architecture) expansion card to work properly, you might be able to solve the problem by changing this item to Manual, and then opening up the IRQ Resources submenu.

In the IRQ Resources submenu, if you assign an IRQ to Legacy ISA, then that Interrupt Request Line is reserved for a legacy ISA expansion card. Press <Esc> to close the IRQ Resources submenu.

### PCI/VGA Palette Snoop (Disabled)

This item is designed to overcome problems that can be caused by some non-standard VGA cards. This board includes a built-in VGA system that does not require palette snooping so you must leave this item disabled.

### INT Pin 1-8 Assignment (Auto)

Identifies the interrupt request (IRQ) line assigned to a device connected to the PCI interface of your system.

### PC Health Status

*On motherboards that support hardware monitoring, this item lets you monitor the parameters for critical voltages, critical temperatures, and fan speeds.*

Phoenix – AwardBIOS CMOS Setup Utility  
PC Health Status

Shutdown Temperature [Disabled]	Item Help
CPU Core Voltage	Menu Level ▶
CPU Temperature	
CPUFAN Speed	

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

### Shutdown Temperature

Enables you to set the maximum temperature the system can reach before powering down.

### System Component Characteristics

These fields provide you with information about the systems current operating status. You cannot make changes to these fields.

## Frequency/Voltage Control

This BIOS menu enables you to set the clock speed and system bus for your system. The clock speed and system bus are determined by the kind of processor you have installed in your system.

Phoenix – AwardBIOS CMOS Setup Utility  
Frequency/Voltage Control

CPU Clock Ratio	[0 X]	Item Help
Auto Detect DIMM/PCI Clk	[Enabled]	Menu Level ►
Spread Spectrum	[Enabled]	
CPU Host/SDRAM/PCI Clock	[Default]	

↑↓→← : Move    Enter : Select    +/-/PU/PD:Value:    F10: Save    ESC: Exit    F1:General Help  
F5:Previous Values    F6:Fail-Safe Defaults    F7:Optimized Defaults

### CPU Clock Ratio (0 X)

Use the CPU Host/SDRAM/PCI Clock to set the frontside bus frequency for the installed processor (usually 133 MHz, 100 MHz or 66 MHz). Then use *CPU Clock Ratio Jumpless* to set a multiple. The multiple times the frontside bus must equal the core speed of the installed processor e.g., **3.5 (multiple) x 100 MHz (frontside bus) = 350 MHz (installed processor clock speed)**.

### Auto Detect DIMM/PCI Clk (Enabled)

When this item is enabled, BIOS will disable the clock signal of free DIMM and PCI slots.

### Spread Spectrum (Enabled)

If you enable spread spectrum, it can significantly reduce the EMI (Electro-Magnetic Interference) generated by the system.

### CPU Host/SDRAM/PCI Clock (Default)

Use the CPU Host Clock to set the frontside bus frequency for the installed processor (usually 133 MHz, 100 MHz or 66 MHz).

## Load Fail-Safe Defaults Option

This option opens a dialog box that lets you install fail-safe defaults for all appropriate items in the Setup Utility:

Press <Y> and then <Enter> to install the defaults. Press <N> and then <Enter> to not install the defaults. The fail-safe defaults place no great demands on the system and are generally stable. If your system is not functioning correctly, try installing the fail-safe defaults as a first step in getting your system working properly again. If you only want to install fail-safe defaults for a specific option, select and display that option, and then press <F6>.

## Load Optimized Defaults Option

This option opens a dialog box that lets you install optimized defaults for all appropriate items in the Setup Utility. Press <Y> and then <Enter> to install the defaults. Press <N> and then <Enter> to not install the defaults. The optimized defaults place demands on the system that may be greater than the performance level of the components, such as the CPU and the memory. You can cause fatal errors or instability if you install the optimized defaults when your hardware does not support them. If you only want to install setup defaults for a specific option, select and display that option, and then press <F7>.

## Set Password

When this function is selected, the following message appears at the center of the screen to assist you in creating a password.

### ENTER PASSWORD

Type the password, up to eight characters, and press <Enter>. The password typed now will clear any previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection.

To disable password, just press <Enter> when you are prompted to enter password. A message will confirm the password being disabled. Once the password is disabled, the system will boot and you can enter BIOS Setup freely.

### PASSWORD DISABLED

If you have selected **System** in "Security Option" of "BIOS Features Setup" menu, you will be prompted for the password every time the system reboots or any time you try to enter BIOS Setup.

If you have selected **Setup** at "Security Option" from "BIOS Features Setup" menu, you will be prompted for the password only when you enter BIOS Setup.

## Save & Exit Setup Option

Highlight this item and press <Enter> to save the changes that you have made in the Setup Utility and exit the Setup Utility. When the Save and Exit dialog box appears, press <Y> to save and exit, or press <N> to return to the main menu:

## Exit Without Saving

Highlight this item and press <Enter> to discard any changes that you have made in the Setup Utility and exit the Setup Utility. When the Exit Without Saving dialog box appears, press <Y> to discard changes and exit, or press <N> to return to the main menu.

---

**Note:** If you have made settings that you do not want to save, use the "Exit Without Saving" item and press <Y> to discard any changes you have made.

---

This concludes Chapter 3. Refer to the next chapter for information on the software supplied with the motherboard.

## Using the Motherboard Software

---

### About the Software CD-ROM

The support software CD-ROM that is included in the motherboard package contains all the drivers and utility programs needed to properly run the bundled products. Below you can find a brief description of each software program, and the location for your motherboard version. More information on some programs is available in a README file, located in the same directory as the software.

---

**Note:** Never try to install software from a folder that is not specified for use with your motherboard.

---

Before installing any software, always inspect the folder for files named README.TXT, INSTALL.TXT, or something similar. These files may contain important information that is not included in this manual.

---

### Auto-installing under Windows 98/ME/2000/XP


The Auto-install CD-ROM makes it easy for you to install the drivers and software for your motherboard.

---

**Note:** If the Auto-install CD-ROM does not work on your system, you can still install drivers through the file manager for your OS (for example, Windows Explorer). Refer to Utility Folder Installation Notes later in this chapter.

---

The support software CD-ROM disc loads automatically under Windows 98/ME/2000/XP. When you insert the CD-ROM disc in the CD-ROM drive, the autorun feature will automatically bring up the install screen. The screen has three buttons on it, Setup, Browse CD and Exit.



---

**Note:** If the opening screen doesn't appear, double-click the file "setup.exe" in the root directory.

---



## Setup Tab

<b>Setup</b>	Click the <b>Setup</b> button to run the software installation program. Select from the menu which software you want to install.
<b>Browse CD</b>	<p>The <b>Browse CD</b> button is the standard Windows command that allows you to open Windows Explorer and show the contents of the support CD.</p> <p>Before installing the software from Windows Explorer, look for a file named README.TXT, INSTALL.TXT or something similar. This file may contain important information to help you install the software correctly.</p> <p>Some software is installed in separate folders for different operating systems, such as DOS, WIN NT, or WIN98/95. Always go to the correct folder for the kind of OS you are using.</p> <p>To install the software, execute a file named SETUP.EXE or INSTALL.EXE by double-clicking the file and then following the instructions on the screen.</p>
<b>Exit</b>	The <b>Exit</b> button closes the Auto Setup window.

## Application Tab

Lists the software utilities that are available on the CD.


## Read Me Tab

Displays the path for all software and drivers available on the CD.

## Running Setup

Follow these instructions to install device drivers and software for the motherboard:

1. Click **Setup**. The installation program begins:




---

**Note:** The following screens are examples only. The screens and driver lists will be different according to the motherboard you are installing.


---

The motherboard identification is located in the upper left-hand corner.

2. Click **Next**. The following screen appears:



3. Check the box next to the items you want to install. The default options are recommended.
4. Click **Next** run the Installation Wizard. An item installation screen appears:



5. Follow the instructions on the screen to install the items. Drivers and software are automatically installed in sequence. Follow the on-screen instructions, confirm commands and allow the computer to restart a few times to complete the installation.

---

## Manual Installation

Insert the CD in the CD-ROM drive and locate the PATH.DOC file in the root directory. This file contains the information needed to locate the drivers for your motherboard.

Look for the chipset and motherboard model; then browse to the directory and path to begin installing the drivers. Most drivers have a setup program (SETUP.EXE) that automatically detects your operating system before installation. Other drivers have the setup program located in the operating system subfolder.

If the driver you want to install does not have a setup program, browse to the operating system subfolder and locate the readme text file (README.TXT or README.DOC) for information on installing the driver or software for your operating system.

---

## Utility Software Reference

All the utility software available from this page is Windows compliant. They are provided only for the convenience of the customer. The following software is furnished under license and may only be used or copied in accordance with the terms of the license.

---

**Note:** These software(s) are subject to change at anytime without prior notice.  
Please refer to the support CD for available software.

---

### AMI/AWARD Flash Memory Utility

This utility lets you erase the system BIOS stored on a Flash Memory chip on the motherboard, and lets you copy an updated version of the BIOS to the chip. Proceed with caution when using this program. If you erase the current BIOS and fail to write a new BIOS, or write a new BIOS that is incorrect, your system will malfunction. Refer to Chapter 3, *Using BIOS* for more information.

### WinFlash Utility

The Award WinFlash utility is a Windows version of the DOS Award BIOS flash writer utility. The utility enables you to flash the system BIOS stored on a Flash Memory chip on the motherboard while in a Windows environment. This utility is currently available for WINXP\ME\2000\98SE. To install the WinFlash utility, run WINFLASH.EXE from the following directory:

UTILITY\WINFLASH 1.51

This concludes Chapter 4.