

Note to Users

This User' s Guide & Technical Reference are for assisting system manufacturers and end users in setting up and installing the motherboard. Every effort has been made to ensure that the information in this manual is accurate. **Champion-First** Electronics Limited is not responsible for printing or clerical errors. Information in this document is subject to change without notice and does not represent a commitment on the part of **Champion-First**. For previous or updated manuals, BIOS, drivers, or product release information, please contact **Champion-First** Electronics Limited at <http://www.champion-first.com> or through any of the means indicated on the following pages.

Companies and products mentioned in this manual are for identification purposes only. Product names appearing in this manual may or may not be registered trademarks or copyrights of their respective owners.

WebSite: <http://www.champion-first.com>
Email: info@champion-first.com
Product Name: GC-2001
Version: 1.00
Edition: May, 2001

Table of Contents

Chapter 1 Introduction	3
1.1 Product Features	3
1.2 Features Summary	3
Chapter 2 Installation	4
2.1 Installation Instructions	4
2.2 Motherboard Layout	4
2.3 Jumper Setting	5
2.4 Function & Installation Instructions	7
2.4.1 ATX Power Supply Connector	7
2.4.2 External Connectors	7
2.4.3 AT Keyboard Connector	8
2.4.4 Serial Port Connector	8
2.4.5 USB Connector	8
2.4.6 PS/2 Connector	8
2.4.7 Parallel Port Connector	8
2.4.8 SDRAM Sockets	9
2.4.9 Floppy Drive Connector	9
2.4.10 IDE Connectors	9
2.4.11 BIOS	9
2.4.12 PCI Slots	10
2.4.13 AGP Slot	10
2.4.14 Wake-On-LAN Interface	10
2.4.15 Front Panel Function Connector	10
2.4.16 PGA370 CPU Socket	10
2.4.17 CPU Fan Connector	11
Chapter 3 Software Installation	12
Chapter 4 AMI BIOS Setup	13
4.1 Standard CMOS Setup	15
4.2 Advanced BIOS Features	17
4.3 Advanced Chipset Features	17
4.4 Power Management Setup	17
4.5 PCI/PnP Setup	17
4.6 CPU Configuration Setup	17
4.7 Save & Exit Setup	17
4.8 Exit Without Saving	17

Chapter 1

Introduction

1.1 Product Features

The Intel 443BX highest performance motherboard is based on the all new Intel 443BX chipset with Baby AT form factor to support the latest Socket 370 including Intel Pentium III FCPGA, Celeron FCPGA / PPGA as well as Cyrix III processors.

1.2 Features Summary

This Motherboard comes with following features:

- ★ Support Intel Pentium III FCPGA, Celeron PPGA or Cyrix III Processor on Socket 370
- ★ Intel 443BX Chipset
- ★ Two DIMM slots Supporting up to 512MB Memory Capacity
- ★ Support 100MHz PC100 SDRAM DIMM
- ★ 4 x PCI slots, 1 x AGP slot
- ★ 2 x USB ports, 1 x PS/2 mouse port, 1 x PS/2 Keyboard port, 1 x IrDA port
- ★ 1 x FDD port, 1 x LPT port, 2 x COM ports
- ★ Dual IDE Channels Supporting Four Ultra-DMA33 IDE Devices
- ★ Advanced Configuration Power Interface (ACPI) Ready.
- ★ 2MB AMI BIOS, PC99/ACPI/DMI Compliant
- ★ AT/ATX Power Supply Interface
- ★ Baby AT format, 220mm x 195mm PCB

Chapter 2 Installation


2.1 Installation Instructions

This section covers External Connectors and Memory Configuration. Please refer to the motherboard layout chart for external connectors, slots and I/O ports. Furthermore, this section lists all necessary connector pin assignments for your reference. The locations of the connectors and ports are illustrated in the following figures. Before inserting these connectors, please pay attention to the orientations.

NOTICE !!!



1. Make sure to unplug your power supply while adding or removing system components
2. Always work on an antistatic surface to avoid possible damage to the motherboard or other components from static discharge.

2.2 Motherboard Layout





2.3 Jumper Setting



CPU Speed - JP1

JP1	CPU Speed
1  (1-2)	100 MHz
1  (2-3)	66 MHz



CPU Speed - JP2

JP2	CPU Speed
1  (1-2)	100 MHz
1  (2-3)	133 MHz






















CPU Voltage - JP9

JP9	CPU Voltage
1  (1-2)	VCC
1  (2-3)	5VSB

CMOS Clear - JP28

JP28	Function
1  (1-2)	Normal (Default)
1  (2-3)	CMOS Clear

CPU Frequency Ratio selection - JP3


JP3	CPU Ratio	CPU Speed		
		66MHz	100MHz	133MHz
7  1 8  2	4.0 X			533MHz
7  1 8  2	4.5 X	300MHz		600MHz
7  1 8  2	5.0 X	333MHz	500MHz	667MHz
7  1 8  2	5.5 X	366MHz	550MHz	733MHz
7  1 8  2	6.0 X	400MHz	600MHz	800MHz
7  1 8  2	6.5 X	433MHz	650MHz	866MHz
7  1 8  2	7.0 X	466MHz	700MHz	933MHz
7  1 8  2	7.5 X	500MHz	750MHz	1000MHz
7  1 8  2	8.0 X	533MHz	800MHz	1066MHz

Remark:  Open  Close

2.4 Function & Installation Instructions

2.4.1 AT Power Supply Connector (12-Pin)

This connector connects to a standard 5V power supply. To connect the leads from the power supply, ensure first that the power supply is not power on. Most power supplies provide two plugs, and each plug contains six wires. Two of six wires are black and please orient the plugs to the connector so that 4 black wires are together.




AT Power Connector

At a slight angle, align the plastic guide pins on the lead to their receptacles on the connector. Once aligned, press the lead onto the connector until the lead locks into place.

2.4.2 ATX Power Supply Connector (20-Pin)

This connector connects to an ATX power supply. The plug from ATX power supply will only insert in one orientation because of the different hole sizes. Find the proper orientation and push down firmly making sure that the pins are aligned. The system power can be turned off through software control, like the shut down in Windows 2000 / ME / 98 / 95 start menu. Power management must be enabled in the system BIOS in order to activate this soft-off feature. Once the system BIOS receives the power management command from the OS, it will switch the system power off.



ATX Power Connector

2.4.3 AT Keyboard Connector


This connector supports a standard IBM-compatible keyboard, such as 101/102 enhanced keyboard (Use a PS/2 keyboard adapter in order to connect a PS/2 KB to this AT connector.).

2.4.4 Serial (COM1/COM2) Port Connector

This motherboard provides two compatible serial ports, it can be used when add additional serial devices.

2.4.5 USB Connector

This 8-pin connector connects to the optional USB ports cable with a mounting bracket.



2.4.6 PS/2 Connector

This 5-pin connector connects to the PS/2 ports cable with a mounting bracket.

2.4.7 Parallel Port Connector (26-pin)

This connector supports the included parallel port ribbon cable with mounting bracket. Connect the parallel port ribbon cable to this connection and mount the bracket to the case on an open slot, it will then be available for a parallel printer cable.


EXPANSION CARDS INSTALLATION

Before adding or removing any expansion cards or system components, confirm that you already unplugged your power supply. Otherwise, it may severely damage to your motherboard and expansion cards. Please follow the installation procedures as below:

1. Check carefully if those hardware or software settings for your expansion cards are in the proper position as shown in their User's Manual.
2. Remove your computer case's cover and unscrew the bracket plate for those slots needed to insert.
3. Those expansion cards must be aligned on the slots firmly with good connection.
4. Put on the computer case cover.
5. If needed, set up the BIOS configuration and install the required drivers for your expansion cards.

2.4.8 SDRAM Sockets

There are two SDRAM sockets on-board to provide more flexibility for your system memory upgrade. Because the number of pins are different on either side of the breaks, the DIMM module will only fit the 3.3V 168-pin unbuffered for this motherboard.




168-Pin SDRAM Module Installation Diagram

2.4.9 Floppy Drive Connector (34-Pin)

This connector supports the provided floppy drive ribbon cable. After connecting the single end to the on-board “FLOPPY” connector, connect the remaining plugs on the other end to the floppy drives correspondingly.

2.4.10 IDE Connectors (40-Pin)

The IDE connectors support the provided IDE HDD ribbon cable. After connecting the single end to the board, connect the two plugs at the other end to your HDDs. If you install two IDE devices on the same cable, you must configure the second device to slave mode by setting its jumper accordingly. (Refer to your IDE device document for the jumper settings. Pin 20 is removed to prevent inserting in the wrong orientation when using ribbon cables with pin 20 plugged.)



IDE Connectors

2.4.11 BIOS

The motherboard flash BIOS provides users with more flexibility in upgrading their motherboards. The flash BIOS can be easily reprogrammed via software.

2.4.12 PCI Slots

This motherboard provides four full-length 32-bit PCI slots with up to 133MB/sec burst data transfer rate.

2.4.13 AGP(Accelerated Graphics Port) Slot

This motherboard provides an AGP Slot to support AGP graphics cards


2.4.14 Wake-On-LAN Interface (WOL)

This connector connects to a LAN card with a Wake-On-LAN output. The connector powers up the system when a wakeup signal is received from the network.



2.4.15 Front Panel Function Connector

The front panel integrates: 4-pin Speaker, 2-pin Reset Switch, 2-pin IDE LED, 2-pin Power Led, 2-pin Power On, 5-pin IrDA, 2-pin EXT SMI, 5-pin Keylock. The connector pin out are described as the figure below:



2.4.16 PGA370 CPU Socket

The motherboard provides a ZIF Socket 370. The CPU that comes with the motherboard should have a fan attached to it to prevent overheating. If it is not so, purchase a fan before you turn on your system.

Notice !!!


Be sure that there is a sufficient air circulation across the processor's heatsink by regularly checking that your CPU fan is working. Without sufficient circulation, the processor could be overheated and it may damage both the processor and the motherboard. You may install an auxiliary fan, if necessary.

Installation step:

1. Turn off the power of your system and remove its cover;
2. Locate the ZIF socket and open it by first pulling the lever sideways away from the socket then upwards to a 90-degree angle;
3. Insert the CPU with correct orientation
(The CPU has a corner pin for two of the four corners, that the CPU only fit in the orientation.)
4. Once completely inserted, pull down the socket' s lever to horizontal and make sure the CPU is firmly locked in the socket.

2.4.17 CPU Fan Connector

CPU Fan cable plug in the 3-pin CPU Fan connector onboard.



- Pin1** Sense
- Pin2** +12V
- Pin3** GND

Chapter 3 **Software Installation**

Note:

Before installation, you must already have Windows 95/98/2000/ME or Windows NT4.0 install on your computer.

The installation procedure is as below:

1. Make sure that Auto-insert detection is enabled for your CDROM drive. It should be enabled by default.
2. Insert this CD disk into your CDROM drive.
3. The Explorer screen will then appear, that gives you instructions for installation.
4. There may require restarts of Windows during some software setup. In these cases, you can just eject then close the CD-tray in order to get back to the Explorer screen. You can then proceed with the next step.

You can get more information with open file: ***readme.txt*** in the CD disk.


Chapter 4 **AMIBIOS Setup**

This GC-2001 motherboard comes with the AMI BIOS from AMI Software Inc. Enter the AMI BIOS program Main Menu by:

1. Turn on or reboot the system. After a series of diagnostic checks, the following message will appear:

Press to enter setup, ESC to skip memory test

2. Press the key and the main program screen will appear as follows.



3. Using the arrows ↑↓→← on your keyboard, select an option, and press <Enter>. Modify the system parameters to reflect the options installed in your system. Otherwise you may return to the Main Menu anytime by pressing <ESC> .

Types of Setup	Description
Standard CMOS Setup	Sets time, date, hard disk type, types of floppy drives, monitor type, and if keyboard is installed.
Advanced CMOS Setup	Sets Typematic Rate and Delay, Above 1MB Memory Test, Memory Test Tick Sound, Hit Message Display, System Boot Up Sequence, and others.
Advanced Chipset Setup	Sets chipset-specific options and features.
Power Management Setup	Controls power conservation options.
PCI/PnP Setup	Sets options related to the PCI bus and Plug and Play options.
Peripheral Setup	Controls I/O Controller-related options.
CPU Configuration Setup	This option selects the type of CPU install in the motherboard. The settings are <i>Auto</i> (AMIBIOS automatically determines the CPU type).

4. In the Main Menu, “Save Settings and Exit” saves your changes and reboots the system, and “Exit Without Saving” ignores your changes and exits the CMOS Setup.

AMIBIOS SETUP - STANDARD CMOS SETUP										
(C)1998 American Megatrends, Inc. All Rights Reserved										
Date (mm/dd/yyyy) : Tue Nov 21, 2000					Base Memory: 640 KB					
Time (hh/mm/ss) : 16:17:06					Extd Memory: 127 MB					
Floppy Drive A: 1.44 MB 3 1/2										
Floppy Drive B: Not Installed										
	Type	Size	Cyln	Head	WPcom	Sec	LBA Mode	Blk Mode	PIO Mode	32Bit Mode
Pri Master	: Auto									On
Pri Slave	: Auto									On
Sec Master	: Auto									On
Sec Slave	: Auto									On
Boot Sector Virus Protection					Disabled					
Available Options:							ESC:Exit ↑↓:Sel			
▶ Disabled							PgUp/PgDn:Modify			
Enabled							F1:Help F2/F3:Color			

4.1 Standard CMOS Setup

Select the AMIBIOS Setup options by choosing Standard Setup from the AMIBIOS Setup main menu. Standard Setup options are described below.

Floppy Drive A: and B:

Move the cursor to these fields via ↑ and ↓ and select the floppy type. The settings are 360 KB 5 1/4 inch, 1.2 MB 5 1/4 inch, 720 KB 3 1/2 inch, 1.44 MB 3 1/2 inch, or 2.88 MB 3 1/2 inch.

Primary Master

Primary Slave

Secondary Master

Secondary Slave

Select these options to configure the drive named in the option. Select *Auto Detect IDE* to let AMIBIOS automatically configure the drive. A screen with a list of drive parameters appears. Click on *OK* to configure the drive.

Type	How to Configure
SCSI	Select <i>Type</i> . Select <i>Not Installed</i> the drive parameter screen. The SCSI drivers provided by the SCSI manufacturer should allow you to configure the SCSI drive.
IDE	Select <i>Type</i> . Select Auto to let AMIBIOS determine the parameters. Click on OK when AMIBIOS displays the drive parameters. Select <i>LBA/Large Mode</i> . Select <i>On</i> if the drive has a capacity greater than 540 MB. Select Block Mode . Select <i>On</i> to allow block mode data transfers. Select 32-Bit Transfer . Select <i>On</i> to allow 32-bit data transfers. Select the PIO Mode . It is best to select <i>Auto</i> to allow AMIBIOS to determine the PIO mode. If you select a PIO mode that is not supported by the IDE drive, the drive will not work properly. If you are absolutely certain that you know the drive's PIO mode, select PIO mode 0-5, as appropriate.
CD-ROM	Select <i>Type</i> . Select <i>CDROM</i> . Click on <i>OK</i> when AMIBIOS displays the drive parameters.
Standard MFM	Select <i>Type</i> . You must know the drive parameters. Select the drive type that exactly matches your drive's parameters.
Non-Standard MFM	Select <i>Type</i> . If the drive parameters do not match the drive parameters listed for drive types 1-46, select <i>User</i> and enter the correct hard disk drive parameters.

Entering Drive Parameters

You can also enter the hard disk drive parameters. The drive parameters are

Parameter	Description
Type	The number for a drive with certain identification parameters.
Cylinders	The number of cylinders in the disk drive.
Heads	The number of heads.
Write Precompensation	The actual physical size of a sector gets progressively smaller as the track diameter diminishes. Yet each sector must still hold 512 bytes. Write precompensation circuitry on the hard disk compensates for the physical difference in sector size by boosting the write current for sectors on inner tracks. This parameter is the track number on the disk surface where write precompensation begins.
Landing Zone	This number is the cylinder location where the heads normally park when the system is shut down.
Sectors	The number of sectors per track. MFM drives have 17 sectors per track. RLL drives have 26 sectors per track. ESDI drives have 34 sectors per track. SCSI and IDE drives have even more sectors per track.
Capacity	The formatted capacity of the drive is the number of heads times the number of cylinders times the number of sectors per track times 512 (bytes per sector).

4.2 Advanced CMOS Setup

The AMIBIOS Setup options described in this section are selected by choosing Advanced CMOS Setup from the AMIBIOS Setup main menu.

4.3 Advanced Chipset Setup

Choose Chipset Setup on the AMIBIOS Setup main menu. All Chipset Setup options are then displayed. AMIBIOS Setup can be customized.

4.4 Power Management Setup

The AMIBIOS Setup options described in this section are selected by choosing Power Management Setup from the AMIBIOS Setup main menu.

4.5 PCI / PnP Setup

Choose PCI/Plug and Play Setup from the AMIBIOS Setup screen to display the PCI and Plug and Play Setup options.

4.6 CPU Configuration Setup

This system BIOS is capable to detect the CPU type, say Pentium III, Pentium II or Celeron. The user is only required to select the CPU speed. In addition, overclocking option is provided for advanced users who prefer to run the CPU over the specified clock frequency.

4.7 Save Settings and Exit

Choose Save Setting and Exit from the AMIBIOS Setup main menu. Type “Y” to exit the BIOS Setup program and saving the values. Type “N” to return to the Setup program.

4.8 Exit Without Saving

Choose Exit Without Saving from the AMIBIOS Setup main menu. Type “Y” to exit the BIOS Setup program without saving the values. Type “N” to return to the Setup program.

The End