

ICPMB-8660
SOCKET 478 PENTIUM 4
Motherboard with
SATA & Ethernet & USB 2.0

User Manual

Version 1.0

July 21, 2004



©Copyright 2004 by ICP Electronics Inc. All Rights Reserved.

Copyright Notice

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Trademarks

ICPMB-8660 is registered trademarks of ICP Electronics Inc.; IBM PC is a registered trademark of International Business Machines Corporation. INTEL is a registered trademark of INTEL Corporation. Award is registered trademarks of American Megatrends Inc., Other product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

SUPPORT

Any questions regarding the content of this manual or related issues can be e-mailed to us directly at: SUPPORT@IEI.COM.TW

Contents

Introduction	1
1.1 Specifications	2
1.2 What You Have	4
Installation	5
2.1 ICPMB-8660's Layout	6
2.2 ICPMB-8660's Dimensions (Unit : mm)	7
2.3 Unpacking Precautions.....	8
2.4 COM2 RS232/RS422/485 Selection	9
2.5 Clear CMOS Setup.....	9
2.6 Compact Flash Master/Slave Function Setting.....	9
Connection	10
3.1 PCI E-IDE Disk Drive Connectors.....	11
3.2 Floppy Connector	11
3.3 Parallel Port Connector.....	12
3.4 Serial Port	13
3.5 Compact Flash Storage Card Socket.....	14
3.6 IrDA Infrared Interface Port.....	15
3.7 USB Port Connector.....	15
3.8 Keyboard/Mouse Connector	16

3.9	Fan Connector	16
3.10	Serial ATA Connector	17
3.11	VGA Connectors.....	17
3.12	LAN Connector	18
3.13	Audio Connectors	18
3.14	LAN LED Connector.....	19
3.15	External Switches and Indicators	19
3.16	ATX +12V Power connector.....	20
3.17	RS422/485 connector	20
3.18	Digital I/O connector.....	20
3.19	iButton connector.....	21
3.20	ATX Power connector	21

Award BIOS Setup 22

4.1	Introduction	22
4.2	Starting Setup.....	22
4.3	Using Setup	23
4.4	Main Menu	23
4.5	Standard CMOS Setup	26
4.6	Advanced BIOS Features.....	28
4.7	Advanced Chipset Features.....	31
4.8	Integrated Peripherals.....	34
4.9	Power Management Setup.....	38

4.10 PnP/PCI Configuration Setup	40
4.11 PC Health Status	42
4.12 Frequency/Voltage Control	42
4.13 Load Fail-Safe Defaults	43
4.14 Load Optimized Defaults	43
4.15 Set Password	43
4.16 Exit Selecting.....	44


Appendix A. Watchdog Timer 45

Appendix B. Address Mapping..... 47

IO Address Map.....	47
1st MB Memory Address Map	48
IRQ Mapping Table.....	48
DMA Channel Assignments.....	48

Appendix C. How to Upgrade a New BIOS 49

Appendix D. Install memory modules 52



Introduction

Welcome to the ICPMB-8660 SOCKET 478 PENTIUM 4 Single Board Computer. The ICPMB-8660 board is an AGP/PCI form factor board, which comes equipped with high performance Processor and advanced high performance multi-mode I/O, designed for the system manufacturers, integrators, or VARs that want to provide all the performance, reliability, and quality at a reasonable price.

The integrated graphics controller provides 3D, 2D, and display capabilities.

ICPMB-8660 is supports one or two 64-bit wide DDR data channels. Available bandwidth up to 2.7GB/s for single-channel mode and 5.4GB/s in dual-channel mode.

For the application that needs high speed serial transmission, the ICPMB-8660 provides USB2.0 for your choice. The high speed USB2.0 host controller implements an ECHI interface that provides 480Mb/s bandwidth.

ICPMB-8660 is equipped with a high speed SATA disk interface.

Besides its better performance than traditional IDE interface, it can also reduce the cabling of hard disk and supports longer cable.

1.1 Specifications

CPU(PGA 478)	Intel Pentium 4 Processor, supports 400/533/800 MHz PSB (set by BIOS)
Bus interface	AGP/PCI bus
Bus speed	PCI: 33MHz
DMA channels	7
Interrupt levels	15
Chipset	INTEL 865G / ICH5
RAM memory	Two 184-pin DIMM sockets support DDR333/400 SDRAM .Support one or two 64-bit wide DDR data channels. The max. Memory is up to 2GB.
Ultra DMA 100 IDE interface	Up to four PCI Enhanced IDE hard drives. The Ultra DMA 100 IDE can handle data transfer up to 100MB/s. Compatible with existing ATA IDE specifications its best advantage, so there is no need to do any changes for users' current accessories.
Floppy disk drive interface	Supports up to two floppy disk drives, 5.25"(360KB and 1.2MB) and/or 3.5" (720KB, 1.44MB, and 2.88MB)
Serial ports	Four RS-232 ports with 16C550 UART (or compatible) with 16-byte FIFO buffer. Support up to 115.2Kbps. Ports can be individually configured to COM1,2,3,4 or disabled.
Bi-directional parallel port	Configurable to LPT1, LPT2, LPT3 or disabled. Supports EPP/ECP/SPP
Hardware monitor	Built-in to monitor power supply voltage and fan speed status
IrDA port	Supports Serial Infrared(SIR) and Amplitude Shift Keyed IR(ASKIR) interface
USB 2.0/1.1 port	Supports 8 USB 2.0/1.1 ports for future expansion
Watchdog timer	Software Programmable. Reset generated when CPU does not periodically trigger the timer.

Serial ATA	Supports two independent serial ATA channels. Data transfer rate is up to 150MB/s
Ethernet	PCI interface. INTEL 82540EM or Realtek RTL8110S Gigabit Ethernet controller. Supports full 10,100 and1000-bast-T Ethernet
Keyboard and PS/2 mouse connector	A connector is located on the mounting bracket for easy connection to a keyboard or PS/2 mouse.
Audio	AC'97 Audio CODEC
Compact flash	It can be used with a passive adapter (True IDE Mode) in a Type I/II CF Socket.
Power consumption	PENTIUM4: 3.0GHz, 2GB DDR400 DDR-SDRAM +5V @ 4.7A , +12V @ 6.1A , +3.3V @ 0.7A -12V @ 0.2A , +5VSB @ 0.7A Recommended : 350-watt power supply or higher
Operating temperature	0° ~ 60° C (*CPU needs Cooler & silicone heatsink paste*)

WARNING : 1. Use ATX-12V power connector (CN6) to provide power for the CPU.

1.2 What You Have

In addition to this *User's Manual*, the ICPMB-8660 package includes the following items:

- ICPMB-8660 Single Board Computer X1.
- RS-232 Cable with bracket X1.
- FDD cable X1.
- IDE cable X2.
- SATA cable X2.
- SATA Power cable X1
- Driver CD X1.


If any of these items are missing or damaged, contact the dealer from whom you purchased this product. Save the shipping materials and carton in case you want to ship or store the product in the future.

2


Installation

This chapter describes how to install the ICPMB-8660. First a layout diagram of the ICPMB-8660 is shown, followed by unpacking information that should be carefully followed. The jumpers and switch settings for the ICPMB-8660 configuration, such as CPU type selection, system clock setting, and watchdog timer, are also listed.

2.1 ICPMB-8660's Layout



2.2 ICPMB-8660's Dimensions (Unit : mm)



2.3 Unpacking Precautions

Some components on ICPMB-8660 are very sensitive to static electric charges and can be damaged by a sudden rush of power. To protect it from unintended damage, be sure to follow these precautions:

- ✓ Ground yourself to remove any static charge before touching your ICPMB-8660. You can do it by using a grounded wrist strap at all times or by frequently touching any conducting materials that is connected to the ground.
- ✓ Handle your ICPMB-8660 by its edges. Don't touch IC chips, leads or circuitry if not necessary.
- ✓ Do not plug any connector or jumper while the power is on.

Note: All shaded rows in tables of this manual are the default settings for the ICPMB-8660.

2.4 COM2 RS232/RS422/485 Selection

- **JP1: COM2 RS232/RS422/485 Selection**

JP1	Description
1-3 Short (default)*	RS232
3-5 Short 2-4 Short	RS422
3-5 Short 4-6 Short	RS485

Note: When RS422/485 is in use, the COM2's RS232 port will be disabled.

2.5 Clear CMOS Setup

To clear the CMOS Setup (e.g. you have forgotten the password, you must clear the CMOS to reset the password), you have to close the JP2 (2-3) for about 3 seconds, then open it. After that, pin 1-2 has to be short for normal operation.

- **JP2 : Clear CMOS Setup**

JP2	DESCRIPTION
1-2 (default)*	Keep CMOS Setup (Normal Operation)
Short 2-3	Clear CMOS Setup

2.6 Compact Flash Master/Slave Function Setting

- **JP3 : Compact Flash Master/Slave Function Setting**

JP3	DESCRIPTION
Short*	Master
Open	Slave

3

Connection

This chapter describes how to connect peripherals, switches and indicators to the ICPMB-8660 board.

Label	Function
IDE1 & IDE2	Ultra ATA100 Primary & Secondary IDE connectors
FDD1	Floppy connector
PRN1	Parallel port connector
COM1,2,3,4	Serial port connectors
CF1	Compact Flash Storage Card Type II connector
IR1	IRDA infrared interface port
USB1	USB port connector
USB2	USB dual port connector
USB3	USB dual port connector
PCI1	PCI slot
KB/MS1	Keyboard & Mouse connector
FAN1 & FAN2	FAN connectors
SATA1 & SATA2	Serial ATA connectors
VGA1 & VGA2	VGA connectors
CN1	USB dual port & LAN RJ45 connector
CN2	Audio connector
CN3	Audio CD in connector
CN4	LAN LED connector
CN5	External switches and indicators
CN6	ATX +12V Power connector
CN7	RS422/485 connector
CN8	Digital I/O connector
CN9	iButton connector
ATX1	ATX Power connector

3.1 PCI E-IDE Disk Drive Connectors

You can attach up to four IDE(Integrated Device Electronics) devices.

- **IDE1 : Primary IDE Connector**
- **IDE2 : Secondary IDE Connector**

PIN	DESCRIPTION	PIN	DESCRIPTION
1	RESET#	2	GROUND
3	DATA 7	4	DATA 8
5	DATA 6	6	DATA 9
7	DATA 5	8	DATA 10
9	DATA 4	10	DATA 11
11	DATA 3	12	DATA 12
13	DATA 2	14	DATA 13
15	DATA 1	16	DATA 14
17	DATA 0	18	DATA 15
19	GROUND	20	N/C
21	DRQ	22	GROUND
23	IOW#	24	GROUND
25	IOR#	26	GROUND
27	CHRDY	28	REV. PULL LOW
29	DACK	30	GROUND-DEFAULT
31	INTERRUPT	32	N/C
33	SA1	34	N/C
35	SA0	36	SA2
37	HDC CS0#	38	HDC CS1#
39	HDD ACTIVE#	40	GROUND

3.2 Floppy Connector

The ICPMB-8660 board is equipped with a 34-pin daisy-chain drive connector cable.

- **FDD1 : Floppy Connector**

PIN	DESCRIPTION	PIN	DESCRIPTION
1	GROUND	2	RWC0-
3	GROUND	4	NC
5	GROUND	6	RWC1-

7	GROUND	8	INDEX-
9	GROUND	10	MO-A
11	GROUND	12	DS-B
13	GROUND	14	DS-A
15	GROUND	16	MO-B
17	GROUND	18	DIR-
19	GROUND	20	STEP-
21	GROUND	22	WD-
23	GROUND	24	WGATE-
25	GROUND	26	TRK0-
27	GROUND	28	WP-
29	GROUND	30	RDATA-
31	GROUND	32	HEAD-
33	GROUND	34	DSKCHG-

3.3 Parallel Port Connector

Usually, a printer is connected to the parallel port. The ICPMB-8660 includes an on-board parallel port


- **PRN1 : Parallel Port Connector**

PIN	DESCRIPTION	PIN	DESCRIPTION
1	STROBE#	2	DATA 0
3	DATA 1	4	DATA 2
5	DATA 3	6	DATA 4
7	DATA 5	8	DATA 6
9	DATA 7	10	ACKNOWLEDGE
11	BUSY	12	PAPER EMPTY
13	PRINTER SELECT	14	AUTO FORM FEED #
15	ERROR#	16	INITIALIZE
17	PRINTER SELECT LN#	18	GROUND
19	GROUND	20	GROUND
21	GROUND	22	GROUND
23	GROUND	24	GROUND
25	GROUND		

3.4 Serial Port


The ICPMB-8660 offers Four high speed NS16C550 compatible UART's with 16-byte Read/Receive FIFO serial ports.

• COM1: D-SUB Serial Port Connector




PIN	DESCRIPTION	PIN	DESCRIPTION
1	(DCD3)	6	(DSR1)
2	(RXD3)	7	(RTS1)
3	(TXD3)	8	(CTS1)
4	(DTR3)	9	(RI1)
5	GROUND		

• COM2/3 : D-SUB Serial Port Connector



PIN	DESCRIPTION	PIN	DESCRIPTION
1	(DCD3)	12	(DCD2)
2	(RXD3)	13	(RXD2)
3	(TXD3)	14	(TXD2)
4	(DTR3)	15	(DTR2)
5	GROUND	16	GROUND
6	(DSR3)	17	(DSR2)
7	(RTS3)	18	(RTS2)
8	(CTS3)	19	(CTS2)
9	(RI3)	20	(RI2)
10	GROUND	21	GROUND
11	GROUND	22	GROUND

• COM4: Serial Port Connector



PIN	DESCRIPTION	PIN	DESCRIPTION
1	(DCD4)	2	(DSR4)
3	(RXD4)	4	(RTS4)
5	(TXD4)	6	(CTS4)
7	(DTR4)	8	(RI4)
9	GROUND	10	GROUND

3.5 Compact Flash Storage Card Socket

The ICPMB-8660 configures Compact Flash Storage Card in IDE Mode. This type II Socket is compatible with IBM Micro Drive.

• **CF1 : Compact Flash Storage Card Socket pin assignment**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GROUND	26	PULL DOWN
2	D3	27	D11
3	D4	28	D12
4	D5	29	D13
5	D6	30	D14
6	D7	31	D15
7	CS1#	32	CS3#
8	N/C	33	N/C
9	GROUND	34	IOR#
10	N/C	35	IOW#
11	N/C	36	VCC
12	N/C	37	IRQ15
13	VCC	38	VCC
14	N/C	39	MASTER/SLAVE
15	N/C	40	N/C
16	N/C	41	RESET#
17	N/C	42	IORDY
18	A2	43	N/C
19	A1	44	VCC
20	A0	45	ACTIVE#
21	D0	46	PDIAG#
22	D1	47	D8
23	D2	48	D9
24	N/C	49	D10
25	PULL DOWN	50	GROUND

3.6 IrDA Infrared Interface Port

The ICPMB-8660 comes with an integrated IrDA port which supports either a Serial Infrared(SIR) or an Amplitude Shift Keyed IR(ASKIR) interface.


- **IR1: IrDA connector**

PIN	DESCRIPTION
1	VCC
2	NC
3	IR-RX
4	Ground
5	IR-TX
6	CIRRX

3.7 USB Port Connector


The ICPMB-8660 is equipped with Eight USB(Version. 2.0) ports for the future new I/O bus expansion.

- **USB1 : 2 ports USB Connector**




PIN	DESCRIPTION	PIN	DESCRIPTION
1	VCC	5	VCC
2	DATA0-	6	DATA1-
3	DATA0+	7	DATA2+
4	GROUND	8	GROUND

- **USB2 : 2 ports USB Connector**




PIN	DESCRIPTION	PIN	DESCRIPTION
1	GROUND	2	GROUND
3	USB GROUND	4	USB GROUND
5	USB VCC	6	USB VCC
7	DATA2-	8	DATA3-
9	DATA2+	10	DATA3+
11	USB GROUND	12	USB GROUND
		14	NC
15	VCC	16	NC
17	GROUND	18	GROUND

- **USB3 : 2 ports USB Connector**



PIN	DESCRIPTION	PIN	DESCRIPTION
1	VCC	2	GROUND
3	DATA4-	4	DATA5+
5	DATA4+	6	DATA5-
7	GROUND	8	VCC

- **CN1 : 2 ports USB Connector**




PIN	DESCRIPTION	PIN	DESCRIPTION
1	VCC	5	VCC
2	DATA6-	6	DATA7-
3	DATA6+	7	DATA7+
4	GROUND	8	GROUND

3.8 Keyboard/Mouse Connector

The ICPMB-8660 has a keyboard/mouse connector

- **KB/MS1 : Keyboard/Mouse Connector**



PIN	DESCRIPTION	PIN	DESCRIPTION
1	KB DATA	7	MS DATA
2	NC	8	NC
3	GROUND	9	GROUND
4	KB VCC	10	MS VCC
5	KB CLOCK	11	MS CLOCK
6	NC	12	NC

3.9 Fan Connector

The ICPMB-8660 also has a CPU with cooling fan connector and chassis fan connector, which can supply 12V/500mA to the cooling fan. There is a “rotation” pin in the fan connector, which transfers the fan’s rotation signal to the system BIOS in order to recognize the fan speed. Please note that only specific fans

offer a rotation signal.

- **FAN1,FAN2 : CPU Fan Connector**

PIN	DESCRIPTION
1	Ground
2	+12V
3	Rotation Signal

3.10 Serial ATA Connector


The ICPMB-8660 provide 2 Serial ATA ports to connect with Serial ATA devices.

- **SATA1, SATA2 : Serial ATA Connector**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	S_TXP	3	S_RXN
2	S_TXN	4	S_RXP


3.11 VGA Connectors

- **VGA1: 15-pin Female Connector**



PIN	DESCRIPTION	PIN	DESCRIPTION
1	RED	2	GREEN
3	BLUE	4	NC
5	GROUND	6	GROUND
7	GROUND	8	GROUND
9	VCC / NC	10	GROUND
11	NC	12	DDC DAT
13	HSYNC	14	VSYNC
15	DDCCLK		

- **VGA2: 10-pin VGA Connector**




PIN	DESCRIPTION	PIN	DESCRIPTION
1	RED	6	DDC CLK
2	GREEN	7	DDC DAT
3	BLUE	8	GROUND

4	HSYNC	9	GROUND
5	VSYNC	10	GROUND

3.12 LAN Connector

The ICPMB-8660 is equipped with Ethernet Controllers 10/100Mbps, which are connected to the LAN via an RJ45 LAN connector. The pin assignments are as follows:

- **CN1 : RJ45 Connector (10/100/1000)**




PIN	DESCRIPTION	PIN	DESCRIPTION
L1	TX0+	L7	TX3+
L2	TX0-	L8	TX3-
L3	TX1+	L9	Active +
L4	TX2+	L10	Active -
L5	TX2-	L11	LINK +
L6	TX1-	L12	LINK -


3.13 Audio Connectors

The onboard AC'97 CODEC supports several audio functions. The audio connectors are described below.

- **CN2 : Audio connector (Line in, Line out, MIC in)**



- **CN3 : Audio CD In connector**



PIN	DESCRIPTION
1.	CD SIGNAL (LEFT)
2.	GROUND
3.	GROUND
4.	CD SIGNAL (RIGHT)

3.14 LAN LED Connector


- CN4 : LAN LED Connector

PIN	DESCRIPTION	PIN	DESCRIPTION
1	ACT_LED-	2	ACT_LED+
3	LINK_LED-	4	LINK_LED+

3.15 External Switches and Indicators

There are several external switches and indicators for monitoring and controlling your CPU board. All functions are in the CN5connector.


- CN5 : Pin Assignment and Functions



FUNCTION	PIN	DESCRIPTION
BUZZER	2	BUZZER-
	4	NC
	6	NC
	8	VCC
RESET	10	RESET
	12	GROUND
HDD LED	9	IDE_LED+
	11	IDE_LED-
POWER LED	1	LED+
	3	LED-(GROUND)
POWER BUTTON	5	VCC
	7	POWER BUTTON

3.16 ATX +12V Power connector

- CN6: ATX +12V Power connector



PIN	DESCRIPTION
1.	GROUND
2.	GROUND
3.	+12V
4.	+12V

3.17 RS422/485 connector

- CN7: RS422/485 connector

PIN	DESCRIPTION
1.	TX+
2.	TX-
3.	RX+
4.	RX-


3.18 Digital I/O connector

One of digital circuit's characteristics is its fast response to high or low signal. This kind of response is highly needed for harsh and critical industrial operating environment. That's why we design 4-bit digital inputs and 4-bit digital outputs on the ICPMB-8660

Digital Input and Output are control signals generally. You can use these signals to control external devices that needs On/Off circuit or TTL devices. The register address is 240H, 260H or 280H, which is selected in BIOS SETUP. You can read or write data to the selected address to enable the function of digital IO.

Read		Write	
Bit0	GPI0	Bit0	GPO0
Bit1	GPI1	Bit1	GPO1
Bit2	GPI2	Bit2	GPO2
Bit3	GPI3	Bit3	GPO3

- **CN8: Digital I/O connector**



PIN	DESCRIPTION	PIN	DESCRIPTION
1	GROUND	2	VCC
3	GPO3	4	GPO2
5	GPO1	6	GPO0
7	GPI3	8	GPI2
9	GPI1	10	GPI0


3.19 iButton connector

- **CN9: iButton connector**

PIN	DESCRIPTION	PIN	DESCRIPTION
1	iButton IN/OUT	2	GROUND

3.20 ATX Power connector

- **ATX1: ATX Power connector**



PIN	DESCRIPTION	PIN	DESCRIPTION
1	VCC3	11	VCC3
2	VCC3	12	-12V
3	GROUND	13	GROUND
4	5V	14	PS-ON
5	GROUND	15	GROUND
6	5V	16	GROUND
7	GROUND	17	GROUND
8	POWER GOOD	18	NC
9	5VSB	19	5V
10	+12V	20	5V

4

Award BIOS Setup

4.1 Introduction

This chapter discusses the Setup program written in the BIOS. It will give you a step-by-step guidance to configure your system. The user-defined configuration is then stored in battery-backed CMOS RAM, which retains the customized information while the power is off.

4.2 Starting Setup

The BIOS is immediately active when you turn on the computer. While the BIOS is in control, the Setup program can be activated in one of two ways:

1. By pressing immediately after switching the system on, or
2. By pressing the key when the following message appears at the bottom of the screen during POST (Power On Self-Test):

Press DEL to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to...

PRESS F1 TO CONTINUE, DEL TO ENTER SETUP


4.3 Using Setup

In general, you can use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more details about how to navigate in the Setup program using the keyboard.

Key	Function
Up Arrow	Move to the previous item
Down Arrow	Move to the next item
Left Arrow	Move to the item on the left (menu bar)
Right Arrow	Move to the item on the right (menu bar)
Esc	Main Menu: Quit without saving changes Submenus: Exit Current page to the next higher level menu
Move Enter	Move to the item you desired
PgUp key	Increase the numeric value or make changes
PgDn key	Decrease the numeric value or make changes
+ key	Increase the numeric value or make changes
- key	Decrease the numeric value or make changes
Esc key	Main Menu -- Quit and save no changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
F1 key	General help on Setup navigation keys
F5 key	Load previous values from CMOS
F6 key	Load the fail-safe defaults from BIOS default table
F7 key	Load the optimized defaults
F10 key	Save all the CMOS changes and exit

4.4 Main Menu

Once you enter the AwardBIOS™ CMOS Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and two exit choices. Use the arrow keys to go through the items and press <Enter> to accept and enter the sub-menu.



Note that a brief description of each highlighted selection appears at the bottom of the screen.

4.4.1 Setup Items

The main menu includes the following main setup categories. Recall that some systems may not include all entries.

Standard CMOS Features

Use this menu for basic system configuration. See Section 4.5 for the details.

Advanced BIOS Features

Use this menu to set the Advanced Features available on your system. See Section 4.6 for the details.

Advanced Chipset Features

Use this menu to change the values in the chipset registers and optimize your system's performance. See section 4.7 for the details.

Integrated Peripherals

Use this menu to configure your settings for integrated peripherals. See section 4.8 for the details.

Power Management Setup

Use this menu to configure your settings for power management. See section 4.9 for the details.

PnP / PCI Configuration

This entry appears if your system supports PnP / PCI. See section 4.10 for the details.

PC Health Status

Use this menu to monitor your hardware. See section 4.11 for details.

Frequency/Voltage Control

Use this menu to configure your settings for frequency/voltage control. See section 4.12 for the details.

Load Fail-Safe Defaults

Use this menu to load the BIOS default values for the minimal/stable performance for your system to operate. See section 4.13 for the details.

Load Optimized Defaults

Use this menu to load the BIOS default values that are factory settings for optimal performance system operations. While Award has designed the custom BIOS to maximize performance, the factory has the right to change these defaults to meet their needs. See section 4.14 for the details.

Set Password

Use this menu to set Passwords. See section 4.15 for the details.

Save & Exit Setup

Save CMOS value changes to CMOS and exit setup. See section 4.16 for the details.

Exit Without Save

Abandon all CMOS value changes and exit setup. See section 4.15 for the details.

4.5 Standard CMOS Setup

The items in Standard CMOS Setup Menu are divided into 10 categories. Each category includes no, one or more than one setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

Phoenix - AwardBIOS CMOS Setup Utility		Item Help
Standard CMOS Features		
Date (mm:dd:yy)	Aug 6 2003	Menu Level ▶ Change the day, month, year and century
Time (hh:mm:ss)	13 : 35 : 53	
▶ IDE Channel 0 Master	[None]	
▶ IDE Channel 0 Slave	[None]	
▶ IDE Channel 1 Master	[None]	
▶ IDE Channel 1 Slave	[None]	
Drive A	[1.44M, 3.5 in.]	
Drive B	[None]	
Video	[EGA/UGA]	
Halt On	[All , But Keyboard]	
↑↓→←:Move Enter:Select +/-/PU/PD:Ualue F10:Save ESC:Exit F1:General Help F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

Item	Options	Description
Date	MM DD YYYY	Set the system date.
Time	HH : MM : SS	Set the system time
IDE Primary Master	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
IDE Primary Slave	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
IDE Secondary Master	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
IDE Secondary Slave	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options

Drive A Drive B	None 360K, 5.25 in 1.2M, 5.25 in 720K, 3.5 in 1.44M, 3.5 in 2.88M, 3.5 in	Select the type of floppy disk drive installed in your system
Video	EGA/VGA CGA 40 CGA 80 MONO	Select the default video device
Halt On	All Errors No Errors All, but Keyboard All, but Diskette All, but Disk/Key	Select the situation in which you want the BIOS to stop the POST process and notify you
Base Memory	N/A	Displays the amount of conventional memory detected during boot up
Extended Memory	N/A	Displays the amount of extended memory detected during boot up
Total Memory	N/A	Displays the total system memory available in the system
IDE HDD Auto-detection	Press Enter	Press Enter to auto-detect the HDD on this channel. If detection is successful, it fills the remaining fields on this menu.
IDE Primary Master	None Auto Manual	Selecting 'manual' lets you set the remaining fields on this screen. Selects the type of fixed disk. "User Type" will let you select the number of cylinders, heads, etc. Note: PRECOMP=65535 means NONE !
Capacity	Auto Display your disk drive size	Disk drive capacity (Approximated). Note that this size is usually slightly greater than the size of a formatted disk given by a

		disk checking program.
Access Mode	CHS LBA Large Auto	Choose the access mode for this hard disk

4.6 Advanced BIOS Features

This section allows you to configure your system for basic operation. You have the opportunity to select the system's default speed, boot-up sequence, keyboard operation, shadowing and security.

Virus Warning

Allows you to choose the VIRUS Warning feature for IDE Hard Disk boot sector protection. If this function is enabled and someone attempt to write data into this area, BIOS will show a warning message on screen and alarm beep.

Phoenix - AwardBIOS CMOS Setup Utility		Item Help
Advanced BIOS Features		Menu Level ▶
▶ Hard Disk Boot Priority	[Press Enter]	Select Hard Disk Boot Device Priority
CPU L1 & L2 Cache	[Enabled]	
Hyper-Threading Technology	[Enabled]	
Quick Power On Self Test	[Enabled]	
First Boot Device	[Floppy]	
Second Boot Device	[Hard Disk]	
Third Boot Device	[LS120]	
Boot Other Device	[Enabled]	
Swap Floppy Drive	[Disabled]	
Boot Up Floppy Seek	[Enabled]	
Boot Up NumLock Status	[On]	
Gate A20 Option	[Fast]	
Typeomatic Rate Setting	[Disabled]	
Security Option	[Setup]	
APIC Mode	[Enabled]	
MPS Version Control For OS	[1.4]	
OS Select For DRAM > 64MB	[Non-OS2]	

↑↓←→: Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Enabled	Activates automatically when the system boots up causing a warning message to appear when anything attempts to access the boot sector or hard disk partition table.
Disabled	No warning message will appear when anything attempts to access the boot sector or hard disk partition table.

Hard Disk Boot Priority

This setting is to select hard disk boot priority

CPU L1 & L2 Cache

These two categories speed up memory access. However, it depends on CPU/chipset design.

Enabled	Enable cache
Disabled	Disable cache

Hyper-Threading Technology

This setting is to enable or disable hyper threading CPU support

Quick Power On Self Test

This category speeds up Power On Self Test (POST) after you power up the computer. If it is set to Enable, BIOS will shorten or skip some check items during POST.

Enabled	Enable quick POST
Disabled	Normal POST

First/Second/Third/Other Boot Device

The BIOS attempts to load the operating system from the devices in the sequence selected in these items.

The Choice: Floppy, LS120, HDD0-3, SCSI, CDROM, ZIP 100 , LAN, Disabled.

Swap Floppy Drive

If the system has two floppy drives, you can swap the logical drive name assignments.

The choice: Enabled/Disabled.

Boot Up Floppy Seek

Seeks disk drives during boot up. Disabling speeds boot up.

The choice: Enabled/Disabled.

Boot Up NumLock Status

Select power on state for NumLock.

The choice: On/Off.

Gate A20 Option

Select if chipset or keyboard controller should control GateA20.

Normal	A pin in the keyboard controller controls GateA20
Fast	Lets chipset control GateA20

Typematic Rate Setting

Key strokes repeat at a rate determined by the keyboard controller. When enabled, the typematic rate and typematic delay can be selected.

The choice: Enabled/Disabled.

Typematic Rate (Chars/Sec)

Sets the number of times a second to repeat a key stroke when you hold the key down.

The choice: 6, 8, 10, 12, 15, 20, 24, 30.

Typematic Delay (Msec)

Sets the delay time after the key is held down before it begins to repeat the keystroke.

The choice: 250, 500, 750, 1000.

Security Option

Select whether the password is required every time the system boots or only when you enter setup.

System	The system will not boot and access to Setup will be denied if the correct password is not entered at the prompt.
Setup	The system will boot, but access to Setup will be denied if the correct password is not entered at the prompt.

Note: To disable security, select PASSWORD SETTING at Main Menu and then you will be asked to enter password. Do not type anything and just press <Enter>, it will disable security. Once the security is disabled, the system will boot and you can enter Setup freely.

OS Select For DRAM > 64MB

Select the operating system that is running with greater than 64MB of RAM on the system.

The choice: Non-OS2, OS2.

Small Logo(EPA) Show

Disabled/Enabled Small Logo(EPA) Show

4.7 Advanced Chipset Features

Phoenix - AwardBIOS CMOS Setup Utility Advanced Chipset Features		Item Help
DRAM Timing Selectable	[By SPD]	Menu Level ▶
CAS Latency Time	[2]	
Active to Precharge Delay	[8]	
DRAM RAS# to CAS# Delay	[4]	
DRAM RAS# Precharge	[4]	
Memory Frequency For	[Auto]	
System BIOS Cacheable	[Enabled]	
Video BIOS Cacheable	[Disabled]	
Memory Hole At 15M-16M	[Disabled]	
Delay Prior to Thermal	[16 Min]	
AGP Aperture Size (MB)	[128]	
Init Display First	[PCI Slot]	
On-Chip UGA	[Enabled]	
On-Chip Frame Buffer Size	[16MB]	
Boot Display	[Auto]	

↑↓→←:Move Enter:Select +/-/PU/PD:Ualue F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

This section allows you to configure the system based on the specific features of the installed chipset. This chipset manages bus speeds and access to system memory resources, such as DRAM and the external cache. It also coordinates communications between the conventional ISA bus and the PCI bus. It must be stated that these items should never need to be altered. The default settings have been chosen because they provide the best operating conditions for your system.

DRAM Timing Selectable

The first chipset settings deal with CPU access to dynamic random access memory (DRAM). The default timings have been carefully chosen and should only be altered if data is being lost. Such a scenario might well occur if your system had mixed speed DRAM chips installed so that greater delays may be required to preserve the integrity of the data held in the slower memory chips.

CAS Latency Time

When synchronous DRAM is installed, the number of clock cycles of CAS latency depends on the DRAM timing.

The Choice: 1.5 , 2, 2.5 , 3

DRAM RAS# to CAS# Delay

This field lets you insert a timing delay between the CAS and RAS strobe signals, used when DRAM is written to, read from, or refreshed. *Fast* gives faster performance; and *Slow* gives more stable performance. This field applies only when synchronous DRAM is installed in the system.

The Choice: 2, 3.

DRAM RAS# Precharge

If an insufficient number of cycles is allowed for the RAS to accumulate its charge before DRAM refresh, the refresh may be incomplete and the DRAM may fail to retain data. *Fast* gives faster performance; and *Slow* gives more stable performance. This field applies only when synchronous DRAM is installed in the system.

The Choice: 2, 3.

DRAM Frequency For

This field displays the capability of the memory modules that you are using either H/W TRAP.

The choice: Auto, DDR266, DDR333, DDR400.

System BIOS Cacheable

Selecting *Enabled* allows caching of the system BIOS ROM at F0000h-FFFFFh, resulting in better system performance. However, if any program writes to this memory area, a system error may result.

The choice: Enabled, Disabled.

Video BIOS Cacheable

Select Enabled allows caching of the video BIOS , resulting in better system performance. However, if any program writes to this memory area, a system error may result.

The Choice: Enabled, Disabled.

Memory Hole At 15M-16M

You can reserve this area of system memory for ISA adapter ROM. When this area is reserved, it cannot be cached. The user information of peripherals that need to use this area of system memory usually discusses their memory requirements.

The Choice: Enabled, Disabled.

AGP Aperture Size (MB)

Select the on-chip video window size for VGA drive use.

The Choice: 4MB, 8MB, 16MB, 32MB, 64MB, 128MB, 256MB

On-chip VGA

Enabled/Disabled On-chip VGA

4.8 Integrated Peripherals

Phoenix - AwardBIOS CMOS Setup Utility Integrated Peripherals

<ul style="list-style-type: none"> ▶ OnChip IDE Device [Press Enter] ▶ Onboard Device [Press Enter] ▶ SuperIO Device [Press Enter] Watch Dog Timer Unit [Second] Onboard Serial Port 3 [3E8] Serial Port 3 Use IRQ [IRQ11] Onboard Serial Port 4 [2E8] Serial Port 4 Use IRQ [IRQ10] Digital I/O Port [280h] 	<table border="1"> <tr> <th style="text-align: left;">Item Help</th> </tr> <tr> <td>Menu Level ▶</td> </tr> </table>	Item Help	Menu Level ▶
Item Help			
Menu Level ▶			

↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Phoenix - AwardBIOS CMOS Setup Utility OnChip IDE Device

<ul style="list-style-type: none"> IDE HDD Block Mode [Enabled] On-Chip Primary PCI IDE [Enabled] IDE Primary Master PIO [Auto] IDE Primary Slave PIO [Auto] IDE Primary Master UDMA [Auto] IDE Primary Slave UDMA [Auto] On-Chip Secondary PCI IDE [Enabled] IDE Secondary Master PIO [Auto] IDE Secondary Slave PIO [Auto] IDE Secondary Master UDMA [Auto] IDE Secondary Slave UDMA [Auto] *** On-Chip Serial ATA Setting *** SATA Mode [IDE] On-Chip Serial ATA [Auto] Serial ATA Port0 Mode [Primary Master] Serial ATA Port1 Mode Primary Master 	<table border="1"> <tr> <th style="text-align: left;">Item Help</th> </tr> <tr> <td>Menu Level ▶▶</td> </tr> <tr> <td>If your IDE hard drive supports block mode select Enabled for automatic detection of the optimal number of block read/writes per sector the drive can support</td> </tr> </table>	Item Help	Menu Level ▶▶	If your IDE hard drive supports block mode select Enabled for automatic detection of the optimal number of block read/writes per sector the drive can support
Item Help				
Menu Level ▶▶				
If your IDE hard drive supports block mode select Enabled for automatic detection of the optimal number of block read/writes per sector the drive can support				

↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Phoenix - AwardBIOS CMOS Setup Utility
Onboard Device

USB Controller [Enabled] USB 2.0 Controller [Enabled] USB Keyboard Support [Disabled] AC97 Audio [Auto]	Item Help <hr/> Menu Level ▶▶
--	----------------------------------

↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
 F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Phoenix - AwardBIOS CMOS Setup Utility
SuperIO Device

POWER ON Function [BUTTON ONLY] KB Power ON Password [Enter] Hot Key Power ON [Ctrl-F1] Onboard FDC Controller [Enabled] Onboard Serial Port 1 [3F8/IRQ4] Onboard Serial Port 2 [2F8/IRQ3] UART Mode Select [Normal] RXD , TXD Active [Hi,Lo] IR Transmission Delay [Enabled] UR2 Duplex Mode [Half] Use IR Pins [IR-Rx2Tx2] Onboard Parallel Port [378/IRQ7] Parallel Port Mode [SPP] EPP Mode Select [EPP1.7] ECP Mode Use DMA [3] PWRON After PWR-Fail [Off]	Item Help <hr/> Menu Level ▶▶
--	----------------------------------

↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
 F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

On-Chip Primary/Secondary PCI IDE

The integrated peripheral controller contains an IDE interface with support for two IDE channels. Select *Enabled* to activate each channel separately.

The choice: Enabled, Disabled.

IDE Primary/Secondary Master/Slave PIO

The four IDE PIO (Programmed Input/Output) fields let you set a PIO mode (0-4) for each of the four IDE devices that the onboard IDE interface supports. Modes 0 through 4 provide successively increased performance. In Auto mode, the system automatically determines the best mode for each device.

The choice: Auto, Mode 0, Mode 1, Mode 2, Mode 3, Mode 4.

IDE Primary/Secondary Master/Slave UDMA

Ultra DMA-33/66 implementation is possible only if your IDE hard drive supports it and the operating environment includes a DMA driver (Windows 95 OSR2 or a third-party IDE bus master driver). If your hard drive and your system software both support Ultra DMA-33/66, select Auto to enable BIOS support.

The Choice: Auto, Disabled.

On-Chip Serial ATA

[Disable] : Disable SATA controller.

[Combined] : SATA and PATA are combined. Max. of 2 IDE drivers in each channel.

[Enhanced] : Enhanced both SATA and PATA. Max. of 6 IDE drivers are support.

[SATA only] : SATA is operating in legacy mode.

USB Controller

Select *Enabled* if your system contains a Universal Serial Bus (USB) controller and you have USB peripherals.

The Choice: Enabled, Disabled.

USB Keyboard Support

Select *Enabled* if your system contains a Universal Serial Bus (USB) controller and you have a USB keyboard.

The Choice: Enabled, Disabled.

AC97 Audio

This item allows you to decide to enable/disable the ALC202A chipset

The choice: Auto, Disabled.

Onboard FDC Controller

Select Enabled if your system has a floppy disk controller (FDC) installed on the system board and you wish to use it. If you install and-in FDC or the system has no floppy drive, select Disabled in this field.

The choice: Enabled, Disabled

Onboard Serial Port 1/Port 2

Select an address and corresponding interrupt for the first and second serial ports.

The choice: 3F8/IRQ4, 2E8/IRQ3, 3E8/IRQ4, 2F8/IRQ3, Disabled,

Auto

UART Mode Select

Select a serial port 2 operation mode.

The choice: Normal, IrDA, ASKIR, SCR

Onboard Parallel Port

Select an address and corresponding interrupt for the parallel ports.

The choice: 378/IRQ7, 278/IRQ5, 3BC/IRQ7, Disabled,

Parallel Port Mode

Select a parallel operation mode.

The choice: SPP, EPP, ECP, ECP+EPP

Watchdog Timer Unit Select

Select the WatchDog Timer unit.

The choice: Second, Minute

4.9 Power Management Setup

The Power Management Setup allows you to configure your system to most effectively save energy while operating in a manner consistent with your own style of computer use.

```
Phoenix - AwardBIOS CMOS Setup Utility
Power Management Setup
```

ACPI Function	[Enabled]	▲	Item Help
ACPI Suspend Type	[S1(POS)]	▲	
x Run VGABIOS if S3 Resume	Auto	▲	Menu Level ▶
Power Management	[User Define]	▲	
Video Off Method	[DPMS]	▲	
Video Off In Suspend	[Yes]	▲	
Suspend Type	[Stop Grant]	▲	
MODEM Use IRQ	[3]	▲	
Suspend Mode	[Disabled]	▲	
HDD Power Down	[Disabled]	▲	
Soft-Off by PWR-BTTN	[Instant-Off]	▲	
Wake-Up by PCI card	[Enabled]	▲	
Power On by Ring	[Enabled]	▲	
x USB KB Wake-Up From S3	Disabled	▲	
Resume by Alarm	[Disabled]	▲	
x Date(of Month) Alarm	0	▲	
x Time(hh:mm:ss) Alarm	0 : 0 : 0	▲	
** Reload Global Timer Events **			

↑|←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

ACPI Function

This feature is switch of ACPI function. Configuration options: Enable/Disable.

ACPI Suspend Type

This feature is switch of POS (S1) or STR (S3) function. Configuration options: [S1<POS>] [S3<STR>] [S1&S3].

Power Management

This category allows you to select the type (or degree) of power saving and is directly related to the following modes:

Min. Power Saving	Minimum power management. Doze Mode = 1 hr. Standby Mode = 1 hr., Suspend Mode = 1 hr., and HDD Power Down = 15 min.
Max. Power Saving	Maximum power management -- ONLY AVAILABLE FOR SL CPU's . Doze Mode = 1 min., Standby Mode = 1 min., Suspend Mode = 1 min., and HDD Power Down = 1 min.
User Defined	Allows you to set each mode individually. When not disabled, each of the ranges are from 1 min. to 1 hr. except for HDD Power Down which ranges from 1 min. to 15 min. and disable.

Video Off Method

This determines the manner in which the monitor is blanked.

V/H SYNC+Blank	This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.
Blank Screen	This option only writes blanks to the video buffer.
DPMS	Initial display power management signaling.

Video Off In Suspend

This determines the manner in which the monitor is blanked.

The choice: Yes, No.

SuspendType

Select the Suspend Type.

The choice: PWRON Suspend, Stop Grant.

Suspend Mode

When enabled and after the set time of system inactivity, all devices except the CPU will be shut off.

The choice: 1Min, 2Min, 4Min, 8Min, 12Min, 20Min, 30Min, 40Min, 1Hour, Disabled.

HDD Power Down

When enabled and after the set time of system inactivity, the hard disk drive will be powered down while all other devices remain active.

The choice: 1Min, 2Min, 3Min, 4Min, 5Min, 6Min, 7Min, 8Min, 9Min, 10Min, Disabled.

Soft-off By PWR-BTTN

Instant-off allows the system to switch off immediately the power button is pressed. Otherwise, it will only so after you press the power switch for more 4 seconds.

Wakeup By PCI Card

When this option is set enabled, system will wakeup then wakeup event from PCI Card.

Resume By Alarm

When this option is set enabled, system will according to you set time then wakeup from soft off mode.

4.10 PnP/PCI Configuration Setup

This section describes configuring the PCI bus system. PCI, or **Personal Computer Interconnect**, is a system which allows I/O devices to operate at speeds nearing the speed the CPU itself uses when communicating with its own special components. This section covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.

Phoenix - AwardBIOS CMOS Setup Utility
PnP/PCI Configurations

Reset Configuration Data [Disabled]	Item Help
Resources Controlled By [Auto(ESCD)] x IRQ Resources Press Enter	Menu Level ▶
PCI/VGA Palette Snoop [Disabled]	Default is Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the OS cannot boot

↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
 F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Reset Configuration Data

Normally, you leave this field Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the operating system can not boot.

The choice: Enabled, Disabled .

Resource controlled by

The Award Plug and Play BIOS has the capacity to automatically configure all of the boot and Plug and Play compatible devices. However, this capability means absolutely nothing unless you are using a Plug and Play operating system such as Windows®95. If you set this field to “manual” choose specific resources by going into each of the sub menu that follows this field (a sub menu is preceded by a “▶”).

The choice: Auto(ESCD), Manual.

PCI/VGA Palette Snoop

Leave this field at *Disabled*.

Choices are Enabled, Disabled.

4.11 PC Health Status

Note: normal CPU Fan RPM is over than 5000 RPM. If your CPU Fan RPM is less than that figure, something is wrong and the CPU will be in overheat condition. Make sure that the connection at Fan1/Fan2 is correct.

Phoenix - AwardBIOS CMOS Setup Utility
PC Health Status

CPU Temperature System Temperature VCore (From VID) Vcore +1.5V +3.3 V +5 V +12 V -12 V Fan1 Speed Fan2 Speed	Item Help Menu Level ▶
---	---------------------------

↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

4.12 Frequency/Voltage Control

Phoenix - AwardBIOS CMOS Setup Utility
Frequency/Voltage Control

Auto Detect DIMM/PCI Clk [Enabled] Spread Spectrum [Disabled]	Item Help Menu Level ▶
--	---------------------------

↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Auto Detect DIMM/PCI Clk

This item allows you to enable/disable auto detect DIMM/PCI Clock.

The choice: Enabled, Disabled.

Spread Spectrum

This item allows you to enable/disable the spread spectrum modulate.

The choice: Enabled, Disabled.

4.13 Load Fail-Safe Defaults

When you press <Enter> on this item you get a confirmation dialog box with a message similar to:

Load Fail-Safe Defaults (Y/N) ? **N**

Pressing 'Y' loads the BIOS default values for the most stable, minimal-performance system operations.

4.14 Load Optimized Defaults

When you press <Enter> on this item you get a confirmation dialog box with a message similar to:

Load Optimized Defaults (Y/N) ? **N**

Pressing 'Y' loads the default values that are factory settings for optimal performance system operations.

4.15 Set Password

can enter and change the options of the setup menus.

ENTER PASSWORD:

Type the password, up to eight characters in length, and press <Enter>. The password typed now will clear any previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable a password, just press <Enter> when you are prompted to enter the password. A message will confirm the password will be disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

PASSWORD DISABLED:

When a password has been enabled, you will be prompted to enter it every time you try to enter Setup. This prevents an unauthorized person from changing any part of your system configuration.

Additionally, when a password is enabled, you can also require the BIOS to request a password every time your system is rebooted. This would prevent unauthorized use of your computer.

You determine when the password is required within the BIOS Features Setup Menu and its Security option (see Section 3). If the Security option is set to password will be required both at boot and at entry to Setup. If set to "Setup", prompting only occurs when trying to enter Setup.

4.16 Exit Selecting

Save & Exit Setup

Pressing <Enter> on this item asks for confirmation:

Save to CMOS and EXIT (Y/N)? Y

Pressing "Y" stores the selections made in the menus in CMOS – a special section of memory that stays on after you turn your system off. The next time you boot your computer, the BIOS configures your system according to the Setup selections stored in CMOS. After saving the values the system is restarted again.

Exit Without Saving

Pressing <Enter> on this item asks for confirmation:

Quit without saving (Y/N)? Y

This allows you to exit Setup without storing in CMOS any change. The previous selections remain in effect. This exits the Setup utility and restarts your computer.

Appendix A. Watchdog Timer

The Watchdog Timer is provided to ensure that standalone systems can always recover from catastrophic conditions that cause the CPU to crash. This condition may have occurred by external EMI or a software bug. When the CPU stops working correctly, hardware on the board will either perform a hardware reset (cold boot) or a Non-Maskable Interrupt (NMI) to bring the system back to a known state.

A BIOS function call (INT 15H) is used to control the Watchdog Timer:

INT 15H:

AH – 6FH
<u>Sub-function:</u>
AL – 2 : Set the Watchdog Timer's period
BL : Time-out value(Its unit--second or minute, is dependent on the item "Watchdog Timer unit select" in CMOS setup).

You have to call sub-function 2 to set the time-out period of Watchdog Timer first. If the time-out value is not zero, the Watchdog Timer will start counting down. While the timer value reaches zero, the system will reset. To ensure that this reset condition does not occur, the Watchdog Timer must be periodically refreshed by calling sub-function 2. However the Watchdog timer will be disabled if you set the time-out value to be zero.

A tolerance of at least 10% must be maintained to avoid unknown routines within the operating system (DOS), such as disk I/O that can be very time-consuming.

Note: when exiting a program it is necessary to disable the Watchdog Timer, otherwise the system will reset.

Example program:

```
; INITIAL TIMER PERIOD COUNTER
;
W_LOOP:
    MOV    AX, 6F02H    ;setting the time-out value
    MOV    BL, 30      ;time-out value is 48 seconds
    INT    15H
;
; ADD YOUR APPLICATION PROGRAM HERE
;
    CMP    EXIT_AP, 1  ;is your application over?
    JNE    W_LOOP     ;No, restart your application

    MOV    AX, 6F02H  ;disable Watchdog Timer
    MOV    BL, 0      ;
    INT    15H
;
; EXIT
;
```

Appendix B. Address Mapping

IO Address Map

I/O address Range	Description
000-01F	DMA Controller
020-021	Interrupt Controller
040-05F	System time
060-06F	Keyboard Controller
070-07F	System CMOS/Real time Clock
080-09F	DMA Controller
0A0-0A1	Interrupt Controller
0C0-0DF	DMA Controller
0F0-0FF	Numeric data processor
1F0-1F7	Primary IDE Channel
2E8-2EF	Serial Port 4 (COM4)
2F8-2FF	Serial Port 2 (COM2)
378-37F	Parallel Printer Port 1 (LPT1)
3B0-3BB	Intel(R) 82865 Graphics Controller
3C0-3DF	Intel(R) 82865 Graphics Controller
3E8-3EF	Serial Port 3 (COM3)
3F6-3F6	Primary IDE Channal
3F7-3F7	Standard floppy disk controller
3F8-3FF	Serial Port 1 (COM1)

1st MB Memory Address Map

Memory address	Description
00000-9FFFF	System memory
A0000-BFFFF	VGA buffer
F0000-FFFFF	System BIOS
1000000-	Extend BIOS

*Default setting

IRQ Mapping Table

IRQ0	System Timer	IRQ8	RTC clock
IRQ1	Keyboard	IRQ9	AUDIO/SMBus Cntrlr
IRQ2	Available	IRQ10	COM4
IRQ3	COM2	IRQ11	COM3
IRQ4	COM1	IRQ12	PS/2 mouse
IRQ5	VGA/SMBus Cntrlr	IRQ13	FPU
IRQ6	FDC	IRQ14	Primary IDE
IRQ7	Available	IRQ15	Secondary IDE

DMA Channel Assignments

Channel	Function
0	Available
1	Available
2	Floppy disk (8-bit transfer)
3	Available
4	Cascade for DMA controller 1
5	Available
6	Available
7	Available

Appendix C. How to Upgrade a New BIOS

<Note> Before flashing BIOS , please enable the item “FLASH BIOS” in BIOS setting.

You can install an upgrade BIOS for the SAGP-865EVG that you can download from the manufacturer's web site (<http://www.ieiworld.com>). New BIOS may provide support for new peripherals ,improvements in performance or fixes to addressed known bugs.

BIOS Update Procedure:

1. Make a boot disk. Go to the DOS command prompt in MS-DOS or Windows 9x and, with an available floppy disk in "A", type "format A: /s" That will format the floppy and transfer the needed system files to it.

NOTES:

- A. This procedure will erase any prior data on that floppy, so please Proceed accordingly.
- B. Typically four files will be transferred, only COMMAND.COM being visible when running a simple directory listing.
- C. Please leave the diskette UN-write protected for the balance of this procedure.

2. Download the BIOS upgrade file and awdfash.exe utility from a ICP web site to a temp directory on your hard drive, or directly to the floppy you made in step 1..

3. Copy (BIOS file and awdfash.exe)two files to the boot floppy.

4. Reboot the system to the DOS command prompt using the boot diskette you just made.

5. At the DOS command prompt type , "awdf flash filename.xxx", where filename.xxx is the file name of the BIOS file . Hit enter.

6. Your first option, in sequence, will be to save the old BIOS. We recommend that you do that in case, for whatever reason, you decide you don't wish to use the new version once it is installed.

NOTES:

A. If you decide to save the old BIOS, PLEASE make sure you do NOT save it to the same file name as the new BIOS - if you use the same BIOS name the old file will be written over the new file with NO warning prompt. A simple file name to save the old BIOS to is OLDBIOS.BIN.

B. If you do NOT decide to save the old BIOS, PLEASE at least write down the version number of the old BIOS and store that information with your important computer documents. Enter N (for "no") and skip to step 9.

7. To save the old BIOS, hit Y (for "yes")

8. Enter a name for the OLD BIOS file and hit enter.

NOTE:PLEASE be sure you do NOT save the old BIOS file to the same file name as the new BIOS - if you use the same BIOS name, the old file will write over the new BIOS file WITHOUT a warning prompt. A simple file name for saving the old BIOS to is OLDBIOS.BIN.

9. Your second option, in sequence, will be whether you want to flash your BIOS. Enter Y (for "yes").

NOTE: This is the critical step. Once you hit the enter key, do NOT touch the keyboard, the reset button, or power switch while the flashing is in progress. There will be a bar progressing across the screen while the flashing is progressing.

10. When the flashing process is complete, you will be asked to reset or power off the system. Remove the floppy diskette from the floppy drive and either hit the reset button or the power button.


11. Reboot the system and note that the BIOS version on the initial boot-up screen has changed to the new BIOS version. Your BIOS upgrade is now complete.

Recovering Your Old BIOS:

1. Assuming you have the floppy made during the upgrade procedure noted above, boot the system with that diskette in the floppy drive. If you do not have floppy made during the upgrade procedure noted above, you will need to repeat steps 1 through 3 (above) for the version of the BIOS you wish to recover to.

2. Complete steps 4, 5, 6B, 9, 10, and 11 (above) substituting the name of the BIOS you wish to recover for the upgrade BIOS at step 5.

Install screen :



Appendix D. Install memory modules

ICPMB-8660 has 2 dual in line memory module (DIMM) sockets . The BIOS will automatically detects memory type and size. To ins tall the memory module, just push it vertically into the DIMM socket. The DIMM module can only fit in one direction due to the notch. Memory size can vary between sockets.

ICPMB-8660 supports the Dual Channel Technology. After operating the Dual Channel Technology, the bandwidth of Memory Bus will add double up to 6.4GB/s.

ICPMB-8660 includes 2 DIMM sockets, and each Channel has one DIMM socket.

If you want to operate the Dual Channel Technology, please note the following explanations due to the limitation of Intel® chipset specifications.

1. Only one DDR memory module is installed: The Dual Channel Technology can't operate when only one DDR memory module is installed.
2. Two DDR memory modules are installed (the same memory size and type): The Dual Channel Technology will operate when two memory modules are inserted individually into Channel A and B