###CPU Type Selection Jumper: JP5, JP12, JP13, JP14, JP15, JP16, JP17 JP18, JP19, JP21 (BLUE color selector)

	JP5	JP12	JP13	JP14	JP15	JP16	JP17	JP18	JP19	JP21	Fastany
	JPO	JP1Z	JFIS	JP14	JP15	JP10	JP17	JPIO	JP19	JPZI	Factory
											default
Intel	OFF	OFF	OFF	OFF	1-2	OFF	1-2	1-2	OFF	ON	
486SX											
Intel	OFF	OFF	OFF	2-3	1-2	OFF	1-2	2-3	OFF	ON	
486DX/DX2											
Intel	ON	3-4	OFF	OFF	1-2	3-4	5-6	1-2	OFF	ON	
486SX-S											
Intel	ON	3-4	OFF	2-3	1-2	3-4	5-6	2-3	OFF	ON	
486DX/DX2/DX4-S											
AMD	OFF	OFF	OFF	2-3	1-2	OFF	1-2	2-3	ON/	ON	C *
486-66(80)/100									OFF		
WRITE THROUGH											
AMD	ON	3-4	1-3,5-6/	2-3	2-3	3-4	5-6	2-3	OFF	ON	
486-66(80)/100			5-6								
WRITE BACK											
Cyrix	ON	5-6	1-2	2-3	1-2	5-6	3-4	2-3	OFF	OFF	
T1/SGS/DX/DX2											
Intel P24D/	ON	3-4	5-6	2-3	2-3	3-4	5-6	2-3	OFF	ON	
Cyrix MISC											
Intel P24T	ON	3-4	OFF	1-2	2-3	3-4	5-6	2-3	OFF	ON	
UMC U5	OFF	1-2	OFF	OFF	1-2	1-2	1-2	1-2	OFF	ON	

TABLE - 1

CPU SPEED Selection Jumper: JP8, JP9, JP10, JP11 (White color selector)

Jumper No./ Mhz	JP8	JP9	JP10	JP11	Factory Default
25MHz	00	00		00	
	open	open	1-2 closed	open	
33MHz	closed	closed	1 3	O O open	
	010000	010000	1 3		
40MHz	$\bigcirc \bigcirc$	00	000	$\bigcirc \bigcirc$	
	closed	open	2-3 closed	closed	

TABLE - 2

CPU Voltage selection Jumper: JP20 (Yellow color selector)

Voltage	JP20	Factory default		
5V	20006 10005			
	1-2 closed 3-4 closed			
4V	2 0 0 6 1 0 0 0 5 4-6 closed			
3.45V	$2 \bigcirc \bigcirc \bigcirc \\ 0 \bigcirc \bigcirc \\ 5 \\ 3-5 \text{closed}$	*		

2-3 External cache installation

Cache	TAG	Data	JP7	JP6
128K	8K/16K/32K*8	32K*8	1 3	1 3
256K	16K32/K*8	64K*8	1 3	1 3
512K	32K*8	128K*8	1 3 000	1 3 000

###CACHE size Jumper selection: JP6, JP7, (Black color selector)

TABLE - 3