


## Chapter 5: Jumper Settings

### D-LINK

### DE - 220CAT

<b>NIC Type</b>	Ethernet
<b>Transfer Rate</b>	10Mbps
<b>Data Bus</b>	16-bit ISA
<b>Topology</b>	Linear Bus/Star
<b>Wiring Type</b>	Unshielded twisted pair AUI Transceiver via DB-15 port RG-58A/U 50ohm coaxial
<b>Boot ROM</b>	Available



N0891

DIAGNOSTIC LED(S)			
LED	Color	Status	Condition
LED1	Green	On	Power on
LED1	Green	Blinking	Data is being transmitted/received (UTP only)
LED1	Green	Off	Power off
LED2	Green	On	Network connection is good
LED2	Green	Blinking	Data is being transmitted/received (UTP only)
LED2	Green	Off	Network connection is broken
LED3	Yellow	On	Collision detected on network
LED3	Yellow	Off	No collision detected on network
LED4	Yellow	On	Network connection is broken (BNC only)
LED4	Yellow	Blinking	Card is transmitting for an extended time (jabber)
LED4	Yellow	Off	Normal operation