



Product Support For

P5K-E

[Find Another Model](#) >

Get Product Support

[Register Product](#)

- CPU / Memory Support
- Driver & Utility
- FAQ
- Manual & Document
- Warranty

CPU SUPPORT

- CPU Support
- Memory / Device Support

NEED HELP?

- [Email Us](#)
- [Find service locations](#)

The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)

CPU	Validated since PCB	Validated since BIOS	Note
Celeron 420(1.60GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0307 GO	
Celeron 430(1.80GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0307 GO	
Celeron 440(2.00GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0307 GO	
Celeron 450(2.2GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	1102 GO	
Celeron Dual Core E1200(revM0,1.6GHz,800 FSB,L2:512K)	ALL	0906 GO	
Celeron Dual Core E1500(revM0,2.2GHz,800 FSB,L2: 512K)	ALL	0906 GO	
Celeron Dual Core E3200(revR0,2.4GHz,800 FSB,L2: 1M)	ALL	1305 GO	
Celeron Dual Core E3300(revR0,2.5GHz,800 FSB,L2: 1M)	ALL	1305 GO	



Celeron Dual Core E3400(revR0,2.6GHz,800 FSB,L2: 1M)	ALL	1305	GO
Celeron Dual Core E3500(revR0,2.7GHz,800 FSB,L2: 1M)	ALL	1305	GO
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0201	GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0201	GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0503	GO
Core 2 Duo E4500 (2.2GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0503	GO
Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0503	GO
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,revG0)	ALL	0906	GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.B2)	ALL	0201	GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0201	GO
Core 2 Duo E6320 (1.86GHz,1066FSB,L2:4MB,rev.B2)	ALL	0201	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.B2)	ALL	0201	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.L2)	ALL	0201	GO
Core 2 Duo E6420 (2.13GHz,1066FSB,L2:4MB,rev.B2)	ALL	0201	GO
Core 2 Duo E6540 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0201	GO
Core 2 Duo E6550 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0201	GO
Core 2 Duo E6600 (2.40GHz,1066FSB,L2:4MB,rev.B2)	ALL	0201	GO
Core 2 Duo E6700 (2.66GHz,1066FSB,L2:4MB,rev.B2)	ALL	0201	GO
Core 2 Duo E6750 (2.66GHz,1333FSB,L2:4MB,rev.G0)	ALL	0201	GO
Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.G0)	ALL	0201	GO
Core 2 Duo E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)	ALL	1013	GO




Core 2 Duo E7300(2.66GHz,1066FSB,L2:3MB,rev.M0)	ALL	1013	GO	
Core 2 Duo E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)	ALL	1202	GO	
Core 2 Duo E7500(2.93GHz,1066FSB,L2:3MB,rev.R0)	ALL	1202	GO	
Core 2 Duo E7600(3.06GHz,1066FSB,L2:3MB,rev.R0)	ALL	1301	GO	beta
Core 2 Duo E8200 (2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0906	GO	
Core 2 Duo E8300 (2.83GHz,1333FSB,L2:6MB,rev.C0)	ALL	1013	GO	
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	1102	GO	
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,rev.C0)	ALL	0906	GO	
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	1102	GO	
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,rev.C0)	ALL	0906	GO	
Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	1102	GO	
Core 2 Extreme QX6700(revB3,2.66GHz,1066FSB,L2:2X4MB)	ALL	0201	GO	
Core 2 Extreme QX6800 (rev.G0,2.93GHz,1066FSB,L2:2X4MB,4 cores)	ALL	0201	GO	
Core 2 Extreme QX6800(revB3,2.93GHz,1066FSB,L2:2X4MB)	ALL	0201	GO	
Core 2 Extreme QX6850(revG0,3.00GHz,1333FSB,L2:2X4MB)	ALL	0503	GO	
Core 2 Extreme QX9650 (rev.C1,3.00GHz,1333FSB,L2:2X6MB,4 cores)	ALL	1013	GO	
Core 2 Extreme QX9650(revC0,3.00GHz,1333FSB,L2:2X6MB)	ALL	0806	GO	
Core 2 Extreme QX9770(revC1,3.2GHz,1600FSB,L2:2X6MB)	ALL	1012	GO	
Core 2 Extreme X6800(2.93GHz,1066FSB,L2:4MB,revB2)	ALL	0503	GO	
Core 2 Quad Q6400 (2.13GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0201	GO	
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0201	GO	



Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0503	GO	
Core 2 Quad Q6700 (2.66GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0503	GO	
Core 2 Quad Q8200 (rev.M1,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1102	GO	
Core 2 Quad Q8200 (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1301	GO	beta
Core 2 Quad Q8200S (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1301	GO	beta
Core 2 Quad Q8300 (rev.R0,2.50GHz,1333FSB,L2:4MB,4 cores)	ALL	1202	GO	
Core 2 Quad Q8400 (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	1301	GO	
Core 2 Quad Q8400S (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	1301	GO	beta
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M1,4 cores)	ALL	1012	GO	
Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	1102	GO	
Core 2 Quad Q9400S (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	1301	GO	beta
Core 2 Quad Q9450 (2.66GHz,1333FSB,L2:12MB,rev.C1)	ALL	1013	GO	
Core 2 Quad Q9500 (2.83GHz,1333FSB,L2:6MB,rev.R0)	ALL	1305	GO	
Core 2 Quad Q9505(rev.R0,2.83GHz,1333FSB,L2:6MB)	ALL	1305	GO	
Core 2 Quad Q9550(2.83GHz,1333FSB,L2:12MB,rev.C1)	ALL	1013	GO	
Core 2 Quad Q9550(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	1102	GO	
Core 2 Quad Q9550S(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	1301	GO	beta
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	1102	GO	
P4-3.20F GHz (EM64T)	ALL	0201	GO	
P4-3.40F GHz (EM64T)	ALL	0201	GO	
P4-3.40GHz(FSB800, revR0)	ALL	0201	GO	



P4-3.60F GHz (EM64T)	ALL	0201 GO
P4-3.73 GHz Extreme Ed. (1066 FSB, HT, revN0, LGA775)	ALL	0201 GO
P4-3.80F GHz (EM64T)	ALL	0201 GO
P4-3.80GHz(FSB800, revR0)	ALL	0201 GO
P4-520/520J (2.8E GHz) (800 FSB) (D0)	ALL	0201 GO
P4-520/520J (2.8E GHz) (800 FSB) (E0)	ALL	0201 GO
P4-521 (2.8GHz, 800 FSB,HT, L2 1MB)(D0,E0)	ALL	0201 GO
P4-530/530J (3E GHz) (800 FSB) (D0,E0)	ALL	0201 GO
P4-531 (3GHz, 800 FSB, L2 1MB)(D0,E0)	ALL	0201 GO
P4-540/540J (3.2E GHz) (800 FSB) (E0,D0)	ALL	0201 GO
P4-541 (3.2GHz, 800 FSB, L2 1MB)(E0,D0)	ALL	0201 GO
P4-550/550J (3.4E GHz) (800 FSB) (D0,E0)	ALL	0201 GO
P4-551 (3.4GHz, 800 FSB, L2 1MB,D0,E0)	ALL	0201 GO
P4-560/560J (3.6 GHz) (800 FSB) (D0,E0)	ALL	0201 GO
P4-561 (3.6GHz, 800 FSB, L2 1MB)	ALL	0201 GO
P4-561 (3.6GHz, 800 FSB, L2 1MB)(E0,D0)	ALL	0201 GO
P4-570J (3.8 GHz) (800 FSB) (D0,E0)	ALL	0201 GO
P4-571 (3.8GHz, 800 FSB, L2 1MB V E0)	ALL	0201 GO
P4-630 (3.0E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0201 GO
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revB1)	ALL	0201 GO
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revC1)	ALL	0201 GO



P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revD0)	ALL	0201 GO
P4-640 (3.2E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0201 GO
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revB1)	ALL	0201 GO
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revC1)	ALL	0201 GO
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revD0)	ALL	0201 GO
P4-650 (3.4E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0201 GO
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revB1)	ALL	0201 GO
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revC1)	ALL	0201 GO
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revD0)	ALL	0201 GO
P4-660 (3.6E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0201 GO
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revB1)	ALL	0201 GO
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revC1)	ALL	0201 GO
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revD0)	ALL	0201 GO
P4-662 (3.6 GHz, 800 FSB, L2:2MB, EM64T, HT, revR0)	ALL	0201 GO
P4-670 (3.8 GHz, 800 FSB, L2:2MB,N0)	ALL	0201 GO
P4-672 (3.8 GHz, 800 FSB, L2:2MB, revR0)	ALL	0201 GO
Pentium D 820 (2.8 GHz, 800 FSB, revA0)	ALL	0201 GO
Pentium D 820 (2.8 GHz, 800 FSB, revB0)	ALL	0201 GO
Pentium D 830 (3.0 GHz, 800 FSB, revA0)	ALL	0201 GO
Pentium D 830 (3.0 GHz, 800 FSB, revB0)	ALL	0201 GO
Pentium D 840 (3.2 GHz, 800 FSB, revA0)	ALL	0201 GO



Pentium D 840 (3.2 GHz, 800 FSB, revB0)	ALL	0201 GO
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0201 GO
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revD0,without VT function)	ALL	0201 GO
Pentium D 920(2.8GHz, 800 FSB, L2 4MB, revB1)	ALL	0201 GO
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0201 GO
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0201 GO
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revB1)	ALL	0201 GO
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revC1)	ALL	0201 GO
Pentium D 935(3.2GHz, 800 FSB, L2 4MB, 95W, revD0)	ALL	0201 GO
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revB1)	ALL	0201 GO
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revC1)	ALL	0201 GO
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0201 GO
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0201 GO
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revB1)	ALL	0201 GO
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revC1)	ALL	0201 GO
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revD0)	ALL	0201 GO
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revC1)	ALL	0201 GO
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revD0)	ALL	0201 GO
Pentium Dual Core E2140(1.6GHz, 800FSB, L2 1MB,L2)	ALL	0201 GO
Pentium Dual Core E2140(1.6GHz,800FSB,L2 1MB,M0)	ALL	0503 GO
Pentium Dual Core E2160(1.8GHz, 800FSB, L2 1MB,L2)	ALL	0201 GO



Pentium Dual Core E2160(1.8GHz,800FSB,L2 1MB,M0)	ALL	0503	GO
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0503	GO
Pentium Dual Core E2200(2.2GHz,800FSB,L2 1MB,M0)	ALL	0906	GO
Pentium Dual Core E2210(2.2GHz,800FSB,L2 1MB,R0)	ALL	1305	GO
Pentium Dual Core E2220(2.4GHz,800FSB,L2 1MB,M0)	ALL	0906	GO
Pentium Dual Core E5000 (3.4GHz,800FSB,L2:2MB,rev.R0)	ALL	1305	GO
Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL	1102	GO
Pentium Dual Core E5200(2.50GHz,800FSB,L2:2MB,rev.R0)	ALL	1301	GO beta
Pentium Dual Core E5300 (2.60GHz,800FSB,L2:2MB,rev.R0)	ALL	1202	GO beta
Pentium Dual Core E5400 (2.70GHz,800FSB,L2:2MB,rev.R0)	ALL	1202	GO
Pentium Dual Core E5500 (2.8GHz,800FSB,L2:2MB,rev.R0)	ALL	1305	GO
Pentium Dual Core E5700 (3.0GHz,800FSB,L2:2MB,rev.R0)	ALL	1305	GO
Pentium Dual Core E5800 (3.2GHz,800FSB,L2:2MB,rev.R0)	ALL	1305	GO
Pentium Dual Core E6300 (2.8GHz,1066FSB,L2:2MB,rev.R0)	ALL	1301	GO beta
Pentium Dual Core E6500 (2.93GHz,1066FSB,L2:2MB,rev.R0)	ALL	1305	GO
Pentium Dual Core E6500K (2.93GHz,1066FSB,L2:2MB,rev.R0)	ALL	1305	GO
Pentium Dual Core E6600 (3.06GHz,1066FSB,L2:2MB,rev.R0)	ALL	1305	GO
Pentium Dual Core E6700 (3.2GHz,1066FSB,L2:2MB,rev.R0)	ALL	1305	GO
Pentium Dual Core E6800 (3.3GHz,1066FSB,L2:2MB,rev.R0)	ALL	1305	GO

Shop and Learn

- Mobile
- Phones
- Accessories
- Accessories

- Accessories
- Motherboards / Components
- Motherboards
- Wired Networking
- Intelligent Robots
- AIoT & Industrial Solutions

Learn More

- Asus Design Center
- ASUSPRO
- Automotive Solutions

About Us

- About ASUS
- News
- Investor Relations

Community



For Home	Gaming Cases	Smart Home	Check Repair Status	Press Room
For Work	Cooling	Accessories	Find Service Locations	ASUSTOR Inc.
For Creators	Power Supply Units	Keyboards	Product Registration	ASUS Cloud Corporation
For Students	Sound Cards	Mice and Mouse Pads	Email Us	UniMax Electronics Inc.
For Gaming	Optical Drives	Headsets and Audio	Call Us	
Accessories	Data Storage	Streaming Kits	Security Advisory	
Displays / Desktops	External Graphics Docks	Apparels Bags and Gears	ASUS Support Videos	
Monitors	Networking / IoT / Servers	Cases and Protection	MyASUS	
Projectors	WiFi Routers	Adapters and Chargers		
All-in-One PCs	Whole Home Mesh WiFi System	Docks Dongles and Cable		
Tower PCs		Power Banks		
Gaming Tower PCs		Controller		
Mini PCs		Gimbal		
Workstations				

