

# P5K-VM



ProArt

Gaming

Business

Mobile

Laptops

Displays /  
Desktops

Motherboards /  
Components

Networking /  
IoT / Servers

Accessories

Support



Product Support For

## P5K-VM

[Find Another Model](#) >

Get Product Support

Register Product

CPU / Memory  
Support

Driver & Utility

FAQ

Manual &  
Document

# CPU SUPPORT

CPU Support

Memory / Device Support

## NEED HELP?

The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)

[Email Us](#)

[Find service locations](#)

### CPU

Validated  
since  
PCB

Validated  
since BIOS

Celeron 420(1.60GHz,800 FSB,L2  
512KB,LGA775,revA1)

ALL

0304

GO

## P5K-VM

Celeron 430(1.80GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0304	GO
Celeron 440(2.00GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0304	GO
Celeron Dual Core E1200(revM0,1.6GHz,800 FSB,L2:512K)	ALL	0704	GO
Celeron Dual Core E1400 (revM0,2.0GHz, 800 FSB, L2: 512K)	ALL	0704	GO
Celeron Dual Core E1500(revM0,2.2GHz,800 FSB,L2: 512K)	ALL	0704	GO
Celeron Dual Core E3200(revR0,2.4GHz,800 FSB,L2: 1M)	ALL	0902	GO
Celeron Dual Core E3300(revR0,2.5GHz,800 FSB,L2: 1M)	ALL	0902	GO
Celeron Dual Core E3400(revR0,2.6GHz,800 FSB,L2: 1M)	ALL	0902	GO
Celeron Dual Core E3500(revR0,2.7GHz,800 FSB,L2: 1M)	ALL	0902	GO
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0304	GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0304	GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0401	GO
Core 2 Duo E4500 (2.2GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0401	GO

## P5K-VM

Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,rev.M0)	ALL		GO
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,rev.G0)	ALL	0902	GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.B2)	ALL	0304	GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0304	GO
Core 2 Duo E6320 (1.86GHz,1066FSB,L2:4MB,rev.B2)	ALL	0304	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.B2)	ALL	0304	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.L2)	ALL	0304	GO
Core 2 Duo E6420 (2.13GHz,1066FSB,L2:4MB,rev.B2)	ALL	0304	GO
Core 2 Duo E6550 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0401	GO
Core 2 Duo E6600 (2.40GHz,1066FSB,L2:4MB,rev.B2)	ALL	0304	GO
Core 2 Duo E6700 (2.66GHz,1066FSB,L2:4MB,rev.B2)	ALL	0304	GO
Core 2 Duo E6750 (2.66GHz,1333FSB,L2:4MB,rev.G0)	ALL	0401	GO
Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.G0)	ALL	0401	GO

# P5K-VM

Core 2 Duo E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)	ALL	.....	GO
Core 2 Duo E7300(2.66GHz,1066FSB,L2:3MB,rev.M0)	ALL	0803	GO
Core 2 Duo E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)	ALL	0902	GO
Core 2 Duo E7500(2.93GHz,1066FSB,L2:3MB,rev.R0)	ALL	0902	GO
Core 2 Duo E7600(3.06GHz,1066FSB,L2:3MB,rev.R0)	ALL	0902	GO
Core 2 Duo E8200 (2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0704	GO
Core 2 Duo E8300 (2.83GHz,1333FSB,L2:6MB,rev.C0)	ALL	0803	GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0902	GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,rev.C0)	ALL	0704	GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0902	GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,rev.C0)	ALL	0704	GO
Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0902	GO
Core 2 Extreme QX6700(revB3,2.66GHz,1066FSB,L2:2X4MB)	ALL	0304	GO

## P5K-VM

Core 2 Extreme QX6800 (rev.G0,2.93GHz,1066FSB,L2:2X4MB,4 cores)	ALL		GO
Core 2 Extreme QX9650(revC0,3.00GHz,1333FSB,L2:2X6MB)	ALL	0602	GO
Core 2 Extreme QX9770(revC1,3.2GHz,1600FSB,L2:2X6MB)	ALL	0803	GO
Core 2 Extreme X6800(2.93GHz,1066FSB,L2:4MB,revB2)	ALL	0304	GO
Core 2 Quad Q6400 (2.13GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0304	GO
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0304	GO
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0401	GO
Core 2 Quad Q8200 (rev.M1,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0803	GO
Core 2 Quad Q8200 (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0902	GO
Core 2 Quad Q8200S (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0902	GO
Core 2 Quad Q8300 (rev.R0,2.50GHz,1333FSB,L2:4MB,4 cores)	ALL	0902	GO
Core 2 Quad Q8400 (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	0902	GO
Core 2 Quad Q8400S (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	0902	GO

# P5K-VM

Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M1,4 cores)	ALL	.....	GO
Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0902	GO
Core 2 Quad Q9400S (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0902	GO
Core 2 Quad Q9450 (2.66GHz,1333FSB,L2:12MB,rev.C1)	ALL	0803	GO
Core 2 Quad Q9500 (2.83GHz,1333FSB,L2:6MB,rev.R0)	ALL	0902	GO
Core 2 Quad Q9505(rev.R0,2.83GHz,1333FSB,L2:6MB)	ALL	0902	GO
Core 2 Quad Q9550(2.83GHz,1333FSB,L2:12MB,rev.C1)	ALL	0803	GO
Core 2 Quad Q9550(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0902	GO
Core 2 Quad Q9550S(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0902	GO
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	0902	GO
P4-3.40GHz(FSB800, revR0)	ALL	0304	GO
P4-3.73 GHz Extreme Ed. (1066 FSB, HT, revN0, LGA775)	ALL	0304	GO
P4-3.80GHz(FSB800, revR0)	ALL	0304	GO

## P5K-VM

P4-520/520J (2.8E GHz) (800 FSB) (D0)	ALL	0304	GO
P4-520/520J (2.8E GHz) (800 FSB) (E0)	ALL	0304	GO
P4-521 (2.8GHz, 800 FSB,HT, L2 1MB)(D0,E0)	ALL	0304	GO
P4-530/530J (3E GHz) (800 FSB) (D0,E0)	ALL	0304	GO
P4-531 (3GHz, 800 FSB, L2 1MB)(D0,E0)	ALL	0304	GO
P4-540/540J (3.2E GHz) (800 FSB) (E0,D0)	ALL	0304	GO
P4-541 (3.2GHz, 800 FSB, L2 1MB)(E0,D0)	ALL	0304	GO
P4-550/550J (3.4E GHz) (800 FSB) (D0,E0)	ALL	0304	GO
P4-551 (3.4GHz, 800 FSB, L2 1MB,D0,E0)	ALL	0304	GO
P4-560/560J (3.6 GHz) (800 FSB) (D0,E0)	ALL	0304	GO
P4-561 (3.6GHz, 800 FSB, L2 1MB)	ALL	0304	GO
P4-561 (3.6GHz, 800 FSB, L2 1MB)(E0,D0)	ALL	0304	GO
P4-570J (3.8 GHz) (800 FSB) (D0,E0)	ALL	0304	GO

# P5K-VM

P4-571 (3.8GHz, 800 FSB, L2 1MB V E0)	ALL	0304	GO
P4-630 (3.0E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0304	GO
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revB1)	ALL	0304	GO
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revC1)	ALL	0304	GO
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revD0)	ALL	0304	GO
P4-640 (3.2E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0304	GO
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revB1)	ALL	0304	GO
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revC1)	ALL	0304	GO
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revD0)	ALL	0304	GO
P4-650 (3.4E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0304	GO
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revB1)	ALL	0304	GO
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revC1)	ALL	0304	GO
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revD0)	ALL	0304	GO



## P5K-VM

P4-660 (3.6E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0304	GO
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revB1)	ALL	0304	GO
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revC1)	ALL	0304	GO
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revD0)	ALL	0304	GO
P4-662 (3.6 GHz, 800 FSB, L2:2MB, EM64T, HT, revR0)	ALL	0304	GO
P4-670 (3.8 GHz, 800 FSB, L2:2MB,N0)	ALL	0304	GO
P4-672 (3.8 GHz, 800 FSB, L2:2MB, revR0)	ALL	0304	GO
Pentium D 820 (2.8 GHz, 800 FSB, revA0)	ALL	0304	GO
Pentium D 820 (2.8 GHz, 800 FSB, revB0)	ALL	0304	GO
Pentium D 830 (3.0 GHz, 800 FSB, revA0)	ALL	0304	GO
Pentium D 830 (3.0 GHz, 800 FSB, revB0)	ALL	0304	GO
Pentium D 840 (3.2 GHz, 800 FSB, revA0)	ALL	0304	GO
Pentium D 840 (3.2 GHz, 800 FSB, revB0)	ALL	0304	GO

## P5K-VM

Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0304	GO
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revD0,without VT function)	ALL	0304	GO
Pentium D 920(2.8GHz, 800 FSB, L2 4MB, revB1)	ALL	0304	GO
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0304	GO
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0304	GO
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revB1)	ALL	0304	GO
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revC1)	ALL	0304	GO
Pentium D 935(3.2GHz, 800 FSB, L2 4MB, 95W, revD0)	ALL	0304	GO
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revB1)	ALL	0304	GO
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revC1)	ALL	0304	GO
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0304	GO
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0304	GO
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revB1)	ALL	0304	GO

## P5K-VM

Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revC1)	ALL	0304	GO
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revD0)	ALL	0304	GO
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revC1)	ALL	0304	GO
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revD0)	ALL	0304	GO
Pentium Dual Core E2140(1.6GHz, 800FSB, L2 1MB,L2)	ALL	0304	GO
Pentium Dual Core E2140(1.6GHz,800FSB,L2 1MB,M0)	ALL	0401	GO
Pentium Dual Core E2160(1.8GHz, 800FSB, L2 1MB,L2)	ALL	0304	GO
Pentium Dual Core E2160(1.8GHz,800FSB,L2 1MB,M0)	ALL	0401	GO
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0401	GO
Pentium Dual Core E2200(2.2GHz,800FSB,L2 1MB,M0)	ALL	0704	GO
Pentium Dual Core E2210(2.2GHz,800FSB,L2 1MB,R0)	ALL	0902	GO
Pentium Dual Core E2220(2.4GHz,800FSB,L2 1MB,M0)	ALL	0704	GO
Pentium Dual Core E5000 (3.4GHz,800FSB,L2:2MB,rev.R0)	ALL	0902	GO

## P5K-VM

Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL		GO
Pentium Dual Core E5200(2.50GHz,800FSB,L2:2MB,rev.R0)	ALL	0902	GO
Pentium Dual Core E5300 (2.60GHz,800FSB,L2:2MB,rev.R0)	ALL	0902	GO
Pentium Dual Core E5400 (2.70GHz,800FSB,L2:2MB,rev.R0)	ALL	0902	GO
Pentium Dual Core E5500 (2.8GHz,800FSB,L2:2MB,rev.R0)	ALL	0902	GO
Pentium Dual Core E5700 (3.0GHz,800FSB,L2:2MB,rev.R0)	ALL	0902	GO
Pentium Dual Core E5800 (3.2GHz,800FSB,L2:2MB,rev.R0)		0902	GO
Pentium Dual Core E6300 (2.8GHz,1066FSB,L2:2MB,rev.R0)	ALL	0902	GO
Pentium Dual Core E6500 (2.93GHz,1066FSB,L2:2MB,rev.R0)	ALL	0902	GO
Pentium Dual Core E6500K (2.93GHz,1066FSB,L2:2MB,rev.R0)	ALL	0902	GO
Pentium Dual Core E6600 (3.06GHz,1066FSB,L2:2MB,rev.R0)	ALL	0902	GO
Pentium Dual Core E6700 (3.2GHz,1066FSB,L2:2MB,rev.R0)	ALL	0902	GO
Pentium Dual Core E6800 (3.3GHz,1066FSB,L2:2MB,rev.R0)	ALL	0902	GO

# P5K-VM

Pentium Extreme Ed-840 (3.2 GHz, 800 FSB, revAO)	ALL	GO
Pentium Extreme Ed-840 (3.2 GHz, 800 FSB, revBO)	ALL	0304 GO
Pentium Extreme ED-955(3.46GHz, rev AO,B1)	ALL	0304 GO
Pentium Extreme ED-965(3.73GHz, rev C1)	ALL	0304 GO



## Shop and Learn

- Mobile
- Phones
- Accessories
- Laptops
- For Home
- For Work
- For Creators
- For Students
- For Gaming
- Accessories
- Displays / Desktops
- Monitors
- Projectors
- All-in-One PCs
- Tower PCs
- Gaming Tower PCs
- Mini PCs
- Workstations
- Accessories
- Motherboards / Components**
- Motherboards
- Graphics Cards
- Gaming Cases
- Cooling
- Power Supply Units
- Sound Cards
- Optical Drives
- Data Storage
- External Graphics Docks
- Networking / IoT / Servers**
- WiFi Routers
- Whole Home Mesh WiFi System
- Wired Networking
- Intelligent Robots
- AIoT & Industrial Solutions
- Servers
- Smart Home
- Accessories**
- Keyboards
- Mice and Mouse Pads
- Headsets and Audio
- Streaming Kits
- Apparel Bags and Gear
- Cases and Protection
- Adapters and Chargers
- Docks Dongles and Cable
- Power Banks


## Learn More

- Asus Design Center
- ASUSPRO
- Automotive Solutions
- AVC Licensing Notice
- Support**
- Check Repair Status
- Find Service Locations
- Product Registration
- Email Us
- Call Us
- Security Advisory
- ASUS Support Videos
- MyASUS

## About Us

- About ASUS
- News
- Investor Relations
- About CSR for global
- Press Room
- ASUSTOR Inc.
- ASUS Cloud Corporation
- UniMax Electronics Inc.

## Community



# P5K-VM