

P5KPL/1600



ProArt

Gaming

Business

Mobile

Laptops

Displays /
Desktops

Motherboards /
Components

Networking /
IoT / Servers

Accessories

Support



Product Support For P5KPL/1600

[Find Another Model](#) >

[Get Product Support](#)

[Register Product](#)

[CPU / Memory Support](#)

[Driver & Utility](#)

[FAQ](#)

[Manual & Document](#)

CPU SUPPORT

[CPU Support](#)

[Memory / Device Support](#)

NEED HELP?

The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)

[Email Us](#)

[Find service locations](#)

CPU

Validated since PCB

Validated since BIOS

Celeron 420(1.60GHz,800 FSB,L2 512KB,LGA775,revA1)

ALL

0311

GO

P5KPL/1600

Celeron 450(2.2GHz,800FSB,L2:512KB,LGA775,revA1)	ALL	GO
Celeron 450(2.2GHz,800FSB,L2:512KB,LGA775,revA1)	ALL	0317 GO
Celeron Dual Core E1200(revM0,1.6GHz,800FSB,L2:512K)	ALL	0311 GO
Celeron Dual Core E3200(revR0,2.4GHz,800FSB,L2: 1M)	3.01G	0512 GO
Celeron Dual Core E3300(revR0,2.5GHz,800FSB,L2: 1M)	3.01G	0512 GO
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0311 GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0311 GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0311 GO
Core 2 Duo E4500 (2.2GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0311 GO
Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0311 GO
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,revG0)	ALL	0311 GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.B2)	ALL	0311 GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0311 GO

P5KPL/1600

Core 2 Duo E6400 (1.86GHz,1066FSB,L2:4MB,rev.B2)	ALL	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.B2)	ALL	0311 GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.L2)	ALL	0311 GO
Core 2 Duo E6420 (2.13GHz,1066FSB,L2:4MB,rev.B2)	ALL	0311 GO
Core 2 Duo E6540 (2.33GHz,1333FSB,L2:4MB,rev.GO)	ALL	0311 GO
Core 2 Duo E6550 (2.33GHz,1333FSB,L2:4MB,rev.GO)	ALL	0311 GO
Core 2 Duo E6600 (2.40GHz,1066FSB,L2:4MB,rev.B2)	ALL	0311 GO
Core 2 Duo E6700 (2.66GHz,1066FSB,L2:4MB,rev.B2)	ALL	0311 GO
Core 2 Duo E6750 (2.66GHz,1333FSB,L2:4MB,rev.GO)	ALL	0311 GO
Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.GO)	ALL	0311 GO
Core 2 Duo E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)	ALL	0311 GO
Core 2 Duo E7300(2.66GHz,1066FSB,L2:3MB,rev.M0)	ALL	0311 GO
Core 2 Duo E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)	ALL	0506 GO

P5KPL/1600

E7500(2.93GHz,1066FSB,L2:3MB,rev.R0)	ALL	GO
Core 2 Duo E7600(3.06GHz,1066FSB,L2:3MB,rev.R0)	ALL	0512 GO
Core 2 Duo E8190(2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0311 GO
Core 2 Duo E8200 (2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0311 GO
Core 2 Duo E8300 (2.83GHz,1333FSB,L2:6MB,rev.C0)	ALL	0311 GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0403 GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,rev.C0)	ALL	0311 GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0403 GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,rev.C0)	ALL	0311 GO
Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0403 GO
Core 2 Extreme QX6700(revB3,2.66GHz,1066FSB,L2:2X4MB)	ALL	0311 GO
Core 2 Extreme QX6800 (rev.G0,2.93GHz,1066FSB,L2:2X4MB,4 cores)	ALL	0311 GO
Core 2 Extreme QX9650 (rev.C1,3.00GHz,1333FSB,L2:2X6MB,4 cores)	ALL	0311 GO

P5KPL/1600

Core 2 Extreme QX9650(revC0,3.00GHz,1333FSB,L2:2X6MB)	ALL		GO
Core 2 Extreme QX9770(revC1,3.2GHz,1600FSB,L2:2X6MB)	ALL		0311 GO
Core 2 Extreme X6800(2.93GHz,1066FSB,L2:4MB,revB2)	ALL		0311 GO
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL		0311 GO
Core 2 Quad Q6700 (2.66GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL		0311 GO
Core 2 Quad Q8200 (rev.M1,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL		0317 GO
Core 2 Quad Q8200 (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	2.03G/3.01G		0507 GO
Core 2 Quad Q8200S (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL		0507 GO
Core 2 Quad Q8400 (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	2.03G/3.01G		0512 GO
Core 2 Quad Q8400S (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	2.03G/3.01G		0512 GO
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M0,4 cores)	ALL		0311 GO
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M1,4 cores)	ALL		0311 GO
Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL		0503 GO

P5KPL/1600

Core 2 Quad Q9450 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	GO
Core 2 Quad Q9450 (2.66GHz,1333FSB,L2:12MB,rev.C1)	ALL	0311 GO
Core 2 Quad Q9500 (2.83GHz,1333FSB,L2:6MB,rev.R0)	ALL	0512 GO
Core 2 Quad Q9505(rev.R0,2.83GHz,1333FSB,L2:6MB)	3.01G	0512 GO
Core 2 Quad Q9550(2.83GHz,1333FSB,L2:12MB,rev.C1)	ALL	0311 GO
Core 2 Quad Q9550S(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0507 GO
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	0503 GO
P4-531 (3GHz, 800 FSB, L2 1MB)(D0,E0)	ALL	0311 GO
P4-540/540J (3.2E GHz) (800 FSB) (E0,D0)	ALL	0311 GO
P4-551 (3.4GHz, 800 FSB, L2 1MB,D0,E0)	ALL	0311 GO
P4-551 (3.4GHz, 800 FSB, L2 1MB,G1)	ALL	0311 GO
P4-570 (3.8 GHz) (800 FSB) (E0)	ALL	0311 GO
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revB1)	ALL	0311 GO

P5KPL/1600


Pentium D 830 (3.0 GHz, 800 FSB, L2:2MB, HT, revR0)	ALL	GO
P4-670 (3.8 GHz, 800 FSB, L2:2MB,N0)	ALL	0311 GO
Pentium D 830 (3.0 GHz, 800 FSB, revA0)	ALL	0311 GO
Pentium D 830 (3.0 GHz, 800 FSB, revB0)	ALL	0311 GO
Pentium D 840 (3.2 GHz, 800 FSB, revA0)	ALL	0311 GO
Pentium D 920(2.8GHz, 800 FSB, L2 4MB, revB1)	ALL	0311 GO
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0311 GO
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0311 GO
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revB1)	ALL	0311 GO
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revB1)	ALL	0311 GO
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revC1)	ALL	0311 GO
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0311 GO
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0311 GO

P5KPL/1600

Pentium D 700(3.0GHz, 800 FSB, L2 1MB, revC1)	ALL		GO
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revD0)	ALL	0311	GO
Pentium Dual Core E2140(1.6GHz, 800FSB, L2 1MB,L2)	ALL	0311	GO
Pentium Dual Core E2140(1.6GHz,800FSB,L2 1MB,M0)	ALL	0311	GO
Pentium Dual Core E2160(1.8GHz, 800FSB, L2 1MB,L2)	ALL	0311	GO
Pentium Dual Core E2160(1.8GHz,800FSB,L2 1MB,M0)	ALL	0311	GO
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0311	GO
Pentium Dual Core E2200(2.2GHz,800FSB,L2 1MB,M0)	ALL	0311	GO
Pentium Dual Core E2210(2.2GHz,800FSB,L2 1MB,RO)	ALL	0512	GO
Pentium Dual Core E2220(2.4GHz,800FSB,L2 1MB,M0)	ALL	0311	GO
Pentium Dual Core E5000 (3.4GHz,800FSB,L2:2MB,rev.R0)	ALL	0512	GO
Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL	0317	GO
Pentium Dual Core E5200(2.50GHz,800FSB,L2:2MB,rev.R0)	3.01G	0512	GO

P5KPL/1600

Pentium Dual Core E5400 (2.60GHz,800FSB,L2:2MB,rev.R0)	ALL	GO
Pentium Dual Core E5400 (2.70GHz,800FSB,L2:2MB,rev.R0)	ALL	0506 GO
Pentium Dual Core E5500 (2.8GHz,800FSB,L2:2MB,rev.R0)	ALL	0512 GO
Pentium Dual Core E5700 (3.0GHz,800FSB,L2:2MB,rev.R0)	ALL	0512 GO
Pentium Dual Core E6300 (2.8GHz,1066FSB,L2:2MB,rev.R0)	2.03G/3.01G	0512 GO
Pentium Dual Core E6500 (2.93GHz,1066FSB,L2:2MB,rev.R0)	3.01G	0512 GO
Pentium Dual Core E6500K (2.93GHz,1066FSB,L2:2MB,rev.R0)	3.01G	0512 GO
Pentium Dual Core E6700 (3.2GHz,1066FSB,L2:2MB,rev.R0)	ALL	0512 GO
Pentium Dual Core E6800 (3.3GHz,1066FSB,L2:2MB,rev.R0)	ALL	0512 GO



Shop and Learn

- Mobile Workstations
- Phones Accessories
- Accessories **Motherboards / Components**
- Laptops Motherboards
- For Home Graphics Cards
- For Work Gaming Cases
- For Creators Cooling

- Wired Networking
- Intelligent Robots
- AIoT & Industrial Solutions
- Servers
- Smart Home
- Accessories
- Keyboards

Learn More


- Asus Design Center
- ASUSPRO
- Automotive Solutions
- AVC Licensing Notice

Support

About Us

- About ASUS
- News
- Investor Relations
- About CSR for global
- Press Room
- ASUSTOR Inc.

Community



P5KPL/1600

Displays / Desktops	Data Storage	Apparel Bags and Gear	Product Registration
Monitors	External Graphics Docks	Cases and Protection	Email Us
Projectors	Networking / IoT / Servers	Adapters and Chargers	Call Us
All-in-One PCs	WiFi Routers	Docks Dongles and Cable	Security Advisory
Tower PCs	Whole Home Mesh WiFi System	Power Banks	ASUS Support Videos
Gaming Tower PCs		Controller	MyASUS
Mini PCs		Gimbal	