



Product Support For

P5KPL-AM

[Find Another Model](#) >

Get Product Support

[Register Product](#)

CPU / Memory
Support

Driver & Utility

FAQ

Manual &
Document

CPU SUPPORT

CPU Support

Memory / Device Support

NEED HELP?

[Email Us](#)

[Find service locations](#)

The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)















CPU	Validated since PCB	Validated since BIOS	N
Celeron 420(1.60GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0301	

[GO](#)



P5KPL-AM

Celeron 400(1.8GHz,800FSB,L2:512KB,LGA775,revA1)	ALL	
Celeron 450(2.2GHz,800FSB,L2:512KB,LGA775,revA1)	ALL	0403 
Celeron Dual Core E1200(revM0,1.6GHz,800FSB,L2:512K)	ALL	0301 
Celeron Dual Core E1400 (revM0,2.0GHz,800FSB, L2: 512K)	ALL	0410 
Celeron Dual Core E1600(revM0,2.4GHz,800FSB,L2: 512K)	ALL	0410 
Celeron Dual Core E3200(revR0,2.4GHz,800FSB,L2: 1M)	2.05G	0516 
Celeron Dual Core E3300(revR0,2.5GHz,800FSB,L2: 1M)	2.05G	0516 
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0301 
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0301 
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0301 
Core 2 Duo E4500 (2.2GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0301 
Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0301 
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,revGO)	ALL	0301 
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.B2)	ALL	0301 

P5KPL-AM

Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0301 
Core 2 Duo E6320 (1.86GHz,1066FSB,L2:4MB,rev.B2)	ALL	0301 
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.B2)	ALL	0301 
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.L2)	ALL	0301 
Core 2 Duo E6420 (2.13GHz,1066FSB,L2:4MB,rev.B2)	ALL	0301 
Core 2 Duo E6540 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0301 
Core 2 Duo E6550 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0301 
Core 2 Duo E6600 (2.40GHz,1066FSB,L2:4MB,rev.B2)	ALL	0301 
Core 2 Duo E6700 (2.66GHz,1066FSB,L2:4MB,rev.B2)	ALL	0301 
Core 2 Duo E6750 (2.66GHz,1333FSB,L2:4MB,rev.G0)	ALL	0301 
Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.G0)	ALL	0301 
Core 2 Duo E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)	ALL	0301 
Core 2 Duo E7300(2.66GHz,1066FSB,L2:3MB,rev.M0)	ALL	0301 
Core 2 Duo E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)	ALL	0411 















P5KPL-AM

Core 2 Duo E7500(2.93GHz,1066FSB,L2:3MB,rev.R0)	ALL	0509 
Core 2 Duo E7600(3.06GHz,1066FSB,L2:3MB,rev.R0)	ALL	0509 
Core 2 Duo E8190(2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0301 
Core 2 Duo E8200 (2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0301 
Core 2 Duo E8300 (2.83GHz,1333FSB,L2:6MB,rev.C0)	ALL	0301 
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0403 
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,rev.C0)	ALL	0301 
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0403 
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,rev.C0)	ALL	0301 
Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0403 
Core 2 Extreme QX6700(revB3,2.66GHz,1066FSB,L2:2X4MB)	ALL	0301 
Core 2 Extreme QX6800(revB3,2.93GHz,1066FSB,L2:2X4MB)	ALL	0301 
Core 2 Extreme QX9650 (rev.C1,3.00GHz,1333FSB,L2:2X6MB,4 cores)	ALL	0301 
Core 2 Extreme QX9770(revC1,3.2GHz,1600FSB,L2:2X6MB)	ALL	0301 















P5KPL-AM

Core 2 Extreme X6800(2.93GHz,1066FSB,L2:4MB,revB2)	ALL		GO
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0301	GO
Core 2 Quad Q6700 (2.66GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0301	GO
Core 2 Quad Q8200 (rev.M1,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0403	GO
Core 2 Quad Q8200 (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	2.03G/2.05G	0509	GO
Core 2 Quad Q8200S (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0411	GO
Core 2 Quad Q8400 (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	2.03G/2.05G	0509	GO
Core 2 Quad Q8400S (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	2.03G/2.05G	0509	GO
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M1,4 cores)	ALL	0301	GO
Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0403	GO
Core 2 Quad Q9400S (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0411	GO
Core 2 Quad Q9500 (2.83GHz,1333FSB,L2:6MB,rev.R0)	ALL	0518	GO
Core 2 Quad Q9505(rev.R0,2.83GHz,1333FSB,L2:6MB)	2.05G	0516	GO
Core 2 Quad Q9550(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0403	GO















P5KPL-AM

Core 2 Quad Q9550S(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0403 
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	0301 
P4-3.73 GHz Extreme Ed. (1066 FSB, HT, revNO, LGA775)	ALL	0301 
P4-520/520J (2.8E GHz) (800 FSB) (D0)	ALL	0301 
P4-520/520J (2.8E GHz) (800 FSB) (E0)	ALL	0301 
P4-521 (2.8GHz, 800 FSB,HT, L2 1MB) (D0,E0)	ALL	0301 
P4-531 (3GHz, 800 FSB, L2 1MB)(D0,E0)	ALL	0301 
P4-540/540J (3.2E GHz) (800 FSB) (E0,D0)	ALL	0301 
P4-551 (3.4GHz, 800 FSB, L2 1MB,D0,E0)	ALL	0301 
P4-551 (3.4GHz, 800 FSB, L2 1MB,G1)	ALL	0301 
P4-570 (3.8 GHz) (800 FSB) (E0)	ALL	0301 
P4-630 (3.0E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0301 
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revB1)	ALL	0301 
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revD0)	ALL	0301 

P5KPL-AM

P4-650 (3.4E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0301 
P4-650 (3.4E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0301 
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revB1)	ALL	0301 
P4-662 (3.6 GHz, 800 FSB, L2:2MB, EM64T, HT, revR0)	ALL	0301 
P4-670 (3.8 GHz, 800 FSB, L2:2MB,N0)	ALL	0301 
Pentium D 820 (2.8 GHz, 800 FSB, revA0)	ALL	0301 
Pentium D 830 (3.0 GHz, 800 FSB, revA0)	ALL	0301 
Pentium D 830 (3.0 GHz, 800 FSB, revB0)	ALL	0301 
Pentium D 840 (3.2 GHz, 800 FSB, revA0)	ALL	0301 
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0301 
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revDO,without VT function)	ALL	0301 
Pentium D 920(2.8GHz, 800 FSB, L2 4MB, revB1)	ALL	0301 
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0301 
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revDO, without VT function)	ALL	0301 

P5KPL-AM

Pentium D 700(3.0GHz, 800 FSB, L2 4MB, revB1)	ALL	0301 
Pentium D 935(3.2GHz, 800 FSB, L2 4MB, 95W, revD0)	ALL	0301 
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revC1)	ALL	0301 
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0301 
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0301 
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revC1)	ALL	0301 
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revD0)	ALL	0301 
Pentium Dual Core E2140(1.6GHz, 800FSB, L2 1MB,L2)	ALL	0301 
Pentium Dual Core E2160(1.8GHz, 800FSB, L2 1MB,L2)	ALL	0301 
Pentium Dual Core E2160(1.8GHz,800FSB,L2 1MB,M0)	ALL	0301 
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0301 
Pentium Dual Core E2200(2.2GHz,800FSB,L2 1MB,M0)	ALL	0301 
Pentium Dual Core E2210(2.2GHz,800FSB,L2 1MB,RO)	ALL	0518 
Pentium Dual Core E2220(2.4GHz,800FSB,L2 1MB,M0)	ALL	0301 

P5KPL-AM

Pentium Dual Core E5000 (3.4GHz,800FSB,L2:2MB,rev.R0)	ALL	GO
Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL	0403 GO
Pentium Dual Core E5200(2.50GHz,800FSB,L2:2MB,rev.R0)	2.05G	0511 GO
Pentium Dual Core E5300 (2.60GHz,800FSB,L2:2MB,rev.R0)	ALL	0411 GO
Pentium Dual Core E5400 (2.70GHz,800FSB,L2:2MB,rev.R0)	ALL	0411 GO
Pentium Dual Core E5500 (2.8GHz,800FSB,L2:2MB,rev.R0)	ALL	0518 GO
Pentium Dual Core E5700 (3.0GHz,800FSB,L2:2MB,rev.R0)	ALL	0518 GO
Pentium Dual Core E6300 (2.8GHz,1066FSB,L2:2MB,rev.R0)	2.03G/2.05G	0509 GO
Pentium Dual Core E6500 (2.93GHz,1066FSB,L2:2MB,rev.R0)	2.05G	0516 GO
Pentium Dual Core E6500K (2.93GHz,1066FSB,L2:2MB,rev.R0)	2.05G	0516 GO
Pentium Dual Core E6600 (3.06GHz,1066FSB,L2:2MB,rev.R0)	ALL	0518 GO
Pentium Dual Core E6800 (3.3GHz,1066FSB,L2:2MB,rev.R0)	ALL	0518 GO

P5KPL-AM

	Motherboards	Servers	Support	global
For Home	Graphics Cards	Smart Home	Check Repair Status	Press Room
For Work	Gaming Cases	Accessories	Find Service Locations	ASUSTOR Inc.
For Creators	Cooling	Keyboards	Product Registration	ASUS Cloud Corporation
For Students	Power Supply Units	Mice and Mouse Pads	Email Us	UniMax Electronics Inc.
For Gaming	Sound Cards	Headsets and Audio	Call Us	
Accessories	Optical Drives	Streaming Kits	Security Advisory	
Displays / Desktops	Data Storage	Apparel Bags and Gear	ASUS Support Videos	
Monitors	External Graphics Docks	Cases and Protection	MyASUS	
Projectors	Networking / IoT / Servers	Adapters and Chargers		
All-in-One PCs	WiFi Routers	Docks Dongles and Cable		
Tower PCs	Whole Home Mesh WiFi System	Power Banks		
Gaming Tower PCs		Controller		
Mini PCs		Gimbal		
		Display Accessories		