

We raden je aan om je lokale website te selecteren en bezoeken voor relevantere producten, promoties en evenementen.

Stay here

Naar je lokale website gaan

## P5KPL-VM



### Product Support For P5KPL-VM

[Find Another Model >](#)

By registering your device, you can easily manage your product warranty, get technical support and keep track of your repair status.

Register Product

CPU / Memory Support

Driver & Utility

FAQ

Manual & Document

Warranty

## CPU SUPPORT

CPU Support

Memory / Device Support
















### NEED HELP?




Email Us
















Find service locations














The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)
















CPU	Validated since PCB	Validated since BIOS	Note
Celeron 420(1,60GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0105 <a href="#">GO</a>	
Celeron 430(1,80GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0105 <a href="#">GO</a>	
















CPU	Validated since PCB	Validated since BIOS	Note
Celeron 440(2.00GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0105 	
Celeron 450(2.2GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0902 	
Celeron Dual Core E1200(revM0,1.6GHz,800 FSB,L2:512K)	ALL	0303 	
Celeron Dual Core E1400 (revM0,2.0GHz, 800 FSB, L2: 512K)	ALL	0303 	
Celeron Dual Core E1500(revM0,2.2GHz,800 FSB,L2: 512K)	ALL	0303 	
Celeron Dual Core E3200(revR0,2.4GHz,800 FSB,L2: 1M)	ALL	0904 	
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0105 	
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0105 	
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0201 	
Core 2 Duo E4500 (2.2GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0105 	
Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0303 	
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,revG0)	ALL	0303 	
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.B2)	ALL	0105 	
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0105 	
Core 2 Duo E6320 (1.86GHz,1066FSB,L2:4MB,rev.B2)	ALL	0105 	

CPU	Validated since PCB	Validated since BIOS	Note
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.L2)	ALL	0105 	
Core 2 Duo E6420 (2.13GHz,1066FSB,L2:4MB,rev.B2)	ALL	0105 	
Core 2 Duo E6550 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0105 	
Core 2 Duo E6600 (2.40GHz,1066FSB,L2:4MB,rev.B2)	ALL	0105 	
Core 2 Duo E6700 (2.66GHz,1066FSB,L2:4MB,rev.B2)	ALL	0105 	
Core 2 Duo E6750 (2.66GHz,1333FSB,L2:4MB,rev.G0)	ALL	0105 	
Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.G0)	ALL	0105 	
Core 2 Duo E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)	ALL	0802 	
Core 2 Duo E7300(2.66GHz,1066FSB,L2:3MB,rev.M0)	ALL	0802 	
Core 2 Duo E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)	ALL	0404 	
Core 2 Duo E8200 (2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0608 	
Core 2 Duo E8300 (2.83GHz,1333FSB,L2:6MB,rev.C0)	ALL	0802 	
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0902 	
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,rev.C0)	ALL	0608 	
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0902 	

CPU	Validated since PCB	Validated since BIOS	Note
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,rev.C0)	ALL	0608 	
Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0902 	
Core 2 Extreme QX6800 (rev.G0,2.93GHz,1066FSB,L2:2X4MB,4 cores)	ALL	0105 	
Core 2 Extreme QX6850(revG0,3.00GHz,1333FSB,L2:2X4MB)	ALL	0105 	
Core 2 Extreme QX9650 (rev.C1,3.00GHz,1333FSB,L2:2X6MB,4 cores)	ALL	0802 	
Core 2 Extreme QX9650(revC0,3.00GHz,1333FSB,L2:2X6MB)	ALL	0505 	
Core 2 Extreme X6800(2.93GHz,1066FSB,L2:4MB,revB2)	ALL	0105 	
Core 2 Quad Q6400 (2.13GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0105 	
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0105 	
Core 2 Quad Q6700 (2.66GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0105 	
Core 2 Quad Q8200 (rev.M1,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0902 	
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M1,4 cores)	ALL	0704 	
Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0902 	
Core 2 Quad Q9450 (2.66GHz,1333FSB,L2:12MB,rev.C1)	ALL	0802 	
Core 2 Quad Q9500 (2.83GHz,1333FSB,L2:6MB,rev.R0)	ALL	0904 	

CPU	Validated since PCB	Validated since BIOS	Note
Core 2 Quad Q9550(2.83GHz,1333FSB,L2:12MB,rev.C1)	ALL	0802 	
Core 2 Quad Q9550(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0902 	
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	0902 	
P4-520/520J (2.8E GHz) (800 FSB) (DO)	ALL	0105 	
P4-520/520J (2.8E GHz) (800 FSB) (E0)	ALL	0105 	
P4-521 (2.8GHz, 800 FSB,HT, L2 1MB)(DO,E0)	ALL	0105 	
P4-531 (3GHz, 800 FSB, L2 1MB)(DO,E0)	ALL	0105 	
P4-540/540J (3.2E GHz) (800 FSB) (E0,DO)	ALL	0105 	
P4-551 (3.4GHz, 800 FSB, L2 1MB,DO,E0)	ALL	0105 	
P4-570J (3.8 GHz) (800 FSB) (DO,E0)	ALL	0105 	
P4-630 (3.0E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0105 	
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revB1)	ALL	0105 	
P4-640 (3.2E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0105 	
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revB1)	ALL	0105 	
P4-650 (3.4E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0105 	

CPU	Validated since PCB	Validated since BIOS	Note
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revB1)	ALL	0105 	
P4-662 (3.6 GHz, 800 FSB, L2:2MB, EM64T, HT, revR0)	ALL	0105 	
P4-670 (3.8 GHz, 800 FSB, L2:2MB,N0)	ALL	0105 	
Pentium D 820 (2.8 GHz, 800 FSB, revA0)	ALL	0105 	
Pentium D 830 (3.0 GHz, 800 FSB, revA0)	ALL	0105 	
Pentium D 830 (3.0 GHz, 800 FSB, revB0)	ALL	0105 	
Pentium D 840 (3.2 GHz, 800 FSB, revB0)	ALL	0105 	
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0105 	
Pentium D 920(2.8GHz, 800 FSB, L2 4MB, revB1)	ALL	0105 	
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0105 	
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0105 	
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revC1)	ALL	0105 	
Pentium D 935(3.2GHz, 800 FSB, L2 4MB, 95W, revD0)	ALL	0105 	
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revB1)	ALL	0105 	
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revC1)	ALL	0105 	

CPU	Validated since PCB	Validated since BIOS	Note
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0105 	
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0105 	
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revB1)	ALL	0105 	
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revC1)	ALL	0105 	
Pentium Dual Core E2140(1.6GHz, 800FSB, L2 1MB,L2)	ALL	0105 	
Pentium Dual Core E2140(1.6GHz,800FSB,L2 1MB,M0)	ALL	0201 	
Pentium Dual Core E2160(1.8GHz, 800FSB, L2 1MB,L2)	ALL	0105 	
Pentium Dual Core E2160(1.8GHz,800FSB,L2 1MB,M0)	ALL	0201 	
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0201 	
Pentium Dual Core E2200(2.2GHz,800FSB,L2 1MB,M0)	ALL	0507 	
Pentium Dual Core E2210(2.2GHz,800FSB,L2 1MB,R0)	ALL	0904 	
Pentium Dual Core E2220(2.4GHz,800FSB,L2 1MB,M0)	ALL	0507 	
Pentium Dual Core E5000 (3.4GHz,800FSB,L2:2MB,rev.R0)	ALL	0904 	
Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL	0902 	
Pentium Dual Core E5200(2.50GHz,800FSB,L2:2MB,rev.R0)	ALL	0904 	

CPU	Validated since PCB	Validated since BIOS	Note
Pentium Dual Core E5500 (2.8GHz,800FSB,L2:2MB,rev.R0)	ALL	0904 <a href="#">GO</a>	
Pentium Dual Core E5700 (3.0GHz,800FSB,L2:2MB,rev.R0)	ALL	0904 <a href="#">GO</a>	
Pentium Dual Core E6600 (3.06GHz,1066FSB,L2:2MB,rev.R0)	ALL	0904 <a href="#">GO</a>	
Pentium Dual Core E6700 (3.2GHz,1066FSB,L2:2MB,rev.R0)	ALL	0904 <a href="#">GO</a>	
Pentium Dual Core E6800 (3.3GHz,1066FSB,L2:2MB,rev.R0)	ALL	0904 <a href="#">GO</a>	

Shop and Learn			Learn More	Support	About Us
<b>Mobile</b>	Workstations	Wired Networking	Asus Design Center	Check Repair Status	About ASUS
Phones	Accessories	Intelligent Robots		Find Service Locations	News
Accessories	<b>Motherboards / Components</b>	AIoT & Industrial Solutions	ASUSPRO	Product Registration	Investor Relations
<b>Laptops</b>	Motherboards	Servers	Automotive Solutions	Email Us	About CSR for global
For Home	Graphics Cards	Smart Home	AVC Licensing Notice	Call Us	Press Room
For Work	Gaming Cases	<b>Accessories</b>	ASUS Blog	Security Advisory	ASUSTOR Inc.
For Creators	Cooling	Keyboards		ASUS Support Videos	ASUS Cloud Corporation
For Students	Power Supply Units	Mice and Mouse Pads		MyASUS	UniMax Electronics Inc.
For Gaming	Sound Cards	Headsets and Audio			
Accessories	Optical Drives	Streaming Kits			
<b>Displays / Desktops</b>	Data Storage	Apparel Bags and Gear			
Monitors	External Graphics Docks	Cases and Protection			
Projectors	<b>Networking / IoT / Servers</b>	Adapters and Chargers			
All-in-One PCs	WiFi 7	Docks Dongles and Cable			
Tower PCs	WiFi 6	Power Banks			
Gaming Tower PCs	WiFi Routers	Controller			
Mini PCs	Whole Home Mesh WiFi System	Gimbal			
	Business Network Solutions				



