

P5Q-EM DO



ProArt

Gaming

Business

Mobile Laptops

Displays /
Desktops

Motherboards /
Components

Networking /
IoT / Servers

Accessories

Support



Product Support For P5Q-EM DO

[Find Another Model](#) >

[Get Product Support](#)

[Register Product](#)

[CPU / Memory Support](#)

[Driver & Utility](#)

[FAQ](#)

[Manual & Document](#)

CPU SUPPORT

[CPU Support](#)

[Memory / Device Support](#)

NEED HELP?

The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)

[Email Us](#)

[Find service locations](#)

CPU

Validated since PCB

Validated since BIOS

Celeron 450(2.2GHz,800 FSB,L2 512KB,LGA775,revA1)

ALL

0405

GO

P5Q-EM DO

Celeron Dual Core E1200(revM0,1.6GHz,800 FSB,L2:512K)	ALL		GO
Celeron Dual Core E1400 (revM0,2.0GHz, 800 FSB, L2: 512K)	ALL	0405	GO
Celeron Dual Core E1500(revM0,2.2GHz,800 FSB,L2: 512K)	ALL	0405	GO
Celeron Dual Core E3200(revR0,2.4GHz,800 FSB,L2: 1M)	ALL	1102	GO
Celeron Dual Core E3300(revR0,2.5GHz,800 FSB,L2: 1M)	ALL	1102	GO
Celeron Dual Core E3400(revR0,2.6GHz,800 FSB,L2: 1M)	ALL	1208	GO
Celeron Dual Core E3500(revR0,2.7GHz,800 FSB,L2: 1M)	ALL	1208	GO
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0405	GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0405	GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0405	GO
Core 2 Duo E4500 (2.2GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0405	GO
Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0405	GO
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,revG0)	ALL	0405	GO

P5Q-EM DO

Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.B2)	ALL	0405	GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0405	GO
Core 2 Duo E6320 (1.86GHz,1066FSB,L2:4MB,rev.B2)	ALL	0405	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.B2)	ALL	0405	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.L2)	ALL	0405	GO
Core 2 Duo E6420 (2.13GHz,1066FSB,L2:4MB,rev.B2)	ALL	0405	GO
Core 2 Duo E6540 (2.33GHz,1333FSB,L2:4MB,rev.GO)	ALL	0405	GO
Core 2 Duo E6550 (2.33GHz,1333FSB,L2:4MB,rev.GO)	ALL	0405	GO
Core 2 Duo E6600 (2.40GHz,1066FSB,L2:4MB,rev.B2)	ALL	0405	GO
Core 2 Duo E6700 (2.66GHz,1066FSB,L2:4MB,rev.B2)	ALL	0405	GO
Core 2 Duo E6750 (2.66GHz,1333FSB,L2:4MB,rev.GO)	ALL	0405	GO
Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.E0)	ALL	0405	GO
Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.GO)	ALL	0405	GO

P5Q-EM DO

Core 2 Duo E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)	ALL	GO
Core 2 Duo E7300(2.66GHz,1066FSB,L2:3MB,rev.M0)	ALL	0405 GO
Core 2 Duo E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)	ALL	0405 GO
Core 2 Duo E7600(3.06GHz,1066FSB,L2:3MB,rev.R0)	ALL	0803 GO
Core 2 Duo E8190(2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0405 GO
Core 2 Duo E8200 (2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0405 GO
Core 2 Duo E8300 (2.83GHz,1333FSB,L2:6MB,rev.C0)	ALL	0405 GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0405 GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,rev.C0)	ALL	0405 GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0405 GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,rev.C0)	ALL	0405 GO
Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0405 GO
Core 2 Extreme QX6700(revB3,2.66GHz,1066FSB,L2:2X4MB)	ALL	0405 GO

P5Q-EM DO

Core 2 Extreme QX6800 (rev.G0,2.93GHz,1066FSB,L2:2X4MB,4 cores)	ALL	0405	GO
Core 2 Extreme QX6800(revB3,2.93GHz,1066FSB,L2:2X4MB)	ALL	0405	GO
Core 2 Extreme QX6850(revG0,3.00GHz,1333FSB,L2:2X4MB)	ALL	0405	GO
Core 2 Extreme QX9650 (rev.C1,3.00GHz,1333FSB,L2:2X6MB,4 cores)	ALL	0405	GO
Core 2 Extreme QX9650(revC0,3.00GHz,1333FSB,L2:2X6MB)	ALL	0405	GO
Core 2 Extreme QX9770(revC1,3.2GHz,1600FSB,L2:2X6MB)	ALL	0405	GO
Core 2 Extreme X6800(2.93GHz,1066FSB,L2:4MB,revB2)	ALL	0405	GO
Core 2 Quad Q6400 (2.13GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0405	GO
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0405	GO
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0405	GO
Core 2 Quad Q6700 (2.66GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0405	GO
Core 2 Quad Q8200 (rev.M1,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0405	GO
Core 2 Quad Q8200 (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0803	GO

P5Q-EM DO

Core 2 Quad Q8200S (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL		GO
Core 2 Quad Q8300 (rev.R0,2.50GHz,1333FSB,L2:4MB,4 cores)	ALL	0405	GO
Core 2 Quad Q8400 (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	0803	GO
Core 2 Quad Q8400S (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	0803	GO
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M0,4 cores)	ALL	0405	GO
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M1,4 cores)	ALL	0405	GO
Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0405	GO
Core 2 Quad Q9400S (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0802	GO
Core 2 Quad Q9450 (2.66GHz,1333FSB,L2:12MB,rev.C1)	ALL	0405	GO
Core 2 Quad Q9500 (2.83GHz,1333FSB,L2:6MB,rev.R0)	ALL	1102	GO
Core 2 Quad Q9505(rev.R0,2.83GHz,1333FSB,L2:6MB)	ALL	1102	GO
Core 2 Quad Q9550(2.83GHz,1333FSB,L2:12MB,rev.C1)	ALL	0405	GO
Core 2 Quad Q9550(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0405	GO

P5Q-EM DO

Core 2 Quad Q9550S(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL		GO
Core 2 Quad Q9650(rev.C1,3.00GHz,1333FSB,L2:12MB)	ALL	0405	GO
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	0405	GO
Pentium Dual Core E2140(1.6GHz,800FSB,L2 1MB,M0)	ALL	0405	GO
Pentium Dual Core E2160(1.8GHz,800FSB,L2 1MB,M0)	ALL	0405	GO
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0405	GO
Pentium Dual Core E2210(2.2GHz,800FSB,L2 1MB,R0)	ALL	1102	GO
Pentium Dual Core E5000 (3.4GHz,800FSB,L2:2MB,rev.R0)	ALL	1102	GO
Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL	0405	GO
Pentium Dual Core E5200(2.50GHz,800FSB,L2:2MB,rev.R0)	ALL	1102	GO
Pentium Dual Core E5300 (2.60GHz,800FSB,L2:2MB,rev.R0)	ALL	0405	GO
Pentium Dual Core E5400 (2.70GHz,800FSB,L2:2MB,rev.R0)	ALL	0405	GO
Pentium Dual Core E5500 (2.8GHz,800FSB,L2:2MB,rev.R0)	ALL	1102	GO

P5Q-EM DO

Pentium Dual Core E5700 (3.0GHz,800FSB,L2:2MB,rev.R0)	ALL		GO
Pentium Dual Core E5800 (3.2GHz,800FSB,L2:2MB,rev.R0)	ALL	1208	GO
Pentium Dual Core E6300 (2.8GHz,1066FSB,L2:2MB,rev.R0)	ALL	0803	GO
Pentium Dual Core E6500 (2.93GHz,1066FSB,L2:2MB,rev.R0)	ALL	1102	GO
Pentium Dual Core E6500K (2.93GHz,1066FSB,L2:2MB,rev.R0)	ALL	1102	GO
Pentium Dual Core E6600 (3.06GHz,1066FSB,L2:2MB,rev.R0)	ALL	1102	GO
Pentium Dual Core E6700 (3.2GHz,1066FSB,L2:2MB,rev.R0)	ALL	1208	GO
Pentium Dual Core E6800 (3.3GHz,1066FSB,L2:2MB,rev.R0)	ALL	1208	GO



Shop and Learn

- Mobile
- Phones
- Accessories
- Accessories
- Laptops
- For Home
- For Work
- For Creators
- For Students
- For Gaming
- Workstations
- Accessories
- Motherboards / Components**
- Motherboards
- Graphics Cards
- Gaming Cases
- Cooling
- Power Supply Units
- Sound Cards

Learn More

- Wired Networking
- Intelligent Robots
- AIoT & Industrial Solutions
- Servers
- Smart Home
- Accessories**
- Keyboards
- Mice and Mouse Pads

- Asus Design Center
- ASUSPRO
- Automotive Solutions
- AVC Licensing Notice

Support

- Check Repair Status

About Us

- About ASUS
- News
- Investor Relations
- About CSR for global
- Press Room
- ASUSTOR Inc.
- ASUS Cloud Corporation
- UniMax Electronics Inc.

Community



P5Q-EM DO

Projectors	Networking / IoT / Servers	Cases and Protection	Email Us
All-in-One PCs	WiFi Routers	Adapters and Chargers	Call Us
Tower PCs	Whole Home Mesh WiFi System	Docks Dongles and Cable	Security Advisory
Gaming Tower PCs		Power Banks	ASUS Support Videos
Mini PCs		Controller	MyASUS
		Gimbal	