

RAMPAGE EXTREME



ProArt

Gaming

Business

Mobile

Laptops

Displays /
Desktops

Motherboards /
Components

Networking /
IoT / Servers

Accessories

Support



Product Support For

RAMPAGE EXTREME

[Find Another Model](#) >

Get Product Support

Register Product

CPU / Memory
Support

Driver & Utility

FAQ

Manual &
Document

CPU SUPPORT

CPU Support

Memory / Device Support

NEED HELP?

The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)

[Email Us](#)

[Find service locations](#)

CPU

Celeron 450(2.2GHz,800 FSB,L2
512KB,LGA775,revA1)

Validated
since
PCB

ALL

Validated
since BIOS

0404



RAMPAGE EXTREME

Celeron Dual Core E1200(revM0,1.6GHz,800 FSB,L2:512K)	ALL		GO
Celeron Dual Core E1500(revM0,2.2GHz,800 FSB,L2: 512K)	ALL	0301	GO
Celeron Dual Core E3200(revR0,2.4GHz,800 FSB,L2: 1M)	ALL	1003	GO
Celeron Dual Core E3300(revR0,2.5GHz,800 FSB,L2: 1M)	ALL	1003	GO
Celeron Dual Core E3400(revR0,2.6GHz,800 FSB,L2: 1M)	ALL	1301	GO
Celeron Dual Core E3500(revR0,2.7GHz,800 FSB,L2: 1M)	ALL	1301	GO
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0301	GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0301	GO
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0301	GO
Core 2 Duo E4500 (2.2GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0301	GO
Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0301	GO
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,revG0)	ALL	0301	GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.B2)	ALL	0301	GO



RAMPAGE EXTREME

Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0301	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.B2)	ALL	0301	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.L2)	ALL	0301	GO
Core 2 Duo E6420 (2.13GHz,1066FSB,L2:4MB,rev.B2)	ALL	0301	GO
Core 2 Duo E6550 (2.33GHz,1333FSB,L2:4MB,rev.GO)	ALL	0301	GO
Core 2 Duo E6600 (2.40GHz,1066FSB,L2:4MB,rev.B2)	ALL	0301	GO
Core 2 Duo E6700 (2.66GHz,1066FSB,L2:4MB,rev.B2)	ALL	0301	GO
Core 2 Duo E6750 (2.66GHz,1333FSB,L2:4MB,rev.GO)	ALL	0301	GO
Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.GO)	ALL	0301	GO
Core 2 Duo E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)	ALL	0301	GO
Core 2 Duo E7300(2.66GHz,1066FSB,L2:3MB,rev.M0)	ALL	0301	GO
Core 2 Duo E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)	ALL	0701	GO
Core 2 Duo E7500(2.93GHz,1066FSB,L2:3MB,rev.R0)	ALL	0701	GO



RAMPAGE EXTREME

Core 2 Duo E7600(3.06GHz,1066FSB,L2:3MB,rev.R0)	ALL	0301	GO
Core 2 Duo E8200 (2.66GHz,1333FSB,L2:6MB,rev.C0)	ALL	0301	GO
Core 2 Duo E8300 (2.83GHz,1333FSB,L2:6MB,rev.C0)	ALL	0301	GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0301	GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,rev.C0)	ALL	0301	GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0301	GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,rev.C0)	ALL	0301	GO
Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0301	GO
Core 2 Extreme QX6700(revB3,2.66GHz,1066FSB,L2:2X4MB)	ALL	0301	GO
Core 2 Extreme QX6800 (rev.G0,2.93GHz,1066FSB,L2:2X4MB,4 cores)	ALL	0301	GO
Core 2 Extreme QX6850(revG0,3.00GHz,1333FSB,L2:2X4MB)	ALL	0301	GO
Core 2 Extreme QX9650 (rev.C1,3.00GHz,1333FSB,L2:2X6MB,4 cores)	ALL	0301	GO
Core 2 Extreme QX9650(revC0,3.00GHz,1333FSB,L2:2X6MB)	ALL	0301	GO



RAMPAGE EXTREME

Core 2 Extreme QX9770(revC1,3.2GHz,1600FSB,L2:2X6MB)	ALL		GO
Core 2 Extreme X6800(2.93GHz,1066FSB,L2:4MB,revB2)	ALL	0301	GO
Core 2 Quad Q6400 (2.13GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0301	GO
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0301	GO
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0301	GO
Core 2 Quad Q6700 (2.66GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0301	GO
Core 2 Quad Q8200 (rev.M1,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	0404	GO
Core 2 Quad Q8200 (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1003	GO
Core 2 Quad Q8200S (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1003	GO
Core 2 Quad Q8300 (rev.R0,2.50GHz,1333FSB,L2:4MB,4 cores)	ALL	0601	GO
Core 2 Quad Q8400 (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	1003	GO
Core 2 Quad Q8400S (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	1003	GO
Core 2 Quad Q9300 (2.5GHz,1333FSB,L2:6MB,rev.M1,4 cores)	ALL	0301	GO



RAMPAGE EXTREME

Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	1003	GO
Core 2 Quad Q9400S (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	1003	GO
Core 2 Quad Q9450 (2.66GHz,1333FSB,L2:12MB,rev.C1)	ALL	0301	GO
Core 2 Quad Q9500 (2.83GHz,1333FSB,L2:6MB,rev.R0)	ALL	1003	GO
Core 2 Quad Q9505(rev.R0,2.83GHz,1333FSB,L2:6MB)	ALL	1003	GO
Core 2 Quad Q9550(2.83GHz,1333FSB,L2:12MB,rev.C1)	ALL	0301	GO
Core 2 Quad Q9550(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0301	GO
Core 2 Quad Q9550S(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	1003	GO
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	0301	GO
P4-3.20F GHz (EM64T)	ALL	0301	GO
P4-3.40F GHz (EM64T)	ALL	0301	GO
P4-3.40GHz(FSB800, revR0)	ALL	0301	GO
P4-3.60F GHz (EM64T)	ALL	0301	GO



RAMPAGE EXTREME

P4-3.80F GHz (EM64T)	ALL	0301	GO
P4-3.80GHz(FSB800, revR0)	ALL	0301	GO
P4-520/520J (2.8E GHz) (800 FSB) (D0)	ALL	0301	GO
P4-520/520J (2.8E GHz) (800 FSB) (E0)	ALL	0301	GO
P4-521 (2.8GHz, 800 FSB,HT, L2 1MB)(D0,E0)	ALL	0301	GO
P4-530/530J (3E GHz) (800 FSB) (D0,E0)	ALL	0301	GO
P4-531 (3GHz, 800 FSB, L2 1MB)(D0,E0)	ALL	0301	GO
P4-540/540J (3.2E GHz) (800 FSB) (E0,D0)	ALL	0301	GO
P4-541 (3.2GHz, 800 FSB, L2 1MB)(E0,D0)	ALL	0301	GO
P4-550/550J (3.4E GHz) (800 FSB) (D0.E0)	ALL	0301	GO
P4-551 (3.4GHz, 800 FSB, L2 1MB,D0,E0)	ALL	0301	GO
P4-551 (3.4GHz, 800 FSB, L2 1MB,G1)	ALL	0301	GO
P4-560/560J (3.6 GHz) (800 FSB) (D0,E0)	ALL	0301	GO



RAMPAGE EXTREME

P4-561 (3.6GHz, 800 FSB, L2 1MB)	ALL	0301	GO
P4-570J (3.8 GHz) (800 FSB) (D0,E0)	ALL	0301	GO
P4-571 (3.8GHz, 800 FSB, L2 1MB V E0)	ALL	0301	GO
P4-630 (3.0E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0301	GO
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revB1)	ALL	0301	GO
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revC1)	ALL	0301	GO
P4-631 (65nm,3.0GHz, 800 FSB, L2:2MB, revD0)	ALL	0301	GO
P4-640 (3.2E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0301	GO
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revB1)	ALL	0301	GO
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revC1)	ALL	0301	GO
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revD0)	ALL	0301	GO
P4-650 (3.4E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0301	GO
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revB1)	ALL	0301	GO



RAMPAGE EXTREME

P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revC1)	ALL	0301	GO
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revD0)	ALL	0301	GO
P4-660 (3.6E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0301	GO
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revB1)	ALL	0301	GO
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revC1)	ALL	0301	GO
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revD0)	ALL	0301	GO
P4-662 (3.6 GHz, 800 FSB, L2:2MB, EM64T, HT, revR0)	ALL	0301	GO
P4-670 (3.8 GHz, 800 FSB, L2:2MB,N0)	ALL	0301	GO
P4-672 (3.8 GHz, 800 FSB, L2:2MB, revR0)	ALL	0301	GO
Pentium D 820 (2.8 GHz, 800 FSB, revA0)	ALL	0301	GO
Pentium D 820 (2.8 GHz, 800 FSB, revB0)	ALL	0301	GO
Pentium D 830 (3.0 GHz, 800 FSB, revA0)	ALL	0301	GO
Pentium D 830 (3.0 GHz, 800 FSB, revB0)	ALL	0301	GO



RAMPAGE EXTREME

Pentium D 840 (3.2 GHz, 800 FSB, revA0)	ALL	0301	GO
Pentium D 840 (3.2 GHz, 800 FSB, revB0)	ALL	0301	GO
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0301	GO
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revDO,without VT function)	ALL	0301	GO
Pentium D 920(2.8GHz, 800 FSB, L2 4MB, revB1)	ALL	0301	GO
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0301	GO
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revDO, without VT function)	ALL	0301	GO
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revB1)	ALL	0301	GO
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revC1)	ALL	0301	GO
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revB1)	ALL	0301	GO
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revC1)	ALL	0301	GO
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0301	GO
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revDO, without VT function)	ALL	0301	GO



RAMPAGE EXTREME

Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revB1)	ALL		GO
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revC1)	ALL	0301	GO
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revC1)	ALL	0301	GO
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revD0)	ALL	0301	GO
Pentium Dual Core E2140(1.6GHz, 800FSB, L2 1MB,L2)			GO
Pentium Dual Core E2140(1.6GHz,800FSB,L2 1MB,M0)			GO
Pentium Dual Core E2160(1.8GHz, 800FSB, L2 1MB,L2)			GO
Pentium Dual Core E2160(1.8GHz,800FSB,L2 1MB,M0)			GO
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0301	GO
Pentium Dual Core E2200(2.2GHz,800FSB,L2 1MB,M0)	ALL	0301	GO
Pentium Dual Core E2210(2.2GHz,800FSB,L2 1MB,R0)	ALL	1202	GO
Pentium Dual Core E2220(2.4GHz,800FSB,L2 1MB,M0)	ALL	0301	GO
Pentium Dual Core E5000 (3.4GHz,800FSB,L2:2MB,rev.R0)	ALL	1301	GO
Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL	0404	GO



RAMPAGE EXTREME

Pentium Dual Core E5200(2.50GHz,800FSB,L2:2MB,rev.R0)	ALL		GO
Pentium Dual Core E5300 (2.60GHz,800FSB,L2:2MB,rev.R0)	ALL	0601	GO
Pentium Dual Core E5400 (2.70GHz,800FSB,L2:2MB,rev.R0)	ALL	0601	GO
Pentium Dual Core E5500 (2.8GHz,800FSB,L2:2MB,rev.R0)	ALL	1301	GO
Pentium Dual Core E5700 (3.0GHz,800FSB,L2:2MB,rev.R0)	ALL	1301	GO
Pentium Dual Core E5800 (3.2GHz,800FSB,L2:2MB,rev.R0)	ALL	1301	GO
Pentium Dual Core E6300 (2.8GHz,1066FSB,L2:2MB,rev.R0)	ALL	1003	GO
Pentium Dual Core E6500 (2.93GHz,1066FSB,L2:2MB,rev.R0)	ALL	1003	GO
Pentium Dual Core E6600 (3.06GHz,1066FSB,L2:2MB,rev.R0)	ALL	1003	GO
Pentium Dual Core E6700 (3.2GHz,1066FSB,L2:2MB,rev.R0)	ALL	1301	GO
Pentium Dual Core E6800 (3.3GHz,1066FSB,L2:2MB,rev.R0)	ALL	1301	GO
Pentium Extreme Ed-840 (3.2 GHz, 800 FSB, revA0)	ALL	0301	GO
Pentium Extreme Ed-840 (3.2 GHz, 800 FSB, revB0)	ALL	0301	GO



RAMPAGE EXTREME

Pentium Extreme ED-955(3.46GHz, rev AO,B1)	ALL	0301	GO
Pentium Extreme ED-965(3.73GHz, rev C1)	ALL	0301	GO



Shop and Learn

- Mobile
 - Phones
 - Accessories
 - Laptops
 - For Home
 - For Work
 - For Creators
 - For Students
 - For Gaming
 - Accessories
 - Displays / Desktops
 - Monitors
 - Projectors
 - All-in-One PCs
 - Tower PCs
 - Gaming Tower PCs
 - Mini PCs
- Workstations
 - Accessories
 - Motherboards / Components**
 - Motherboards
 - Graphics Cards
 - Gaming Cases
 - Cooling
 - Power Supply Units
 - Sound Cards
 - Optical Drives
 - Data Storage
 - External Graphics Docks
 - Networking / IoT / Servers**
 - WiFi Routers
 - Whole Home Mesh WiFi
- Wired Networking
 - Intelligent Robots
 - AIoT & Industrial Solutions
 - Servers
 - Smart Home
 - Accessories**
 - Keyboards
 - Mice and Mouse Pads
 - Headsets and Audio
 - Streaming Kits
 - Apparel Bags and Gear
 - Cases and Protection
 - Adapters and Chargers
 - Docks Dongles and Cable
 - Power Banks
 - Controller
 - Gimbal

Learn More

- Asus Design Center
- ASUSPRO
- Automotive Solutions
- AVC Licensing Notice
- Support**
- Check Repair Status
- Find Service Locations
- Product Registration
- Email Us
- Call Us
- Security Advisory
- ASUS Support Videos
- MyASUS

About Us

- About ASUS
- News
- Investor Relations
- About CSR for global
- Press Room
- ASUSTOR Inc.
- ASUS Cloud Corporation
- UniMax Electronics Inc.

Community

