



Jumper Settings

Jumper Table

Jumper Table Summary of Vi15g

5v CPU Type

Jumper Settings

CPU Type	JP9	JP10	JP13	JP23	JP24	JP25	JP26	JP27
Intel 486 SX/DX/DX2 SL- Enhanced	1-2	1-2	1-2	3-4, 5-6, 7-8	7-8	Open	1-2, 5-6	4-5, 7-8
Cyrix Cx486DX/DX2	2-3	2-3	1-2	2-3, 5-6, 7-8	2-3, 7-8	2-3 or Open	4-5	2-3, 7-8
Intel/AMD 486SX	1-2	1-2	Open	6-7	Open	Open	Open	7-8
Intel/AMD 486DX/DX2	1-2	1-2	Open	5-6, 7-8	7-8	Open	Open	7-8
Intel P24D	1-2	2-3	1-2	1-2, 3-4, 5-6, 7-8	7-8	1-2, 5-6	2-3, 5-6, 7-8	4-5, 6-7
Intel P24T	1-2	2-3	1-2	3-4, 5-6, 7-8	6-7	Open	5-6	1-2, 7-8

3.45V CPU Type

Jumper	Intel DX4 (W/T)	Intel DX4 (W/B)	AMD DX2	AMD DX4 V8T	AMD DX4-S SV8B	AMD DX4-S SV8T	Cyrix DX2	TI DX2	Cx486DX4 M7 P/O	Cx486DX4 iDX4 P/O	Misc. 5x86
JP9	1-2	1-2	1-2	1-2	1-2	1-2	2-3	2-3	2-3	2-3	1-2
JP10	1-2	2-3	1-2	1-2	2-3	1-2	2-3	2-3	2-3	2-3	1-2
JP13	1-2	1-2	Open	Open	1-2	1-2	1-2	1-2	1-2	1-2	1-2
JP23	3-4, 5-6, 7-8	1-2, 3-4, 5-6, 7-8	5-6, 7-8	5-6, 7-8	1-2, 3-4, 5-6, 7-8	3-4, 5-6, 7-8	2-3, 5-6, 7-8	2-3, 5-6, 7-8	2-3, 5-6, 7-8	1-2, 3-4, 5-6, 7-8	1-2, 3-4, 5-6, 7-8
JP24	7-8	7-8	7-8	7-8	7-8	7-8	2-3, 7-8	2-3, 7-8	2-3, 7-8	7-8	7-8
JP25	Open	1-2, 5-6	3-4, Pin7 must be connected to pin7 of JP26	3-4	1-2, 3-4, 5-6	Open	3-4	3-4	3-4	1-2	1-2
JP26	1-2, 5-6	2-3, 5-6, 7-8	Pin7 must be connected to Pin7 of JP25	Open	2-3, 5-6, 7-8	1-2, 5-6	4-5	4-5	4-5	2-3, 5-6	2-3, 5-6
JP27	4-5, 7-8	4-5, 6-7	7-8	7-8	4-5, 6-7	4-5, 7-8	2-3, 7-8	2-3, 7-8	2-3, 7-8	4-5, 7-8	4-5, 7-8
JP16	Closed	Closed	Open	Closed	Closed	Closed	Open	Open	1-2	1-2	1-2

Last Updated: 2004/07/15